

bZ WOODLAND

2 0 2 7

OWNER'S MANUAL

NOTICE TO QUEBEC CONSUMERS:

Toyota Canada Inc. is pleased to offer a 36 month / 60,000 km (whichever occurs first) limited new-vehicle warranty on your vehicle. This limited warranty covers repairs on any part of the vehicle supplied by Toyota Canada that is defective in material or workmanship, subject to certain exceptions that are stated in your warranty manual. For more details of the warranty, check the Owner's Manual Supplement included with your vehicle, or visit toyota.ca.

Quebec's Consumer Protection Act requires Toyota Canada to disclose whether we guarantee the availability of replacement parts, repair services, and information necessary to maintain or repair the vehicle or its components. While Toyota Canada is pleased to honour the terms of our limited warranty, **please note that Toyota in no way guarantees the availability of replacement parts, repair services and information necessary to maintain or repair the vehicle or its components.**

Pictorial index	Search by illustration	
For safety and security	Make sure to read through them (Main topics: Child seat, theft deterrent system)	1
Electric Vehicle system	Reading charging-related information (Main topics: Electric Vehicle system, charging methods)	2
Vehicle status information and indicators	Reading driving-related information (Main topics: Meters, multi-information display)	3
Before driving	Opening and closing the doors and windows, adjustment before driving (Main topics: Keys, doors, seats)	4
Driving	Operations and advice which are necessary for driving (Main topics: Starting Electric Vehicle system, driving support systems)	5
Interior features	Usage of the interior features (Main topics: Air conditioner, storage features)	6
Maintenance and care	Caring for your vehicle and maintenance procedures (Main topics: Interior and exterior, light bulbs)	7
When trouble arises	What to do in case of malfunction and emergency (Main topics: 12-volt battery discharge, flat tire)	8
Vehicle specifications	Vehicle specifications, customizable features (Main topics: Fluids, tire inflation pressure)	9
For owners	Reporting safety defects for U.S. owners, and seat belt, SRS airbag and headlight aim instructions for Canadian owners	10
Index	Search by symptom	
	Search alphabetically	

For your information	6
Reading this manual	14
How to search	15
Pictorial index	16

1 For safety and security

1-1. For safe use	
Before driving	26
For safe driving	27
Seat belts	29
SRS airbags	33
Front passenger occupant classification system	41
1-2. Child safety	
Riding with children	47
Child restraint systems	48
1-3. Emergency assistance	
Safety Connect	62
1-4. Theft deterrent system	
Immobilizer system	66
Alarm	67

2 Electric Vehicle system

2-1. Electric vehicle system	
Electric Vehicle system features	70
Electric Vehicle system precautions	74
Battery Electric Vehicle driving tips	79
Driving range	81
2-2. Charging	
Charging equipment	83
Locking and unlocking the AC charging connector	85
Charging methods	87
Charging tips	90
Things to know before charging	91

How to use AC charging	94
How to use DC charging	100
Using the charging schedule function	105
Using Battery Preconditioning	112
Using My Room Mode	115
When charging cannot be carried out	118
Plug & Charge system	129
How to use Plug & Charge system	129
When Plug & Charge system cannot be used normally..	131

3 Vehicle status information and indicators

3-1. Instrument cluster	
Warning lights and indicators	134
Gauges and meters	139
Multi-information display	142
Displayed content	144
Electricity consumption	148

4 Before driving

4-1. Key information	
Keys	152
Digital Key	155
4-2. Opening, closing and locking the doors	
Side doors	157
Power back door	162
Smart key system	175
4-3. Adjusting the seats	
Front seats	181
Rear seats	182
Head restraints	184

4-4. Adjusting the steering wheel and mirrors	
Steering wheel	188
Inside rear view mirror.....	189
Digital Rear-view Mirror.....	190
Outside rear view mirrors...	199
4-5. Opening, closing the windows	
Power windows	203
4-6. Favorite settings	
Driving position memory.....	206
My Settings	209

5 Driving

5-1. Before driving	
Driving the vehicle.....	213
Cargo and luggage	219
Vehicle load limits.....	222
Trailer towing.....	223
Dinghy towing	233
5-2. Driving procedures	
Power (ignition) switch	234
Shift position	238
Turn signal lever.....	244
Parking brake	245
Brake Hold	249
5-3. Operating the lights and wipers	
Headlight switch.....	251
AHB (Automatic High Beam)	253
Windshield wipers and washer	256
Rear window wiper and washer	259
Headlight cleaner switch	260
5-4. Using the driving support systems	
Toyota Safety Sense 3.0/Traffic Jam Assist software update	261

Toyota Safety Sense 3.0	263
Driver monitor	271
PCS (Pre-Collision System)	273
LTA (Lane Tracing Assist)...	285
LCA (Lane Change Assist)	290
LDA (Lane Departure Alert)	293
PDA (Proactive driving assist)	300
FCTA (Front Cross Traffic Alert)	306
RSA (Road Sign Assist)	308
Dynamic radar cruise control	311
Cruise control	322
Emergency Driving Stop System	326
Traffic Jam Assist	329
BSM (Blind Spot Monitor) ..	335
Safe Exit Assist	340
Intuitive parking assist.....	344
RCTA (Rear cross traffic alert) function	351
RCD (Rear camera detection)	356
PKSB (Parking Support Brake)	360
Parking Support Brake function (static objects front and rear of the vehicle)	365
Parking Support Brake function (moving vehicles rear of the vehicle)	367
Parking Support Brake function (pedestrians rear of the vehi- cle)	369
Multi-terrain Monitor	371
X-MODE.....	434
Driving assist systems	438

5-5. Driving tipsWinter driving tips..... **444**Utility vehicle precautions... **447****6 Interior features****6-1. Using the air conditioning system and defogger**ALL AUTO (ECO) control ... **452**Automatic air conditioning system..... **454**Heated steering wheel/seat heaters/seat ventilators/radiant heaters **463****6-2. Using the interior lights**Interior lights list..... **466****6-3. Using the storage features**List of storage features **469**Luggage compartment features **472****6-4. Using the other interior features**Electronic sunshade..... **477**Other interior features..... **478**Power outlets (120 VAC 1500 W) **490**When the power outlet (AC 120V/1500 W) cannot be used properly **497**Garage door opener..... **499****7 Maintenance and care****7-1. Maintenance and care**Cleaning and protecting the vehicle exterior..... **508**Cleaning and protecting the vehicle interior..... **512****7-2. Maintenance**Maintenance requirements **515**General maintenance..... **516****7-3. Do-it-yourself maintenance**Do-it-yourself service precautions **519**Hood **521**Positioning a floor jack **523**Motor compartment..... **524**Tires **530**Replacing the tire **542**Tire inflation pressure..... **547**Wheels **549**Air conditioning filter..... **551**Electronic key battery..... **553**Checking and replacing fuses **555**Headlight aim **557**Light bulbs..... **558****8 When trouble arises****8-1. Essential information**Emergency flashers **560**If your vehicle has to be stopped in an emergency **560**If the vehicle is submerged or water on the road is rising **561****8-2. Steps to take in an emergency**If your vehicle needs to be towed **563**If you think something is wrong **566**If a warning light turns on or a warning buzzer sounds.... **568**If a warning message is displayed **578**If you have a flat tire..... **585**If the EV system will not start **596**If you lose your keys **597**

If the electronic key does not
operate properly..... 598

If the 12-volt battery is dis-
charged 600

If your vehicle overheats 604

If the vehicle becomes stuck
..... 606

9 Vehicle specifications

9-1. Specifications

Maintenance data 610

Tire information 617

9-2. Customization

Customizable features 627

9-3. Initialization

Items to initialize..... 640

9-4. Free/open source software

Free/open source software infor-
mation 641

10 For owners

10-1. For owners

Reporting safety defects for U.S.
owners 644

Reporting safety defects for
Canadian owners 644

Seat belt instructions for Cana-
dian owners (in French) ... 645

SRS airbag instructions for
Canadian owners (in French)
..... 646

Headlight aim instructions for
Canadian owners (in French)
..... 651

Index

What to do if... (Troubleshooting)
..... 654

Alphabetical Index..... 657

1

2

3

4

5

6

7

8

9

10

For your information

Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find explanations for equipment not installed on your vehicle and the illustrations used may differ from your vehicle.

All specifications provided in this manual are current at the time of printing. Over time, your vehicle may receive updates that modify the vehicle and make material in this manual incomplete and/or inaccurate. Because of Toyota's interest in continual product improvement, Toyota reserves the right to make changes to this manual at any time without notice.

If Toyota chooses to update the manual, updated versions can be viewed by selecting your vehicle by model and year at the following URL or on your mobile device if you have access to the Toyota app.

www.toyota.com/owners

Accessories, spare parts and modification of your Toyota

A wide variety of non-genuine spare parts and accessories for

Toyota vehicles are currently available in the market. You should know that Toyota does not warrant these products and is not responsible for their performance, repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Toyota vehicle.

This vehicle should not be modified with non-genuine Toyota products. Modification with non-genuine Toyota products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

Also, remodeling like this will have an effect on advanced safety equipment such as Toyota Safety Sense 3.0 and there is a danger that it will not work properly or the danger that it may work in situations where it should not be working.

Cyber Attack Risk

Installing electronic devices and radios increases the risk of cyber attacks through the installed parts, which may lead to unexpected accidents and leakage of personal information.

Toyota does not make any guar-

antees for problems caused by installing non-genuine Toyota products.

Installation of a mobile two-way radio system

The installation of a mobile two-way radio system in your vehicle could affect electronic systems such as:

- EV system
- Toyota Safety Sense 3.0
- Anti-lock brake system
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Toyota dealer for precautionary measures or special instructions regarding installation of a mobile two-way radio system.

High voltage parts and cables on the battery electric vehicles emit approximately the same amount of electromagnetic waves as the conventional gasoline powered vehicles or home electronic appliances despite of their electromagnetic shielding.

Unwanted noise may occur in the reception of the mobile two-way radio.

Vehicle data recording

This vehicle is equipped with sophisticated computers that record certain data regarding

vehicle controls and operations.

This data is transmitted to Toyota if the External Vehicle Video Capture consent has been accepted for the vehicle.

n Data recorded by the computers^{*1}

^{*1}: The recorded data varies according to the vehicle grade level and options with which it is equipped.

Certain data, such as the following, is recorded depending on the operation timing and status of each function.

- Basic vehicle behavior related data (electric motor speed, accelerator/brake pedal operation, vehicle speed, etc.)
- Operating state of the driving support systems (recorded during system operation, includes basic vehicle behavior related data)
- Driving support system sensor data
- Image data (images from the front, rear, vehicle periphery, and driver monitor cameras)^{*2}

^{*2}: The vehicle has multiple cameras. For details on from which cameras images are recorded, contact your Toyota dealer.

● Location information

These computers do not record conversations, sounds, or images of the inside of the vehicle.

Also, personal information which

may be used to identify the owner of the vehicle (name, gender, age, etc.) is not recorded.

n Usage of recorded data and personal information by the Toyota Safety Sense 3.0

The operating state of each system, data from each sensor, image data (images from the front/rear cameras), and position information is recorded by the Toyota Safety Sense 3.0 in the following situations. Toyota obtains this information when the vehicle is brought to the dealership or when sent to the Toyota servers.

- In certain collisions or collision-like situations
- When driving on roads with certain traffic situations, such as congestion, poor road surfaces, poor weather, etc.
- When driving on certain roads, such as roads which were recently opened or extended
- After the EV system is started, for a certain amount of time

To learn more about the vehicle data collected, used and shared by Toyota, please visit www.toyota.com/privacyvts/.

n Data provision and use purpose by third parties

Data recorded by the computers may be used for collision analysis, malfunction diagnosis, auto-

mated driving, advanced safety and map related technologies (technology, product development, product improvement, etc.) and products and services which use data (maps used for automated driving and advanced safety technologies, driving condition analysis, analysis of the driving environment, such as road infrastructure, traffic condition communication, etc. Herein referred to as “individual services”).

Also, this data may be used for customer support related to a collision, collision analysis or resolution.

In situations such as the following, Toyota may disclose the recorded data to a third party:

- When the consent of the vehicle owner (or the lessee if the vehicle is leased) has been given
- When officially requested by the police, a court of law or a government agency
- When it is to be used by Toyota in a lawsuit
- When data is to be used research purposes after processing so that the data is not tied to a specific vehicle or vehicle owner

In addition to the above, Toyota may disclose the data recorded by the Toyota Safety Sense 3.0 to a third party in the following situations:

- When separate consent of the vehicle owner (or the lessee if the vehicle is leased) has been given. This includes situations when the user subscribes to an individual service which is provided by a second party and uses vehicle recorded data, where the provider has obtained the user's consent for providing data to a third-party
- When providing data to a company involved in autonomous driving software, etc. for the purpose of research and development (technology, product development, product improvement, etc.) of automated driving, advanced safety and map related technologies
- When providing image data and position information to a company involved in map creation, etc. for the purpose of research and development map related technologies
- When providing image data and position information to a local government for the purpose of road maintenance, etc.
- When providing processed image data and position information to traffic condition communication individual services
- When providing image data

from near a fire, or other area that emergency services are dispatched, to the fire department of a local government which has entered a separate contract with Toyota

Image information recorded by the vehicle can be erased by your Toyota dealer.

The image recording function can be disabled. However, if the function is disabled, data from when systems operate will not be available.

If you wish to stop the collection of Toyota Safety Sense 3.0 data by the Toyota servers for the purpose of research and development and provision to individual services, contact your Toyota dealer.

Statement on Warranty Coverage for Aftermarket and Recycled Parts (For U.S. Owners)

The Magnuson-Moss Warranty Act, 15 U.S.C. s.2301 et seq., makes it illegal for motor vehicle manufacturers to void a motor vehicle warranty or deny warranty coverage solely because an aftermarket or recycled part has been used to repair the vehicle or someone other than the authorized service provider performed service on the vehicle. This provision does not apply to a new motor vehicle purchased solely for commercial or industrial use.

Under federal law, a manufac-

turer may deny warranty coverage and charge for repairs to a vehicle if it is discovered that an aftermarket or recycled part installed on the vehicle is defective or was installed incorrectly and caused damage to another part of the vehicle otherwise covered under warranty. The Federal Trade Commission requires that a manufacturer demonstrate that an aftermarket or recycled part or service performed by a person other than an authorized service provider caused damage to another part of the vehicle otherwise covered under warranty before denying warranty coverage. Additionally, federal law allows a manufacturer to void a motor vehicle warranty or deny warranty coverage if the manufacturer provides the article or service to consumers free of charge under the warranty or the manufacturer has secured a waiver from the Federal Trade Commission.

Event data recorder

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed.

The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the

vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

● Disclosure of the EDR data

Toyota will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
- In response to an official request by the police, a court of law or a government agency
- For use by Toyota in a lawsuit

However, if necessary, Toyota may:

- Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

dealer before you scrap your vehicle.

Scrapping of your Toyota

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Toyota

NOTICE TO QUEBEC CONSUMERS

Toyota Canada Inc. is pleased to offer a 36 month / 60,000 km (whichever occurs first) limited new-vehicle warranty on your vehicle. This limited warranty covers repairs on any part of the vehicle supplied by Toyota Canada that is defective in material or workmanship, subject to certain exceptions that are stated in your warranty manual. For more details of the warranty, check the Owner's Manual Supplement included with your vehicle, or visit toyota.ca.

Quebec's Consumer Protection Act requires Toyota Canada to disclose whether we guarantee the availability of replacement parts, repair services, and information necessary to maintain or repair the vehicle or its components. While Toyota Canada is pleased to honour the terms of our limited warranty, please note that Toyota in no way guarantees the availability of replacement parts, repair services and information necessary to maintain or repair the vehicle or its components.

Perchlorate Material

Special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate.

Your vehicle has components that may contain perchlorate. These components may include the airbags, seat belt pretensioners, wireless remote control batteries, and the batteries in the tire pressure warning valve and transmitters.

“QR Code”

The word “QR Code” is registered trademark of DENSO WAVE INCORPORATED in Japan and other countries.

Caution symbols attached to the high voltage components


High voltage components, such as the power control unit, may have labels attached indicating care required.

Each caution symbol indicates the following:

Symbols	Meanings
	Indicates danger
	Indicates high voltage part

Symbols	Meanings
	Indicates not to touch
	Indicates high temperature part

“PFAS” Label



WARNING

n General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

n General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.


Reading this manual

Explains symbols used in this manual


Symbols in this manual

Symbols	Meanings
	WARNING: Explains something that, if not obeyed, could cause death or serious injury to people.
	NOTICE: Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.
1 2 3...	Indicates operating or working procedures. Follow the steps in numerical order.

Symbols in illustrations



Symbols	Meanings
	Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
	Indicates the outcome of an operation (e.g. a lid opens).




Symbols	Meanings
	Indicates the component or position being explained.
	Means Do not , Do not do this , or Do not let this happen .

How to search


n Searching by name

- Alphabetical index: →P.657



n Searching by installation position

- Pictorial index: →P.16




n Searching by symptom or sound

- What to do if... (Troubleshooting): →P.654




n Searching by title

- Table of contents: →P.2



Pictorial index

n Exterior



- A Side doors P.157**
 - Locking/unlocking P.157
 - Opening/closing the side windows P.203
 - Locking/unlocking by using the mechanical key P.598
 - Warning messages P.578
- B Back door P.162**
 - Locking/unlocking P.163
 - Opening/closing the back door P.163
 - Power back door P.163
 - Warning messages P.578
- C Outside rear view mirrors P.199**
 - Adjusting the mirror angle P.199
 - Folding the mirrors P.199
 - Driving position memory* P.206
 - Defogging the mirrors P.457
- D Windshield wipers..... P.256**

Precautions against winter season	P.444
To prevent freezing (windshield wiper de-icer).....	P.458
Precautions against car wash (rain-sensing windshield wipers).....	P.510

E Charging port lids P.83

Charging methods.....	P.87
-----------------------	------

F Tires..... P.530

Tire size/inflation pressure	P.615
Winter tires/tire chain	P.444
Checking/rotation/tire pressure warning system	P.530
Coping with flat tires.....	P.585

G Hood..... P.521

Opening	P.521
Coping with overheat	P.604
Warning messages	P.578

Light bulbs of the exterior lights for driving

(Replacing method: P.558)

H Headlights/daytime running lights P.251

I Parking lights P.251

Turn signal lights	P.244
--------------------------	-------

J Front side marker lights P.251

K Rear turn signal lights P.244

L Tail lights/Rear side marker lights P.251

Stop lights	
-------------	--

M Tail lights..... P.251

Back-up light	
---------------	--


Shifting the shift position to R	P.238
--	-------

N License plate lights..... P.251

O Side turn signal lights P.244

*: If equipped

n Instrument panel




- A Power switch P.234**
 - Starting the EV system/changing the modes P.234, 237
 - Emergency stop of the EV system P.560
 - When the EV system will not start P.596
 - Warning messages P.578
- B Rotary shifter P.238**
 - Changing the shift position P.239
 - Precautions against towing P.563
- C Meters P.139**
 - Reading the meters/adjusting the instrument panel lights P.139, 141
 - Warning lights/indicator lights P.134
 - When the warning lights come on P.568
- D Multi-information display P.142**
 - Display P.142
 - When the warning messages are displayed P.578
- E Turn signal lever P.244**

Headlight switch	P.251
Headlights/parking lights/tail lights/license plate lights/daytime running lights	P.251
[F] Windshield wiper and washer switch.....	P.256, 259
Usage.....	P.256, 259
Adding washer fluid.....	P.530
Headlight cleaners	P.260
Warning messages	P.578
[G] Emergency flasher switch.....	P.560
[H] Hood lock release lever	P.521
[I] Tilt and telescopic steering lock release lever.....	P.188
Adjustment	P.188
[J] Air conditioning system	P.454
Usage.....	P.454
Rear window defogger	P.457
[K] Multimedia system*	


*: Refer to "MULTIMEDIA OWNER'S MANUAL".

n Switches




A	Instrument panel light control switches	P.141
B	“ODO TRIP” switch	P.141
C	Camera switch*	P.375
D	Brake hold switch	P.249
E	Parking brake switch	P.245
	Applying/releasing	P.245
	Precautions against winter season	P.445
	Warning buzzer/message	P.568, 578
F	“ECO MODE” switch.....	P.243
G	VSC (Vehicle Stability Control) off switch	P.439
H	Grip Control switch.....	P.436
I	“X-MODE” switch.....	P.434
J	Power back door switch.....	P.162
K	Headlight cleaner switch	P.260
L	Automatic High Beam switch	P.253

*: Refer to “MULTIMEDIA OWNER’S MANUAL”.



- A** Position memory switches* P.206
- B** Outside rear view mirror switches P.199
- C** Door lock switches P.160
- D** Power window switches..... P.203
- E** Window lock switch P.205

*: If equipped




- A** Meter control switches P.144
- B** TEL switch* P.144
- C** Cruise control switch
Dynamic radar cruise control P.311

Cruise control	P.322
D LTA (Lane Tracing Assist) switch	P.285
E Audio remote control switches*	
F Talk switch*	
G Paddle shift switches	P.243


*: Refer to "MULTIMEDIA OWNER'S MANUAL".

n Interior



A	SRS airbags	P.33
B	Floor mats	P.26
C	Front seats	P.181
D	Rear seats	P.182
E	Head restraints	P.184
F	Seat belts	P.29
G	Inside lock buttons	P.160
H	Assist grips	P.489
I	Coat hooks	P.489
J	Cup holders	P.470
K	Console box	P.469
L	Rear seat heater switches	P.464

n Ceiling



A	Inside rear view mirror ^{*1}	P.189
	Digital Rear-view Mirror ^{*1}	P.190
B	Sun visors.....	P.478
C	Vanity mirrors.....	P.478
D	Electronic sunshade switches ^{*1}	P.477
E	Interior light ^{*2}	P.467
	Personal lights	P.467
F	“SOS” button.....	P.62

^{*1}: If equipped

^{*2}: The illustration shows the front, but they are also equipped in the rear.

For safety and security

1

1-1. For safe use

Before driving	26
For safe driving	27
Seat belts	29
SRS airbags	33
Front passenger occupant classification system	41

1-2. Child safety

Riding with children	47
Child restraint systems...	48

1-3. Emergency assistance

Safety Connect	62
----------------------	----

1-4. Theft deterrent system

Immobilizer system	66
Alarm.....	67


Before driving

Observe the following before starting off in the vehicle to ensure safety of driving.


Installing floor mats

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

- 1** Insert the retaining hooks (clips) into the floor mat eye-lets.



- 2** Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.



Always align the $\triangle$ marks **A**.

The shape of the retaining hooks (clips) may differ from that shown in the illustration.

⚠ WARNING

Observe the following precautions.

Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle. This could lead to an accident, resulting in death or serious injury.


n When installing the driver's floor mat

- I** Do not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- I** Only use floor mats designed for the driver's seat.
- I** Always install the floor mat securely using the retaining hooks (clips) provided.
- I** Do not use two or more floor mats on top of each other.
- I** Do not place the floor mat bottom-side up or upside-down.

⚠ WARNING

n Before driving

- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.




- With the EV system stopped and the shift position in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.

For safe driving

For safe driving, adjust the seat and mirror to an appropriate position before driving.

Correct driving posture



- A** Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P.181)
- B** Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P.181)
- C** Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (→P.184)
- D** Wear the seat belt correctly. (→P.29)

**WARNING****n For safe driving**

Observe the following precautions.

Failure to do so may result in death or serious injury.

- I Do not adjust the position of the driver's seat while driving. Doing so could cause the driver to lose control of the vehicle.
- I Do not place a cushion between the driver or passenger and the seatback.
A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- I Do not place anything under the front seats.
Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.
- I Always observe the legal speed limit when driving on public roads.
- I When driving over long distances, take regular breaks before you start to feel tired. Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle. (→P.29)

Use a child restraint system appropriate for the child until the

child becomes large enough to properly wear the vehicle's seat belt. (→P.48)

Adjusting the mirrors

Make sure that you can see the rear of the vehicle clearly, by adjusting the inside rear view mirror (if equipped), Digital Rear-view Mirror (if equipped) and outside rear view mirrors properly. (→P.189, 190, 199)

Seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.




WARNING

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident. Failure to do so may cause death or serious injury.

n Wearing a seat belt

- | Ensure that all passengers wear a seat belt.
- | Always wear a seat belt properly.
- | Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- | Toyota recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- | To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- | Do not wear the shoulder belt under your arm.
- | Always wear your seat belt low and snug across your hips.

n Pregnant women



Obtain medical advice and wear the seat belt in the proper way. (→P.30)

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.

n People suffering illness

Obtain medical advice and wear the seat belt in the proper way. (→P.30)

n When children are in the vehicle

→P.56


n Seat belt damage and wear

- | Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.

WARNING

- I Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- I Ensure that the belt and plate are locked and the belt is not twisted.
If the seat belt does not function correctly, immediately contact your Toyota dealer.
- I Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- I Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Toyota dealer. Inappropriate handling may lead to incorrect operation.

Correct use of the seat belts



- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.

- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.


n Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.

- I Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P.56)
- I When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions regarding seat belt usage. (→P.29)

n Seat belt extender

If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Toyota dealer free of charge.



WARNING

n Using a seat belt extender


Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident. Failure to do so may cause death or serious injury.

⚠ WARNING

- I** Do not wear the seat belt extender if you can fasten the seat belt without the extender.
- I** Do not use the seat belt extender when installing a child restraint system because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- I** The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.

⚠ NOTICE**n When using a seat belt extender**

When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt.
This helps prevent damage to the vehicle interior and the extender itself.

Fastening and releasing the seat belt

- 1** To fasten the seat belt, push the plate into the buckle until

a click sound is heard.


- 2** To release the seat belt, press the release button **A**.

n Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. When the seat belt locks, pull the belt strongly and then release the belt, then a slow and easy pulling will allow the belt to extend.

n Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold the child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more. (→P.56)

Adjusting the seat belt shoulder anchor height (front seats)

- 1** Push the seat belt shoulder anchor down while pressing the release button **A**.
- 2** Push the seat belt shoulder anchor up while pressing the

release button .

Move the height adjuster up and down as needed until you hear a click.



WARNING

n Adjustable shoulder anchor

Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident.

Seat belt pretensioners

When the vehicle is subjected to a severe frontal or side impact or rollover, the pretensioners retract the seat belts of the front seats and rear outer seats to securely restrain the occupants.

The pretensioners will not operate in minor frontal or side impacts, or rear impacts.

n Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

n PCS-linked control

If the PCS (Pre-Collision System) determines that the possibility of a collision with a vehicle is high, the seat belt pretensioners will be prepared to operate.



WARNING

n Seat belt pretensioners

Observe the following precautions to reduce the risk of injury in the event of sudden braking or an accident.

Failure to do so may result in death or serious injury.


I Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not operate in the event of a collision.

I If a pretensioner has operated, the SRS warning light will illuminate. In this situation, the seat belt cannot be used and must be replaced by your Toyota dealer.

SRS airbags

The SRS airbags deploy when the vehicle is subjected to certain types of severe impact that may cause significant injury to the occupants. The airbags work together with the seat belts to help reduce the risk of death or serious injury.

SRS airbag system



A SRS front airbags (SRS driver airbag/SRS front passenger airbag)

Help reduce impact to the head and chest of the driver and front passenger

B SRS knee airbags

Help reduce impact to the driver and front passenger

C SRS side airbags

Help reduce impact to the chest of the occupants of the front seats

D SRS curtain shield airbags

- Help reduce impact to the heads of the occupants of the front and rear outer seats
- Can help prevent the occupants from being thrown from the vehicle in the event of a vehicle rollover

Your vehicle is equipped with ADVANCED AIRBAGS designed

based on US motor vehicle safety standards (FMVSS208). The airbag sensor assembly (ECU) controls airbag deployment based on information obtained from the sensors, etc., shown in the system components diagram above. This information includes crash severity and occupant information. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

n If the SRS airbags deploy (inflate)

- | Slight abrasions, burns, bruising, etc., may be sustained from SRS airbags, due to the extremely high speed of deployment (inflation) by hot gases.
- | A loud noise and white powder will be emitted.
- | Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the parts around the airbags may be hot for several minutes. The airbag itself may also be hot.
- | The windshield may crack.
- | The EV system will be stopped. (→P.78)
- | All of the doors will be unlocked. (→P.158)
- | The brakes and stop lights will be controlled automatically. (→P.439)
- | The interior lights will turn on automatically. (→P.467)
- | The emergency flashers will turn on automatically. (→P.560)

n Emergency call

- | For Safety Connect subscribers, if any of the following situations occur, the system is designed to send an emergency call to the response center.
- When an SRS airbag has been deployed
- When a seat belt pretensioner has operated
- When the vehicle received an impact exceeding a certain level

Emergency services may be dispatched even if there is no response to calls from the agent.

n The SRS airbags deploy in a frontal impact when

- | The following SRS airbags will deploy in the event of an impact that exceeds a threshold level (level of force corresponding to an approximately 12 - 18 mph [20 - 30 km/h] frontal collision with a fixed wall that does not move or deform):
 - SRS front airbags
 - SRS knee airbags
- | The threshold level at which the SRS airbags will deploy will be higher than normal in the in the following situations:
 - When the vehicle collides with an object, such as a parked vehicle or sign pole, which moves or deforms on impact
 - If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle “underrides”, or goes under, the bed of a truck
- | Depending on the type of collision, only the following may deploy:
 - Seat belt pretensioners
- | The SRS airbags for the front passenger's seat will not deploy if there is no passenger in the front passenger seat. However, the SRS airbags for the front passenger's seat may deploy, even if the seat is unoccupied, if luggage is put on the seat.
- | In the event of an especially severe frontal collision, the left

and right SRS curtain shield airbags may also deploy.

n The SRS airbags deploy in a side impact when

| The following SRS airbags will deploy in the event of an impact that exceeds the set threshold level (level of force corresponding to the impact force produced by an approximately 3300 lb. [1500 kg] vehicle colliding with the passenger compartment at a perpendicular angle at an approximate speed of 12 - 18 mph [20 - 30 km/h]):

- SRS side airbags
- SRS curtain shield airbags

| In the event of a side collision, regardless of the impacted side, both the left and right SRS curtain shield airbags will deploy.


| If the vehicle is involved in a rollover, the following SRS airbags will deploy:

- Both left and right SRS curtain shield airbags

n The SRS airbags deploy in an underside impact when


| The following airbags may deploy if the underside of the vehicle collides with a hard object:

- SRS front airbags
- SRS knee airbags
- SRS side airbags
- SRS curtain shield airbags



| The following airbags may deploy if the vehicle becomes significantly tilted or is strongly impacted by skidding into a curb, etc.:


- SRS curtain shield airbags



n The SRS airbags will not deploy when


| The following SRS airbags will not normally deploy in side or rear collisions, vehicle rollovers, or low speed frontal collisions. However, if such a collision causes sufficient sudden deceleration, the SRS airbags may deploy.

- SRS front airbags
- SRS knee airbags




| The following SRS airbags may not deploy if the vehicle is collided with at a certain angle or in a side collision where an area of the vehicle other than the passenger compartment is collided with:

- SRS side airbags
- SRS curtain shield airbags




| The following SRS airbags will not normally deploy in front or rear collisions, vehicle rollovers, or low speed side collisions:

- SRS side airbags



| The following SRS airbags will not normally deploy in rear collisions, end over end vehicle rollovers, or low speed front or side collisions:


- SRS curtain shield airbags



n When to contact your Toyota dealer

In the following situations, the vehicle will require inspection and/or repair. Contact your Toyota dealer as soon as possible.


- | When any of the SRS airbags have been deployed
- | When the front of the vehicle is damaged or deformed, or was involved in a collision that was not severe enough to cause any of the following SRS airbags to deploy:
 - SRS front airbags
 - SRS knee airbags



- | When a door or its surrounding area is damaged, deformed or has had a hole made in it, or was

involved in a collision that was not severe enough to cause any of the following SRS airbags to deploy:

- SRS side airbags
- SRS curtain shield airbags



- | When the pad section of the steering wheel, the dashboard near the front passenger SRS airbag or the lower side of the instrument panel is scratched, cracked, or otherwise damaged.
- | When the surface of a seat with an SRS side airbag is scratched, cracked, or otherwise damaged.
- | When the part of a front pillar, rear pillar or roof side rail garnish (padding) which covers a SRS curtain shield airbag is scratched, cracked, or otherwise damaged.



WARNING

n SRS airbag precautions

Observe the following precautions.

Failure to do so may result in death or serious injury.

- | The driver and all passengers must wear their seat belts correctly. The SRS airbags are supplemental devices to be used with the seat belts.

**WARNING**

I The SRS driver airbag deploys with considerable force, and can cause death or serious injury, especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration (NHTSA) advises:

Since the risk zone for the driver's airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If your current driving position places you less than 10 in. (250 mm) away from the driver airbag, you can change your driving position in several ways:

- Move your seat to the rear as far as possible while still being able to reach the pedals comfortably.
- Slightly recline the seatback. Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the seatback somewhat. If reclining the seatback makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.

- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck. The seat should be adjusted as recommended by the NHTSA, while still being able to control the vehicle with the pedals and steering wheel, and maintaining your view of the instrument panel controls.


- I** If a seat belt extender has been connected to the front passenger seat belt buckle but the latch plate of the front passenger seat belt has not been fastened to the seat belt extender, the SRS airbag system will judge that the front passenger is wearing the seat belt even though the seat belt has not been fastened. In this case, the SRS front airbags for the front passenger may not deploy correctly in a collision, resulting in death or serious injury. Be sure to wear the seat belt correctly when using a seat belt extender.

- I** The SRS front passenger airbag deploys with considerable force, and can cause death or serious injury, especially if the front passenger is very close to the airbag. The front passenger seat should be positioned as far possible from the airbag with the seatback adjusted so that the passenger is sat upright.


WARNING

Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (→P.48)

Do not sit on the edge of the seat or lean against the dashboard.



Do not allow a child to stand in front of the SRS front passenger airbag or sit on the lap of a front passenger.




Front seat occupants should never hold items on their lap.


Do not lean against the door, roof side rail, or front, side, or rear pillar.



Do not allow anyone to kneel on a seat toward the door or put their head or hands outside the vehicle.




Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel.



! WARNING

- Do not attach anything to areas such as the doors, windshield, side windows, front or rear pillars, roof side rails and assist grips. (With the exception of the speed limit label →P.589)



- Do not hang coat hangers or other hard objects on the coat hooks. These items could become projectiles if the SRS curtain shield airbags deploy, possibly leading to death or serious injury.
- If a vinyl cover is attached to the area where the SRS knee airbag deploys, be sure to remove it.
- Do not use seat accessories which cover the parts from which the SRS airbags deploy, as they may interfere with inflation of the SRS airbags. Such accessories may prevent the SRS airbags from deploying correctly, may disable the system or cause the SRS airbags to inflate unintentionally, possibly resulting in death or serious injury.
- Do not strike or apply significant force to the SRS airbag system components, front doors or their surrounding area. Doing so may cause the SRS airbags to malfunction.

- Do not touch any components of the SRS airbags immediately after the SRS airbags have deployed (inflated) as they may be hot.

- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.

- If a part where an SRS airbag is stored is damaged or cracked, have it replaced by your Toyota dealer.

- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the SRS front airbags for the front passenger's seat may not deploy in the event of a collision.

n Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Toyota dealer. The SRS airbags may malfunction or deploy unintentionally, possibly leading to death or serious injury.

- Removal, installation, disassembly or repair of the SRS airbags
- Repair, removal or modification of the following parts or their surrounding
 - Steering wheel
 - Instrument panel

**WARNING**

- Dashboard
- Seats
- Seat upholstery
- Front pillars
- Side pillars
- Rear pillars
- Roof side rails
- Front door panels
- Front door trim
- Front door speakers
- | Modifications to the front door panels (such as making holes in them)
- | Repair or modification of the following parts or their surrounding
 - Front fender
 - Front bumper
 - Sides of the vehicle interior
- | Installation of the following parts or accessories
 - Bull bars or kangaroo bars
 - Snow plows
 - Winches
 - Roof luggage carriers
- | Modifications to the vehicle's suspension
- | Installation of electronic devices such as mobile two-way radios (RF-transmitter) and CD players
- | Modifications to your vehicle for a persons with a physical disability

Front passenger occupant classification system


Your vehicle is equipped with a front passenger occupant classification system.

This system detects the conditions of the front passenger seat and activates or deactivates the following SRS airbags.

- SRS front passenger airbag
- SRS front passenger knee airbag


System components

► Type A



- A** SRS warning light
- B** Seat belt reminder light (Front passenger's)
- C** "AIR BAG OFF" indicator light
- D** "AIR BAG ON" indicator light

► Type B



- A** SRS warning light
- B** Seat belt reminder light
- C** "AIR BAG OFF" indicator light
- D** "AIR BAG ON" indicator light

Front passenger occupant classification system conditions and operation

n Adult*1

Indicator/warning light	“AIR BAG ON” and “AIR BAG OFF” indicator lights	“AIR BAG ON”
	SRS warning light	Off
	Seat belt reminder light	Off*2 or flashing*3
Devices	Front passenger airbag	Activated
	Front passenger knee airbag	

n Child*4

Indicator/warning light	“AIR BAG ON” and “AIR BAG OFF” indicator lights	“AIR BAG OFF” or “AIR BAG ON”*4
	SRS warning light	Off
	Seat belt reminder light	Off*2 or flashing*3
Devices	Front passenger airbag	Deactivated or activated*4
	Front passenger knee airbag	Deactivated or activated*4, 2

n Child restraint system with infant*5

Indicator/warning light	“AIR BAG ON” and “AIR BAG OFF” indicator lights	“AIR BAG OFF”*6
	SRS warning light	Off
	Seat belt reminder light	Off*2 or flashing*3
Devices	Front passenger airbag	Deactivated
	Front passenger knee airbag	

n Unoccupied

Indicator/warning light	“AIR BAG ON” and “AIR BAG OFF” indicator lights	“AIR BAG OFF”
	SRS warning light	Off
	Seat belt reminder light	
Devices	Front passenger airbag	Deactivated
	Front passenger knee airbag	

n System malfunction

Indicator/warning light	“AIR BAG ON” and “AIR BAG OFF” indicator lights	“AIR BAG OFF”
	SRS warning light	On
	Seat belt reminder light	
Devices	Front passenger airbag	Deactivated
	Front passenger knee airbag	

- *1: The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may not recognize them as an adult depending on their physique and posture.
- *2: In the event the front passenger is wearing a seat belt.
- *3: In the event the front passenger does not wear a seat belt.
- *4: For some children, child in seat, child in booster seat or child in convertible seat, the system may not recognize them as a child. Factors which may affect this can be the physique or posture.
- *5: Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P.48)
- *6: In case the indicator light is not illuminated, consult this manual on how to install the child restraint system properly. (→P.50)

**WARNING**

n Front passenger occupant classification system precautions

Observe the following precautions regarding the front passenger occupant classification system. Failure to do so may cause death or serious injury.

- I Wear the seat belt properly.
- I Make sure the front passenger's seat belt plate has not been left inserted into the buckle before someone sits in the front passenger seat.

**WARNING**

- I Make sure the “AIR BAG OFF” indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the “AIR BAG OFF” indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, and reconnect the seat belt extender after making sure the “AIR BAG ON” indicator light is illuminated. If you use the seat belt extender while the “AIR BAG OFF” indicator light is illuminated, the SRS airbags for the front passenger will not activate, which could cause death or serious injury in the event of a collision.
- I Do not apply a heavy load to the front passenger seat or equipment (e.g. seatback pocket).
- I Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- I Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- I Do not put objects under the front passenger seat.
- I Do not recline the front passenger seatback so far that it touches a rear seat. This may cause the “AIR BAG OFF” indicator light to be illuminated, which indicates that the SRS airbags for the front passenger will not activate in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.
- I If an adult sits in the front passenger seat, the “AIR BAG ON” indicator light is illuminated. If the “AIR BAG OFF” indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the “AIR BAG OFF” indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- I When it is unavoidable to install a forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. (→P.50)
- I Do not modify or remove the front seats.
- I Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the front passenger occupant classification system. In this case, contact your Toyota dealer immediately.

**WARNING**

- | Child restraint systems installed on the rear seat should not contact the front seatbacks.
- | Do not use a seat accessory, such as a cushion and seat cover, that covers the seat cushion surface.
- | Do not modify or replace the upholstery of the front seat.

Riding with children

Observe the following precautions when children are in the vehicle.

Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the steering wheel, wiper switch, etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally.
(→P.160, 205)
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, back door, seats etc.



WARNING

n When children are in the vehicle

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Child restraint systems

Before installing a child restraint system in the vehicle, there are precautions that need to be observed, different types of child restraint systems, as well as installation methods, etc., written in this manual.

Use a child restraint system when riding with a small child that cannot properly use a seat belt. For the child's safety, install the child restraint system to a rear seat. Be sure to follow the installation method that is in the operation manual enclosed with the restraint system.

Table of contents

Points to remember: P.48

Child restraint system: P.50

When using a child restraint system: P.50

Child restraint system installation method

- Fixed with a seat belt: P.52
- Fixed with a child restraint LATCH anchor: P.57
- Using an anchor bracket (for top tether strap): P.59

Points to remember

The laws of all 50 states of the U.S.A. as well as Canada now require the use of child restraint systems.

- Prioritize and observe the warnings, as well as the laws and regulations for child restraint systems.
- Use a child restraint system until the child becomes large enough to properly wear the vehicle's seat belt.
- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.



WARNING

n When a child is riding

Observe the following precautions.

Failure to do so may result in death or serious injury.

- I For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system which is correctly installed. For installation details, refer to the operation manual enclosed with the child restraint system. General installation instruction is provided in this manual.

**WARNING**

- I Toyota strongly urges the use of a proper child restraint system that conforms to the weight and size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- I Holding a child in your or someone else's arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield or between the holder and the interior of the vehicle.

n Handling the child restraint system




If the child restraint system is not properly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving, or an accident.

- I If the vehicle were to receive a strong impact from an accident, etc., it is possible that the child restraint system has damage that is not readily visible. In such cases, do not reuse the restraint system.
- I Make sure you have complied with all installation instructions provided with the child restraint system manufacturer and that the system is properly secured.
- I Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
- I If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the luggage compartment.

Child restraint system

n Types of child restraint system installation methods

Confirm with the operation manual enclosed with the child restraint system about the installation of the child restraint system.

Installation method		Page
Seat belt attachment		P.52
Child restraint LATCH anchors attachment		P.57
Anchor brackets (for top tether strap) attachment		P.59

When using a child restraint system


n When installing a child restraint system to a front passenger seat

For the safety of a child, install child restraint systems to a rear seats. When installing child restraint system to a front passenger seat is unavoidable, adjust the seat as follows and

install the child restraint system.

- Adjust the seatback angle to the most upright position.
- Move the front seat fully rearward. If the passenger seat height can be adjusted, move it to the upper most position.
- If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

Otherwise, put the head restraint in the upper most position.



WARNING

n When using a child restraint system

Observe the following precautions.

Failure to do so may result in death or serious injury.

- ! Never install a rear-facing child restraint system on the front passenger seat even if the "AIR BAG OFF" indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.

A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat.


A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. When installing a forward-facing child restraint system on the front passenger seat, raise the seatback as much as possible, move the seat to the rearmost position, and raise the seat to the highest position, even if the "AIR BAG OFF" indicator light is illuminated.

If the head restraint interferes with the installation of the child restraint system, and the head restraint can be removed, remove the head restraint.




WARNING

- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front or rear pillars, or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.



- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder.
- Use child restraint system suitable to the age and size of the child and install it to the rear seat.

- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand rear seat.



- Adjust the front passenger seat so that it does not interfere with the child restraint system.

Child restraint system fixed with a seat belt

A child restraint system for a small child or baby must itself be properly restrained on the seat with the lap portion of the lap/shoulder belt.

- Installing child restraint system using a seat belt (child restraint lock function belt)**


Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.

- Rear-facing — Infant seat/convertible seat**


- Adjust the rear seat.

If there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.


- 2** Place the child restraint system on the rear seat facing the rear of the vehicle.



- 3** Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.




- 4** Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.



- 5** While pushing the child restraint system down into

the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.



- 6** After installing the child restraint system, rock it back and forth to ensure that it is installed securely. (→P.56)

n **Forward-facing — Convertible seat**

- 1** Adjust the seat.

► **When using the front passenger seat**


If installing the child restraint system to the front passenger seat is unavoidable, refer to P.50 for the front passenger seat adjustment.

► **When using the rear seat**


If there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.

- 2** If the head restraint interferes with the child restraint system installation and the head restraint can be removed,


remove the head restraint.
(→P.185)



- 3** Place the child restraint system on the seat facing the front of the vehicle.




- 4** Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.




- 5** Fully extend the shoulder belt and allow it to retract to put it

in lock mode. In lock mode, the belt cannot be extended.



- 6** While pushing the child restraint system into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.




- 7** If the child restraint has a top tether strap, follow the child restraint manufacturer's operation manual regarding the installation, using the top tether strap to latch onto the top tether strap anchor.
(→P.59)

- 8** After installing the child restraint system, rock it back

and forth to ensure that it is installed securely. (→P.56)


n **Booster seat**

- 1 If installing the child restraint system to the front passenger seat is unavoidable, refer to P.50 for the front passenger seat adjustment.
- 2 High back type: If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint. (→P.185)




- 3 Place the child restraint system on the seat facing the front of the vehicle.

► **Booster type**




► **High back type**



- 4 Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.

Check that the shoulder belt is correctly positioned over the child's shoulder and that the lap belt is as low as possible. (→P.29)




n **Removing a child restraint system installed with a seat belt**

Press the buckle release button and fully retract the seat belt.

When releasing the buckle, the child restraint system may spring up due to the rebound of the seat cushion. Release the buckle while holding down the child restraint

system.

Since the seat belt automatically reels itself, slowly return it to the stowing position.



WARNING

n When installing a child restraint system

Observe the following precautions.

Failure to do so may result in death or serious injury.

- | Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.**
- | Ensure that the belt and plate are securely locked and the seat belt is not twisted.**
- | Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.**
- | After securing a child restraint system, never adjust the seat.**

| When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder.

| Follow all installation instructions provided by the child restraint system manufacturer.

| When securing some types of child restraint systems in rear seats, it may not be possible to properly use the seat belts in positions next to the child restraint without interfering with it or affecting seat belt effectiveness. Be sure your seat belt fits snugly across your shoulder and low on your hips. If it does not, or if it interferes with the child restraint, move to a different position. Failure to do so may result in death or serious injury.

| When installing a child restraint system in the rear center seat, adjust both seat cushions to the same position and align both seatbacks at the same angle. The seatbacks must be adjusted to the same angle. Otherwise, the child restraint system cannot be securely restrained and this may cause death or serious injuries in the event of sudden braking, sudden swerving or an accident.

| If the seat is adjusted, reconfirm the security of the child restraint system.

! WARNING**n When installing a booster seat**


To prevent the belt from going into ALR lock mode, do not fully extend the shoulder belt. ALR mode causes the belt to tighten only. This could cause injury or discomfort to the child. (→P.31)

n Do not use a seat belt extender

If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of sudden braking, sudden swerving or an accident.

Child restraint system fixed with a child restraint LATCH anchor**n Child restraint LATCH anchors**

LATCH anchors are provided for the outboard rear seats.


**n When installing in the rear outboard seats**

Install the child restraint system in accordance to the operation

manual enclosed with the child restraint system.

1 Adjust the seat.


If there is a gap between the child seat and the seatback, adjust the seatback angle until good contact is achieved.

2 If the head restraint interferes with the child restraint system installation and the head restraint can be removed, remove the head restraint. (→P.185)**► With flexible lower attachments****3 Latch the hooks of the lower attachments onto the LATCH anchors.**

For owners in Canada:

The symbol on a child restraint system indicates **A**

the presence of a lower connector system.



A Canada only


► With rigid lower attachments

3 Latch the buckles onto the LATCH anchors.

For owners in Canada:

The symbol on a child restraint system indicates **A**

the presence of a lower connector system.



A Canada only

4 If the child restraint has a top tether strap, follow the child restraint manufacturer's operation manual regarding the installation, using the top tether strap to latch onto the top tether strap anchor. (→P.59)

5 After installing the child restraint system, rock it back and forth to ensure that it is installed securely. (→P.56)

n When installing in the rear center seat

There are no LATCH anchors on the rear center seat. However, the inboard LATCH anchors of the outboard seats, which are 16.54 in. (420 mm) apart, can

be used if the child restraint system manufacturer's instructions permit use of those anchors with the anchor spacing stated.

Child restraint systems with rigid lower attachments cannot be installed in the center seat. This type of child restraint system can only be installed in the out-board seat.

n Laws and regulations pertaining to anchors

The LATCH system conforms to FMVSS225 or CMVSS210.2. Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used. This vehicle is designed to conform to SAE J1819.



WARNING

n When installing a child restraint system

Observe the following precautions.

Failure to do so may result in death or serious injury.

- I** When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system.
- I** Follow all installation instructions provided by the child restraint system manufacturer.

I Never attach two child restraint system attachments to the same anchor. In a collision, one anchor may not be strong enough to hold two child restraint system attachments and may break.

If the LATCH anchors are already in use, use the seat belt to install a child restraint system in the center seat.

I When securing some types of child restraint systems in rear seats, it may not be possible to properly use the seat belts in positions next to the child restraint without interfering with it or affecting seat belt effectiveness. Be sure your seat belt fits snugly across your shoulder and low on your hips. If it does not, or if it interferes with the child restraint, move to a different position. Failure to do so may result in death or serious injury.

I If the seat is adjusted, reconfirm the security of the child restraint system.


Using an anchor bracket (for top tether strap)

n Anchor brackets (for top tether strap)

Anchor brackets are provided for each rear seat.

Use anchor brackets when fixing the top tether strap.


► Outboard rear seats



A Anchor brackets

B Top tether strap

► Rear center seat



A Anchor bracket


B Top tether strap

n **Fixing the top tether strap to the anchor bracket**

Install the child restraint system in accordance to the operation manual enclosed with the child restraint system.


► Outboard rear seats

- 1 Remove the head restraint. (→P.184)



- 2 Latch the attaching clip onto the anchor fitting and tighten the upper anchorage strap.

Make sure the upper anchorage strap is securely latched. (→P.56)



A Hook


B Top tether strap

► Rear center seat

- 1 Adjust the head restraint to the upmost position.

If the head restraint interferes with the child restraint system or top strap installation and the head restraint can be removed, remove


the head restraint. (→P.184)



2 Latch the attaching clip onto the anchor fitting and tighten the upper anchorage strap.

Make sure the upper anchorage strap is securely latched.

When installing the child restraint system with the head restraint being raised, be sure to have the top tether strap pass underneath the head restraint.



A Hook

B Top tether strap

n Laws and regulations pertaining to anchors

The LATCH system conforms to FMVSS225 or CMVSS210.2.

Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to SAE J1819.



WARNING

n When installing a child restraint system

Observe the following precautions.

Failure to do so may result in death or serious injury.

- ! Firmly attach the top tether strap and make sure that the belt is not twisted.
- ! Do not attach the top strap to anything other than the anchor bracket.
- ! Follow all installation instructions provided by the child restraint system manufacturer.
- ! Rear center seat: When installing the child restraint system with the head restraint being raised, after the head restraint has been raised and then the anchor bracket has been fixed, do not lower the head restraint.



NOTICE

n Anchor brackets (for top tether strap)

When not in use, make certain to close the lid. If it remains open, the lid may be damaged.


Safety Connect

Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Toyota's designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

By using the Safety Connect service, you are agreeing to be bound by the Telematics Subscription Service Agreement and its Terms and Conditions, as in effect and amended from time to time, a current copy of which is available at Toyota.com in the United States, Toyota.pr.com in Puerto Rico and Toyota.ca in Canada. All use of the Safety Connect service is subject to such then-applicable Terms and Conditions.

System components



- A** Microphone
- B** "SOS" button
- C** LED light indicators
- D** Speaker

Services

Subscribers have the following Safety Connect services available:

- Automatic Collision Notification*

Helps drivers receive necessary response from emergency service providers. (→P.64)

*: U.S. Patent No. 7,508,298 B2

- Stolen Vehicle Location

Helps drivers in the event of vehicle theft. (→P.64)

- Emergency Assistance Button ("SOS")

Connects drivers to response-center support. (→P.64)

● Enhanced Roadside Assistance

Provides drivers various on-road assistance. (→P.65)

Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.

A variety of subscription terms are available for purchase. Contact your Toyota dealer, call the following appropriate Customer Experience Center or push the “SOS” button in your vehicle for further subscription details.

- The United States

1-800-331-4331

- Canada

1-888-869-6828

- Puerto Rico

1-877-855-8377

n Safety Connect Services Information

- | Phone calls using the vehicles Bluetooth® technology will not be possible when Safety Connect is active and in use.
- | Safety Connect is available beginning Fall 2009 on select Toyota models (in the contiguous United States only). Contact with the Safety Connect response center is dependent upon the telematics device being in operative condition, cellular connection availability, and GPS satellite signal reception, which can limit the ability to reach the response center or

receive emergency service support. Enrollment and Telematics Subscription Service Agreement are required. A variety of subscription terms are available; charges vary by subscription term selected and location.

- | Automatic Collision Notification, Emergency Assistance and Stolen Vehicle Location are available in the United States, including Hawaii and Alaska, Puerto Rico and Canada, and Enhanced Roadside Assistance are available in the United States, Puerto Rico and Canada.
- | Automatic Collision Notification, Emergency Assistance, Stolen Vehicle and Enhanced Road Assistance will not function in the United States Virgin Islands. For vehicles first sold in the USVI, no Safety Connect services will function in and outside the United States Virgin Islands.
- | Safety Connect services are not subject to section 255 of the Telecommunications Act and the device is not TTY compatible.

n Languages

The Safety Connect response center will offer support in multiple languages. The Safety Connect system will offer voice prompts in English, Spanish, and French. Please indicate your language of choice when enrolling.

n When contacting the response center

You may be unable to contact the response center if the network is busy.

Safety Connect LED light Indicators

When the power switch is turned to ON, the red indicator light comes on for 2 seconds then

turns off. Afterward, the green indicator light comes on, indicating that the service is active.

The following indicator light patterns indicate specific system usage conditions:

- Green indicator light on = Active service
- Green indicator light flashing = Safety Connect call in process
- Red indicator light (except at vehicle start-up) = System malfunction (contact your Toyota dealer)
- No indicator light (off) = Safety Connect service not active

Safety Connect services

n Automatic Collision Notification

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and

requests that assistance be sent to the location.

n Stolen Vehicle Location

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Customer Experience Center at 1-800-331- 4331 in the United States, 1-877-855-8377 in Puerto Rico or 1-888-869-6828 in Canada, and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at Toyota.com in the United States, Toyotapr.com in Puerto Rico and Toyota.ca in Canada.

n Emergency Assistance Button ("SOS")

In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing

an emergency.

n Enhanced Roadside Assistance

Enhanced Roadside Assistance adds GPS data to the already included warranty-based Toyota roadside service.

Subscribers can press the “SOS” button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, etc. For a description of the Enhanced Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at Toyota.com in the United States, Toyotapr.com in Puerto Rico and Toyota.ca in Canada.

Safety information for Safety Connect

Important! Read this information about exposure to radio frequency signals before using Safety Connect;

n Exposure to radio frequency signals

The Safety Connect system installed in your vehicle is a low-power radio transmitter and receiver. It receives and also sends out radio frequency (RF) signals.

In August 1996, the Federal

Communications Commission (FCC) adopted RF exposure guidelines with safety levels for mobile wireless phones. Those guidelines are consistent with the safety standards previously set by the following U.S. and international standards bodies.

- ANSI (American National Standards Institute) C95.1 [1992]
- NCRP (National Council on Radiation Protection and Measurement) Report 86 [1986]
- ICNIRP (International Commission on Non-Ionizing Radiation Protection) [1996]

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. Over 120 scientists, engineers, and physicians from universities, and government health agencies and industries reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of Safety Connect complies with the FCC guidelines in addition to those standards.

Immobilizer system

The vehicle's keys have built-in transponder chips that prevent the EV system from starting if a key has not been previously registered in the vehicle's on-board computer.


Never leave the keys inside the vehicle when you leave the vehicle.

This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.

Operating the system

The indicator light flashes after the power switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the power switch has been turned to ACC or ON to indicate that the system has been canceled.



n System maintenance

The vehicle has a maintenance-free type immobilizer system.

n Conditions that may cause the system to malfunction

- l If the grip portion of the key is in contact with a metallic object
- l If the key is in close proximity to or touching a key registered to the security system (key with a built-in transponder chip) of another vehicle



NOTICE

n To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

Alarm

The alarm uses light and sound to give an alert when an intrusion is detected. The alarm is triggered in the following situations when the alarm is set:

- A locked door or back door is unlocked or opened in any way other than using the entry function, wireless remote control or mechanical key. (The doors will lock again automatically.)
- The hood is opened.

Setting/deactivating/stopping the alarm system

n Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following:


- Nobody is in the vehicle.
- The windows are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

n Setting

Close the doors, back door and hood, and lock all the doors. The system will be set automatically after 30 seconds.

The indicator light changes from

being on to flashing when the system is set.



n Deactivating or stopping

Do one of the following to deactivate or stop the alarms:

- Unlock the doors.
- Turn the power switch to ACC or ON, or start the EV system. (The alarm will be deactivated or stopped after a few seconds.)

n Setting the alarm

The alarm can be set if all the doors are closed even with the hood open.


n System maintenance

The vehicle has a maintenance-free type alarm system.


n Triggering of the alarm

The alarm may be triggered in the following situations: (Stopping the alarm deactivates the alarm system.)


- l The doors are unlocked using the mechanical key.



- I A person inside the vehicle opens a door, the back door or hood, or unlocks the vehicle.



- I The 12-volt battery is recharged or replaced when the vehicle is locked. (→P.602)



n Alarm-operated door lock

In the following cases, depending on the situation, the door may automatically lock to prevent improper entry into the vehicle:

- I When a person remaining in the vehicle unlocks the door and the alarm is activated.
- I While the alarm is activated, a person remaining in the vehicle unlocks the door.
- I When recharging or replacing the 12-volt battery



NOTICE

n To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

Pre-alarm

If a door is unlocked with the mechanical key while the alarm is being set, the pre-alarm will sound for 10 seconds.

If either the door is locked again or the pre-alarm is stopped within those 10 seconds, an alarm will sound.

Do any of the following in order to deactivate or stop the pre-alarm:

- Close the doors, and lock all doors by smart access system or wireless remote control.
- Turn the power switch to ACC or ON, or start the EV system. (The alarm will be deactivated or stopped after a few seconds.)

Electric Vehicle system

2

2-1. Electric vehicle system

Electric Vehicle system features	70
Electric Vehicle system precautions.....	74
Battery Electric Vehicle driving tips.....	79
Driving range.....	81

2-2. Charging

Charging equipment.....	83
Locking and unlocking the AC charging connector	85
Charging methods.....	87
Charging tips.....	90
Things to know before charging	91
How to use AC charging	94
How to use DC charging	100
Using the charging schedule function.....	105
Using Battery Preconditioning	112
Using My Room Mode	115
When charging cannot be carried out	118
Plug & Charge system	129

How to use Plug & Charge system **129**


When Plug & Charge system cannot be used normally **131**

Electric Vehicle system features

Battery electric vehicles are considerably different from conventional vehicles.

They use electricity charged in a traction battery, to drive the electric motor. Since battery electric vehicles are driven using electricity, they do not emit any emissions such as CO₂ (Carbon Dioxide) and NO_x (Nitrogen Oxides). Battery electric vehicles are environmentally friendly vehicles.

System components



The illustration is an example for explanation and may differ from the actual item.

A ESU: Electricity Supply Unit (built in onboard traction battery charger/DC-DC converter)

B eAxle (Traction motor/Inverter/Transaxle) (front/rear)

C Traction battery

Provides electricity to the electric motor.

D Charging port

E 12-volt battery

Provides electricity to various vehicle systems such as the SRS airbags, headlights, wipers, etc.

n **When braking (regenerative braking)**

The electric motor (traction motor) charges the traction battery.

The driving range can be extended by actively using this regenerative braking to store electricity in the traction battery.

Charging

The battery electric vehicle is driven using electricity, which is received from an external power source and stored in the traction battery. Not only public charging stations, but also household outlets can be used for charging. Procedures are different from refueling a conventional vehicle. Therefore, make sure to read the following thoroughly.

- Charging equipment (→P.83)
- Things to know before charging (→P.91)
- How to charge your vehicle (→P.94, 100)
- When charging cannot be performed normally (→P.118)

n **Regenerative braking**

In the following situations, kinetic energy is converted to electric energy and deceleration force can be obtained in conjunction with the recharging of the traction battery.

- l The accelerator pedal is released while driving with the shift position in D.
- l The brake pedal is depressed while driving with the shift position in D.

n **Charging the 12-volt battery**

The 12-volt battery is charged from the traction battery when the EV system is operated or while the traction battery is being charged.

If the vehicle has not been used for a long time, the 12-volt battery may become low due to self-discharge. If this occurs, follow the correct procedures. (→P.600)

n **When not using the vehicle for an extended period of time**

- l When the vehicle will not be used for an extended period of time, charge the traction battery once a month.
This protects the traction battery from extreme voltage decline due to self discharging.
- l When the vehicle will not be used for an extended period of time, the 12-volt battery will be charged from the traction battery to reduce the risk of the 12-volt battery discharged. In this case, the cooling fan may operate, however it is not a malfunction.
- l To prevent the 12-volt battery from being discharged, do not leave the charging port lid open or the charging cable connected to the vehicle.
When it is not necessary to have the charging cable connected, keep it disconnected from the vehicle.

n **Charging the traction battery**

Be sure to maintain the traction battery charge level suitable for your driving needs.

If the traction battery fully discharges, the vehicle cannot be driven at all. When the battery becomes low, charge it as soon as possible.

n If the traction battery becomes low

| If the traction battery becomes low, the traction battery charge warning light comes on or flashes and a message will be displayed on the multi-information display. (→P.570)

| If the traction battery is completely discharged, the EV system cannot be started and driving will not be possible. When the traction battery becomes low, charge it as soon as possible.

n Sounds and vibrations specific to an electric vehicle

Because there is no engine sound or vibration, it is easy to mistake the battery electric vehicle for being off when it is actually still running, as indicated by the "READY" indicator being illuminated. For safety, make sure to always shift the shift position to P and apply the parking brake when parked.

Before and after the EV system is started, the following sounds and vibrations may occur. However, these sounds and/or vibrations are not signs of malfunctions:

- | The brake system operation sound may be heard from the front of the vehicle when the driver's door is opened.
- | Motor sounds may be heard from the motor compartment or luggage compartment.
- | Electrical relay sounds may be heard from the motor compartment when the EV system starts or stops.
- | Relay operating sounds such as a snap or soft clank will be emitted from the traction battery in the following situations:

- When the EV system is started or stopped
- When charging starts or completes
- When the vehicle is driven the first time after the traction battery has been charged using DC charging
- | Sounds may be heard due to regenerative braking when the brake pedal is depressed or as the accelerator pedal is released.
- | Cooling fan operating sounds from the radiator.
- | The operation sound of the air conditioning system (air conditioning compressor, blower motor).
- n Maintenance, repair, recycling, and disposal**

Contact your Toyota dealer regarding maintenance, repair, recycling and disposal. Do not dispose of the vehicle yourself.

Acoustic Vehicle Alerting System

A sound which changes in accordance with the driving speed, will be played in order to warn people nearby of the vehicle's approach. This sound may be heard inside the vehicle. The sound will stop when the vehicle speed exceeds approximately 23 mph (37 km/h).

n Acoustic Vehicle Alerting System

In the following cases, the Acoustic Vehicle Alerting System may be difficult for surrounding people to hear.

- | In very noisy areas
- | In the wind or the rain

Also, as the Acoustic Vehicle Alerting System is installed on the front

of the vehicle, it may be more difficult to hear from the rear of the vehicle compared to the front.


n **When the multi-information display shows “Acoustic Vehicle Alerting System Malfunction Visit your Dealer”**

There is a possibility that there is an abnormality in the Acoustic Vehicle Alerting System. Please contact your Toyota dealer.

Electric Vehicle system precautions

Be careful of the high voltage components (nominal voltage at 391.0 V), such as the traction battery, electricity supply unit, orange colored high voltage cables, and electric motor, as well as high temperature components such as the cooling radiator, which are provided on the battery electric vehicle. Read the following descriptions carefully before using the EV system, and handle the EV system correctly. Note that warning labels with a  mark are attached to the high voltage components to remind you of careful handling required.

System components



The illustration is an example for explanation and may differ from the actual item.

- A** High voltage cables (orange)
- B** ESU: Electricity Supply Unit (built in onboard traction battery charger/DC-DC converter)
- C** Service plug
- D** Charging inlet

- E** Traction battery
- F** eAxle (Traction motor/Inverter/Transaxle) (front/rear)
- G** Air conditioning compressor

n Electromagnetic waves

High-voltage parts and cables on the battery electric vehicles incorporate electro-magnetic shielding, and therefore emit approximately the same amount of electromagnetic waves as conventional gasoline-powered vehicles or home electronic appliances.

Your vehicle may cause sound interference in some third party-produced radio parts.

n Traction battery (Lithium-ion battery)

The traction battery has a limited service life.

The traction battery capacity (the ability to store energy) reduces with time and use in the same way as other rechargeable batteries. The extent at which capacity reduces changes drastically depending on the environment (outside temperature, etc.) and usage conditions, such as how the vehicle is driven and how the traction battery is charged.

This is a natural characteristic of lithium-ion batteries, and is not a malfunction. Also, even though the driving range decreases when the traction battery capacity reduces, vehicle performance does not significantly become worse. In order to reduce the possibility of the capacity reducing, follow the directions listed on P.93, "Capacity reduction of the traction battery".

n Starting the EV system in an extremely cold environment

When the traction battery is extremely cold (below approximately -22°F [-30°C]) due to the

temperature outside of the vehicle, it may not be possible to start the EV system. In this case, try to start the EV system again after the temperature of the traction battery increases due to the outside temperature increasing, etc.

! WARNING

n High-voltage precautions


The vehicle has high voltage DC and AC systems as well as a 12-volt system.

DC and AC high voltage systems are very dangerous and can cause severe burns and electric shock that may result in death or serious injury.

Never touch, disassemble, remove, or replace the high voltage parts, cables (orange) or their connectors.

Do not touch the high voltage components. They are extremely hot, especially after driving.

The service plug is located under the console box. The service plug is used only when the vehicle is being serviced and is subject to high voltage.



 WARNING**n Road accident cautions**

Observe the following precautions to reduce the risk of death or serious injury:

- i** Stop the vehicle in a safe place to prevent subsequent accidents. While depressing the brake pedal, apply the parking brake and shift the shift position to P to stop the EV system. Then, slowly release the brake pedal.
- i** Do not touch the high voltage parts, cables (orange) and connectors.
- i** If electric wires are exposed inside or outside your vehicle, an electric shock may occur. Never touch exposed electric wires.
- i** Do not touch the traction battery if liquid is leaking from or adhered to it. If electrolyte (Organic Carbonate-based electrolyte) from the traction battery comes into contact with the eyes or skin, it could cause blindness or skin wounds. In the unlikely event that it comes into contact with the eyes or skin, wash it off immediately with a large amount of water, and seek immediate medical attention.
- i** If electrolyte is leaking from the traction battery, do not approach the vehicle. Even in the unlikely event that the traction battery has been damaged, the internal construction of the battery will prevent a large amount of electrolyte from leaking out. However, if electrolyte leaks, vapors will be emitted. These vapors are an irritant to skin and eyes and could cause acute poisoning if inhaled.

- i** Do not bring burning or high-temperature items close to the electrolyte. The electrolyte may ignite and cause a fire.

- i** If a fire occurs in the battery electric vehicle, leave the vehicle as soon as possible. Never use a fire extinguisher that is not meant for electrical fires. Using even a small amount of water may be dangerous.

- i** If your vehicle needs to be towed, be sure to transport the vehicle with the four wheels raised. If the vehicle is towed with the wheels which are connected to the electric motor (traction motor) contacting the ground, electricity generated by the operation of the motor may cause a fire to occur depending on the nature of the damage or malfunction. (→P.563)

- i** Carefully inspect the ground under the vehicle. If leaked liquid (other than water from the air conditioning) is found on the ground, the traction battery may have been damaged. Leave the vehicle as soon as possible. In addition, contact your Toyota dealer with regard to the leakage found on the ground. Even in the event of a minor accident, the traction battery and surrounding parts may be damaged. In case of an accident, have the traction battery inspected at a Toyota dealer.

n Traction battery

- i** Your vehicle contains a sealed lithium-ion battery.

**WARNING**

- I Never resell, hand over or modify the traction battery. To prevent accidents, traction batteries that have been removed from a disposed vehicle are collected through your Toyota dealer. Do not dispose of the battery yourself. Unless the battery is properly collected, the following may occur, resulting in death or serious injury:
- Do not illegally dispose of or dump the traction battery, and it is hazardous to the environment or someone may touch a high voltage part, resulting in an electric shock.
- The traction battery is intended to be used exclusively with your battery electric vehicle. If the traction battery is used outside of your vehicle or modified in any way, accidents such as electric shock, heat generation, smoke generation, an explosion and electrolyte leakage may occur. When reselling or handing over your vehicle, the possibility of an accident is extremely high because the person receiving the vehicle may not be aware of the dangers from these modifications.
- I If your vehicle is disposed of without the traction battery having been removed, there is a danger of serious electric shock if high voltage parts, cables and their connectors are touched. In the event that your vehicle must be disposed of, the traction battery must be disposed of by your Toyota dealer or a qualified service shop. If the traction battery is not disposed of properly, it may cause electric shock that can result in death or serious injury.

I For information about traction battery collection locations, contact information, or the recycling process, contact your Toyota dealer.

n Caution while driving

I Pay special attention to the area around the vehicle. Because there is no engine noise, pedestrians, people riding bicycles or other people and vehicles in the area may not be aware of the vehicle starting off or approaching them, so take extra care while driving. Therefore, take extra care while driving even if the Acoustic Vehicle Alerting System is active.

I If the vehicle under floor area receives strong shock or impact while driving, stop the vehicle in a safe place and check around the bottom of the vehicle. If there is damage to the traction battery or liquid leakage, it may lead to a vehicle fire, etc. Do not touch the vehicle and immediately contact your Toyota dealer. Even if no damage can be seen under the floor, the traction battery may be damaged. If the vehicle received an impact under the floor, have the traction battery inspected at a Toyota dealer.

n Modifications


Do not make modifications that lower the height of the vehicle. The traction battery in the under floor area may come into contact with the ground when the height of vehicle is lowered. If the traction battery is damaged, a vehicle fire may occur, possibly resulting in death or serious injury.

Emergency shut off system

When a certain level of impact is detected by the impact sensors, the emergency shut off system turns off the EV system and blocks the high voltage current. If the emergency shut off system activates, your vehicle will not restart. To restart the EV system, contact your Toyota dealer.

Warning message

A message is automatically displayed when a malfunction occurs in the EV system or an improper operation is attempted.



If a warning message is shown on the multi-information display, read the message and follow the instructions. (→P.124, 578)

- n **If a warning light comes on, a warning message is displayed, or the 12-volt battery is disconnected**

The EV system may not start.

In that case, try to start the system again. If the “READY” indicator does not come on, contact your Toyota dealer.

- n **When the traction battery is completely discharged**

When the EV system cannot be started due to the traction battery being completely discharged, restart the system after AC charging or DC charging. When charging, it is recommended to charge the traction battery until the traction battery charge warning light turns off in order to ensure sufficient driving distance.

Battery Electric Vehicle driving tips

Unlike the conventional vehicles, the electricity consumption efficiency of battery electric vehicles will decline if they continue driving on highways (or freeways) or at high average speeds, causing the possible driving distance to reduce. Therefore, if the remaining charge of the traction battery is low, avoid relying on the displayed possible driving distance too much as well as driving on highways (or freeways). Driving the vehicle at moderate speeds, the traction battery's electricity consumption can be controlled.

The following driving tips will contribute to reduction in the battery consumption and increase in the driving range.

Shift position operation

Shift the shift position to D when stopped at a traffic light, or driving in heavy traffic, etc. Shift the shift position to P when parking. When shifting the shift position to N while driving, there is no positive effect on electricity consumption. In the N, the traction

battery cannot be charged. Also, when using the air conditioning system, etc., the traction battery electricity is consumed. (→P.239)

Delays

Repeated acceleration and deceleration due to traffic congestion, long waits at traffic lights, and driving on steep inclines will lead to poor electricity consumption. In order to avoid those situations as much as possible, check traffic reports before leaving. If the vehicle is driven in traffic congestion, gently release the brake pedal to allow the vehicle to move forward slightly, avoid overuse of the accelerator pedal. Doing so can help minimize unnecessary electricity consumption.

When braking

Make sure to operate the brakes gently and a timely manner. A greater amount of electrical energy can be regenerated when slowing down.

Highway (or freeways) driving

Control and maintain the vehicle at a constant speed. Before stopping at a toll booth or similar, allow plenty of time to

release the accelerator and gently apply the brakes. A greater amount of electrical energy can be regenerated when slowing down.

Air conditioning

- Use the air conditioning only when necessary. Doing so can help reduce excessive electricity consumption.

In summer: When the ambient temperature is high, use the recirculated air mode. Doing so will help to reduce the burden on the air conditioning system and reduce electricity consumption as well.

In winter: Excessive or unnecessary heating should be avoided. Also, electricity consumption can be improved by avoiding overuse of the heater.

- When the ALL AUTO (ECO) switch on the air conditioner operation switch is turned ON, the air conditioning system prioritizes the use of direct heating such as seat heaters to warm the surroundings of the occupants and reduce electricity consumption by the air conditioner.

Checking tire inflation pressure

Make sure to check the tire inflation pressure frequently. Improper tire inflation pressure

can cause poor electricity consumption.

Also, as snow tires can cause large amounts of friction, their use on dry roads will lead to poor electricity consumption. Use tires that are appropriate for the season.

Luggage

Carrying heavy luggage will lead to poor electricity consumption. Avoid carrying unnecessary luggage.

Driving range

The driving range displayed on the multi-information display, etc., shows the reference distance that driving is possible, and the actual distance that can be driven may differ from that displayed.

Displayed value

A value for which a sufficient level of driving performance can be provided is estimated based on the remaining charge of the traction battery, the state of the traction battery, the outside temperature, etc., and is displayed on the multi-information display. (→P.139)

When the outside temperature is low, the traction battery output may be decreased, causing the possible driving distance to be shorter. However, this is not a malfunction. Charge the traction battery earlier than usual.

Tips for extending the driving range

Possible driving distance varies significantly depending on how the vehicle is driven, road conditions, the weather, the outside temperature, usage conditions of electrical components and the

number of occupants.

Possible driving distance could be extended if the followings are performed:

- Maintain a safe distance from the vehicle in front and avoid unnecessary acceleration and deceleration
- Accelerate and decelerate the vehicle as smoothly as possible
- Drive at moderate speeds as much as possible and maintain a constant speed
- Set the air conditioning system to a moderate temperature and avoid using the heating and cooling functions excessively.
- Use tires of the specified size and maintain the specified tire pressure
- Do not add unnecessary weight to the vehicle

Display when charging is completed

The followings indicate that charging has been carried out properly.

- The charging indicator turns off
- “Charging Complete” is displayed on the multi-information display when a door is opened while the power

switch is off. (→P.91)


Regardless of the type of power source or whether the charging schedule function is used, charging is completed if the above can be confirmed.

Charging-related messages:

→P.124

Charging equipment

Charging equipment and names



- A** Charging inlet
- B** Charging indicator (→P.84) and Charging inlet light
- C** Charging port lid (→P.83)
- D** Charging port
- E** AC charging cable *

*: It is an example for explanation and may differ from the actual item. The AC charging cable can be purchased at your Toyota dealer.


For proper handling and precautions for the AC charging cable, refer to the owner's manual that comes with it.

Opening/closing the charging port lid

Fully open the charging port lid by hand.


n Open

Slightly open the charging port lid by pressing the rear edge of it. (the position shown in the illustration)




n Close

Move the charging port lid to the slightly open position and then press the rear edge (the position shown in the illustration) to close it.



Charging indicator

The illumination/flashing pattern changes to inform the user of the charging status in the following ways.



Illumination/flashing pattern	Vehicle condition
Illuminated	<ul style="list-style-type: none">• Charging is in progress^{*1}• Traction battery heater (→P.88) is operating
Flashes normally ^{*2}	When charging schedule is registered (→P.105) and AC charging cable is connected to vehicle
Flashes rapidly ^{*2}	When charging cannot be carried out due to malfunction in a power source or the vehicle, etc. (→P.119)

^{*1}: The indicator is dimmed when the charging is done.

^{*2}: Flashes for a certain period of time, and then turns off.


Locking and unlocking the AC charging connector

Helps to prevent the AC charging connector from being disconnected while charging or tampering such as someone other than the user taking away the charging cable.

Locking and unlocking the AC charging connector

n Locking the charging connector


The charging connector will be automatically locked when inserting it into the AC charging inlet.



n Unlocking the charging connector

The AC charging connector will be unlocked when the release button is pressed while carrying the electronic key on your person or when the doors are unlocked.

While charging is stopped, the AC charging connector will be unlocked when the doors are unlocked using the smart key system or wireless remote control.



n AC charging connector lock function

If the AC charging connector is locked/unlocked repeatedly, it may not work temporarily due to protect the system by AC charging system. In this case, wait for a while before connecting the AC charging connector to AC charging inlet again.

- l The connector lock pin may move when the vehicle is driven or when the AC charging connector is removed, however, this is not a malfunction.
- l The AC charging connector lock function does not guarantee that theft of the AC charging cable will be prevented, and is not necessarily effective for all mischiefs.

n Security function for unlocking


After the doors are unlocked, if the doors are locked again or approximately 180 seconds elapse before removing the AC charging connector, the AC charging connector will be locked again.

n When the AC charging connector cannot be inserted into the AC charging inlet

Check that the connector lock pin is

not lowered.

If the connector lock pin is lowered, the connector lock is operating. Unlock the doors using the smart key system or wireless remote control and unlock the AC charging connector lock and check that the connector lock pin is not extended.



n If the AC charging connector cannot be unlocked

I If the AC charging connector cannot be unlocked even though you have the electronic key with you, unlock the doors to unlock the connector.

I If the AC charging connector cannot be unlocked by normal operations, or if the release button has a malfunction and the AC charging connector cannot be unlocked, the AC charging connector can be unlocked using one of the followings.

- Perform the unlock operations of the doors 3 times using the wireless remote control or door lock switches.
- Stop charging on the meter display (→P.99).

If the AC charging connector cannot be unlocked even after performing the above, the AC charging connector can be unlocked by operating the emergency release wire.


Do not unlock the AC charging connector this way unless it is an emergency.

If the problem is not solved, have the vehicle inspected by your Toyota dealer immediately.


1 Open the hood. (→P.521)

2 Pull the emergency release wire.

The AC charging connector is unlocked and can be removed.



- 3** After unlocking the AC charging connector, fix the handle of the emergency release wire to the attachment.



⚠ NOTICE

n When locking the AC charging connector

Observe the following precautions. Failure to do so may cause a malfunction in the charging connector locking system.

- I Check that the AC charging connector is compatible with this vehicle.
An AC charging connector of the different type or a charging connector with damaged or deformed insertion part may not be locked.

**NOTICE**

I Do not apply excessive force to the AC charging connector after the charging connector is inserted.
When removing the AC charging connector, make sure to unlock the AC charging connector.

Charging methods

The following methods can be used to charge the traction battery.

Types of charging methods**n AC charging (→P.94)**

This is a charging method used when charging from an AC outlet with the AC charging cable or charging that use an AC charger.

By setting charging schedule, it is also possible to charge at the desired date and time. (→P.105)

n DC charging (→P.100)

This is a charging method that uses a DC charger that complies with SAE J 3400. The traction battery can be charged in a shorter time than AC charging.

SAE is an abbreviation for an industrial standard issued by the Society of Automotive Engineers.

This is a charging method that uses a DC charger that complies with NACS. The traction battery can be charged in a shorter time than AC charging.

Charging-linked functions

This vehicle is equipped with several functions that are linked

with charging.

n **My Room Mode (→P.115)**

When the charging cable is connected to the vehicle, electrical components such as the air conditioning system and audio system can be used by the power supply from an external power source*.

*: Depending on the situation, electricity of the traction battery may be consumed.

n **Traction battery heater**

When the outside temperature is low and the charging cable is connected to the vehicle, this function automatically warms the traction battery until it reaches a certain temperature.

- The operation of this function is stopped automatically when the charging cable is disconnected or if the charging cable is left connected to the vehicle for approximately 3 days.
- When the charging schedule is set (→P.105), this function operates according to the charging start time.

n **Traction battery warming control**

This control operates after the charging cable remains connected to the vehicle for approximately 3 days and the traction battery heater automatically stops. It automatically insulates

the traction battery in extremely low temperatures.

- This control stops 31 days after the charging cable is connected, even if it is still connected to the vehicle.
- When this control operates, charging schedule settings are ignored and charging starts.

n **Traction battery cooler**

When the traction battery is hot and the AC charging cable is connected to the vehicle, this function cools the traction battery to protect it.

The function may operate when continuously driving at high speeds such as driving on highways or freeways, or during DC charging.

n **Using My Room Mode during DC charging**

→P.116

n **Traction battery heater**

- | Traction battery heater may operate when charging is not being performed.
- | When traction battery heater is operating, the charging indicator illuminates.
- | When traction battery heater is operating during charging, the charging may take longer than normal.
- | The remaining charge of the traction battery declines when the traction battery heater operates, it might be necessary to recharge the traction battery again in order to supplement the remaining

charge.

n **Traction battery cooler**

- | For AC charging: Traction battery cooler settings can be changed on the multimedia. (→P.89)
- | The charging indicator is illuminated while traction battery cooler is on standby or operating.
- | When the charge level of the traction battery is low, the traction battery cooler may not operate, even if the temperature of the traction battery is high.
- | When the following conditions are met while the traction battery cooler is operating, the cooling operation will stop.
 - The hood is opened.
 - The power switch is turned to ACC or ON.
 - The shift position is changed to any position other than P.
 - The remaining charge of the traction battery drops below a certain amount.
- | The traction battery cooler operates using power supplied by the traction battery and an external power source.
 - While the traction battery cooler is operating, the charge of the traction battery will increase and decrease within a certain range, and will not increase as during charging.
 - When the traction battery cooler operates, charger will recognize it as the battery being charged. If this function operates while a charger which charges a charging fee is connected to the vehicle, charging fees will apply.

n **Changing of the traction battery cooler setting**

Setting can be changed on the multimedia.

Use the multimedia and select , "Vehicle customize", "Charging", "Battery cooling", and change the setting. When selecting to off, the

traction battery output may be restricted depending on the driving situation.

Charging tips


This section explains methods for using the charging function for this vehicle and checking information related to charging.

Systematically charging

To enable the use of battery electric vehicle, we recommend systematically charging the vehicle.


n Before leaving home

In order to use the Electric Vehicle, charge the traction battery at home before leaving.



n On the way to the destination or at the destination

When the remaining charge of the traction battery gets low, recharge the battery at the nearest charging station.



n After returning home

In order to drive the next time, charge the traction battery.

Setting the charging schedule allows you to charge the traction battery at the desired time such as late at night or early in the morning. Furthermore, the charging schedule can be set to automatically charge the traction battery every day or at the same time on certain days. (→P.105)

Checking information related to charging

Information related to charging is displayed and can be checked on the multi-information display.


n While charging

When any door is opened during charging with the power switch off, the current charging condition and approximate time remaining until charging is complete are displayed for a certain period of time.

The actual charging time and the charging power may differ depending on conditions such

as the remaining capacity of the traction battery, outside temperature, and specifications of the charger.

The time until charging completed may not be displayed if the charging current to the traction battery becomes smaller and the charging time becomes longer.



n After charging is complete

When any door is opened with the power switch off after charging is complete, a message detailing the results of the charging is displayed for a while.

Also, a message is displayed if an operation that stops charging is performed or a situation where charging cannot be performed occurs.

When a message is displayed, follow the instructions displayed on the screen. (→P.124)

Things to know before charging

Make sure to read the following precautions before charging the traction battery.

n Safety functions

- l The EV system will not start while the charging cable is attached to the vehicle, even if the power switch is operated.
- l If the charging cable is connected while the "READY" indicator is illuminated, the EV system will stop automatically and driving will not be possible.

! WARNING

n Cautions when charging

People with implantable cardiac pacemakers or cardiac resynchronization therapy-pacemakers should not carry out the charging procedure. Ask someone else to do it.

- l Do not approach the charger, charging cable and the vehicle during charging.
Charging procedure may affect the operation of pacemakers.
- l Do not remain in the vehicle during charging.
Charging procedure may affect the operation of pacemakers.
- l Do not enter the vehicle (including the luggage compartment) to retrieve something from it, or for any purpose.
Charging procedure may affect the operation of pacemakers.

**WARNING****n When the charging cable is connected to the vehicle**

Do not change the shift position from P.

In the unlikely event that the charging cable has been damaged, the shift position may change from P to another position and the vehicle could move, possibly leading to an accident.

n Charging precautions

This vehicle has been designed to allow charging from an external power source using an AC charging cable for exclusive use with standard household AC outlets. However, the vehicle differs greatly from standard household electrical goods in the following ways, and incorrect usage could cause fire or electric shock, possibly leading to death or serious injury.

- ! When charging, a large amount of current will flow for a long time.
- ! Depending on the charging environment, perform charging outdoors.

**NOTICE****n Charging precautions**

To charge properly, follow the procedure after reading the explanation below. Charging is intended to be carried out by licensed drivers only who properly understand the charging procedure.

- ! Do not allow people who is not used to charging, such as children, to perform charging without supervision.
- ! When charging with a charger, follow the procedures for using each charger.

Confirm the following before charging

Before charging, always check the following items.

- The parking brake is applied. (→P.245)
- The power switch is turned to off. (→P.234)
- Lights such as the headlights, emergency flashers and interior lights, etc., are turned off.

If these light switches are turned on, then these features will consume electricity, and charging time will increase.

n During charging

- ! The charging starting time may differ depending on the state of the vehicle, but this does not indicate a malfunction.
- ! During charging, sounds may be heard from near the traction battery in accordance with the operation of the air conditioning system or traction battery cooler (→P.89).
- ! Depending on radio wave conditions, interference may be heard on the radio.

n When charging using a public charging facility, check the setting of the charging schedule function.

- ! When the charging schedule is registered, temporarily turn off the function or turn "Charge Now" on. (→P.105)
- ! When the charging schedule is set to on, charging will not start even if the AC charging cable is connected. Also, charging fee may occur due to connection of the AC charging cable.

n **Capacity reduction of the traction battery**

The capacity of the traction battery will decline gradually when the traction battery is in use. The rate at which it declines will differ in accordance with environmental conditions and the way in which the vehicle is used. Observing the following can help suppress the decline in the traction battery capacity.

- | Avoid parking the vehicle in high temperature areas, under direct sunlight when the traction battery is fully charged.
- | Avoid accelerating and decelerating frequently and suddenly.
- | Avoid frequent driving at high speed.
- | Use the charging schedule function as much as possible in order to fully charged the traction battery before starting off. (→P.105)
- | Avoid frequent DC charging

Also, if the capacity of the traction battery capacity reduces, the distance that can be driven decreases. However, vehicle performance does not significantly become worse.

n **When the remaining charge of the traction battery is low after charging**

In the following situations, the remaining charge of the traction battery after charging completes may be less than normal in order to protect the traction battery (the driving range after the battery is fully charged may be shorter).*

- | Charging is performed when the outside temperature is low or high
- | Charging is performed immediately after high-load driving or in extreme heat

In any other situation, if the remaining charge of the traction battery is significantly lower than normal after

charging completes, have the vehicle inspected by your Toyota dealer.

*: When this occurs, even if the remaining charge display of the traction battery shows that it is fully charged, the remaining charge rapidly decreases faster than normal.

n **When the charging amount sent to the traction battery decreases**

When the charging power to the traction battery becomes low due to the use of the air conditioner or the operation of the traction battery heater, the charging amount to the traction battery or the remaining charge of the traction battery may decrease.

n **Certification**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

n **Charging time may increase**

In the following situations, charging time may become longer than normal:

- | In very hot or very cold temperatures.
- | When the traction battery becomes hot, such as immediately after high-load driving.
- | The vehicle is consuming a lot of electricity, for example, when the headlights are on, etc.
- | When using My Room Mode. (→P.115)
- | When opening the hood while charging
- | There is a power outage during charging.

- | When adjusting the power supply with the charger.
- | There is a drop in the voltage of external power source.
- | The charge in the 12-volt battery is low, for example due to the vehicle being left unused for a long period of time.
- | When the upper limit of charging current is changed in the charging current setting of the vehicle (→P.96)
- | When the traction battery heater operates. (→P.89)
- | When the traction battery cooler is operated before charging. (→P.89)
- | When the plug generates heat due to a loose socket connection, etc.
- | When frequently and repeatedly using DC charging.
- | When selecting “DC Charging power” setting other than “Max”.
- | When the temperature of charging-related parts is high.

n AC charging electricity

This vehicle can be charged up to approximately 11kW.

However, depending on the used AC charger or AC charging cable, charging electricity may be limited.

How to use AC charging

This section explains the procedure for charging the traction battery with AC charging cable.

When using an AC charger, make sure to check the operation instructions on the AC charger.

When the charging schedule is registered, make sure “Charge Now” is turned on before charging. (→P.110)



NOTICE

n When using the AC charging related parts

To prevent damage to the AC charging related parts, observe the following precautions.

- | When removing the AC charging cable, check that the AC charging connector is unlocked.
- | Do not apply a vibration to the AC charging connector while charging. Charging may be stopped.
- | Do not insert anything but the AC charging connector into the AC charging inlet.
- | Do not disassemble, repair or modify the AC charging inlet. When the AC charging inlet needs to be repaired, consult your Toyota dealer.

Charging precautions

→P.92

When charging


- 1 Prepare the AC charging cable.
- 2 Insert the plug of the AC charging cable into the outlet of the external power source.

Make sure to hold the body of the plug and insert it firmly into the socket.

When the remote switch is equipped, turn it on.

- 3 Open the charging port lid. (→P.83)

The charging inlet light **A** will illuminate.




- 4 Insert the AC charging connector into the AC charging inlet.

Align the guide position on the bottom of the AC charging connector, and push the AC charging connector straight into the AC charging inlet as far as possible.

When the AC charging connector is inserted straight as far as possible,

it will automatically lock. (→P.85)




- 5 Confirm that the charging indicator of the charging port is illuminated.

Charging will not start if the charging indicator does not illuminate when the AC charging connector is inserted. (→P.84)

If the charging indicator is flashing, the charging schedule is registered. (→P.105)


The charging indicator will turn off when charging is completed.

The charging indicator will also turn off when charging is stopped for some reason before completion. In this case, refer to P.118.



n When connecting the AC charging connector

If the door is opened or the power switch is turned to ON with the AC charging connector connected, the charging cable indicator turns on to notify that the AC charging connector is connected.



n If the charging indicator of the charging port flashes after connecting the AC charging cable

The charging schedule (→P.105) is registered and charging cannot be performed. To cancel charging using the charging schedule and start charging, perform any of the following procedures.

- l Turn “Charge Now” on (→P.107, 110)
- l While the charging indicator is flashing, remove and reconnect the AC charging connector immediately. The setting of charging current and charging limit will be temporarily initialized (→P.97).

n When the AC charging connector cannot be inserted into the charging inlet

→P.85

n Safety function

If the release button is pressed, charging will not begin even if the AC charging cable is connected.

Also, charging will be stopped if the AC charging connector is unlocked during charging. When restarting charging, do one of the followings, and check that the charging indicator of the charging port illuminates.

- l Remove and reinsert the AC charging connector
- l Lock the doors

n Charging time may increase

→P.93

n To charge using the AC charging connector that complies with SAE J 1772

Use a conversion adapter provided by Toyota. When using, follow the instructions in the manual provided with the conversion adapter and perform the operation safely. If a conversion adapter is connected between the charging inlet and AC charging connector, the AC charging connector cannot be locked.

n When your circuit breaker trips during charging

The upper limit of the charging current can be changed on the multi-media.

- 1 Select .
- 2 Select “Vehicle customize”.
- 3 Select “Charging”.
- 4 Select “Charging current”.
- 5 Select “32A”, “24A”, “16A” or “8A”.^{*1}

During charging, the maximum charging current will be restricted to the set current or lower.^{*2}

If the breaker still trips while charging, even after changing the upper limit of the charging current, check if the connected power source meets the specified charging conditions. (→P.86)

Although the charging current setting can be changed even while charging, it may take some time for the change to become effective.

If changing the charging current setting while charging, it may cause house lights to flicker or trip a circuit breaker.

^{*1}: Even if the charging current setting is changed on the customize menu, charging is performed at 12 A or less when charging at 120 V.

^{*2}: Restricting the charging current

will lengthen the charging time.

n Changing the “Charging limit” settings

The upper limit of the charge capacity can be changed on the multimedia.

The selected upper limit value is common to AC charging and DC charging.

- 1 Select .
- 2 Select “Vehicle customize”.
- 3 Select “Charging”.
- 4 Select “Charging limit”.
- 5 Select “Full”, “90%”, “80%”, “70%”, “60%” or “50%”.

If the setting is changed during DC charging, charging may stop due to the operation of the DC charger timer and the traction battery cannot be fully charged.

n To initialize the setting of charging current and charging limit temporarily

Remove the AC charging connector within 15 seconds after connecting it, and then reconnect it immediately. The setting of charging current and charging limit will be temporarily initialized.

Also, if the procedure above is performed while the charging indicator is flashing normally and the charging schedule is registered, “Charge Now” is turned on. (→P.96)

⚠ WARNING

n When charging

Observe the following precautions.

Failure to do so may cause an unexpected accident, resulting in death or serious injury.

I Before charging, check that the AC charging inlet is not deformed, damaged or corroded, and check that the inlet is free of foreign matter such as dirt, snow and ice. If there is dirt or dust in these areas, remove completely before inserting the AC charging connector.

I Do not touch the terminals of the AC charging connector and AC charging inlet with a sharp metal objects (needles, etc.) or hands, or short them with foreign objects.

I In order to stop charging at the charging station, follow the instructions of the AC charger.

I If any heat, smoke, odors, noise or other abnormalities are noticed during charging, stop charging immediately.

I Do not charge the vehicle during a lightning storm.

I Prevent the AC charging cable from being caught in the door or back door.

I Make sure to connect the AC charging cable to a socket within reach and do not use an extension cord.

**WARNING**

I Close the hood before using the charging system.

The cooling fan may start operating suddenly. Touching or getting close to rotating parts such as the fan may cause your hands or clothes (especially a necktie or scarf) to become caught and result in a serious injury.

n Onboard traction battery charger

The onboard traction battery charger is located in the motor compartment. Make sure to observe the following precautions regarding the onboard traction battery charger. Failure to observe these precautions may result in death or serious injury such as burns and electric shocks.

I The onboard traction battery charger is hot during charging. Do not touch the onboard traction battery charger, as doing so may result in burns.

I Do not disassemble, repair or modify the onboard traction battery charger. When the onboard traction battery charger needs to be repaired, consult your Toyota dealer.

**NOTICE**

n When charging

Do not insert the plug into the AC charging inlet.

The AC charging inlet may be damaged.

n Using private power generator

Do not use private power generators as a power source for charging.

Doing so may make charging unstable, the voltage may be insufficient, and the charging operation may stop.

Noise may be heard from around the motor room, even if charging can be continued.

n Charging station

Due to the environment in which the power equipment is located, charging may be unstable due to noise, the voltage may be insufficient, and the charging operation may stop.

After charging

- 1 Stop charging on the meter display, or unlock the AC charging connector by pressing the release button (→P.85).


If the AC charging connector is removed and then immediately reconnected, charging will no longer be able to be stopped on the meter display. In this case, if the AC charging connector is removed, charging can be stopped on the meter display next time.

If the release button is pressed during charging (while the charging indicator is illuminated), charging will be interrupted.


- 2 Make sure to hold the body of the AC charging connector and pull it towards you.

If the charging stop switch is pressed during charging (while the charging indicator is illuminated),

charging will be interrupted.



3 Close the charging port lid.



n When the outside temperature is low or high

The level shown on the SOC (State of Charge) gauge (→P.139) may drop slightly when the power switch is turned to ON, even if charging has been completed and the traction battery is fully charged. However, this does not indicate a malfunction.

n When stopping charging on the meter display

1 While the charging status is displayed on the multi-information display, press "OK" of the meter control switches.

2 Select "Yes".


Charging will stop.

n When removing the AC charging connector

Press the release button to unlock the AC charging connector, and after making sure it is unlocked, pull the AC charging connector towards

you.

If the lever does not down even if the release button is pressed, the AC charging connector is locked. In this case, unlock the door using the smart key system or wireless remote control, and unlock the AC charging connector. (→P.85)



n If the AC charging connector cannot be unlocked

→P.86



NOTICE

n After charging

After removing the AC charging connector from the AC charging inlet, make sure to close the charging port lid.

If the charging port lid is left open, water or foreign objects may enter the AC charging inlet, which could lead to vehicle damage.

How to use DC charging

This section explains the DC charging procedure for the traction battery.

When using a DC charger, make sure to check the operation instructions of the DC charger.

Using “Battery preconditioning” adjusts the traction battery temperature to the optimum state during DC charging. By keeping the traction battery at the optimum temperature, charging time can be shortened. (→P.112)



WARNING

n When using a DC charger

Observe the following precautions.

Failure to do so may cause an unexpected accident, resulting in death or serious injury.

1 Use a DC charger that complies with SAE J 3400.

2 By using a conversion adapter, A DC charger that complies with SAE J 1772 can be used. Use only a conversion adapter provided by Toyota. When using a DC charger, follow the instructions in the manual provided with the DC charger and perform the operation safely.


3 Do not use the charging cable longer than 30 meters.

Confirm the following before charging


→P.92

When charging

- 1 Open the charging port lid. (→P.83)



- 2 The charging inlet light **A** will illuminate.




- 3 Insert DC charging connector into the charging inlet.

Insert the DC charging connector and it will lock automatically.

The DC charging connector shape and treatment will differ depending on the type of DC charger.

Perform the operations in accordance to handling procedures of

the DC charger.



4 Operate the DC charger and start the charging.


Follow the handling procedures of the DC charger to start charging.

Charging starts after a system check is done.

Stop the charging in accordance to the handling procedures of the DC charger when it is desired to interrupt the DC charging.

n When connecting the DC charging connector

If the door is opened or the power switch is turned to ON with the DC charging connector connected, the charging cable indicator turns on to notify that the DC charging connector is connected.



n Charging time may increase

→P.93

n When the DC charging connector cannot be inserted into the charging inlet

→P.85

n If a message indicating vehicle error on the DC charger side is displayed

Even if a message indicating vehicle error on the DC charger side (ex. vehicle error found, vehicle error occurred, etc.) is displayed, there is no vehicle fault but possibly a communication error between the DC charger and vehicle. In this case, there may be a terminal damage (bad contact) in the DC charging connector.

If there is no error with the vehicle, contact the facility manager of the DC charger.

n During DC charging

- | The current charging condition can be checked on the multi-information display.
- | The actual charging time may differ from that displayed on the DC charger during charging.
- | There may be occasions the radio cannot be heard due to noise occurrence during DC charging.
- | As the battery approaches full charge, the charging speed will decrease and it will take longer to complete charging.
- | Depending on the specifications of the charger, charging will stop before fully charging.
- | The time to complete charging may change, or charging may stop before reaching the upper limit of the charge capacity, due to the remaining charge of the traction battery, the outside temperature, the specifications of the charger, etc.
- | When DC charging using an adapter, protection functions may activate depending on the outside temperature or the usage, resulting in longer charging times, DC charging suspensions, or charging not starting.
- | It is recommended to avoid fre-

quent DC charging to prevent a decline in the traction battery capacity.

- I Quickly move from the DC charging space for other users after the DC charging is completed.
- I If DC charging is performed while the traction battery is extremely cold, such as in cold weather, steam may come out of the motor compartment or dew may be formed on the hood. This is because the heat, generated while the traction battery is warmed, causes snow, ice, or frost to evaporate. This is not a malfunction.
- I The charge amount is corrected when the traction battery is fully charged, so 100% remaining the traction battery may not be displayed.

n **How to set the DC charging power**

You can change the DC charging power limit on the multimedia.

- 1 Select .
- 2 Select "Vehicle customize".
- 3 Select "Charging".
- 4 Select "DC charging power".
- 5 Select from "Max", "125kW", "100kW", "75kW", "50kW".

The maximum power when charging is limited to the selected power or less. If "Max" is selected, the vehicle will be charged with the maximum power that can be charged.

n **Changing the "Charging limit" settings**

→P.97

n **If the DC charging power limit and "Charging limit" settings cannot be changed**

Remove the DC charging connector and immediately reinsert it while the charging indicator is flashing in green. The settings will be changed

to the default settings.

The settings will be return to the customized setting next time the charging is performed.

If the DC charging connector is locked immediately after inserting it, press  switch of the wireless remote control or the door unlock switch on the driver's side 3 times at intervals of about one second to stop DC charging, and then remove the DC charging connector.

WARNING

n **Warnings for DC charging**

Be sure to observe the following when using DC charging.

Failure to do so may cause an accident that could lead to death or serious injury.

- I Check that the DC charger and charging inlet are not damaged. If there is any damage to the charging inlet, do not perform a DC charge and have it inspected immediately at your Toyota dealer.
- I Do not touch the terminals of the DC charging connector or inlet with metallic sharp tips (wires and needles), or allow a short circuit to occur with foreign objects.
- I Do not insert anything other than the DC charging connector into the charging inlet.
- I Check that the DC charging cable is not coiled up or pinned underneath heavy objects.
- I Do not connect conversion adapters, extension cords, etc., between the DC charging connector and charging inlet.

⚠ WARNING

- I When DC charging is interrupted, follow the handling procedures of the DC charger. Immediately stop the DC charging when there is an outbreak of heat, smoke, strange noises or smells, etc., during charging.
- I Check that the DC charging connector and charging inlet do not have foreign objects or snow or ice attached to it. If anything is attached to the inlet, be sure to completely remove the material before connecting the DC charging connector.
- I Do not charge the vehicle when there is a possibility of lightning. If you notice lightning while charging the vehicle, do not touch the vehicle and the DC charging cable.
- I Do not get the charging inlet terminals wet.
- I Close the hood when using DC charging.
The cooling fan may suddenly start to run. Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fan. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.
- n **When connecting the DC charging connector**
- I Follow the handling procedures of the DC charger to connect the DC charging connector. If the connector is not connected properly, the system cannot recognize the connection, and it may be possible to start the EV system.

- I Do not remove the DC charging connector from the charging inlet during DC charging. After operating the DC charger to stop charging, remove the DC charging connector from the charging inlet.

⚠ NOTICE

n When using DC charging

Make sure to follow the handling procedures of the DC charger. If the procedures are not followed properly, the vehicle and the DC charger may be damaged.

After charging

- 1 Operate the DC charger and stop the charging.


The DC charging connector will be unlocked when charging is completed, while carrying the electronic key on your person or when the doors are unlocked.

- 2 Remove the DC charging connector.


The DC charging connector shape and treatment will differ depending on the type of DC charger.

Perform the operations in accordance to handling procedures of the DC charger.

Return the removed DC charging connector to its original position.



3 Close the charging port lid.



n If the EV system was not started after DC charging and the EV system has been started by pressing the power switch

If the system check after DC charging does not finish properly, the EV system may not start even if the power switch is pressed with the brake pedal depressed.


If the EV system is started when the power switch is pressed again, this is not a malfunction.

n When DC charging cannot be stopped

If DC charging from the DC charger cannot be stopped due to a malfunction, etc., press the door unlock button, either on the wireless remote control or on the driver's door, three times at about 1 second intervals. Then the DC charging will be stopped.

n When stopping charging using the charging stop button

- 1 Press "OK" of the meter control switches while the charging status is displayed on the multi-information display.



2 Select "YES" and press "OK" to stop charging.

If the DC charging connector is removed and immediately reinserted while the charging indicator is flashing in green, charging cannot be stopped using "Stop charging". To stop charging, remove the DC charging connector.

n If the DC charging connector cannot be unlocked

→P.86

n After DC charging

Even if the traction battery is charged to the upper limit value that is set, the level of charge displayed on the DC charger may be lower than the actual one.

⚠ WARNING

n Cautions after DC charging

After charging is completed, make sure to remove the DC charging connector from the charging inlet before starting the EV system.

If the vehicle is started off with the connector still connected, it could lead to an accident, possibly resulting in death or serious injury.

⚠ NOTICE

n Precautions after DC charging

Be sure to close the charging port lid after removing the DC charging connector from the charging inlet.

Using the charging schedule function

AC charging can be carried out at the desired time by registering the charging schedule.

n Schedule function

Charging schedule is performed according to the day and time shown on the multimedia. For details, refer to the "MULTIMEDIA OWNER'S MANUAL".

Setting of the charging schedule function

When registering the charging schedule, the following settings can be changed.

n Select the charging mode

One of the two following charging modes can be selected.

► "Start"

Starts charging at the set time and finishes charging when fully charged.

► "Start and stop"

AC charging is performed according to the set start time and stop time.

n Repeated setting

The periodic charging schedule can be set by selecting your desired day of the week. Select one or more day of the week to

do the charging schedule.

n Turning "Charge now" on and off

To start charging without changing the charging schedule setting, turn "Charge now" on to temporarily cancel the charging schedule and enable charging after connecting the AC charging connector.*

*: If the AC charging connector is removed while the charging schedule is registered and "Charge now" is on, "Charge now" turns off.

n "Next charging event"

Of the registered charging schedules, the closest charging schedule after the current time is called the "Next charging event".


For charging schedule, AC charging will be performed according to the Next Event.

Registering the charging schedule

The Charging Schedule can be registered on the multimedia.

Only "Charge Now" can be set on the multi-information display.

- Multi-information display operation: →P.107
- Multimedia operation: →P.108



n **Charging schedule function**

- | The charging schedule cannot be set while driving.
- | A maximum of 15 charging schedules can be registered.

If the charging mode is set to “Start-stop” and the start time and end time are set to the same time, charging will be performed for 24 hours from the start time.

The charging schedule function can not be used when using DC charging.

n **To make sure that the charging schedule function operates correctly**

Check the following items.

- | The multimedia screen displays the correct time and day of week

For details, refer to the “MULTIMEDIA OWNER’S MANUAL”.

- | Check that the power switch is turned off
- | After registering the charging schedule, connect the AC charging connector

The charging start time is determined based on the charging schedule at the time that the AC charging connector was connected.

- | Connect the AC charging connector before the start time

When the charging mode is set to “Start”, if you connect the AC charging connector after the set

start time, the next charging schedule will be referenced.

When the charging mode is “Start and stop”, if you connect the AC charging connector after the start time, charging will start immediately and charging will be performed until the stop time.

- | After connecting the AC charging connector, check that the charging indicator of the charging port flashes (→P.84)
- | Do not use an socket that has a power cut off function (including a charging schedule function)

Use an socket that constantly supplies electricity. For sockets where the power is cut off due to a charging schedule function, etc., charging may not be carried out according to plan if the power is cut off during the set time.

n **When the AC charging connector remains connected to the vehicle**

- | When the charging mode is set to “Start”, even if multiple consecutive charging schedules are registered, the next charge will not be carried out according to the charging schedule until the AC charging connector is removed and reconnected after charging completes. Also, when the traction battery is fully charged, charging according to the charging schedule will not be carried out.
- | If the charging stop time is reached before the traction battery is fully charged and the charging mode is set to “Start and stop”, the nearest charging schedule after the stop time is updated as the next charging schedule, and charging is repeated until the battery is fully charged.

n Smartphone-linked operation

After applying to Toyota App, it is possible to use the smartphone application to change charging schedule settings.

For details about Toyota Apps, refer to <http://www.toyota.com/connected-services> in the United States and <http://www.toyota.ca/connected> in Canada.

n When charging schedules are ignored

When the following operations are performed while the charging schedule is on standby, charging schedule is temporarily canceled and charging is started.


- l When turning My Room Mode on (→P.115)
- l When turning "Charge now" on (→P.107, 110)
- l When an operation that temporarily cancel charging using the charging schedule (→P.96)

n Traction battery heater (→P.88)/Traction battery cooler (→P.88)

Depending on the temperature of the traction battery, the traction battery heater or traction battery cooler may be activated and the charging indicator may light up while the charging schedule is waiting for charging.

Setting operations on multi-information display

When operating charging schedule, use the meter control switches.



A Meter control switches
(→P.144)

B Multi-information display

n Setting "Charge Now" to on

1 Turn the power switch off.

The "Closing Display" screen will be displayed on the multi-information display.
(If the door is opened while waiting for charging schedule, the same screen will be displayed.)

2 Press OK to set "Charge Now" to on.

Each time "OK" is pressed, "Charge Now" switches between on and off.

After setting operations are complete, charging starts when the AC charging connector is connected.
(→P.94)*

*: If the AC charging connector is removed while the charging schedule is registered and "Charge Now" is on, "Charge Now" turns off.

If "Charge Now" cannot be set to on even when performing the operations above, remove the AC charging connector while the charging indicator is flashing at the normal speed and then immediately reconnect it.

If this operation is performed, the setting of charging current and charging limit will be temporarily initialized. (→P.97)

Setting operations on multimedia

For details on how to operate the multimedia screen, refer to “MULTIMEDIA OWNER’S MANUAL”.

Setting operations related to the charging schedule are performed on the “Charging schedule” screen.


n Displaying the “Charging schedule” screen

- 1 Turn the power switch to ON.


It is not possible to control the Charging Schedule settings in Accessory Mode.

- 2 Select  and “Charging schedule”, in that order.

The “Charging schedule” screen will be displayed.



n How to read the “Charging schedule” screen



A Charging schedules

Displays the week-long registered charging schedule in a list using icons.

B “Add” button

Press to add a new item to the charging schedule. (→P.109)

C “Edit” button

Press to change or delete registered items on the charging schedule.

(→P.110)

D “Charge now” button

Each time the button is pressed, “Charge now” switches between on and off. (→P.110)

E Return button

Press to close the “Charging schedule” screen.

n Registering the charging schedule


1 Display the “Charging schedule” screen. (→P.108)

2 Press “Add”.

The “Add event” screen will be displayed on the screen.

3 Select the charging mode.

Select the button in the row of the “Start at set time” or “Start and stop at set times”.



4 Operate “Start at set time” screen and select desired time, and then select OK .

When the charging mode is “Start at set time”, set the charging start time.

When the charging mode is “Start and stop at set times”, also set the charging stop time.

5 When activating the repeated settings, select the desired day, and then select OK .

Each time the day is selected, the

repeated setting for the selected day switches between on and off.

When turned on, the check box is highlighted and the charging schedule is repeated on that day. It is possible to turn more than one day on.

6 After setting operations are complete. Select “Save”.

The charging schedule is added to the list and an icon is added to the “Charging schedule” screen.

n Switching charging schedules between on and off

1 Display the “Charging schedule” screen. (→P.108)


2 Press “Edit”.

The “Events” screen will be displayed on the screen.

3 From the items displayed on the screen, press on or off in the row of the charging schedule you wish to change.

If the charging schedule you wish to change is not displayed on the screen, scroll the list up and down to display it.

Each time the button is pressed, the charging schedule switches between on and off.




n Changing the registered charging schedules

1 Display the “Charging schedule” screen. (→P.108)

2 Press “Edit”.

The “Events” screen will be displayed on the screen.

3 Press “Edit” on the “Events” screen.



4 From the items displayed on the screen, press “Edit” in the row of the charging schedule you wish to change.

● Changing registered items:

Change the desired settings as described starting from step 3 of the “Registering the charging schedule” procedure. (→P.109)

When a setting is changed, its icon on the “Charging schedule” screen also changes.

● Deleting registered items:

Press “Delete”.

A deletion confirmation message will be displayed.

Press “Delete” to delete the selected charging schedule.

When a charging schedule is deleted, its icon is also deleted from the “Charging schedule” screen.

n Turning “Charge now” on

1 Display the “Charging schedule” screen. (→P.108)

2 Press “Charge now”.

Each time the button is pressed, “Charge now” switches between on and off.

After setting operations are complete, charging starts when the AC charging connector is connected. (→P.94)


If “Charge now” cannot be set to on even when performing the operations above, remove the AC charging connector while the charging indicator is flashing at the normal speed and then immediately reconnect it.

If this operation is performed, the setting of charging current and charging limit will be temporarily initialized. (→P.97)

n Displaying Next Event

Turn the power switch off.

Next event will be displayed according to the charging schedule settings.*



*: If the multimedia customize content “ACC customize” is not set to OFF, the ending screen will not be displayed. If it is this case, check the settings of the multimedia.

When press “OK”, close Next charging event screen.

When press “Charge now”, charge now is turned on.

n When all charging schedules are turned off

The icon is not displayed on the “Charging schedule” screen.

The icon will be displayed by turning it ON on the “Events” screen.

n When charging schedule setting operations are canceled

When the vehicle is in the following conditions, charging schedule setting operations are canceled.

- l The power switch is turned off before the settings are confirmed
- l The vehicle starts off
- l A display with a higher priority than that of the charging schedule setting is shown

n When charging schedule are changed while charging

If the charging schedule is changed, Next Event will be updated and charging may stop. After changing the charging schedule, please check Next Event.

If you want to continue charging, turn on “Charge now”.



NOTICE

n While performing the setting operation

When performing the setting operation while the EV system is stopped, be careful that the 12-volt battery will not be discharged.

Using Battery Preconditioning

By setting battery preconditioning in advance before DC charging, the temperature of the traction battery is adjusted to the optimal state for charging. Charging time can be shortened by bringing the traction battery to the optimal temperature for charging.

- The cruising distance may be shortened as electric power is used to adjust the temperature of the traction battery.
- Battery preconditioning may not be available when the traction battery charge level is low.

What can be done with battery preconditioning settings.

Battery preconditioning settings allow you to configure the following features:

Battery preconditioning can be setup via the Multimedia.

- ▶ “Battery preconditioning” (→P.112)

When turned ON, “Battery preconditioning” starts and adjusts the temperature of the traction battery.

- ▶ “Battery preconditioning with navigation” (→P.113)

When a DC charging station is set as a destination in the navigation system, “Battery preconditioning” is automatically turned on according to the estimated arrival time.

- It may not work depending on how the destination on the navigation system or the quick charging station is set.
- Depending on traffic conditions and driving style, temperature adjustment may not be completed by the arrival time.
- ▶ “Scheduled battery preconditioning” (→P.113)


By setting the departure time, the temperature of the drive battery will be adjusted in advance according to the departure time.

This feature helps allow the battery to be ready to accept faster charging speeds.

Switching “Battery preconditioning” ON-OFF

- 1 Turn the power switch to ON.
- 2 Select .
- 3 Select “Battery preconditioning”.
- 4 Select “General”.


5 Select “Battery preconditioning”.



“Battery preconditioning” switches between ON and OFF with each touch of the button.

Switching “Battery preconditioning with navigation” ON-OFF

- 1 Turn the power switch to ON.
- 2 Select .
- 3 Select “Battery preconditioning”.
- 4 Select “General”.
- 5 Select “Battery preconditioning with navigation”.



“Battery preconditioning with navigation” switches between ON and OFF with each touch of the button.

When “Battery preconditioning with navigation” is set to ON and a DC charging station is set as a destina-

tion in the navigation system, “Battery preconditioning” will automatically be set to ON.

Setting “Scheduled battery preconditioning”

n Schedule Setup

Departure preconditioning, will be performed according to the date and time displayed in the multimedia.

When attempting to set up departure preconditioning, make sure to check the schedule settings to make sure it is set to the correct date and correct them if it is incorrect.


If the schedule contents are incorrect, departure preconditioning will not work properly.

For details on how to operate the multimedia screen, refer to “MULTIMEDIA OWNER’S MANUAL”


n Registering “Scheduled battery preconditioning”

- 1 Turn the power switch to ON.
- 2 Select .
- 3 Select “Battery preconditioning”.
- 4 Select “Schedule”.


5 Select “Add”.



6 Operate the screen to set the desired time and touch “OK”.



7 Select the desired day of the week to enable the repeat setting and touch “OK”.




Each time the check box is selected, the repeat setting for the selected day of the week will be turned on or off.

8 When all settings are complete, touch “Save”.

n **Switching the settings of “Scheduled battery preconditioning”**

- 1 Turn the power switch ON.
- 2 Select .
- 3 Select “Battery preconditioning”.
- 4 Select “Schedule”.
- 5 From the displayed list, touch the button for the preconditioning setting desired to turn ON/OFF.




If the preconditioning setting desired to turn ON/OFF is not displayed on the screen, scroll the list display up or down to display the preconditioning setting.

Each time the button is selected, the preconditioning setting will switch between ON and OFF.


n **Changing the registered contents of “Scheduled battery preconditioning”**

- 1 Turn the power switch to ON.
- 2 Select .
- 3 Select “Battery preconditioning”.
- 4 Select “Schedule”.

5 Select “Edit”.



- 6 From the list displayed on the screen, touch the preconditioning settings in which it is desired to change the registered contents.



- When changing the registered contents:

Change the settings to the desired settings by following the steps from step 5 of “Registering “Scheduled battery preconditioning””.

- When deleting the registered contents:
Touch “Delete”

A message appears to confirm the deletion.

Touch “Delete” to delete the selected charging schedule.

Using My Room Mode

When the charging cable is connected to the vehicle, electrical components such as the air conditioning system and audio system can be used by the power supply from an external power source.

Starting My Room Mode

- 1 Connect the charge cable to the vehicle to start charging.
AC Charging: →P.94
DC Charging: →P.100
- 2 Turn the power switch to ON while charging.

My Room Mode settings is automatically displayed on the multimedia.

- 3 Select the “Yes”.

My Room Mode is started and it is possible to use the air conditioning system, audio system, etc.

Select “No” when My Room Mode is not being used.

To disable My Room Mode, turn the power switch off.

My Room Mode will automatically be off when DC charging is completed.

n Meter display while charging

After turning the power switch to ON while charging, the power switch automatically turns off if My Room Mode is not selected within approximately 100 seconds.

n When using My Room Mode the following may occur

- | When the remaining charge of the traction battery drops to the lower limit, the air conditioning system automatically stops. In that case, the air conditioning system, audio system, etc., can not operate until the remaining charge of the traction battery increases. Turn off the power switch once, then use My Room Mode after the remaining charge of the traction battery increases.
- | If the doors are unlocked while using My Room mode, the AC charging connector will be unlocked and My Room mode will be stopped. To use My Room mode again, perform the operation to start it. (→P.115)
In addition, when using AC charger at the public charging station, it is necessary to perform the operation to start the charger before using My Room mode.
- | The charging time of the traction battery gets longer.
- | Noise may be heard from the radio depending on conditions of the radio wave.
- | The surrounding area of the onboard traction battery charger in the motor compartment may become hot.
- | The electric power steering system warning light (yellow) may

turn on, but this is not a malfunction.

- | When charging the battery in normal mode, the amount of charge is controlled so that the battery is not fully recharged in order to maintain the My Room Mode.

n Using My Room Mode during DC charging

- | When using My Room mode during DC charging, the amount of charge at the time of charge completion will be lower than when not using it. In addition, when DC charging during low outdoor temperatures and a high humidity environment, the windows may fog up. Turning on the cooling and dehumidification functions (→P.115) will dehumidify the vehicle interior and remove fogging from the windows. In this case, the temperature control of the traction battery will be stopped and the amount of charge may decrease.
- | When the battery is fully charged, the system will exit the My Room Mode.

n When My Room Mode is used while the traction battery is fully charged

When My Room Mode is used while the traction battery is fully charged, the electric power of the traction battery may be consumed. In this case, charging may be performed again.

n Warning message display

When trying to start My Room Mode or My Room Mode is being used, if a message is displayed on the multi-information display, refer to the corresponding table and perform the appropriate correction procedures.

Message	Correction procedure
"Traction battery is too low for "My Room Mode"."	There is no remaining charge of the traction battery to start My Room Mode. Wait until the remaining charge of the traction battery increases, start My Room Mode.
"My Room Mode" has stopped due to low traction battery."	The remaining charge of the traction battery is insufficient. Stop using My Room Mode and charge the traction battery.
"My Room Mode" will stop when traction battery is too low. Reduce power usage to continue using "My Room Mode"."	<p>When My Room mode electricity consumption exceeds the charge amount, the traction battery charge level becomes too low.*</p> <ul style="list-style-type: none"> • If the electricity consumption of the vehicle can not be improved, My Room Mode will be off. • When My Room Mode continuation is desired, turn off the air conditioning system, audio system, etc., to increase the remaining charge of the traction battery.

*: During My Room Mode, the information for electric power balance can be checked on the multimedia.



WARNING

n Warnings for using My Room Mode

Observe the following precautions.

Failure to do so may result in death or a serious health hazard.

- ! Do not leave children, people who need care, or pets inside the vehicle. The temperature inside the vehicle may become high or low due to features such as the automatic shut-off. The children, people who need care, or pets left inside the vehicle may suffer heatstroke dehydration or hypothermia. Also, since the wipers, etc., can be operated, there may be accidental operation, possibly leading to an accident.

- ! Use the mode after sufficiently checking the vicinity of the vehicle for safety hazards.

When charging cannot be carried out

When charging does not start, even though the normal procedure is followed, check each of the following items.

If a message is shown on the multi-information display, also refer to P.124.

When charging cannot be carried out

Refer to the following table and carry out the appropriate correction procedure.

n Charging indicator of the charging port does not illuminate, even though AC charging connector is connected.

Likely cause	Correction procedure
AC charging connector is not securely connected to AC charging inlet	<p>Check the connection status of the charging connector.</p> <ul style="list-style-type: none">• When connecting the AC charging connector, insert the AC charging connector securely.• After connecting the AC charging connector, check that the charging indicator of the charging port is turned on. <p>If the charging indicator of the charging port does not illuminate, even though the AC charging connector is securely connected, there may be a malfunction in the system. Immediately stop charging and contact your Toyota dealer.</p>
Traction battery is already fully charged	When the traction battery is fully charged, charging is not performed.
The remaining charge of the traction battery exceeds the set upper limit of the charge capacity	Change to a higher upper limit setting than the current remaining charge capacity and perform charging again.
The AC charger does not operate	Please contact the facility manager when there is a problem with AC charger.

n Charging indicator of the charging port flashes and charging cannot be carried out.

Likely cause	Correction procedure
When charging indicator of the charging port flashes normally*: Charging schedule is registered	When you wish to charge according to the charging schedule, wait until the set time. To start charging, set "Charge Now" to on. (→P.107, 110)
When charging indicator of the charging port rapidly flashes*: Malfunction occurred in an external power source or the vehicle	When a door is opened while the power switch is off, a message will be displayed on the multi-information display. Follow the instructions displayed on the multi-information display.

*: Refer to P.84 for details regarding charging indicator of the charging port illumination and flashing.

When DC charging cannot be performed normally

n DC charging does not start

Likely cause	Correction procedure
The DC charging connector is not properly connected to the vehicle.	Check the connection status of the DC charging connector and be sure that it is locked.
The DC charging connector is not securely locked.	<p>If the DC charging does not start, even though the DC charging connector is securely connected, there may be a malfunction with the DC charger or charging system.</p> <ul style="list-style-type: none"> • If there is a malfunction with the DC charger, contact the charging station manager. • If there is not a malfunction with the DC charger, there may be a malfunction in the system. Contact your Toyota dealer.

Likely cause	Correction procedure
Error is detected by the DC charger or vehicle's system check.	<p>There may be a malfunction with the DC charger or charging system.</p> <ul style="list-style-type: none"> • If there is a malfunction with the DC charger, contact the charging station manager. • If there is not a malfunction with the DC charger, there may be a malfunction in the system. Contact your Toyota dealer. • If the EV system can not be started, contact your Toyota dealer.
The DC charger power goes off.	Contact the charging station manager and check the power status.
Traction battery is already fully charged	When the traction battery is fully charged, DC charging cannot be performed.
The EV system is started.	<p>When the EV system is started, DC charging cannot be started.</p> <p>Also, if the shift position is not in P, DC charging cannot be performed.</p>
The upper limit of the charge capacity is lower than the remaining charge of the traction battery	Set the upper limit of the charge capacity to a value higher than the current remaining charge of the traction battery, and then perform the charging procedure again.
DC charging was repeatedly performed	After waiting a few minutes after starting the EV system, stop the EV system and perform charging again.

n When DC charging is interrupted

Likely cause	Correction procedure
The timer for the DC charger operates.	Depending on the type of the DC charger, the timer may be set to stop charging after a certain time. Check with the charging station manager.
The power for the DC charger is off.	Check the power status of the DC charger. If there are uncertainties with the power status, contact the charging station manager.
The temperature of the traction battery is extremely high or low.	DC charging may not be performed in extremely high or extremely low temperature environments. Charge the traction battery after the temperature has been stabilized.
Error is detected by the DC charger or vehicle's system check.	<p>There may be a malfunction with the DC charger or charging system.</p> <ul style="list-style-type: none"> • If there is a malfunction with the DC charger, contact the facility manager. • If there is not a malfunction with the DC charger, there may be a malfunction in the system. Contact your Toyota dealer. • If the EV system can not be started, contact your Toyota dealer.
High temperature of charging related parts	If the temperature of charging related parts is high, DC charging may not be possible. Wait for a while and then charge again.
The electrical components such as the air conditioning system stop operating while the traction battery is approximately fully charged.	Keep the electrical components such as the air conditioning system in the OFF state, and then perform the DC charging procedure again.

n EV system does not start after DC charging

Likely cause	Correction procedure
Charging system check is not completed properly after DC charging.	Do a system check following the procedures on P.104. If the system check can not be completed properly even after these procedures are performed, contact your Toyota dealer.
The DC charging connector is still connected.	For safety, the EV system can not be started when the DC charging connector is connected. (→P.91) Remove the DC charging connector immediately after the charging is completed.
The DC charging system is malfunctioning	<ul style="list-style-type: none"> Depending on the type of malfunction, the EV system can be started after the charging system check is completed. (→P.104) If the EV system can not be started, contact your Toyota dealer.

When charging schedule function does not operate normally

Refer to the following table and carry out the appropriate correction procedure.

n Charging does not start at desired time

Likely cause	Correction procedure
The vehicle day and time is not set correctly.	<p>Check the calendar setting and set it to the correct date.*</p> <p>Check the clock setting and set to the proper time.*</p>

Likely cause	Correction procedure
AC charging connector is not connected to vehicle	Before using the charging schedule, connect the AC charging connector.
AC charging connector was connected after set time	Connect the AC charging connector before the time set in "Start". When the charging mode is set to "Start and stop", the traction battery will charge even if the start time has passed, if the AC charging connector is connected before the stop time.

*: For details on setting the clock, refer to the separate "MULTIMEDIA OWNER'S MANUAL".

n **Charging starts, even though charging schedule is registered**


Likely cause	Correction procedure
"Charge Now" is set to on	When charging according to the charging schedule, set "Charge Now" to off. (→P.107, 110)
Charging schedule is set to off	Check that charging schedule is not set to off. (→P.109)
The charging mode is set to "Start and stop" and the AC charging connector was connected between the start time and stop time	When the charging mode is "Start and stop", connecting the AC charging connector after the start time will perform charging until the stop time. Check the charging schedule.

Likely cause	Correction procedure
AC charging connector was removed and reinserted while charging indicator of the charging port was flashing	If the AC charging connector is removed and reinserted while the charging indicator is flashing, the charging schedule is canceled (→P.96). Temporarily remove the AC charging connector, and then reconnect it.
Outside temperature is low and traction battery warming control (→P.88) operated	<ul style="list-style-type: none">• When traction battery warming control operates, the charging schedules are ignored and charging starts. In order to protect the traction battery, allow charging to continue.• After the 12-volt battery is removed and reconnected, the charging schedule setting may be disabled due to the initial setting of the temperature control system for the drive battery, even when the outside temperature is not low. In this case, after driving a few times, the system initial settings will be completed and the charging schedule settings will be enabled when the outside temperature is not low.

When charging-related message is displayed

When a door is opened with the power switch off, after charging, a message is displayed in the multi-information display.

When this occurs, follow the instructions displayed on the screen.



n If “Charging Stopped Due to Pulled Charging Connector” is shown

Likely cause	Correction procedure
AC charging connector is removed while AC charging	When the AC charging connector is removed while AC charging, charging stops. If you want to fully charge the traction battery, reconnect the AC charging connector.
After the traction battery is fully charged, the AC charging connector is removed while the traction battery is being recharged again because electricity-consuming functions* have been used and the remaining charge is now reduced.	
The release button of the AC charging connector was pressed while AC charging	When the release button is pressed while AC charging, charging stops. To continue charging, reconnect the AC charging connector.

*: Electricity is consumed when operating traction battery heater (→P.88)

n If “Charging Complete Limited Charge Due to Battery Temp” is shown

Likely cause	Correction procedure
Charging was stopped to protect the traction battery as it continued to remain hot for a certain period of time.	Allow the traction battery to cool down and perform charging again if the charging amount has not reached the desired amount.

n If “Charging Stopped Check Charging Source” is shown

Likely cause	Correction procedure
Problem in power supply from external power source	<p>Check the following items.</p> <ul style="list-style-type: none">• The plug is securely inserted.• Extension cord or multi-socket is not used.• The remote switch is not off.• Connected to a dedicated power line.• Power outage has occurred or not.• The circuit breakers have not tripped. <p>If all of the above conditions are met, the electrical socket may be malfunctioning. Contact an electrician and request an inspection.</p> <p>If charging cannot be performed, even though there is no problem with the power source path, there may be a malfunction in the system. Have the vehicle inspected by your Toyota dealer.</p>
AC charging is stopped by AC charger	<p>Depending on the specifications of AC charger, charging may be canceled by an interruption of power supply. Charging may be stopped by the following.</p> <p>Refer to AC charger handling methods.</p> <ul style="list-style-type: none">• The charging stop button of charger is pressed.• AC charger with off charging schedule function canceled charging• AC charger that is not compatible with the charging schedule function of the vehicle• Check if it can be charged with another AC charger. <p>If charging cannot be carried out even when using another AC charger, contact your Toyota dealer.</p>
The AC charger is not compatible with the vehicle	<p>Check if it can be charged with another AC charger. If charging cannot be carried out even when using another AC charger, contact your Toyota dealer.</p>

Likely cause	Correction procedure
The DC charger is malfunctioning.	If the message above is displayed when DC charging has not stopped operations, the DC charger may be damaged, so do not use that DC charger.
The DC charger is not compatible with the vehicle.	Check if it is possible to charge with another DC charger. If the message is still displayed and charging cannot be performed even though another DC charger is used, drive the vehicle for several kilometers and then charge the traction battery with different DC charger.

n If “Charging Stopped High Energy Use See Owner’s Manual” is shown

Likely cause	Correction procedure
Power is being consumed by electrical components of vehicle	Check the following items, and then carry out charging again. <ul style="list-style-type: none"> • If the headlights and audio are turned on, turn them off. • Turn the power switch off. If charging cannot be carried out, even after performing the above, the 12-volt battery may not be sufficiently charged. Operate the EV system for approximately 15 minutes or more to charge the 12-volt battery.

n If “Charging System Malfunction See Owner’s Manual” is shown

Likely cause	Correction procedure
Malfunction occurred in charging system	Have the vehicle inspected by your Toyota dealer.

n If “The Traction Battery Temp is low System put priority on charging to preserve battery condition” is shown

Likely cause	Correction procedure
The traction battery warming control is operated (→P.88)	<p>When the traction battery warming control operates, the charging schedule is not used and charging is performed.</p> <p>This is a control to protect the traction battery, and not a malfunction.</p>

n If “Charging Stopped Time Limit Reached” is shown

Likely cause	Correction procedure
The DC charging is not completed within the restricted time with DC charger.	<ul style="list-style-type: none">Depending on the type of DC charger, the timer may be set to stop charging after a certain time. Check with the charging station manager.
	<p>Depending on the condition of the vehicle, the charging time may become longer than normal, and the DC charging may not be completed within the restricted time.</p> <ul style="list-style-type: none">When the A/C, headlights, audio system, etc., are turned on, the electricity consumption of the vehicle will be increased. Perform the DC charging after turning off all of the above.The temperature of the traction battery may be low. Perform the DC charging after warming up the traction battery.

n If “Charging Stopped Check Charging Source or Vehicle” is shown

Likely cause	Correction procedure
Malfunction occurred in connector locking system.	Have the vehicle inspected by your Toyota dealer.

Plug & Charge system

Before using the system, read the following information for proper use.

Plug & Charge system

The system simplify the charging fee payment (billing authentication) procedure, allowing payment being made automatically and DC charging beginning simply by inserting the DC charging connector.

To use this system, a DC charger* is required (a DC charger is not equipped to the vehicle).

*: Use a DC charger that supports the Plug & Charge system conforming to ISO 15118.

How to use Plug & Charge system

Before using the Plug & Charge system, read the following information for proper use.

Confirm the following before Plug & Charge

Make sure to confirm the following.

- Toyota remote service app is contracted.
- Plug & Charge is set to ON. (→P.129)

Start charging using Plug & Charge

→P.100

Operating the DC charger is unnecessary.

A payment is automatically processed using the contract information stored in the vehicle.

n Setting operations on the Multimedia

The Plug & Charge settings can be set on the Multimedia.

- 1 Select .
- 2 Select "Plug & Charge".

The charging/power supply mode selection screen will be displayed.

- 3 Select the ON/OFF button of "Plug & Charge".

To turn it off, touch the button once

again.

 NOTICE

n When reselling the vehicle

If the Plug & Charge contract has not yet expired, the features may be used by someone else, for example if the vehicle is resold. To prevent this, the contract data should be erased from the vehicle.

When Plug & Charge system cannot be used normally

When charging does not start, even though the normal procedure is followed, or an error message is displayed, check each of the following items.

When DC charging cannot be performed normally

Refer to the following table and perform the appropriate correction procedure.

n Charging with Plug & Charge cannot be started

Likely cause	Correction procedure
Plug & Charge is not set	Set up Plug & Charge on the Multi-media (→P.129).
Plug & Charge contract data has been erased from the vehicle	Check the contract status and install the contract certificate using the smartphone app.

When Plug & Charge cannot be set normally

Refer to the following table and perform the appropriate correction procedure.

n Settings cannot be changed on the multimedia, multi-information display, or smartphone app

Likely cause	Correction procedure
The DC charging connector is connected	Remove the DC charging connector and try changing the setting.

When Plug & Charge related message is displayed

When a door is opened while the power switch is off after charging, a message will be displayed on the multi-information display.

If any of the following messages is displayed, follow the message and perform the appropriate correction procedures.

n

If “Plug & Charge System Failure See Owner’s Manual” is shown

Likely cause	Correction procedure
Authentication with Plug & Charge has failed	<p>If this message is displayed, reconnected the charging plug and try charging.</p> <p>If charging still does not start, turn the Plug & Charge setting off and start charging again.</p> <p>If charging still does not start, contact the facility manager.</p> <p>To use Plug & Charge again, turn the Plug & Charge setting on.</p>

3-1. Instrument cluster

Warning lights and indicators 134

Gauges and meters 139

Multi-information display
..... 142

Displayed content 144

Electricity consumption
..... 148


Warning lights and indicators

The warning lights and indicators on the instrument cluster, outside rear view mirrors and overhead console inform the driver of the status of the vehicle's various systems.

Warning lights and indicators displayed on the instrument cluster

For the purpose of explanation, the following illustrations display all warning lights and indicators illuminated.

► Type A



► Type B



Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.

BRAKE Brake system warning light*¹ (→P.568)
(U.S.A.)

 Brake system warning light*¹ (→P.568)
(Canada)

 Brake system warning light*¹ (→P.568)
(Yellow)

 Charging system warning light*² (→P.568)

 EV system malfunction indicator lamp*¹ (→P.569)

 SRS warning light*¹ (→P.569)

ABS ABS warning light*¹ (→P.569)
(U.S.A.)

 ABS warning light*¹ (→P.569)
(Canada)

 Inappropriate pedal operation warning light*² (→P.569)

 Electric power steering system warning light*¹ (Red) (→P.570)

 Electric power steering system warning light*¹ (Yellow) (→P.570)

 Traction battery charge warning light (→P.570)
(Yellow)

 Seat belt reminder light (Driver's and front passenger's) (→P.570)
(Type A)

 Seat belt reminder light (Rear passengers') (Type A) (→P.571)

 Seat belt reminder light (Driver's and front passenger's) (Type B) (→P.571)

 Seat belt reminder light (Rear passengers') (Type B) (→P.572)

 Tire pressure warning light*¹ (→P.572)

 PCS warning light*¹ (→P.572)

 LTA indicator (→P.573)
(Yellow)

 LDA indicator (→P.573)
(Yellow)

 PDA indicator (→P.573)
(Yellow)

 Dynamic radar cruise control indicator (→P.573)
(Yellow)

 Cruise control indicator (→P.573)
(Yellow)

 Driving assist information indicator*¹(→P.574)

 Intuitive parking assist OFF indicator*¹ (→P.574)

 Slip indicator*¹ (→P.574)

 Brake hold operated indicator*¹ (→P.575)
(Flashes)

PARK Parking brake indicator
(Flashes) (→P.575)
(U.S.A.)

(P) Parking brake indicator
(Flashes) (→P.575)
(Canada)

*1: These lights come on when the power switch is turned on to indicate that a system check is being performed. They will turn off after the EV system is started, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or turn off. Have the vehicle inspected by your Toyota dealer.

*2: This light illuminates on the multi-information display.

! WARNING

n If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning light not come on when you start the EV system, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Toyota dealer immediately if this occurs.

Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.

 Turn signal indicator
(→P.244)

 Headlight indicator
(→P.251)
(U.S.A.)

 Tail light indicator
(→P.251)
(Canada)

 Headlight high beam indicator (→P.253)

 AHB indicator (→P.253)

 PCS warning light*^{1, 2}
(→P.273)

 LTA indicator (→P.288)
(Green)

 LTA indicator (→P.288)
(Yellow [Flashing])

 LTA indicator (→P.288)
(White)

 LDA indicator (→P.297)
(Yellow [Flashing])

 LDA indicator (→P.297)
(Green)

 LDA indicator (→P.297)
(White)

 LDA OFF indicator*^{2, 3}
(→P.297)
(Yellow)

 PDA indicator (→P.304)
(Green)

 PDA indicator (→P.304)
(White)

	Dynamic radar cruise control indicator (→P.319)
(Green)	
	Dynamic radar cruise control indicator (→P.319)
(White)	
	Cruise control indicator (→P.324)
(Green)	
	Cruise control indicator (→P.324)
(White)	
	Outside rear view mirror indicators ^{*4} (→P.335, 340, 351)
	Driving assist information indicator ^{*1, 2} (→P.335, 340, 351, 356, 360)
	Intuitive parking assist OFF indicator ^{*1, 2} (→P.344)
	Intuitive parking assist detection indicator ^{*9} (→P.344)
	Slip indicator ^{*1} (→P.439)
(Flashes)	
	VSC OFF indicator ^{*1, 2} (→P.439)
	Brake hold standby indicator ^{*1} (→P.249)
	Brake hold operated indicator ^{*1} (→P.249)
	Smart key system indicator ^{*5} (→P.234)
	Charging cable indicator (→P.95)
	"READY" indicator (→P.234)
	Parking brake indicator (→P.245)
(U.S.A.)	

	Parking brake indicator (→P.245)
(Canada)	
	Low outside temperature indicator ^{*6} (→P.139)
	Security indicator (→P.66, 67)
	"AIR BAG ON/OFF" indicator ^{*1, 7} (→P.41)
	Eco mode indicator (→P.243)
	Downhill assist control system indicator (→P.434)
	Grip Control indicator (→P.434)
	Grip Control set speed indicator (if equipped) (→P.434)
	Grip Control set speed indicator (→P.434)
	SNOW/DIRT mode indicator (→P.434)
(^{*8})	
	D.SNOW/MUD mode indicator (→P.434)
(^{*8})	
	REC indicator (if equipped) (→P.333)
	Stop light indicator (→P.138)

^{*1}: These lights come on when the power switch is turned on to indicate that a system check is being performed. They will turn off after the EV system is started, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or turn off. Have the vehicle inspected by your Toyota dealer.

^{*2}: This light comes on when the

system is turned off.

*3: Except for Puerto Rico

*4: This light illuminates on the outside rear view mirrors.

*5: This light illuminates on the multi-information display with a message.

*6: When the outside temperature is approximately 37°F (3°C) or lower, this indicator will flash for approximately 10 seconds, then stay on.

*7: This light illuminates on the overhead console.

*8: Depending on the operating condition, the color of the light change.

*9: Vehicles without multimedia display or rear camera

n Stop light indicator

This light comes on when the stop lights are illuminated by the operation of the brake pedal or the driving assist system.

n Intuitive parking assist OFF indicator


Vehicles without multimedia display:
The indicators turn off when the shift position is changed to R regardless of whether the Intuitive parking assist function is turned on or off.

Gauges and meters

The meters display various drive information.

Meter display

n Locations of gauges and meters



The units of measure may differ depending on the intended destination of the vehicle.

A Multi-information display

Presents the driver with a variety of vehicle data. (→P.142)

Displays warning messages if a malfunction occurs. (→P.578)

Display/hide for the multi-information display can be changed. (→P.578)

B Outside temperature

Displays the outside temperature within the range of -40°F (-40°C) to 140°F (60°C).

C Power meter (→P.140)

Displays EV system output or regeneration level.

D Speedometer

Displays the vehicle speed.

E Clock

Automatically adjusts the time by using the GPS time information (GPS clock). For details, refer to the "MULTIMEDIA OWNER'S MANUAL".

F Shift position indicator/regenerative braking power indicator (→P.238)


G SOC (State of Charge) gauge

Displays the amount of charge remaining in the traction battery.

H Driving range

Displays driving range with remaining charge. (→P.238)

When the air conditioning system is operating,  and the driving range with the air conditioning system on are displayed.

I Odometer and trip meter display (→P.141)**n Power meter****A** Charge area

Shows regeneration^{*1} status.

Regenerated energy will be used to charge the EV battery (traction battery).

B Power area

Displays the EV system output (acceleration force) while driving.

C Regeneration^{*1} restrictions reference display^{*2}

In the following situations, regenerative braking is restricted, and the references for those restrictions are displayed in the charge area.

- When the traction battery has a large amount of charge and can no longer be regenerated
- When the temperature of the traction battery is extremely high or extremely low

D Output restrictions reference display^{*2}

In the following situations, the output is restricted, and the references for those restrictions are displayed in the power area.

- When the traction battery has a low amount of charge and can no longer output power
- When the temperature of the traction battery is extremely high or extremely low

^{*1}: The meaning of “Regeneration” here means converting kinetic energy into electrical energy.

^{*2}: This is a reference display, so it may differ from the actual restriction depending on the vehicle condition.

n Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change:

- When stopped, or driving at low speeds (less than 16 mph [25 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)
- When “--” is displayed, the system may be malfunctioning. Take your vehicle to your Toyota dealer.
- When the outside temperature is approximately 37°F (3°C) or

lower, the indicator  will flash for approximately 10 seconds, then stay on.

n Liquid crystal display

→P.143

WARNING


n The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the regenerative braking power appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive regenerative braking and possibly an accident resulting in death or injury.

Switching the meter display

The multi-information display can be switched between display and hidden.



Odometer and trip meter display

n Display items

● Odometer


Displays the total distance the vehicle has been driven.

● Trip meter A/Trip meter B

Displays the distance the vehicle has been driven since the meter was last reset. Trip meters A and B can be used to record and display different distances independently.


n Switching the display

The display switches each time the switch is pressed. Also, when the switch is continuously pressed during the trip meter display, the driving distance can be changed to "0".



Adjusting the instrument panel light control

The brightness of the instrument panel lights can be adjusted.



- 1** Darker
2 Brighter


n Instrument panel illumination adjustment

The brightness level can be adjusted when the surroundings are bright (daytime, etc.) or dark (night-time, etc.).

Multi-information display

Display and menu icons

n Display



A Driving support system status display area

Displays an image when the following systems are operating and a menu icon other than  is selected:

- LDA (Lane Departure Alert) (→P.293)
- LTA (Lane Tracing Assist) (→P.285)
- LCA (Lane Change Assist) (if equipped) (→P.290)
- RSA (Road Sign Assist) (if equipped) (→P.308)
- Dynamic radar cruise control (→P.311)
- Cruise control (→P.322)
- PDA (Proactive driving assist) (→P.300)

B Content display area

By selecting menu icons on the multi-information display, a variety of driving-related information can be displayed. The multi-information display can also be used to change display settings and other vehicle

settings.

Warning or advice pop-up displays are also displayed in certain situations.

n Menu icons

The menu icons will be displayed by pressing the  or  meter control switch.



Driving information display (→P.144)



Driving support system information display (→P.145)



Audio system-linked display (→P.146)



Vehicle information display (→P.146)



Warning message display (→P.578)

n Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.



WARNING

n Caution for use while driving

- I When operating the multi-information display while driving, pay extra attention to the safety of the area around the vehicle.
- I Do not look continuously at the multi-information display while driving as you may fail to see pedestrians, objects on the road, etc., ahead of the vehicle.


n The information display at low temperatures

→P.141

Displayed content

Changing the meter display

The multi-information display is operated using the meter control switches.



- A** $\wedge/\vee$: Select menu icons, scroll the screen and move the cursor
 $\langle/\rangle$: Change displayed content, scroll the screen and move the cursor
- B** Press: Enter/Set
 Press and hold: Reset/Display customizable items
- C** Return to the previous screen
- D** Call sending/receiving and history display

Linked with the hands-free system, sending or receiving call is displayed. For details regarding the hands-free system, refer to the "MULTIMEDIA OWNER'S MANUAL".

Display of drive information

Driving related information is displayed on the following displays.

- Multi-information display
- Multimedia display

The items displayed will differ depending on the display.

Content of driving information


n Display items

- Total average (Average electricity consumption [after reset])
- Trip average (Average electricity consumption [after start])

n Total average (Average electricity consumption [after reset])

Displays the average electricity consumption since the vehicle was reset.

Use the displayed values as a reference only.



A Current electricity consumption

Displays instantaneous current electricity consumption.


B Total Average

To reset the average electricity consumption display, press and hold the OK meter control switch.

n Trip average (Average electricity consumption [after start])

Displays the average electricity consumption since EV system start.

Use the displayed values as a reference only.



A Current electricity consumption

Displays instantaneous current electricity consumption.

B Trip Average

To reset the average electricity consumption display, press and hold the OK meter control switch.

n Electricity consumption

It is a numerical value that represents the electricity consumption rate and corresponds to the fuel consumption rate of gasoline engine

vehicles. In this car, the number of miles traveled (miles/kWh) per kilowatt hour of electricity (1 kWh) is displayed on each screen as "electricity cost".

Driving support system information display

n Driving support system information

Select to display the operational status of the following systems:

- LDA (Lane Departure Alert) (→P.293)
- LTA (Lane Tracing Assist) (→P.285)
- LCA (Lane Change Assist) (if equipped) (→P.290)
- RSA (Road Sign Assist) (if equipped) (→P.308)
- Dynamic radar cruise control (→P.311)
- Cruise control (→P.322)
- PDA (Proactive driving assist) (→P.300)

n Navigation system-linked display

Select to display the following navigation system-linked information:

- Route guidance to destination
- Compass display (head-up display)

Audio system-linked display

The operating conditions of the audio system can be displayed on the multi-information display.

Vehicle information display

n Display items

The following items can be displayed on the multi-information display.

- Driving information
- Battery status display

n Driving information

Use the displayed information as a reference only.

- “Average Speed”: Displays the average vehicle speed since the display was reset
- “Total Time”: Displays elapsed time since the display was reset

n Battery status display

Displays the traction battery degradation status.

A “State of Health”

The current health of the traction battery displayed as the measured charge capacity compared to the initial full charge capacity.

B “Distance Traveled Since Last Update”

At vehicle delivery or after repair at the dealer, “Distance Traveled Since Last Update” may display its default value (40727 miles/65535 km).

This value will be reset after the “State of Health” is updated.


AWD operation status display

AWD operation status display can be displayed on the Multi-media display.


n Displaying AWD operation status display on the Multi-media display

- 1 Select  on the main menu.
- 2 Select “All wheel drive”.

n AWD operation status



Torque distribution display: Displays the drive status of each



wheel in 6 steps from 0 to 5.

The illustration used is intended as an example, and may differ from the image that is actually displayed on the multi-information display or Multimedia display.

Tire pressure

The tire pressure detected by the tire pressure warning system can be displayed on the Multimedia display.

n Displaying the tire pressure on the Multimedia display

- 1 Select  on the main menu.
- 2 Select "Tire pressure".

n Tire inflation pressure

→P.615

Suggestion function

Displays suggestions to the driver in the following situations. To select a response to a displayed suggestion, use the meter control switches.

n Suggestion to enable the power back door

If the power back door system is disabled (setting on  set to off) and the power back door switch on the instrument panel is operated, a suggestion mes-

sage will be displayed asking if you wish to enable the power back door system. To enable the power back door system, select "Yes".

After enabling the power back door system, press the power back door switch again to open or close the power back door.

n Suggestion to turn on the headlights

If the headlight switch is in other than  or AUTO, and the vehicle speed is 3 mph (5 km/h) or higher for a certain amount of time when the surroundings are dark, a suggestion message will be displayed.

n Suggestion to turn off the headlights

If the headlights are left on for a certain amount of time after the power switch has been turned off, a suggestion message will be displayed.

n Customization

The suggestion function can be turned on/off. (Customizable features: →P.628)

Electricity consumption

Electricity consumption information can be displayed on the multimedia system.

Consumption

n Display procedure


- 1 Select  on the main menu.
- 2 Select the "Trip information".

n Current electricity consumption screen

If a screen other than current electricity consumption screen is displayed, touch "Current".

Use the displayed average electricity consumption as a reference.

The image is an example only, and may vary slightly from actual conditions.



- A** Resetting the consumption data
- B** Electricity consumption in the

past 15 minutes

- C** Current electricity consumption
- D** Average vehicle speed since the EV system was started.
- E** Trip range
- F** Elapsed time since the EV system was started.


Use the displayed average electricity consumption as a reference.

n History screen

If a screen other than history screen is displayed, press "History".

Use the displayed average electricity consumption as a reference.

The image is an example only, and may vary slightly from actual conditions.



- A** Latest electricity consumption
- B** Best recorded electricity consumption
- C** Previous electricity consumption record
- D** Resetting the history data

E Updating the latest average electricity consumption data

n Updating the history data

Update the latest electricity consumption by selecting “Update” to measure the current electricity consumption again.

n Resetting the data

The electricity consumption data can be deleted by selecting “Clear data”.

n Cruising range

Displays the estimated maximum distance that can be driven with the quantity of electricity remaining.

This distance is computed based on your average electricity consumption.

As a result, the actual distance that can be driven may differ from that displayed.

4-1. Key information

Keys	152
Digital Key	155

4-2. Opening, closing and locking the doors

Side doors	157
Power back door	162
Smart key system	175

4-3. Adjusting the seats

Front seats	181
Rear seats	182
Head restraints	184

4-4. Adjusting the steering wheel and mirrors

Steering wheel	188
Inside rear view mirror	189
Digital Rear-view Mirror	190
Outside rear view mirrors	199

4-5. Opening, closing the windows

Power windows	203
---------------------	-----


4-6. Favorite settings

Driving position memory	206
My Settings	209

Keys

The keys

The following keys are provided with the vehicle.



A Electronic keys

- Operating the smart key system (→P.175)
- Operating the wireless remote control function (→P.154)

B Mechanical keys

C Key number plate

n When riding in an aircraft

When bringing an electronic key onto an aircraft, make sure you do not press any buttons on the electronic key while inside the aircraft cabin. If you are carrying an electronic key in your bag, etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the electronic key to emit radio waves that could interfere with the operation of the aircraft.

n Electronic key battery depletion

- l The standard battery life is 1 to 2 years.
- l If the battery becomes low, an alarm will sound in the cabin and a message will be displayed on the multi-information display when the EV system stops.

- l To reduce key battery depletion when the electronic key is to not be used for long periods of time, set the electronic key to the battery-saving mode. (→P.177)
- l As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the electronic key battery may be depleted. Replace the battery when necessary. (→P.553)
 - The smart key system or the wireless remote control does not operate.
 - The detection area becomes smaller.
 - The LED indicator on the key surface does not turn on.
- l You can replace the battery by yourself (→P.553). However, as there is a danger that the electronic key may be damaged, it is recommended that replacement is carried out by your Toyota dealer.
- l To avoid serious deterioration, do not leave the electronic key within 3 ft. (1 m) of the following electrical appliances that produce a magnetic field:
 - TVs
 - Personal computers
 - Cellular phones, cordless phones and battery chargers
 - Recharging cellular phones or cordless phones
 - Table lamps
 - Induction cookers
- l If the electronic key is near the vehicle for longer than necessary, even if the smart key system is not used, the key battery may become depleted faster than normal. When not using the smart key system, it is recommended not to stay with the electronic key near the vehicle longer than necessary.

n Replacing the battery

→P.553

n Confirmation of the registered key number

The number of keys already registered to the vehicle can be confirmed. Ask your Toyota dealer for details.

n If a message regarding the state of the electronic key or power switch mode, etc. is shown

To prevent trapping the electronic key inside the vehicle, leaving the vehicle carrying the electronic key on your person without turning the power switch to OFF or other passengers from unintentionally taking the key out of the vehicle, etc., a message that prompts the user to confirm the state of the electronic key or power switch mode may be shown on the multi-information display. In those cases, follow the instructions on the display immediately.

n If “Key Battery Low Replace Key Battery” is displayed on the multi-information display

The electronic key has a low battery. Replace the electronic key battery. (→P.553)

n If “A New Key has been Registered Contact Your Dealer for Details” is shown on the multi-information display

This message will be displayed each time the driver's door is opened when the doors are unlocked from the outside for approximately 10 days after a new electronic key has been registered.

If this message is displayed but you have not had a new electronic key registered, ask your Toyota dealer to check if an unknown electronic key (other than those in your possession) has been registered.



NOTICE

n To prevent key damage

- I** Do not drop the keys, subject them to strong shocks or bend them.
- I** Do not expose the keys to high temperatures for long periods of time.
- I** Do not get the keys wet or wash them in an ultrasonic washer, etc.
- I** Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- I** Do not disassemble the keys.
- I** Do not attach a sticker or anything else to the surface of the electronic key.
- I** Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers.
- I** Do not place the keys near medical electrical equipment such as low-frequency therapy equipment or microwave therapy equipment, and do not receive medical attention with the keys on your person.

n Carrying the electronic key on your person

Carry the electronic key 3.9 in. (10 cm) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 3.9 in. (10 cm) of the electronic key may interfere with the key, causing the key to not function properly.

n In case of a smart key system malfunction or other key-related problems


→P.598

NOTICE

n When an electronic key is lost
→P.597

Wireless remote control

The electronic keys are equipped with the following wireless remote control:




- A** Locks all the doors (→P.157)
- B** Unlocks all the doors (→P.157)
- C** Opens the side windows* (→P.157)
- D** Opens and closes the power back door (→P.163)
- E** Sounds the alarm (→P.154)

*: These settings must be customized at your Toyota dealer.

n Theft deterrent panic mode

When  is pressed for longer than about 1 second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the electronic key.




Using the mechanical key

To take out the mechanical key, slide the release lever **A** and take the key out.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and re-attempt to insert it.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key. (→P.598)



n If you lose your mechanical keys

→P.597

n If a wrong key is used

The key cylinder rotates freely, isolated from the internal mechanism.

Digital Key

A smartphone can be used instead of the electronic key of the vehicle by installing the dedicated Digital Key App on a smartphone. Also, Digital Key can be shared with your family or friends using the Digital Key App.

Digital key usage conditions

In order to use the Digital Key, you need to install the Toyota App. Register the Vehicle to the customer's Toyota App profile, and subscribe to Remote Services, and enroll in Digital Key.

Digital key precautions

- A Digital Key can be used when the smartphone and server can communicate. The Digital Key may become unusable if the smartphone is not connected to the Internet. Be sure to carry the electronic key of the vehicle if traveling to a location with unreliable communications.
- If the smartphone battery is depleted, the smartphone cannot be used as Digital Key. If the battery level is low, be sure to charge the smartphone prior to going out.
- The Digital Key system is related to the smart key system. If the smart key system has been deactivated in the vehicle customization setting, the Digital Key will also be disabled.
- Depending on the radio wave environment, the Digital Key may not be able to be used. (→P.177)
- When transferring vehicle ownership, make sure to delete the Digital Keys.
- If the vehicle is not operated for 14 days or more, the Digital Key will not connect automatically. Therefore, it may take some time before the system operates after a door handle is touched.
- A part of the services may be stopped for a certain period of time due to server maintenance. However, registered Digital Keys can be used during the maintenance.
- A smartphone with the Digital Key App enabled will be able to lock and unlock the doors, start the EV system and perform any other operations as same as the electronic key of the vehicle. Be especially careful not to lose the smartphone or allow it to be stolen.

If the smartphone is lost or stolen, contact your Toyota dealer immediately.

- When taking your vehicle to a Toyota dealer for an inspection or repairs, make sure to bring an electronic key.
- With the Digital Key alone, no vehicle lights will illuminate when approached to the vehicle. Also, with the digital key alone, some functions, such as the power back door's close & lock function, etc., cannot be used.


Side doors

The vehicle can be locked and unlocked using the entry function, wireless remote control or door lock switches.

Unlocking and locking the doors from the outside

n Smart key system

Carry the electronic key to enable this function.



- 1** Grip the driver's door handle to unlock the door. Holding the driver's door handle for approximately 2 seconds unlocks all the doors. Grip the front passenger's door handle to unlock all the doors.*

Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked.


*: The door unlock settings can be changed.

- 2** Touch the lock sensor (the indentation on the side of the

front door handle) to lock all the doors.

Check that the door is securely locked.

n Using the wireless remote control



1 Locks all the doors

Check that the door is securely locked.

2 Unlocks all the doors

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.*

Press and hold to open the side windows*.

*: This setting must be customized at your Toyota dealer.

n Switching the door unlock function

It is possible to set which doors the entry function unlocks using the wireless remote control. Perform the switching operation in the vehicle or within approximately 3.2 ft. (1 m) of the vehicle.

- 1** Turn the power switch to OFF.
- 2** When the indicator light on the key surface is not on, press and hold ,  or  for approximately 5 seconds while pressing and holding .

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step 2.)

Multi-informa- tion display/Beep	Unlocking func- tion
 Exterior: Beeps 3 times	Holding the driver's door handle unlocks only the driver's door.
	Holding any of the passenger door handles unlocks all the doors.
 Exterior: Beeps twice	Holding a door handle unlocks all the doors.

To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door is not opened within 60 seconds after  is pressed, the doors will be locked again and the alarm will automatically be set.) In a case that the alarm is triggered, immediately stop the alarm. (→P.67)

n Impact detection door lock release system

If the vehicle is involved in a severe frontal or rear collision, manual release handle operation will be enabled for all of the doors.

Depending on the force of the impact or the type of accident, however, the system may not operate.

n Operation signals

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

A buzzer sounds to indicate that the windows are operating.


n Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again. (However, depending on the location of the electronic key, the key may be detected as being in the vehicle. In this case, vehicle may be unlocked.)

n When the door cannot be locked by the lock sensor on the surface of the door handle

When the door cannot be locked even if the lock sensor on the surface of the door handle is touched by a finger, touch the lock sensor with the palm.

When gloves are being worn, remove the gloves.



n Open door warning buzzer

If an attempt to lock the doors using the smart key system is made when a door is not fully closed, a buzzer will sound continuously for 5 seconds. Fully close the door to stop the buzzer, and lock the doors again.

n Setting the alarm

Locking the doors will set the alarm system. (→P.67)

n Conditions affecting the operation of the smart key system or wireless remote control

→P.177

n If the smart key system or the wireless remote control does not operate properly

- I Use the mechanical key to lock and unlock the doors. (→P.598)
- I Replace the key battery with a new one if it is depleted. (→P.553)

n If the 12-volt battery is discharged

The doors cannot be locked and unlocked using the smart key system or wireless remote control. Lock or unlock the doors using the mechanical key. (→P.598)

n Rear seat reminder function

- I In order to remind you not to forget luggage, etc. in the rear seat, when the power switch is turned off after any of the following conditions are met, a buzzer will sound and a message will be displayed on the multi-information display for approximately 6 seconds.
 - The EV system is started within approximately 10 minutes after opening and closing a rear door.
 - A rear door has been opened and closed after the EV system was started.

However, if a rear door is opened and then closed within approximately 2 seconds, the rear seat reminder function may not operate.

- I The rear seat reminder function determines that luggage, etc. has been placed in a rear seat based on opening and closing of a rear door. Therefore, depending on the situation, the rear seat reminder function may not operate and you may still forget luggage, etc. in the rear seat, or it may operate unnecessarily.
- I The rear seat reminder function can be enabled/disabled.

(→P.627)

n Customization

Settings (e.g. unlocking function using a key) can be changed. (Customizable features:→P.627)

⚠ WARNING

n To prevent an accident

Observe the following precautions while driving the vehicle.

Failure to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.

- I Ensure that all doors are properly closed and locked.
- I Do not pull the inside handle of the doors while driving.

Be especially careful for the front doors, as the doors may be opened even if the inside lock buttons are in locked position

- I Set the rear door child-protector locks when children are seated in the rear seats.

n When opening or closing a door

When closing a door, swing it closed with slight force applied to it. If you press on the door by hand to close it, it may not be closed completely.

Check the surroundings of the vehicle such as whether the vehicle is on an incline, whether there is enough space for a door to open and whether a strong wind is blowing. When opening or closing the door, hold the door handle tightly to prepare for any unpredictable movement.


WARNING

n When using the wireless remote control and operating the power windows

Operate the power windows after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the windows. Also, do not allow children to operate the wireless remote control. It is possible for children and other passengers to get caught in the power windows.


Unlocking and locking the doors from the inside

n Using the door lock switches



- 1** Locks all the doors
- 2** Unlocks all the doors

n Using the inside lock buttons



- 1** Locks all the doors
- 2** Unlocks all the doors

The front doors can be opened by pulling the inside handle even if the lock buttons are in the lock position.

n Locking the front doors from the outside without a key

- 1** Move the inside lock button to the lock position. (→P.160)
- 2** Close the door.

The door cannot be locked if the power switch is in ACC or ON, or the electronic key is left inside the vehicle.

Depending on the position of the electronic key, the key may not be detected correctly and the door may be locked.

n Open door warning buzzer


If the vehicle speed reaches 3 mph (5 km/h), a buzzer sounds to indicate that the door(s) or the hood is not fully closed. The open door(s) or hood is displayed on the multi-information display.

n When all the doors are locked with the entry function or wireless remote control

- l The doors cannot be unlocked with the door lock switch.
- l The door lock switches can be reset by unlocking all the doors with the entry function or wireless remote control.

Rear door child-protector lock

The door cannot be opened from inside the vehicle when the lock is set.



1 Unlock

2 Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.

Automatic door locking and unlocking systems

The following functions can be set or canceled:

For instructions on customizing, refer to P.627.

Function	Operation
Speed linked door locking function	All doors are automatically locked when the vehicle speed is approximately 12 mph (20 km/h) or higher.
Shift position linked door locking function	All doors are automatically locked when shifting the shift position other than P.

Function	Operation
Shift position linked door unlocking function	All doors are automatically unlocked when shifting the shift position to P.
Driver's door linked door unlocking function	All doors are automatically unlocked when driver's door is opened within approximately 45 seconds after turning the power switch off.

Power back door

The power back door can be opened using the power back door opener switch, smart key system or wireless remote control.

WARNING

Observe the following precautions.

Failure to do so may result in death or serious injury.

n Before driving the vehicle

Make sure that the power back door is fully closed. If the power back door is not fully closed, it may open unexpectedly while driving, causing an accident.

n Caution while driving

- I** Keep the power back door closed while driving.

If the power back door is left open, it may hit nearby objects while driving or luggage may be unexpectedly thrown out, causing an accident.

- I** Never let anyone sit in the luggage compartment. In the event of sudden braking, sudden swerving or a collision, they are susceptible to death or serious injury.

n When children are in the vehicle

Observe the following precautions.

Failure to do so may result in death or serious injury.

- I** Do not allow children to play in the luggage compartment.

If a child is accidentally locked in the luggage compartment, they could have heat exhaustion or other injuries.

- I** Do not allow a child to open or close the power back door.

Doing so may cause the power back door to move unexpectedly, or cause the child's hands, arms, head, or neck to be caught by the closing power back door.

n Operating the power back door

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in death or serious injury.

- I** Remove any heavy loads, such as snow and ice, from the power back door before opening it. Failure to do so may cause the power back door to suddenly shut again after it is opened.

- I** When opening or closing the power back door, thoroughly check to make sure the surrounding area is safe.


- I** If anyone is in the vicinity, make sure they are safe and let them know that the power back door is about to open or close.

- I** Use caution when opening or closing the power back door in windy weather as it may move abruptly in strong wind.

- I** The power back door may suddenly shut if it is not opened fully, while on a steep incline. Make sure that the power back door is secured before using the luggage compartment.

⚠ WARNING

- I** When closing the power back door, take extra care to prevent your fingers, etc., from being caught.



- I** When closing the power back door, make sure to press it lightly on its outer surface. If the back door handle is used to fully close the power back door, it may result in hands or arms being caught.

- I** Do not pull on the back door spindle (→P.172) to close the power back door, and do not hang on the back door spindle.

Doing so may cause hands to be caught or the back door spindle to break, causing an accident.


- I** If a bicycle carrier or similar heavy object is attached to the power back door, it may suddenly shut again after being opened, causing someone's hands, arms, head or neck to be caught and injured. When installing an accessory part to the power back door, using a genuine Toyota part is recommended.

Unlocking and locking the power back door from the outside

n Using the entry function

Carry the electronic key to

enable this function.



1 Unlocks all the doors

The doors cannot be unlocked for 3 seconds after the doors are locked.

2 Locks all the doors

Check that the door is securely locked.

n Using the wireless remote

→P.154

Unlocking and locking the power back door from the inside

n Using the door lock switches

→P.160

Opening/closing the power back door

n Using the wireless remote control

Press and hold the switch for approximately 1 second.


The power back door automatically opens/closes.

The power back door can be operated when it is locked*.

Pressing the switch while the power back door is opening/closing will stop the operation.

Pressing and holding the switch again for approximately 1 second will operate the power back door in the opposite direction.

*: Opening of the power back door when it is locked can be disabled by a customized setting.
(→P.631)




n Opening/closing the power back door from the inside

Press and hold the switch for approximately 1 second.

A buzzer sounds and the power back door automatically opens/closes. Unlock the power back door before operating.

Pressing the switch while the power back door is opening/closing stops the operation.

Pressing and holding the switch again for approximately 1 second will operate the power back door in the opposite direction.



n Opening the back door using the back door opener switch


When the power back door is unlocked: Press the back door opener switch.

When the power back door is locked: While carrying the electronic key on your person, press and hold the power back door opener switch.

The power back door automatically opens.

Pressing the switch while the power back door is opening stops the operation.

Pressing the switch again will open the back door automatically.



n Using the power back door switch on the back door


- Close

Press the  switch.

The power back door automatically closes.

Pressing the  switch while the power back door is closing will stop the operation.

When the switch is pressed again during the halted operation, the back door will perform the reverse operation.




- Close the back door and lock all doors (close & lock function)

Close all of the doors except the back door, carrying an electronic key and press the  switch on the lower part of the back door.

A different buzzer than the normal one will sound and the power back door will begin closing automatically. When the power back door is closed, all of the doors will lock simultaneously and operation signals will indicate that all of the doors have been locked.

Pressing the  switch while the power back door is operating will stop the operation.

When the  switch is pressed again during the halted operation, the power back door will be closed.




- Close the back door and lock all doors after moving away from the back door (close & lock [Walk-Away] function)*

*: This setting can be customized by your Toyota dealer.

- 1 Close all of the doors except the back door, carrying an electronic key and press the  switch on the lower part of the back door.

A different buzzer than the normal one will sound and the close & lock (Walk-Away) function will go into standby.



- 2 While the buzzer is sounding, move away from the back door.

When the sensor detects that you are away from the back door, the emergency flashers will flash, and the buzzer will sound. Depending on the direction of moving away from the back door, the location and

how to hold the electronic key or circumstances, it may not be detected properly.

All the doors other than the back door will be locked, and after the back door is closed, the back door will also be locked. When all the doors have been closed and locked, the buzzer will sound and the emergency flashers will flash.


The standby state is canceled if you do not move away from the back door for 30 seconds. To operate the function again, perform the procedure again from the beginning.

If the  switch is pressed after the back door operation has stopped, the close & lock (Walk-Away) function will go into standby again.

n Using the back door handles

Lower the back door using the back door handle.

The power back door closing assist (→P.168) will be activated, and the power back door will fully close automatically.




n Using the kick sensor (Hands Free Power Back Door)

When operating the Hands Free Power Back Door, make sure that the power switch is in OFF, the Hands Free Power Back

Door operation is enabled (→P.169) and you are carrying an electronic key.


- 1** While carrying an electronic key, stand within the smart key system operation range, approximately 19.7 to 27.6 in. (50 to 70 cm) from the rear bumper.



- A** Kick sensor
 - B** Hands Free Power Back Door operation detection area
 - C** Smart key system operation detection area (→P.176)
- 2** Perform a kick operation by moving your foot to within approximately 3.9 in. (10 cm) of the rear bumper and then pulling your foot back after the buzzer sounds.
- Perform the entire kick operation within 1 second.
 - The Hands Free Power Back Door will not start operating while a foot is detected under the rear bumper.
 - Operate the Hands Free Power Back Door without

contacting the rear bumper with your foot.

- If another electronic key is in the cabin or luggage compartment, it may take slightly longer than normal for the operation to occur.



A Kick sensor

B Hands Free Power Back Door operation detection area

- 3 When the kick sensor detects a kicking motion with the foot, the buzzer sounds, and when the foot being pulled is detected, the power back door automatically fully opens or fully closes.

If a foot is moved under the rear bumper while the back door is operating, the back door will stop moving.

If a foot is moved under the rear bumper again during the halted operation, the back door will perform the reverse operation.

The buzzer can be turned off with the customize function. (→P.627)

n Luggage compartment lights

- l The luggage compartment lights turn on when the back door is opened.

- l When the power switch is turned off, the lights will go off automatically after 20 minutes.

n Back door closer

In the event that the power back door is left slightly open, the back door closer will automatically close it to the fully closed position.

Whatever the state of the power switch, the power back door closer operates.

n Power back door operating conditions

The power back door can automatically open and close under the following conditions:


- l When the power back door system is enabled. (→P.163)
- l When the power switch is in ON, in addition to the above for the opening operations, the power back door operates for any of the following conditions:
 - The parking brake is engaged.
 - The brake pedal is depressed.
 - The shift position is in P.

n Operation of the power back door

- l A buzzer sounds and the emergency flashers flash twice to indicate that the power back door is opening/closing.
- l When the power back door system is disabled, the power back door does not operate but it can be opened and closed by hand.
- l When the power back door automatically opens, if an abnormality due to people or objects is detected, operation will stop.

n Jam protection function

Sensors are equipped on both sides of the power back door. If anything obstructs the power back door while it is closing, the back door will automatically operate in the opposite direction or stop.



n Fall-down protection function

While the power back door is opening automatically, applying excessive force to it will stop the opening operation to prevent the power back door from suddenly shutting.

n Back door closing assist

If the back door is lowered manually when the back door is stopped at an open position, the back door will fully close automatically.

n Back door reserve lock function

This function is a function which reserves locking of all doors, beforehand, when the power back door is open.

When the following procedure is performed, all the doors except the power back door are locked and then power back door will also be locked at the same time it is closed.

- 1 Close all of the doors, except the power back door.
- 2 During the power back door closing operation, lock the doors using the smart key system from the side doors (→P.157) or the wireless remote control. (→P.154)

Operation signals will indicate that all the doors have been closed and locked. (→P.158)

- l If the electronic key is placed inside the vehicle after starting a close operation via the door reserve lock function, the electronic key may become locked inside the vehicle.
- l If the back door does not fully close due to the operation of the jam protection function, etc., while

the back door is automatically closing after a door reserve lock operation is performed, the door reserve lock function is canceled and all the doors will unlock.

- l Before leaving the vehicle, make sure that all the doors are closed and locked.

n Close & lock function

When the power back door is open, this function closes the power back door and then locks all of the doors simultaneously.

When the following procedures are performed and there are no electronic keys for the vehicle within the vehicle, all of the doors will lock when the power back door is completely closed.

- 1 Close all of the doors except the power back door.
- 2 While carrying an electronic key, press the  switch on the lower part of the power back door (→P.164).

A different buzzer than the normal one will sound and then the power back door will begin closing automatically. When the power back door is closed, all of the doors will lock simultaneously and operation signals will indicate that all of the doors have been locked.

n Situations in which the close & lock function may not operate properly

In the following situations, the close & lock function may not operate properly:

- l If the  switch on the lower part of the power back door (→P.164) is pressed by a hand which is holding an electronic key
- l If the  switch on the lower part of the power back door (→P.164) is pressed when the electronic key is in a bag, etc. that is placed on the ground

- | If the  switch on the lower part of the power back door (→P.164) is pressed with the electronic key not near the vehicle.

n **Hands Free Power Back Door operating conditions**

The Hands Free Power Back Door will open/close automatically when the following conditions are met:

- | The Hands Free Power Back Door operation is enabled (→P.174)
- | The power switch is in OFF.
- | The electronic key is within the operational range. (→P.176)
- | A foot is put near the lower center part of the rear bumper and moved away from the rear bumper.
The power back door may also be operated by putting a hand, an elbow, a knee, etc. near the lower center part of the rear bumper and moving it away from the rear bumper. Make sure to put it close enough to the center part of the rear bumper.

n **Situations in which the Hands Free Power Back Door may not operate properly**

In the following situations, the Hands Free Power Back Door may not operate properly:

- | When a foot remains under the rear bumper
- | If the rear bumper is strongly hit with a foot or is touched for a while

If the rear bumper has been touched for a while, wait for a short time before attempting to operate the Hands Free Power Back Door again.

- | When standing excessively close to the rear bumper
- | When an external radio wave source interferes with the communication between the electronic key and the vehicle (→P.177)
- | When charging from an external

power source or connecting the AC charging cable

- | When the vehicle is parked near an electrical noise source which affects the sensitivity of the Hands Free Power Back Door, such as a pay parking spot, gas station, electrically heated road, or fluorescent light
- | When the vehicle is near a TV tower, electric power plant, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- | When a large amount of water is applied to the rear bumper, such as when the vehicle is being washed or in heavy rain
- | When mud, snow, ice, etc. is attached to the rear bumper
- | When the vehicle has been parked for a while near objects that may move and contact the rear bumper, such as plants
- | When an accessory is installed to the rear bumper

If an accessory has been installed, turn the Hands Free Power Back Door operation setting off.

n **Preventing unintentional operation of the Hands Free Power Back Door**

When an electronic key is in the operation range, the Hands Free Power Back Door may operate unintentionally, so be careful in the following situations.

- | When a large amount of water is applied to the rear bumper, such as when the vehicle is being washed or in heavy rain
- | When dirt is wiped off the rear bumper
- | When a small animal or small object, such as a ball, moves under the rear bumper
- | When an object is moved from under the rear bumper

- | If someone is swinging their legs while sitting on the rear bumper
- | If the legs or another part of someone's body contacts the rear bumper while passing by the vehicle
- | When the vehicle is parked near an electrical noise source which affects the sensitivity of the Hands Free Power Back Door, such as a pay parking spot, gas station, electrically heated road, or fluorescent light
- | When the vehicle is near a TV tower, electric power plant, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- | When operated while a person is too close to the rear bumper
- | If luggage, etc. is set near the rear bumper
- | If accessories or a vehicle cover is installed/removed near the rear bumper
- | When the vehicle is being towed

To prevent unintentional operation, turn the Hands Free Power Back Door operation setting off. (→P.174)

n **When reconnecting the 12-volt battery**

To enable the power back door to operate properly, close the back door manually.


n **If the power back door opener is inoperative**

The power back door can be unlocked from the inside


1 Remove the cover.

To prevent damage, cover the tip of


the screwdriver with a rag.




2 Loosen the screw.



3 Move the cover.



4 Move the lever.




5 When installing, reverse the steps listed.

n **Customization**

Some functions can be customized. (→P.627)

! WARNING**n Back door closer**

- In the event that the power back door is left slightly open, the back door closer will automatically close it to the fully closed position. It takes several seconds before the back door closer begins to operate. Be careful not to catch fingers or anything else in the power back door, as this may cause bone fractures or other serious injuries.



- Use caution when using the back door closer as it still operates when the power back door system is canceled.

n Power back door

Observe the following precautions when operating the power back door.

Failure to do so may cause death or serious injury.

- Check the safety of the surrounding area to make sure there are no obstacles or anything that could cause any of your belongings to get caught.
- If anyone is in the vicinity, make sure they are safe and let them know that the power back door is about to open or close.

- If the power back door system is turned off while the power back door is operating automatically, the automatic operation is stopped. The power back door then has to be operated manually. Take extra care when on an incline, as the power back door may open or close unexpectedly.

- If the operating conditions of the power back door are no longer met, a buzzer may sound and the power back door may stop opening or closing. The power back door then has to be operated manually. Take extra care when on an incline, as the power back door may open or close abruptly.

- On an incline, the power back door may suddenly shut after it opens. Make sure the power back door is fully open and secure.

- In the following situations, the power back door may detect an abnormality and automatic operation may be stopped. In this case, the power back door has to be operated manually. Take extra care when on an incline, as the power back door may open or close abruptly.

- When the power back door contacts an obstacle
- When the 12-volt battery voltage suddenly drops, such as when the power switch is turned to ON or the EV system is started during automatic operation

! WARNING

- I If a bicycle carrier or similar heavy object is attached to the power back door, the power back door may not operate, causing itself to malfunction, or the power back door may suddenly shut again after being opened, causing someone's hands, arms, head or neck to be caught and injured.

When installing an accessory part to the power back door, ask your Toyota dealer for details.

n Jam protection function

Observe the following precautions.

Failure to do so may cause death or serious injury.

- I Never use any part of your body to intentionally activate the jam protection function.
- I The jam protection function may not work if something gets caught just before the power back door fully closes. Be careful not to catch fingers or anything else.
- I The jam protection function may not work depending on the shape of the object that is caught. Be careful not to catch fingers or anything else.

n Hands Free Power Back Door

Observe the following precautions when operating the Hands Free Power Back Door.

Failure to do so may cause death or serious injury.

- I Check the safety of the surrounding area to make sure there are no obstacles or anything that could cause any of your belongings to get caught.


- I When putting your foot near the lower center part of the rear bumper and moving it from the rear bumper, be careful not to touch the exhaust pipes until they have cooled down sufficiently, as touching hot exhaust pipes can cause burns.

- I Do not leave the electronic key within the effective range (detection area) of the luggage compartment.

! NOTICE**n Back door spindles**

The back door is equipped with spindles that hold the power back door in place. Observe the following precautions.

Failure to do so may cause damage to the power back door spindle, resulting in malfunction.



- I Do not attach any foreign objects, such as stickers, plastic sheets, or adhesives to the spindle rod.
- I Do not touch the spindle rod with gloves or other fabric items.
- I Do not attach any accessories other than genuine Toyota parts to the power back door.
- I Do not place your hand on the spindle or apply lateral forces to it.

**NOTICE****n To prevent back door closer malfunction**

Do not apply excessive force to the power back door while the power back door closer is operating. Applying excessive force may cause the power back door closer to malfunction.

n To prevent malfunction of the power back door

I Make sure that there is no ice between the power back door and frame that would prevent movement of the power back door. Operating the power back door when excessive load is present on the power back door may cause a malfunction.

I Do not apply excessive force to the power back door while the power back door is operating.

I Take care not to damage the sensors (installed on the right and left edges of the power back door) with a knife or other sharp object. If the sensor is disconnected, the power back door will not close automatically.

n Close & lock function

When closing the power back door using the close & lock function, a different buzzer than the normal one will sound before the operation begins.

To check that the operation has started correctly, check that a different buzzer than the normal one has sounded.

Additionally, when the power back door is fully closed and locked, operation signals will indicate that all of the doors have been locked.

Before leaving the vehicle, make sure that the operation signals have operated and that all of the doors are locked.

n Hands Free Power Back Door precautions

The kick sensor is located behind lower center part of the rear bumper. Observe the following to ensure that the Hands Free Power Back Door function operates properly:

I Keep the lower center part of the rear bumper clean at all times.

If the lower center part of the rear bumper is dirty or covered with snow, the kick sensor may not operate. In this situation, clean off the dirt or snow, move the vehicle from the current position and then check if the kick sensor operates.

If it does not operate, have the vehicle inspected by your Toyota dealer.

I Do not apply coatings that have a rain clearing (hydrophilic) effect, or other coatings, to the lower center part of the rear bumper.

I Do not park the vehicle near objects that may move and contact the lower center part of the rear bumper, such as grass or trees.

If the vehicle has been parked for a while near objects that may move and contact the lower center part of the rear bumper, such as grass or trees, the kick sensor may not operate. In this situation, move the vehicle from the current position and then check if the kick sensor operates.

If it does not operate, have the vehicle inspected by your Toyota dealer.

**NOTICE**

I Do not subject the rear bumper to a strong impact.

If the rear bumper has been subjected to a strong impact, the Hands Free Power Back Door may not operate properly.

If the Hands Free Power Back Door does not operate in the following situations, have the vehicle inspected by your Toyota dealer.

- The kick sensor or its surrounding area has been subjected to a strong impact.
- The lower center part of the rear bumper is scratched or damaged.

I Do not disassemble the rear bumper.

I Do not attach stickers to the rear bumper.

I Do not paint the rear bumper.

I If a bicycle carrier or similar heavy object is attached to the power back door, disable the Hands Free Power Back Door.

Changing settings of the power back door system

The settings for the power back door can be changed from the settings screen of the multimedia display. (→P.629)

When the power back door settings have been changed, they will not be reset even if the power switch is turned OFF.

To return the settings to their previous values, it is necessary to use the settings screen of the multimedia display again.


Adjusting the open position of the power back door

The open position of the power back door can be adjusted.

- 1** Stop the power back door at the desired position.
(→P.164)
- 2** Press and hold the  switch on the lower part of the power back door for 2 seconds.

When the settings are completed, the buzzer sounds 4 times.


When opening the power back door the next time, the power back door will stop at that position.



Canceling the adjusted open position of the power back door

Press and hold the  switch on the lower part of the power back door for 7 seconds.

After the buzzer sounds 4 times, it sounds twice more. When the power back door does the opening operation the next time, the door will open to the initial settings position.



n Customization

The automatic opening stop position for the power back door can also be changed from the multimedia display. (→P.629)


When the stop position has been set by both the vehicle side power back door open/close switch and the multimedia display, priority will be given to whichever one was set most recently.

Smart key system

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. The driver should always carry the electronic key.

- Locks and unlocks the doors (→P.157)
- Locks and unlocks the back door (→P.163)
- Starts and stops the EV system (→P.234)


n Antenna location



- A** Antennas outside the cabin (front)
- B** Antennas outside the cabin (rear)
- C** Antennas inside the cabin
- D** Antenna inside the luggage compartment
- E** Antenna outside the luggage compartment

compartment

n **Effective range (areas within which the electronic key is detected)**



A When locking or unlocking the doors

The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of the front door handles, rear door handles and back door opener switch. (Only the doors detecting the key can be operated.)

B When starting the EV system or changing power switch modes

The system can be operated when the electronic key is inside the vehicle.

n **Alarms and warning messages**

An alarm sounds and warning messages are displayed on the multi-information display to protect against unexpected accidents or theft of the vehicle resulting from erroneous operation. When a warning message is displayed, take appropriate measures based on the displayed message. (→P.578)

When only an alarm sounds, circumstances and correction procedures are as follows.

- l When an exterior alarm sounds once for 5 seconds

Situation	Correction procedure
An attempt was made to lock the vehicle while a door was open.	Close all of the doors and lock the doors again.

- l When an interior alarm sounds continuously

Situation	Correction procedure
The power switch was turned to ACC while the driver's door was open (The driver's door was opened when the power switch was in ACC).	Turn the power switch off and close the driver's door.
The power switch was turned off while the driver's door was open.	Close the driver's door.

n **If “Key Detected in Vehicle” is shown on the multi-information display**

An attempt was made to lock the doors using the smart key system while the electronic key was still inside the vehicle. Retrieve the electronic key from the vehicle and lock the doors again.

n **Battery-saving function**

The battery-saving function will be activated in order to prevent the electronic key battery and the 12-volt battery from being discharged while the vehicle is not in operation for a long time.

- l In the following situations, the smart key system may take some time to unlock the doors.
 - The electronic key has been left near the vehicle for a certain

amount of time.


- The smart key system has not been used for a few days or longer.
- | If the smart key system has not been used for 14 days or longer, the doors cannot be unlocked at any doors except the driver's door. In this case, take hold of the driver's door handle, or use the wireless remote control or the mechanical key, to unlock the doors.

n **Turning an electronic key to battery-saving mode**

- | When battery-saving mode is set, battery depletion is minimized by stopping the electronic key from receiving radio waves.

Press  twice while pressing and holding . Confirm that the electronic key indicator flashes 4 times.

While the battery-saving mode is set, the smart key system cannot be used. To cancel the function, press any of the electronic key buttons.



Electronic keys that will not be used for long periods of time can be set to the battery-saving mode in advance.

n **When electronic key function stops**

If the position of the electronic key has not changed for a certain amount of time such as when the electronic key is left somewhere, the function of the electronic key stops to reduce depletion of the battery.

In this case, function can automatically be restored by moving the

position of the key such as by lifting it up.

n **Conditions affecting operation**

The smart key system, wireless remote control and immobilizer system use weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart key system, wireless remote control and immobilizer system from operating properly. (Ways of coping: →P.598)

- | When the electronic key battery is depleted
- | Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- | When the electronic key is in contact with, or is covered by the following metallic objects
 - Cards to which aluminum foil is attached
 - Cigarette boxes that have aluminum foil inside
 - Metallic wallets or bags
 - Coins
 - Hand warmers made of metal
 - Media such as CDs and DVDs
- | When other wireless keys (that emit radio waves) are being used nearby
- | When carrying the electronic key together with the following devices that emit radio waves
 - Portable radio, cellular phone, cordless phone or other wireless communication devices
 - Another electronic key or a wireless key that emits radio waves
 - Personal computers or personal digital assistants (PDAs)
 - Digital audio players
 - Portable game systems
- | If window tint with a metallic content or metallic objects are attached to the rear window
- | When the electronic key is placed

near a battery charger or electronic devices

- | When the vehicle is parked in a pay parking spot where radio waves are emitted

If the doors cannot be locked/unlocked using the smart key system, lock/unlock the doors by performing any of the following:

- | Bring the electronic key close to either front door handle and operate the entry function.
- | Operate the wireless remote control.

If the doors cannot be locked/unlocked using the above methods, use the mechanical key. (→P.598)

If the EV system cannot be started using the smart key system, refer to →P.599

n Note for the entry function

- | Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:

- The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
- The electronic key is on the instrument panel, luggage compartment, floor, or in the door pockets or glove box when the EV system is started or power switch modes are changed.
- The electronic key is blocked by a body between the electronic key and the vehicle when the door is unlocked.
- | Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the door will become lockable from the outside,

possibly trapping the electronic key inside the vehicle.

- | As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- | Even if the electronic key is not inside the vehicle, it may be possible to start the EV system if the electronic key is near the window.
- | The doors may unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash when the electronic key is within the effective range. (The door will automatically be locked after approximately 60 seconds if the doors are not opened and closed.)
- | If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- | Touching the door lock sensor while wearing gloves may delay or prevent lock operation. Remove the gloves and touch the lock sensor again.
- | When the lock operation is performed using the lock sensor, recognition signals will be shown up to two consecutive times. After this, no recognition signals will be given.
- | If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:
 - Place the electronic key in a location 6 ft. (2 m) or more away from the vehicle. (Take care to ensure that the key is not stolen.)
 - Set the electronic key to bat-

tery-saving mode to disable the smart key system. (→P.177)

- l If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.
- l The lock sensor may not work properly if it comes into contact with ice, snow, mud, etc. Clean the lock sensor and attempt to operate it again.
- l A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.
- l If there is another electronic key in the detection area, it may take slightly longer to unlock the doors after the door handle is gripped.

n When the vehicle is not driven for extended periods

- l To prevent theft of the vehicle, do not leave the electronic key within 6 ft. (2 m) of the vehicle.
- l The smart key system can be deactivated in advance.
- l Setting the electronic key to battery-saving mode helps to reduce key battery depletion. (→P.177)

n To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off

accidentally, or the door lock prevention may not operate.)

n If the smart key system does not operate properly

- l If the doors cannot be locked or unlocked and the back door cannot be opened, perform the following.
 - Bring the electronic key close to the door handle and perform a lock or unlock operation.
 - Bring the electronic key close to the button on the back door (→P.163) and press the button.
 - Use the wireless remote control.

If the doors cannot be locked or unlocked by perform the above, use the mechanical key. (→P.598) However, if the mechanical key is used while the alarm system is set, the warning will sound. (→P.67)

- l If the EV system cannot be started, refer to →P.599

n Customization

Settings (e.g. smart key system) can be changed. (Customizable features :→P.627)

If the smart key system has been deactivated by a customized setting, refer to the explanations for the following operations.

- l Locking and unlocking the doors:
Use the wireless remote control or mechanical key. (→P.157, 163, 598)
- l Starting the EV system and changing power switch modes:
→P.599
- l Stopping the EV system: →P.236

**WARNING****n Caution regarding interference with electronic devices**

I People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should keep away from the smart key system antennas. (→P.175)

The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Toyota dealer for details, such as the frequency of radio waves and timing of the emitted radio waves. Then, consult your doctor to see if you should disable the entry function.

I Users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.

Radio waves could have unexpected effects on the operation of such medical devices.


Ask your Toyota dealer for details on disabling the entry function.

Front seats

The seats can be adjusted (longitudinally, vertically, etc.).

Adjust the seat to ensure the correct driving posture.

Adjustment procedure



- A** Seat position adjustment switch
- B** Seat cushion (front) angle adjustment switch
- C** Seatback angle adjustment switch
- D** Vertical height adjustment switch
- E** Lumbar support adjustment switch (for driver's side)

n When adjusting the seat

- l Make sure that any surrounding passengers or objects are not contact the seat.
- l Take care when adjusting the seat

so that the head restraint does not touch the ceiling and sun visor.

n Power easy access system (if equipped)

The driver's seat move in accordance with power switch mode and the driver's seat belt condition. (→P.206)

⚠ WARNING

n When adjusting the seat position

- l Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- l Do not put your hands under the seat or near the moving parts to avoid injury. Fingers or hands may become jammed in the seat mechanism.
- l Make sure to leave enough space around the feet so they do not get stuck.

n Seat adjustment

To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.


If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident. Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

Rear seats

Reclining adjustments and folding the seatbacks can be done with lever operation.

Adjustment procedure

Pull the seatback angle adjustment lever **A**, and adjust the seatback angle.



WARNING


n When operating the rear seatback

Observe the following precautions.

Failure to do so may result in death or serious injury.

- ! Keep other passengers from being hit by the rear seatback.
- ! Do not put your hands between the seats or near the moving parts, or let any part of your body get caught.

! After adjusting the seat, make sure that the seat is locked in position. If the seatback is not securely locked, the red marking will be visible. Make sure that the red marking is not visible.



Folding down the rear seatbacks

n Before folding down the rear seatbacks

- 1 Park the vehicle in a safe place.

Apply the parking brake firmly (→P.245) and shift the shift position to P. (→P.239)

- 2 Adjust the position of the front seat and the angle of the seatback. (→P.181)

Depending on the position of the front seat, if the seatback is folded back-ward, it may interfere with the operation of the rear seat.


- 3 Lower the head restraint of the rear seat. (→P.184)
- 4 Stow the armrest of the rear seat if it is pulled out. (→P.489)

This step is not necessary when operating the left side seat only.

n Folding down the rear seatbacks


- Using the seatback angle adjustment lever

While pulling the seatback angle adjustment lever **A**, fold the seatback down.




- Using the rear seat remote control lever

While pulling the rear seat remote control lever, fold the seatback down.



n Returning the rear seatbacks

To avoid trapping the seat belt between the seat and the inside of the vehicle, pass the seat belt outside the seat belt guide **A** and then return the seatback securely to the locked position.



⚠ WARNING

n When folding the rear seatbacks down

Observe the following precautions.

Failure to do so may result in death or serious injury.

- ! Do not attempt to fold the seatbacks down while driving.
- ! Stop the vehicle on level ground, set the parking brake and shift the shift position to P.
- ! Do not allow anyone to sit on a folded seatback or in the luggage compartment while driving.
- ! Do not allow children to enter the luggage compartment.
- ! Do not operate the rear seat if it is occupied.
- ! Be careful not to get feet or hands caught in the moving parts or joints of the seats during operation.
- ! Do not allow children to operate the seat.


n After returning the rear seatback to the upright position

Observe the following precautions.

Failure to do so may result in death or serious injury.

WARNING

- Make sure that the seatback is securely locked in position by lightly pushing it back and forth. If the seatback is not securely locked, the red marking will be visible on the seatback lock release lever. Make sure that the red marking is not visible.



- Check that the seat belts are not twisted or caught in the seatback.

Head restraints

Head restraints are provided for all seats.

WARNING


n Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.
- Make sure the rear outer seats head restraints are locked by pushing them up and down before using the head restraints.

Adjusting a head restraint vertically

n Front seats




- 1** Up

Pull the head restraints up.

2 Down

Push the head restraint down while pressing the lock release button **A**.

n Rear center seat



1 Up

Pull the head restraints up.


2 Down

Push the head restraint down while pressing the lock release button **A**.

n Rear outer seats

Head restraints cannot be adjusted.

n Adjusting the height of the head restraints (front seats)



Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.

n Adjusting the rear center seat head restraints


Always raise the head restraint one level from the stowed position when using.

Removing the head restraints

n Front seats


Pull the head restraint up while pressing the lock release button **A**.

If the head restraint touches the ceiling, making the removal difficult, change the seat height or angle. (→P.181)



n Rear center seat


Pull the head restraint up while pressing the lock release button **A**.




n Rear outer seats

1 Pull the seatback lock release lever **A** and fold down the seatback until it reaches the position where

the head restraints can be removed.



- 2** Pull the head restraint up while pressing the lock release button **B**.




Installing the head restraints

n Front seats

Align the head restraint with the installation holes and push it down to the lock position.


Press and hold the lock release button **A** when lowering the head restraint.



n Rear center seat

Align the head restraint with the installation holes and push it down to the lock position.


Press and hold the lock release button **A** when lowering the head restraint.




n Rear outer seats

- 1** Pull the seatback lock release lever **A** and fold down the seatback until it reaches the position where

the head restraints can be installed.




- 2** Align the head restraint with installation holes and push it down to the lock position.



Steering wheel


Adjustment procedure

- 1 Hold the steering wheel and push the lever down.



- 2 Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.



WARNING

n Caution while driving

Do not adjust the steering wheel while driving.


Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

n After adjusting the steering wheel

Make sure that the steering wheel is securely locked. Otherwise, the steering wheel may move suddenly, possibly causing an accident, resulting in death or serious injury. Also, the horn may not sound if the steering wheel is not securely locked.

Sounding the horn

To sound the horn, press on or close to the  mark.



Inside rear view mirror*


*: If equipped

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

Adjusting the height of rear view mirror

The height of the rear view mirror can be adjusted to suit your driving posture.

Adjust the height of the rear view mirror by moving it up and down.



WARNING

n Caution while driving

Do not adjust the position of the mirror while driving. Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.

Anti-glare function


Responding to the level of brightness of the headlights of

vehicles behind, the reflected light is automatically reduced.

This function turns on each time the power switch is turned to ON.

n To prevent sensor error

To ensure that the sensors operate properly, do not touch or cover them.



Digital Rear-view Mirror*

*: If equipped

The Digital Rear-view Mirror is a system that uses the camera on the rear of the vehicle and displays its image on the display of the Digital Rear-view Mirror.

The Digital Rear-view Mirror can be changed between mirror mode and digital mirror mode by operating the lever.

The Digital Rear-view Mirror allows the driver to see the rear view despite obstructions, such as the head restraints or luggage, ensuring rear visibility. Also, the rear seats are not displayed and privacy of the passengers is enhanced.



WARNING

Observe the following precautions.

Failure to do so may result in death or serious injury.


n Before using the Digital Rear-view Mirror

- I** Make sure to adjust the mirror before driving. (→P.192)
- Change to mirror mode and adjust the position of the Digital Rear-view Mirror so that the area behind your vehicle can be viewed properly.

- Change to digital mirror mode and adjust the display settings.

I As the range of the image displayed by the Digital Rear-view Mirror is different from that of the mirror, make sure to check this difference before driving.

System components



A Camera indicator

Indicates that the camera is operating normally.

B Icon display area

Displays icons, adjusting gauge, etc. (→P.192)

C Select/adjust button

Press to change the setting of the item you want to adjust.

D Menu button


Press to display the icon display area and select the item you want to adjust.

E Lever

Operate to change between digital mirror mode and mirror mode.

Changing modes

Operate the lever to change between digital mirror mode and mirror mode.



1 Digital mirror mode

Displays an image of the area behind the vehicle.

 will illuminate in this mode.

2 Mirror mode

Turns off the display of the Digital Rearview Mirror allows it to be used as an mirror.

n Digital mirror mode operating condition

The power switch is turned to ON.

When the power switch is changed from ON to OFF or ACC, the image will disappear after several seconds.

n When using the Digital Rear-view Mirror in digital mirror mode

- | If it is difficult to see the displayed image due to light reflected off the Digital Rear-view Mirror, the camera being dirty or covered with water droplets, dust, etc., or if lights of a vehicle behind your vehicle or the displayed image are bothering you, change to mirror mode.
- | When it is raining, if the image is unclear due to water on the rear window, operate the rear wiper.
- | When the back door is open, the Digital Rear-view Mirror image may not display properly. Before driving, make sure the back door is closed.
- | If the display is difficult to see due

to reflected light, close the electronic sunshade for the panoramic moon roof (if equipped).

- | Any of the following conditions may occur when driving in the dark, such as at night. None of them indicates that a malfunction has occurred.
- Colors of objects in the displayed image may differ from their actual color.
- Depending on the height of the lights of the vehicle behind, the area around the vehicle may appear white and blurry.
- Automatic image adjustment for brighter surrounding image may cause flickering.

If it is difficult to see the displayed image or flickering bothers you, change to mirror mode.


- | The Digital Rear-view Mirror may become hot while it is in digital mirror mode. This is not a malfunction.

- | Depending on your physical condition or age, it may take longer than usual to focus on the displayed image. In this case, change to mirror mode.

- | Do not let passengers stare at the displayed image when the vehicle is being driven, as doing so may cause motion sickness.

n When the system malfunctions

If the symbol shown in the illustration is displayed when using the Digital Rear-view Mirror in digital mirror mode, the system may be malfunctioning. The symbol will disappear in a few seconds. Operate the lever, change to mirror mode and have the vehicle inspected by your Toyota dealer.




Adjusting the mirror

n Adjusting the mirror height

The height of the rear view mirror can be adjusted to suit your driving posture.

Change to mirror mode, adjusting the height of the rear view mirror by moving it up and down.




n Display settings (digital mirror mode)

Settings of the display in the digital mirror mode, on/off operation of the automatic anti-glare function, etc. can be changed.

1 Press the menu button.

The icons will be displayed.



2 Press the menu button repeatedly and select the item you want to adjust.

3 Press  or  to change the setting.

The icons will disappear if a button is not operated for approximately 5 seconds or more.

Icons	Settings
	Select to adjust the brightness of the display.
	Select to adjust the area displayed up/down.
	Select to adjust the area displayed to the left/right.
	Select to adjust the angle of the displayed image.  : The area moves one phase clockwise by 1 push  : The area moves one phase counter clockwise by 1 push

Icons	Settings
	Select to zoom in/out the displayed image.
	Select to enable/disable the automatic anti-glare function.* Responding to the brightness of the headlights of vehicles behind, the reflected light is automatically adjusted. The automatic anti-glare function is enabled each time the power switch is changed to ON.
	Select to display HomeLink® Training Tutorial to assist customers to train their Garage Door Opener System. (→P.500)
	Select to change the language of the Homelink® Training Tutorial.

*: This is a function for the mirror mode, however, the setting can also be changed while using the digital mirror mode.

n Enabling/disabling the automatic anti-glare function (mirror mode)

The automatic anti-glare function in the mirror mode can be enabled/disabled. The setting can be changed in both the digital mirror mode and the mirror

mode.


► When using the digital mirror mode

→P.192

► When using the mirror mode

1 Press the menu button.

The icons will be displayed.



2 Press  or  to enable ("ON")/disable ("OFF") the automatic anti-glare function.

The icons will disappear if a button is not operated for approximately 5 seconds or more.

n Adjusting the display (digital mirror mode)

| The icons will disappear if a button is not operated for approximately 5 seconds or more.

| If the displayed image is adjusted, it may appear distorted. This is not a malfunction.


| If the brightness of the Digital Rearview Mirror is set too high, it may cause eye strain. Adjust the Digital Rear-view Mirror to an appropriate brightness. If your eyes become tired, change to mirror mode.

| The brightness of the Digital Rear-view Mirror will change automatically according to the brightness of the area in front of your

vehicle.

n To prevent the light sensors from malfunctioning

To prevent the light sensors from malfunctioning, do not touch or cover them.



! WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

n While driving

I Do not adjust the position of the Digital Rear-view Mirror or adjust the display settings while driving.

Stop the vehicle and operate the Digital Rear-view Mirror control switches.

Failure to do so may cause a steering wheel operation error, resulting in an unexpected accident.

I Always pay attention to the vehicle's surroundings.

The size of the vehicles and other objects may look different when in digital mirror mode and mirror mode.

When backing up, make sure to directly check the safety of the area around your vehicle, especially behind the vehicle.

Additionally, if a vehicle approaches from the rear in the dark, such as at night, the surrounding area may appear dim.

n To prevent causes of fire

If the driver continues using the Digital Rear-view Mirror while smoke or odor comes from the mirror, it may result in fire. Stop using the system immediately and contact your Toyota dealer.

Cleaning the Digital Rear-view Mirror


n Cleaning the mirror surface

If the mirror surface is dirty, the image on the display may be difficult to see.

Clean the mirror surface gently using a soft dry cloth.

n The camera

The camera for the Digital Rear-view Mirror is located as shown.



! NOTICE


n To prevent the camera from malfunctioning

I Observe the following precautions, otherwise the Digital Rear-view Mirror may not operate properly.

- Do not strike or hit the camera or subject it to a strong impact, as the camera installation position and angle may be changed because the camera unit is designed to be waterproof.

**NOTICE**

- Do not remove, disassemble or modify the camera.
 - Do not allow an organic solvent, car wax, window cleaner or glass coating to adhere to the camera. If this happens, wipe it off as soon as possible.
 - When cleaning the camera lens, wipe the camera lens with a damp soft cloth. When it is difficult to clean it with a cloth, use a swab. Do not strongly rub the camera lens, as it may be scratched and will not be able to transmit a clear image.
 - When applying colored film (including transparent film) to the rear window glass, do not apply it to the area in front of the camera. If film is applied to the area in front of the camera, the image from the camera may not display properly.
- I Do not subject the camera to a strong impact as this could cause a malfunction. If this happens, have the vehicle inspected by your Toyota dealer as soon as possible.
- I Do not block the vent holes of the mirror. Otherwise, the mirror may be hot, leading to a malfunction or a fire.

**If you notice any symptoms**

If you notice any of the following symptoms, refer to the following

table for the likely cause and the solution.

If the symptom is not resolved by the solution, have the vehicle inspected by your Toyota dealer.

Symptom	Likely cause	Solution
The image is difficult to see.	The mirror surface is dirty.	Clean the mirror surface gently, using a soft dry cloth.
	Sunlight or headlights are shining directly into the Digital Rear-view Mirror.	Change to mirror mode. (If the light is coming through the panoramic moon roof [if equipped], close the sunshade or electronic sunshade.)
	<ul style="list-style-type: none">• The vehicle is in a dark area.• The vehicle is near a TV tower, broadcasting station, electric power plant, or other location where strong radio waves or electrical noise may be present.• The temperature around the camera is extremely high/low.• The ambient temperature is extremely low.• It is raining or humid.• Sunlight or headlights are shining directly into the camera lens.• The vehicle is under fluorescent lights, sodium lights, mercury lights, etc.• Exhaust gas is obstructing the camera.	Change to mirror mode. (Change back to digital mirror mode when the conditions have improved.)

Symptom	Likely cause	Solution
The image is difficult to see.	Foreign matters such as water droplets or dust is on the camera lens.	Have the vehicle inspected by your Toyota dealer.
	The luggage in the luggage compartment is reflected off the rear window glass and obstructing the camera.	<ul style="list-style-type: none">• Change to mirror mode.• Move the luggage to a position where it does not obstruct the camera or cover it with a black cloth to reduce the amount it is reflected off the rear window glass.
	The rear window glass is fogged up.	Change to mirror mode. After defogging the rear window using the rear window defogger (→P.457), use the digital mirror mode again.
	The outside of the rear window glass is dirty.	Use the rear window wiper to remove dirt.
	The inside of the rear window glass is dirty.	Have the vehicle inspected by your Toyota dealer.
The image is out of alignment.	The back door is not fully closed.	Fully close the back door.
	The camera or its surrounding area has received a strong impact.	Change to mirror mode and have the vehicle inspected by your Toyota dealer.
The display is dim and  is displayed.	The system may be malfunctioning.	Change to mirror mode and have the vehicle inspected by your Toyota dealer.
 goes off.		

Symptom	Likely cause	Solution
 is displayed.	<p>The Digital Rear-view Mirror is extremely hot.</p> <p>(The display will gradually become more dim. If the temperature continues to increase, the Digital Rear-view Mirror will turn off.)</p>	<p>Reducing the cabin temperature is recommended to reduce the temperature of the mirror.</p> <p>( will disappear when the mirror becomes cool.)</p> <p>If  does not disappear even though the mirror is cool, have the vehicle inspected by your Toyota dealer.</p>
The lever cannot be operated properly.	The lever may be malfunctioning.	<p>Change to mirror mode and have the vehicle inspected by your Toyota dealer.</p> <p>(To change to mirror mode, press and hold the menu button for approximately 10 seconds.)</p>

Outside rear view mirrors

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

n When using the outside rear view mirrors in a cold weather

When it is cold and the outside rear view mirrors are frozen, it may not be possible to fold/extend them or adjust the mirror surface. Remove the ice, snow, etc. covering the outside rear view mirrors.

! WARNING

n Important points while driving

Observe the following precautions while driving.


Failing to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- I Do not adjust the mirrors while driving.
- I Do not drive with the mirrors folded.
- I Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

Adjustment procedure

► Type A


- 1 To select a mirror to adjust, press the switch.



A Left

B Right

- 2 To adjust the mirror, press the switch.



A Up


B Right

C Down

D Left

► Type B

- 1 When selecting the mirror to adjust, the indicator on the switch illuminates.




A Left

B Right

Pressing the same switch again will put the switch in neutral.

- 2 To adjust the mirror, press the switch.



A Up

B Right

C Down

D Left

n Mirror angle can be adjusted when

The power switch is in ACC or ON.

n Defogging the mirrors

The outside rear view mirrors can be cleared using the mirror defog-

gers. Turn on the rear window defogger to turn on the outside rear view mirror defoggers. (→P.457)

n Automatic adjustment of the mirror angle (if equipped)


A desired mirror face angle can be entered to memory and recalled automatically by the driving position memory. (→P.206)

! WARNING

n When the mirror defoggers are operating

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

Folding and extending the mirrors (Type A)



1 Extends the mirrors

2 Folds the mirrors

Putting the outside rear view mirror folding switch in the neutral position sets the mirrors to automatic mode.


Automatic mode allows the folding or extending of the mirrors to be linked to locking/unlocking of the doors.

Folding and extending the mirrors (Type B)

n Using the switch

Press the switch to fold the mirrors.

Press it again to extend them to the original position.




n Setting automatic mode

Press the "AUTO" switch to set automatic mode.

When in automatic mode, the indicator **A** will come on.

Automatic mode allows the folding or extending of the mirrors to be linked to locking/unlocking of the doors.

Pressing the switch once more will return to manual mode.



n When disconnecting and reconnecting 12-volt battery terminals

The automatic folding/extending mirror function will return to off as default. To turn the function on, press the switch again to select on.

n Customization

Some functions can be customized. (→P.627)

! WARNING

n When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

Linked mirror function when reversing (if equipped)

When the mirror select switch is in the "L" or "R" position, the outside rear view mirrors will automatically angle downwards when the vehicle is reversing in order to give a better view of the ground.

To disable this function, move the mirror select switch to the neutral position (between "L" and "R").

n Adjusting the mirror angle when the vehicle is reversing

With the shift position in R, adjust the mirror angle at a desired position.

The adjusted angle will be mem-

orized and the mirror will automatically tilt to the memorized angle whenever the shift position is shifted to R from next time.

The memorized downward tilt position of the mirror is linked to the normal position (angle adjusted with the shift position in other than R). Therefore, if the normal position is changed after adjustment, the tilt position will also change.


When the normal position is changed, readjust the angle in reversing.

Power windows

Opening and closing the power windows

The power windows can be opened and closed using the switches.

Operating the switch moves the windows as follows:



- 1 Closing
- 2 One-touch closing*
- 3 Opening
- 4 One-touch opening*

*: To stop the window partway, operate the switch in the opposite direction.

n The power windows can be operated when

The power switch is in ON.

n Operating the power windows after turning the EV system off

The power windows can be operated for approximately 45 seconds even after the power switch is turned to ACC or turned off. They cannot, however, be operated once either front door is opened.

n Jam protection function

If an object becomes jammed between the window and the win-

dow frame while the window is closing, window movement is stopped and the window is opened slightly.

n Catch protection function

If an object becomes caught between the door and window while the window is opening, window movement is stopped.

n When the window cannot be opened or closed

When the jam protection function or catch protection function operates unusually and the door window cannot be opened or closed, perform the following operations with the power window switch of that door.

- 1 Stop the vehicle. With the power switch in ON, within 4 seconds of the jam protection function or catch protection function activating, continuously operate the power window switch in the one-touch closing direction or one-touch opening direction so that the door window can be opened and closed.

- 2 If the door window cannot be opened and closed even when performing the above operations, perform the following procedure for function initialization.

- 1 Turn the power switch to ON.
- 2 Pull and hold the power window switch in the one-touch closing direction and completely close the door window.
- 3 Release the power window switch for a moment, resume pulling the switch in the one-touch closing direction, and hold it there for approximately 6 seconds or more.
- 4 Press and hold the power window switch in the one-touch opening direction. After the door window is completely opened, continue holding the switch for an additional 1 second or more.
- 5 Release the power window switch for a moment, resume

pushing the switch in the one-touch opening direction, and hold it there for approximately 4 seconds or more.

- 6 Pull and hold the power window switch in the one-touch closing direction again. After the door window is completely closed, continue holding the switch for a further 1 second or more.

If you release the switch while the window is moving, start again from the beginning.

If the window reverses and cannot be fully closed or opened, have the vehicle inspected by your Toyota dealer.

n **Door lock linked window operation**

- | The power windows can be opened and closed using the mechanical key.* (→P.598)
- | The power windows can be opened using the wireless remote control.* (→P.157)
- | The alarm may be triggered if the alarm is set and the power window is closed using the door lock linked power window operation function. (→P.67)

*: These settings must be customized at your Toyota dealer.

n **Power windows open reminder function**

A buzzer sounds and a message is shown on the multi-information display in the instrument cluster when the power switch is turned off and the driver's door is opened with the power windows open.

n **Customization**

Some functions can be customized. (→P.627)


⚠ WARNING

Observe the following precautions.

Failing to do so may result in death or serious injury.

n **Closing the windows**

- | The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch. (→P.205)
- | Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.



- | When using the wireless remote control or mechanical key and operating the power windows, operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window. Also do not let a child operate window by the wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the power window.

WARNING

I When exiting the vehicle, turn the power switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

n Jam protection function

I Never use any part of your body to intentionally activate the jam protection function.


I The jam protection function may not work if something gets jammed just before the window is fully closed. Be careful not to get any part of your body jammed in the window.

n Catch protection function

I Never use any part of your body or clothing to intentionally activate the catch protection function.

I The catch protection function may not work if something gets caught just before the window is fully opened. Be careful not to get any part of your body or clothing caught in the window.

opened and closed using the driver's switch even if the lock switch is on.



n The power windows can be operated when

The power switch is in ON.

n When the 12-volt battery is disconnected

The window lock switch is disabled. If necessary, press the window lock switch after reconnecting the 12-volt battery.

Preventing accidental operation (window lock switch)

This function can be used to prevent children from accidentally opening or closing a passenger window.

Press the switch.

The indicator **A** will come on and the passenger windows will be locked.

The passenger windows can still be

Driving position memory*

*: If equipped

This feature automatically adjusts the positions of the driver's seat and outside rear view mirrors to make entering and exiting the vehicle easier or to suit your preferences.

Driving positions can be recorded for 3 drivers that has been registered for My Settings.

When electronic key assignment is registered for My Settings, the driving position for each driver can be recalled (memory recall function).


For details about My Settings, refer to P.209.

Enabling easier driver entry and exit (power easy access system)

When all of the following have been performed, the driver's seat is automatically adjusted to a position that allows driver to enter and exit the vehicle easily.

- The shift position has been shifted to P.
- The power switch has been turned to OFF.
- The driver's seat belt has

been unfastened.



When any of the following has been performed, the driver's seat automatically return to its original position.

- The power switch has been turned to ACC or ON.
- The driver's seat belt has been fastened.

n Operation of the power easy access system

When exiting the vehicle, the power easy access system may not operate if the seat is already close to the rearmost position, etc.

n Customization

The seat movement amount settings of the power easy access system can be customized. (→P.627)

⚠ WARNING


n While the power easy access system is operating and the steering wheel and seat is moving

Be careful not to get body parts or luggage caught. Failure to do so may cause an injury or damage to the luggage.

Recording a driving position into memory button

- 1 Check that the shift position is in P.
- 2 Turn the power switch to ON.
- 3 Adjust the driver's seat and outside rear view mirrors to the desired positions.
- 4 While pressing the "SET" button, or within 3 seconds after the "SET" button is pressed, press button "1" or "2" until the buzzer sounds.

If the selected button has already been preset, the previously recorded position will be overwritten.



n Seat position that can be memorized (→P.181)

The adjusted positions other than the position adjusted by lumbar support switch can be recorded.

n In order to correctly use the driving position memory function

If a seat position is already in the furthest possible position and the seat is operated in the same direction, the recorded position may be slightly different when it is recalled.


⚠ WARNING

n Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel.

Recalling a driving position

- 1 Check that the shift position is in P.
- 2 Turn the power switch to ON.
- 3 Press one of the buttons for the driving position you want to recall until the buzzer sounds.



n To stop the position recall operation part-way through

Perform any of the following operations:

- l Press the "SET" button.
- l Press button "1" or "2".
- l Operate any of the seat adjustment switches.

n Using the voice control system*

*: If equipped

The following operations can be performed using the voice control system:

- | Driving position registration
- | Driving position recall (only when the shift position is in P)

For details, refer to the “MULTIMEDIA OWNER’S MANUAL”

n Operating the driving position memory after turning the power switch off

Recorded seat positions can be activated up to 180 seconds after the driver's door is opened and another 60 seconds after it is closed again.

n When recalling the driving position

Take care so that a head restraint does not contact the ceiling or a sun visor.

n If the 12-volt battery is disconnected

The memorized positions are erased

n When the recorded seat position cannot be recalled

The seat position may not be recalled in some situations when the seat position is recorded in a certain range. For details, contact your Toyota dealer.

n Jam protection function

While the driving position is recalled or the power easy access system is operating, if an object is stuck behind the front seat, the front seat will stop and then slightly move forward. When the jam protection function operates, the seat stops at a position other than the set seat position. Check the seat position.

Recalling a driving position automatically when getting in the vehicle (memory recall function) (driver's seat only)

n When an individual is identified using My Settings:

The driving positions can be automatically recalled for each driver registered in My Settings. (→P.210)

● Driving position registration procedure

When the shift position is shifted to P after driving the vehicle, the current driving position will be recorded.

● Driving position recall procedure

- 1 Carry only the key that has been assigned and registered in My Settings, and then unlock and open the driver's door using the smart key system or wireless remote control.

The driving position will move to the recorded position. If the driving position is in a position that has already been recorded, the seat will not move.

- 2 Turn the power switch to ACC or ON.

The seat will move to the recorded position.

● Memory recall function cancelation procedure

How to cancel the memory call

function varies depending on the authentication device.

For details, refer to the “MULTIMEDIA OWNER’S MANUAL”.

n Recalling the driving position using the memory recall function

- | The timing of operation may differ depending on the device used to identify an individual.
- | As a driving position can be registered to each electronic key, if 2 or more keys are carried, the recall driving position may differ.

My Settings

Drivers are identified using devices such as electronic keys to store the driving position and vehicle settings for each. Then the information can be recalled the next time the vehicle is driven.

Authentication devices can be assigned in advance to drivers so that they can drive using their preferred settings.

Settings for 3 drivers can be stored in My Settings.

For information on authentication devices registration/deletion, changing the driver’s name, initializing driver registered settings, manually switching drivers and deleting drivers registration, refer to the “MULTIMEDIA OWNER’S MANUAL”.

Types of assigned authentication devices

An individual can be identified using the following authentication devices:

- **Electronic key**

An individual is identified when the smart key system detects their electronic key.

- Face identification

Individuals are identified by detecting the face from the driver monitor.

- Bluetooth® devices

An individual can be identified if the same Bluetooth® device that was used as a hands-free phone the last time the vehicle was entered is connected to the multimedia system.

For information on how to connect Bluetooth® devices, refer to the "MULTIMEDIA OWNER'S MANUAL".

If an individual is identified by detecting an electronic key, identification by Bluetooth® device will not be performed.

When an individual is identified, the vehicle settings used when the power switch was last turned off are recalled.

- Safe driving support function*2

When an individual is identified, the vehicle settings used when the power switch was last turned off are recalled.

*1: If equipped

*2: Some settings are excluded

Recalled functions

When an individual is identified from an authentication device, settings for the following functions are recalled:

- Driving position (memory recall function)*1

After an individual is identified, the driving position that was set when driving was last completed is recalled when either of the following operations is performed.

Identification using electronic key:
The driver's door is unlocked and opened using the smart key system or wireless remote control.

- Vehicle settings that can be set using the multimedia display*2

5-1. Before driving

Driving the vehicle.....	213
Cargo and luggage	219
Vehicle load limits	222
Trailer towing.....	223
Dinghy towing	233

5-2. Driving procedures

Power (ignition) switch	234
Shift position	238
Turn signal lever.....	244
Parking brake	245
Brake Hold	249

5-3. Operating the lights and wipers

Headlight switch	251
AHB (Automatic High Beam).....	253
Windshield wipers and washer.....	256
Rear window wiper and washer.....	259
Headlight cleaner switch	260

5-4. Using the driving support systems

Toyota Safety Sense 3.0/Traffic Jam Assist software update	261
Toyota Safety Sense 3.0	263

Driver monitor.....	271
PCS (Pre-Collision System)	273
LTA (Lane Tracing Assist)	285
LCA (Lane Change Assist)	290
LDA (Lane Departure Alert)	293
PDA (Proactive driving assist)	300
FCTA (Front Cross Traffic Alert).....	306
RSA (Road Sign Assist)	308
Dynamic radar cruise control	311
Cruise control	322
Emergency Driving Stop System	326
Traffic Jam Assist	329
BSM (Blind Spot Monitor)	335
Safe Exit Assist	340
Intuitive parking assist.	344
RCTA (Rear cross traffic alert) function.....	351
RCD (Rear camera detection)	356
PKSB (Parking Support Brake).....	360

Parking Support Brake function (static objects front and rear of the vehicle) 365

Parking Support Brake function (moving vehicles rear of the vehicle)..... 367

Parking Support Brake function (pedestrians rear of the vehicle)..... 369

Multi-terrain Monitor 371

X-MODE..... 434

Driving assist systems 438

5-5. Driving tips

Winter driving tips 444

Utility vehicle precautions 447

Driving the vehicle

The specified procedures should be observed to ensure safe driving:

Driving procedure

n Before starting the EV system

Check that the charging cable is disconnected. (→P.94, 100)

n Starting the EV system

→P.234

n Driving

- 1 With the brake pedal depressed, shift the shift position to D.

Check that the shift position indicator shows D.

- 2 If the parking brake is set, release the parking brake. (→P.245)

If the parking brake is in automatic mode, the parking brake will be released automatically. (→P.246)

- 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

n Stopping

- 1 Depress the brake pedal.
- 2 If necessary, set the parking brake. (→P.245)

If the vehicle is to be stopped for an extended period of time, shift the shift position to P. (→P.239)

n Parking the vehicle

- 1 Depress the brake pedal to stop the vehicle completely.
- 2 If the parking brake is released, set the parking brake. (→P.245)

Make sure the parking brake indicator light is on.

- 3 Shift the shift position to P. (→P.239)

Check that the shift position indicator shows P and the parking brake indicator is illuminated.

- 4 Press the power switch to stop the EV system.
- 5 Slowly release the brake pedal.
- 6 Lock the door, making sure that you have the electronic key on your person.

If parking on a hill, block the wheels as needed.

n Starting off on a steep uphill

- 1 Firmly depress the brake pedal and shift the shift position to D.

The hill-start assist control will be activated.

- 2 Set the parking brake. (→P.245)
- 3 Release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.
- 4 Release the parking brake. (→P.245)

n Driving in the rain

- | Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- | Drive carefully when it starts to rain, because the road surface will be especially slippery.
- | Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

n Restraining the EV system output (Brake Override System)

- | When the accelerator and brake pedals are depressed at the same time, the EV system output may be restrained.
- | A warning message is displayed on the multi-information display while the system is operating.

n Breaking in your new Toyota

To extend the life of the vehicle, observing the following precautions is recommended:

- | For the first 200 miles (300 km):
Avoid sudden stops.
- | For the first 500 miles (800 km):
Do not tow a trailer.
- | For the first 1000 miles (1600 km):
 - Do not drive at extremely high speeds.
 - Avoid sudden acceleration.
 - Do not drive at a constant speed for extended periods.



WARNING

Observe the following precautions.
Failure to do so may result in death or serious injury.

n When starting the vehicle

Always keep your foot on the brake pedal while stopped with the “READY” indicator is illuminated. This prevents the vehicle from creeping.

n When driving the vehicle

- | Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
- Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident.
- When backing up, you may twist your body around, leading to difficulty in operating the pedals. Make sure to operate the pedals properly.
- Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
- Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- | The driver should pay extra attention to pedestrians. As there is no engine noise, the pedestrians may misjudge the vehicle's movement. Even though the vehicle is equipped with the Acoustic Vehicle Alerting System, drive with care as pedestrians in the vicinity may still not notice the vehicle if the surrounding area is noisy.

**WARNING**

- I During normal driving, do not turn off the EV system. Turning the EV system off while driving will not cause loss of steering or braking control, however, power assist to the steering will be lost. This will make it more difficult to steer smoothly, so you should pull over and stop the vehicle as soon as it is safe to do so. In the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: →P.560
- I Use regenerative braking to maintain a safe speed when driving down a steep hill. Using the brakes continuously may cause the brakes to over-heat and lose effectiveness. (→P.238)
- I If “Regenerative braking limited. Press brake to decelerate.” appears on the multi-information display, firmly depress the brake pedal to decelerate the vehicle. (→P.578)
- I Do not adjust the positions of the steering wheel, the seat, or the inside or outside rear view mirrors while driving. Doing so may result in a loss of vehicle control.
- I Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle.
- I Do not drive the vehicle off-road. This is not a AWD vehicle designed for off-road driving. Proceed with all due caution if it becomes unavoidable to drive off-road.

I Do not drive across a river or through other bodies of water. This may cause electric/electronic components to short circuit, damage the EV system or cause other serious damage to the vehicle.

I Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has high-speed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.

n When driving on slippery road surfaces

- I Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle.
- I Sudden acceleration or regenerative braking due to shift changing could cause the vehicle to skid, resulting in an accident.
- I After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected.

**WARNING****n When shifting the shift position**

| Do not let the vehicle roll backward while a forward driving position is selected, or roll forward while the shift position is in R. Doing so may result in an accident or damage to the vehicle.

| Do not shift the shift position to P while the vehicle is moving. Doing so can damage the transmission and may result in a loss of vehicle control.

| Do not shift the shift position to R while the vehicle is moving forward. Doing so can damage the transmission and may result in a loss of vehicle control.

| Do not shift the shift position to a driving position while the vehicle is moving backward. Doing so can damage the transmission and may result in a loss of vehicle control.

| Changing the shift position to N while the vehicle is moving will disengage the EV system. Regenerative braking is not available with the EV system disengaged.

| Be careful not to change the shift position with the accelerator pedal depressed. Changing the shift position to any positions other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury. After changing the shift position, make sure to confirm the current shift position displayed on the shift position indicator inside the meter.

n If you hear a squealing or scraping noise (brake pad wear limit indicators)

Have the brake pads checked and replaced by your Toyota dealer as soon as possible.

Rotor damage may result if the pads are not replaced when needed.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

n When the vehicle is stopped

| Do not depress the accelerator pedal unnecessarily.

If the shift position is in any position other than P or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.

| In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while stopped with the "READY" indicator is illuminated, and apply the parking brake as necessary.

| If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.

n When the vehicle is parked

| Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.

Doing so may result in the following:

- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.

**WARNING**

- The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
 - Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- I** Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such as the glove box or on the floor, it may be lit accidentally when luggage is loaded or the seat is adjusted, causing a fire.
- I** Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle.
- I** Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
- I** Always apply the parking brake, shift the shift position to P, stop the EV system and lock the vehicle.
Do not leave the vehicle unattended while the "READY" indicator is illuminated.
If the vehicle is parked with the shift position in P but the parking brake is not set, the vehicle may start to move, possibly leading to an accident.

n When taking a nap in the vehicle

Always turn the EV system off. Otherwise, you may accidentally move the shift position or depress the accelerator pedal, causing the vehicle to unintentionally move, which can lead to an accident, resulting in death or serious injury.

n When braking

I When the brakes are wet, drive more cautiously.
Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle.

I If the electronically controlled brake system does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking.
In this case, braking is still possible, but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately.

I The brake system consists of 2 or more individual hydraulic systems; if one of the systems fails, the other(s) will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase. Have your brakes fixed immediately.

n If the vehicle becomes stuck

Do not spin the wheels excessively when any of the tires is up in the air, or the vehicle is stuck in sand, mud, etc. This may damage the driveline components or propel the vehicle forward or backward, causing an accident.



NOTICE

n When driving the vehicle

- I** Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain the EV system output.
- I** Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

n Avoiding damage to vehicle parts

- I** Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.
Doing so may damage the power steering.
- I** When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

n If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- I** It may be difficult to control your vehicle.
- I** The vehicle will make abnormal sounds or vibrations.
- I** The vehicle will lean abnormally.

Information on what to do in case of a flat tire (→P.585)

n When encountering flooded roads

Do not drive on a road that has flooded after heavy rain, etc. Doing so may cause the following serious damage to the vehicle:

- I** Short in electrical components
- I** Traction battery damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Toyota dealer check the following:

- I** Brake function
- I** Changes in quantity and quality of transmission fluid, etc.
- I** Lubricant condition for the bearings and suspension joints (where possible), and the function of all joints, bearings, etc.
- I** Components connected to the traction battery.

If the shift control system is damaged by flooding, it may not be possible to shift the shift position to P, or from P to other positions. In this case, contact your Toyota dealer.

n When parking the vehicle

Always set the parking brake, and shift the shift position to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

n When involved in a minor accident

Damage to the traction battery or battery peripheral components could cause malfunctions. Even if it is a minor accident, have the vehicle inspected at a Toyota dealer.

Sudden start restraint control (Drive-Start Control [DSC])

When the following unusual operation is performed with the accelerator pedal depressed, the EV system output may be restrained.

- When the shift position to R*.
- When the shift position is shifted from P or R to forward drive shift position such as D*.

When the system operates, a message appears on the multi-information display. Read the message and follow the instruction.

*: Depending on the situation, the shift position may not be changed.

n Drive-Start Control (DSC)

- I When the TRAC is turned off (→P.440), sudden start restraint control also does not operate. If your vehicle have trouble escaping from the mud or fresh snow due to sudden start restraint control operation, deactivate TRAC (→P.440) so that the vehicle may become able to escape from the mud or fresh snow. Also, sudden start restraint control will not operate in the following conditions:
When "X-MODE" is selected

Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load:

Capacity and distribution

Cargo capacity depends on the total weight of the occupants.

(Cargo capacity) = (Total load capacity) — (Total weight of occupants)

Steps for Determining Correct Load Limit —

(1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.

(2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.

(3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.

(4) The resulting figure equals the available amount of cargo and luggage load capacity.


For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1400 –

750 (5 × 150) = 650 lbs.)

(5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

(6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle. (→P.222)

Calculation formula for your vehicle



A Cargo capacity

B Total load capacity (vehicle capacity weight) (→P.610)

When 2 people with the combined weight of A lb. (kg) are riding in your vehicle, which has a total load capacity (vehicle capacity weight) of B lb. (kg), the available amount of cargo and luggage load capacity will

be C lb. (kg) as follows:

$$B^{*2} \text{ lb. (kg)} - A^{*1} \text{ lb. (kg)} = C^{*3} \text{ lb. (kg)}$$

^{*1}: A = Weight of people

^{*2}: B = Total load capacity

^{*3}: C = Available cargo and luggage load

In this condition, if 3 more passengers with the combined weight of D lb. (kg) get on, the available cargo and luggage load will be reduced E lb. (kg) as follows:

$$C \text{ lb. (kg)} - D^{*4} \text{ lb. (kg)} = E^{*5} \text{ lb. (kg)}$$

^{*4}: D = Additional weight of people

^{*5}: E = Available cargo and luggage load

As shown in the example above, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.

**WARNING**

n Things that must not be carried in the luggage compartment

The following things may cause a fire if loaded in the luggage compartment:

- I Receptacles containing gasoline
- I Aerosol cans

n Storage precautions

Observe the following precautions.

Failure to do so may prevent the pedals from being depressed properly, may block the driver's vision, or may result in items hitting the driver or passengers, possibly causing an accident.

- I Stow cargo and luggage in the luggage compartment whenever possible.
- I Do not stack cargo and luggage in the luggage compartment higher than the seatbacks.
- I When you fold down the rear seats, long items should not be placed directly behind the front seats.
- I Never allow anyone to ride in the luggage compartment. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened.
- I Do not place cargo or luggage in or on the following locations.
 - At the feet of the driver
 - On the front passenger or rear seats (when stacking items)
 - On the luggage cover
 - On the instrument panel

- On the dashboard
- In front of the instrument cluster
- I Secure all items in the occupant compartment.

n Capacity and distribution

- I Do not exceed the maximum axle weight rating or the total vehicle weight rating.
- I Even if the total load of occupant's weight and the cargo load is less than the total load capacity, do not apply the load unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

n When using a roof luggage carrier

Observe the following precautions:

- I Place the cargo so that its weight is distributed evenly between the front and rear axles.
- I If loading long or wide cargo, never exceed the vehicle overall length or width. (→P.610)
- I Before driving, make sure the cargo is securely fastened on the roof luggage carrier.
- I Loading cargo on the roof luggage carrier will make the center of gravity of the vehicle higher. Avoid high speeds, sudden starts, sharp turns, sudden braking or abrupt maneuvers, otherwise it may result in loss of control or vehicle rollover due to failure to operate this vehicle correctly and result in death or serious injury.

**WARNING**

- I If driving for a long distance, on rough roads, or at high speeds, stop the vehicle now and then during the trip to make sure the cargo remains in its place.
- I Do not exceed 165 lb. (75 kg) cargo weight on the roof luggage carrier.

**NOTICE**

- n **When loading cargo (vehicles with panoramic moon roof)**

Be careful not to scratch the surface of the panoramic moon roof.

Vehicle load limits

Vehicle load limits include total load capacity, seating capacity, TWR (Trailer Weight Rating) and cargo capacity.

- Total load capacity (vehicle capacity weight): →P.610

Total load capacity means the combined weight of occupants, cargo and luggage.

- Seating capacity:→P.610

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

- TWR (Trailer Weight Rating): →P.228, 610

TWR means the maximum gross trailer weight (trailer weight plus its cargo weight) that your vehicle is able to tow.

- Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

- n **Total load capacity and seating capacity**

These details are also described on the tire and loading information label. (→P.547)

**WARNING****n Overloading the vehicle**

Do not overload the vehicle. It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.

Trailer towing

Your vehicle is designed primarily as a passenger-and-load-carrying vehicle. Towing a trailer can have an adverse impact on handling, performance, braking, durability, and electricity consumption. For your safety and the safety of others, you must not overload your vehicle or trailer. You must also ensure that you are using appropriate towing equipment, that the towing equipment has been installed correctly and used properly, and that you employ the requisite driving habits.

Vehicle-trailer stability and braking performance are affected by trailer stability, brake performance and setting, trailer brakes, the hitch and hitch systems (if equipped).


To tow a trailer safely, use extreme care and drive the vehicle in accordance with your trailer's characteristics and operating conditions.

Toyota warranties do not apply to damage or malfunction caused by towing a trailer for commercial purposes.

Contact your Toyota dealer for further information about additional requirements such as a towing kit, etc.

n Matching trailer ball height to trailer coupler height

No matter which class of tow hitch applies, for a more safe trailer hookup, the trailer ball setup must be the proper height for the coupler on the trailer.



A Coupler

B Trailer ball

n Before towing

Check that the following conditions are met:

- | Ensure that your vehicle's tires are properly inflated. (→P.615)
- | Trailer tires are inflated according to the trailer manufacturer's recommendation.

- | All trailer lights work as required by law.
- | All lights work each time you connect them.
- | The trailer ball is set at the proper height for the coupler on the trailer.
- | The trailer is level when it is hitched.
Do not drive if the trailer is not level, and check for improper tongue weight, overloading, worn suspension, or other possible causes.
- | The trailer cargo is securely loaded.
- | The rear view mirrors conform to all applicable federal, state/provincial or local regulations. If they do not, install rear view mirrors appropriate for towing purposes.

n When towing a trailer

Disable the following systems, as the systems may not operate properly.

- | LTA (Lane Tracing Assist) (→P.285)
- | LCA (Lane Change Assist) (if equipped) (→P.290)
- | LDA (Lane Departure Alert) (→P.293)
- | Dynamic radar cruise control (→P.311)
- | Cruise control (→P.322)
- | BSM (Blind Spot Monitor) (→P.335)
- | Intuitive parking assist (→P.344)
- | RCTA (Rear Cross Traffic Alert) function (→P.351)
- | RCD (Rear Camera Detection) function (→P.356)
- | PKSB (Parking Support Brake) (→P.360)

n Break-in schedule

If your vehicle is new or equipped with any new power train compo-

nents (such as an electric motor [traction motor], transaxle or wheel bearing), Toyota recommends that you do not tow a trailer until the vehicle has been driven for over 500 miles (800 km).

After the vehicle has been driven for over 500 miles (800 km), you can start towing. However, for the next 500 miles (800 km), drive the vehicle at a speed of less than 50 mph (80 km/h) when towing a trailer, and avoid full throttle acceleration.

n Maintenance

| If you tow a trailer, your vehicle will require more frequent maintenance due to the additional load. (See “Scheduled Maintenance Guide” or “Owner’s Manual Supplement”.)

| Retighten the fixing bolts of the towing ball and bracket after approximately 600 miles (1000 km) of trailer towing.

n If trailer sway occurs

One or more factors (crosswinds, passing vehicles, rough roads, etc.) can adversely affect handling of your vehicle and trailer, causing instability.

- | If trailer swaying occurs:
 - Firmly grip the steering wheel. Steer straight ahead. Do not try to control trailer swaying by turning the steering wheel.
 - Begin releasing the accelerator pedal immediately but very gradually to reduce speed. Do not increase speed. Do not apply vehicle brakes.

If you make no extreme correction with the steering or brakes, your vehicle and trailer should stabilize. (if enabled, Trailer Sway Control can also help to stabilize the vehicle and trailer.)

- | After the trailer swaying has stopped:
 - Stop in a safe place. Get all occupants out of the vehicle.

- Check the tires of the vehicle and the trailer.
- Check the load in the trailer. Make sure the load has not shifted. Make sure the tongue weight is appropriate, if possible.
- Check the load in the vehicle. Make sure the vehicle is not overloaded after occupants get in.

If you cannot find any problems, the speed at which trailer swaying occurred is beyond the limit of your particular vehicle-trailer combination. Drive at a lower speed to prevent instability. Remember that swaying of the towing vehicle-trailer increases as speed increases.



WARNING

n Trailer towing precautions

To tow a trailer safely, use extreme care and drive the vehicle in accordance with the trailer’s characteristics and operating conditions. Failure to do so could cause an accident resulting in death or serious injury. Vehicle stability and braking performance are affected by trailer stability, brake setting and performance, and the hitch. Your vehicle will handle differently when towing a trailer.

n To avoid accident or injury

- | Do not exceed the TWR, unbraked TWR, GCWR, GVWR or GAWR.
- | If the gross trailer weight is over 2000 lb. (907 kg), a sway control device with sufficient capacity is required.
- | Adjust the tongue weight within the appropriate range. Place heavier loads as close to the trailer axle as possible.

**WARNING**

- I Do not exceed 65 mph (104 km/h), the posted towing speed limit or the speed limit for your trailer as set forth in your trailer owner's manual, whichever is lowest. Slow down sufficiently before making a turn, in cross winds, on wet or slippery surface, etc. to help avoid an accident. If you experience a vehicle-trailer instability from reducing a certain speed, slow down and make sure you keep your vehicle speed under the speed of which you experience the instability.
- I Do not make jerky, abrupt or sharp turns.
- I Do not apply the brakes suddenly as you may skid, resulting in jackknifing and loss of vehicle control. This is especially true on wet or slippery surfaces.
- I Do not exceed the trailer hitch assembly weight, gross vehicle weight, gross axle weight and trailer tongue weight capacities.
- I Slow down and downshift before descending steep or long downhill grades. Do not make sudden downshifts while descending steep or long downhill grades.
- I Vehicle-trailer instability is more likely on steep long downhills. Before descending steep or long downhill grades, slow down and downshift. Do not make sudden downshifts when descending steep or long downhill grades. Avoid holding the brake pedal down too long or applying the brakes too frequently. This could cause the brakes to overheat and result in reduced braking efficiency.

- I Do not tow the vehicle when the tire installed is repaired with the emergency tire puncture repair kit.

n When towing a trailer

Toyota recommends trailers with brakes that conform to any applicable federal and state/provincial regulations.

- I If the gross trailer weight exceeds unbraked TWR, trailer brakes are required. Toyota recommends trailers with brakes that conform to all applicable federal and state/provincial regulations.
- I Never tap into your vehicle's hydraulic system, as this will lower the vehicle's braking effectiveness.
- I Never tow a trailer without using a safety chain securely attached to both the trailer and the vehicle. If damage occurs to the coupling unit or hitch ball, there is danger of the trailer wandering into another lane.

**NOTICE****n When installing a trailer hitch**

Use only the position recommended by your Toyota dealer. Do not install the trailer hitch on the bumper; this may cause body damage.


n Do not directly splice trailer lights

Do not directly splice trailer lights. Directly splicing trailer lights may damage your vehicle's electrical system and cause a malfunction.

Towing related terms


n GCWR (Gross Combination Weight Rating)

The maximum allowable gross combination weight. The gross combination weight is the sum of the total vehicle weight (including the occupants, cargo and any optional equipment installed on the vehicle) and the weight of the trailer being towed (including the cargo in the trailer).




n GVWR (Gross Vehicle Weight Rating)

The maximum allowable gross vehicle weight. The gross vehicle weight is the total weight of the vehicle. When towing a trailer, it is the sum of the vehicle weight (including the occupants, cargo and any optional equipment installed on the vehicle) and the tongue weight.



n GAWR (Gross Axle Weight Rating)

The maximum allowable gross axle weight. The gross axle weight is the load placed on each axle (front and rear).



A Front GAWR

B Rear GAWR

n TWR (Trailer Weight Rating)


The maximum allowable gross trailer weight. The gross trailer weight is the sum of the trailer weight and the weight of the cargo in the trailer.

TWR is calculated assuming base vehicle with one driver, one front passenger, towing

package (if available), hitch and hitch systems (if required).

Additional optional equipment, passengers and cargo in the vehicle will reduce the trailer weight rating so as not to exceed GCWR, GVWR and GAWR.


If the gross trailer weight exceeds 3000 lb. (1360 kg), it is recommended to use a trailer with 2 or more axles.



A With brakes

n **Unbraked TWR (Unbraked Trailer Weight Rating)**


The trailer weight rating for towing a trailer without a trailer service brake system.



A Without brakes

n **Tongue Weight**

The load placed on the trailer hitch ball. (→P.229)



Weight limits

- The gross trailer weight must never exceed 3500 lb. (1500 kg).
- The gross combination weight must never exceed 8575 lb. (3890 kg).
- The gross vehicle weight must never exceed the GVWR indicated on the Certification Label. (→P.610)
- The gross axle weight on each axle must never exceed the GAWR indicated on the Certification Label. (→P.610)
- If the gross trailer weight is over the unbraked TWR, trailer service brakes are required.
- If the gross trailer weight is over 2000 lb. (907 kg), a sway control device with sufficient capacity is required.

GCWR, TWR and Unbraked TWR

Confirm that the gross trailer weight, gross combination

weight, gross vehicle weight, gross axle weight and tongue weight are all within the limits.

n **GCWR***

8575 lbs (3890 kg)

n **TWR***

3500 lb. (1500 kg)

n **Unbraked TWR***

1500 lb. (750 kg)

*: This models meet the tow-vehicle trailering requirement of SAE International per SAE J2807.


Trailer Tongue Weight

- A recommended tongue weight varies in accordance with the types of trailers or towing as described below.
- To ensure the recommended values shown below, the trailer must be loaded by referring to the following instructions.
- Tongue Weight

The gross trailer weight should be distributed so that the tongue weight is 9% to 11%.

(Tongue weight/Gross trailer weight x 100 = 9% to 11%)

The gross trailer weight, gross axle weight and tongue weight can be measured with platform scales found at a highway weighing station, building supply company, trucking company, junk yard, etc.



A Gross trailer weight

B Tongue weight

Hitch

Trailer hitch assemblies have different weight capacities. Toyota recommends the use of Toyota hitch/bracket for your vehicle. For details, contact your Toyota dealer.

- If you wish to install a trailer hitch, contact your Toyota dealer.
- Use only a hitch that conforms to the gross trailer weight requirement of your vehicle.
- Follow the directions supplied by the hitch manufacturer.
- Lubricate the hitch ball with a light coating of grease.
- Remove the hitch ball whenever you are not towing a trailer. Remove the trailer hitch if you do not need it. After removing the hitch, seal any mounting hole in the vehicle body to prevent entry of any substances into the vehi-

cle.

⚠ WARNING


n Hitches

Trailer hitch assemblies have different weight capacities established by the hitch manufacturer. Even though the vehicle may be physically capable of towing a higher weight, the operator must determine the maximum weight rating of the particular hitch assembly and never exceed the maximum weight rating specified for the trailer-hitch. Exceeding the maximum weight rating set by the trailer-hitch manufacturer can cause an accident resulting in death or serious personal injuries.

Selecting trailer ball

Use the correct trailer ball for your application.

Trailer class	Typical trailer ball size
IV	2 5/16 in.
II and III	2 in.
I	1 7/8 in.




- A** Trailer ball load rating
Matches or exceeds the gross trailer weight rating of the trailer.
- B** Ball diameter

Matches the size of the trailer coupler. Most couplers are stamped with the required trailer ball size.

- C** Shank length
Protrudes beyond the bottom of the lock washer and nut by at least 2 threads.
- D** Shank diameter
Matches the ball mount hole diameter size.

Positions for towing hitch receiver and hitch ball



- A** Weight carrying ball position: 47.99 in. (1219 mm)
- B** Hitch receiver pin hole position: 41.61 in. (1057 mm)

Trailer towing tips

Your vehicle will handle differently when towing a trailer. Help to avoid an accident, death or serious injury, keep the following in mind when towing:

- Speed limits for towing a trailer vary by state or province. Do not exceed the posted towing speed limit.
- Toyota recommends that the


vehicle-trailer speed limit is 65 mph (104 km/h) on a flat, straight, dry road. Do not exceed this limit, the posted towing speed limit or the speed limit for your trailer as set forth in your trailer owner's manual, whichever is lowest. Instability of the towing vehicle-trailer combination (trailer sway) increases as speed increases. Exceeding speed limits may cause loss of control.

- Before starting out, check the trailer lights, tires and the vehicle-trailer connections. Recheck after driving a short distance.
- Practice turning, stopping and reversing with the trailer attached in an area away from traffic until you become accustomed to the feel of the vehicle-trailer combination.
- Reversing with a trailer attached is difficult and requires practice. Grip the bottom of the steering wheel and move your hand to the left to move the trailer to the left. Move your hand to the right to move the trailer to right. (This is generally opposite to reversing without a trailer attached.) Avoid sharp or prolonged turning. Have someone guide you when reversing to reduce the risk of an accident.
- As stopping distance is increased when towing a trailer, vehicle-to vehicle distance should be increased. For each 10 mph (16 km/h) of speed, allow at least one vehicle and trailer length.
- Avoid sudden braking as you may skid, resulting in the trailer jackknifing and a loss of vehicle control. This is especially true on wet or slippery surfaces.
- Avoid jerky starts or sudden acceleration.
- Avoid jerky steering and sharp turns, and slow down before making turn.
- Note that when making a turn, the trailer wheels will be closer than the vehicle wheels to the inside of the turn. Compensate by making a wider than normal turning radius.
- Slow down before making a turn, in cross winds, on wet or slippery surfaces, etc. Increasing vehicle speed can destabilize the trailer.
- Take care when passing other vehicles. Passing requires considerable distance. After passing a vehicle, do not forget the length of your trailer, and be sure you have plenty of room before changing lanes.

- Instability happens more frequently when descending steep or long downhill grades. Before descending, slow down and downshift. Do not make sudden downshifts while descending steep or long downhill grades.
- Avoid holding the brake pedal down too long or applying the brakes too frequently. This could cause the brakes to overheat and result in reduced braking efficiency.
- Due to the added load of the trailer, your vehicle's EV system may overheat on hot days (at temperatures over 85°F [30°C]) when driving up a long or steep grade. If the high coolant temperature warning light comes on, it indicates that the EV system is overheating. Immediately turn off the air conditioning (if in use), pull your vehicle off the road and stop in a safe spot. (→P.604)
- Always place wheel blocks under both the vehicle's and the trailer's wheels when parking. Put the transmission in P and apply the parking brake. Avoid parking on a slope, but if unavoidable, do so only after performing the following:
 - 1 Apply the brakes and keep them applied.
 - 2 Have someone place wheel blocks under both the vehicle and trailer wheels.
 - 3 When the wheel blocks are in place, release the brakes slowly until the blocks absorb the load.
 - 4 Apply the parking brake.
 - 5 Shift into P and turn off the EV system.
- When restarting after parking on a slope:
 - 1 With the transmission in the P, start the EV system. Be sure to keep the brake pedal depressed.
 - 2 Shift into a forward gear. If reversing, shift into R.
 - 3 If the parking brake is in manual mode, release the parking brake. (→P.245)
 - 4 Release the brake pedal, and slowly pull or back away from the wheel blocks. Stop and apply the brakes.
 - 5 Have someone retrieve the blocks.

Dinghy towing

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.




NOTICE

n To avoid serious damage to your vehicle

Do not tow your vehicle with 4 wheels on the ground.

n To prevent causing serious damage to the transmission and AWD system

Never tow this vehicle with any of the wheels on the ground. This may cause serious damage to the transmission and AWD system.



Power (ignition) switch

Performing the following operations when carrying the electronic key on your person starts the EV system or changes power switch modes.

Starting the EV system

- 1** Check that the charging cable is disconnected.
(→P.94, 100)
- 2** Pull the parking brake switch to check that the parking brake is set. (→P.245)

The parking brake indicator will come on.

- 3** Firmly depress the brake pedal.

 and a message will be displayed on the multi-information display.

If it is not displayed, the EV system cannot be started.

When the shift position is N, the EV system cannot start. Shift the shift position to P when starting the EV system. (→P.239)

- 4** Press the power switch shortly and firmly.


When operating the power switch, one short, firm press is enough.

It is not necessary to press and hold the switch.

If the “READY” indicator turns on, the EV system will operate normally.

Continue depressing the brake pedal until the “READY” indicator is illuminated.

The EV system can be started from any power switch mode.



- 5** Check that the “READY” indicator is illuminated.

The vehicle cannot be driven if the “READY” indicator is off.

n Power switch illumination

In the following situations, the power switch is illuminated.

- | When the driver's or passenger's door is opened.
- | When the power switch is in ACC or ON.
- | When the power switch mode is changed from ACC or ON to off.

Also, in the following situation, the power switch flashes.

- | When depressing the brake pedal while carrying the electronic key.

n If the EV system does not start

- | The immobilizer system may not have been deactivated. (→P.66) Contact your Toyota dealer.
- | The charging cable may be connected to the vehicle. (→P.91)
- | If a message related to start-up is shown on the multi-information display, read the message and follow the instructions.
- | The smart key system may not be operating properly. (→P.177)

- l If the door is unlocked with the mechanical key, the EV system cannot be started using the smart key system. Refer to P.599 to start the EV system. However, if the electronic key is carried inside the vehicle and the doors are locked (→P.160), the EV system can be started.
- n **When the ambient temperature is low, such as during winter driving conditions**
 - l When starting the EV system, the flashing time of the “READY” indicator may be long. Leave the vehicle as it is until the “READY” indicator is steady on, as steady means the vehicle is able to move.
 - l When the traction battery is extremely cold (below approximately -22°F [-30°C]) under the influence of the outside temperature, it may not be possible to start the EV system. In this case, try to start the EV system again after the temperature of the traction battery increases due to the outside temperature increase, etc.
- n **Sounds and vibrations specific to an electric vehicle**
→P.72
- n **If the 12-volt battery is discharged**
The EV system cannot be started using the smart key system. Refer to P.600 to restart the EV system.
- n **Electronic key battery depletion**
→P.152
- n **Conditions affecting operation**
→P.177
- n **Note for the entry function**
→P.178
- n **If “Smart Key System Malfunction See Owner’s Manual” is displayed on the multi-information display**

The system may be malfunctioning.

Have the vehicle inspected by your Toyota dealer immediately.

n **If the “READY” indicator does not come on**

In the event that the “READY” indicator does not come on even after performing the proper procedures for starting the vehicle, contact your Toyota dealer immediately.

n **If the EV system is malfunctioning**

→P.78

n **Electronic key battery**

→P.553

n **Operation of the power switch**

l If the switch is not pressed shortly and firmly, the power switch mode may not change or the EV system may not start.

l If attempting to restart the EV system immediately after turning the power switch off, the EV system may not start in some cases. After turning the power switch off, please wait a few seconds before restarting the EV system.

n **Customization**

If the smart key system has been deactivated in a customized setting, refer to P.598.

 WARNING

n **When starting the EV system**

Always start the EV system while sitting in the driver’s seat. Do not depress the accelerator pedal while starting the EV system under any circumstances. Doing so may cause an accident resulting in death or serious injury.

**NOTICE****n When starting the EV system**

If the EV system becomes difficult to start, have your vehicle checked by your Toyota dealer immediately.

n Symptoms indicating a malfunction with the power switch

If the power switch seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact your Toyota dealer immediately.

Stopping the EV system

1 Stop the vehicle completely.

2 Set the parking brake.
(→P.245)

3 Press the P position switch.
(→P.239)

Check that the shift position indicator shows P and the parking brake indicator is illuminated.

4 Press the power switch.

The EV system will stop, and the meter display will be extinguished (the shift position indicator will be extinguished a few seconds after the meter display).

5 Release the brake pedal and check that “ACCESSORY” or “POWER ON” is not shown on the meter.

operating for an extended period.

- | The EV system will automatically shut off after approximately 1 hour if it has been left operating while the shift position is in P.
- | The timer for the automatic EV system shut off feature will reset if the brake pedal is depressed or if the shift position is in a position other than P.
- | After the vehicle is parked, if the door is locked with the door lock switch (→P.160) from the inside or the mechanical key (→P.598) from the outside, the automatic EV system shut off feature will be disabled. The timer for the automatic EV system shut off feature will be reenabled if the driver's door is opened.

n When the shift control system malfunctions

If the shift control system is malfunctioning, when attempting to turn the power switch off, it may not be able to be turned off. In this situation, it may be possible to turn the power switch off by applying the parking brake and then operating the power switch.

If there is a malfunction in the system, have the vehicle inspected by your Toyota dealer immediately.

n Automatic P position selection function

→P.241

n Automatic EV system shut off feature

- | The vehicle is equipped with a feature that automatically shuts off the EV system when the shift position is in P with the EV system

! WARNING**n Stopping the EV system in an emergency**

l If you want to stop the EV system in an emergency while driving the vehicle, press and hold the power switch for more than 2 seconds, or press it briefly 3 times or more in succession. (→P.560)


However, do not touch the power switch while driving except in an emergency. Turning the EV system off while driving will not cause loss of steering or braking control, however, power assist to the steering will be lost. This will make it more difficult to steer smoothly, so you should pull over and stop the vehicle as soon as it is safe to do so.

l If the power switch is operated while the vehicle is running, a warning message will be shown on the multi-information display and a buzzer sounds.

l When restarting the EV system after an emergency shutdown, press the power switch shortly and firmly.

Changing power switch modes

Modes can be changed by pressing the power switch with the brake pedal released. (The mode changes each time the switch is pressed.)



A “ACCESSORY”

B “POWER ON”

1 OFF

The emergency flashers can be used.

2 ACC*

Some electrical components such as the audio system can be used. “ACCESSORY” will be displayed on the meter.

3 ON

All electrical components can be used. “POWER ON” will be displayed on the multi-information display.

*: ACC mode can be enabled/disabled on the customize menu. (→P.632)

n When ACC customization is in off

l With the power switch is turned off, the multimedia system can still be used for a certain time until the battery saving function starts operating.

l When the safe exit assist is operating, a buzzer will sound and a voice guidance will be given.

n Auto power off function

If the vehicle is left in ACC for more than a few minutes or ON (the EV system is not operating) for more than 20 minutes with the shift position in P, the power switch will automatically turn off. However, this function cannot entirely prevent the 12-volt battery discharge. Do not leave the vehicle with the power switch in ACC or ON for long periods of time when the EV system is not operating.

 NOTICE

n To prevent 12-volt battery discharge

I Do not leave the power switch in ACC or ON for long periods of time without the EV system on.

I If “ACCESSORY” or “POWER ON” is displayed on the multi-information display while the EV system is not operating, the power switch is not OFF. Exit the vehicle after turning the power switch off.

Shift position

Select the shift position depending on your purpose and situation.

Shift position purpose and functions

Shift position	Objective or function
P	Parking the vehicle/starting the EV system
R	Reversing
N	Neutral (Condition in which the power is not transmitted)
D	Normal driving

n Restraining sudden start (Drive-Start Control)

→P.219

n If a message about a shift operation is shown

To prevent the shift position from being selected incorrectly or the vehicle from moving unexpectedly, the shift position may be changed automatically or operating the shifting operation may be required. In this case, change the shift position following the messages on the multi-information display.

n After recharging/reconnecting the 12-volt battery

→P.602


⚠ WARNING**n When driving on slippery road surfaces**

Be careful of sudden acceleration, as this could result in the vehicle skidding to the side or spinning.

⚠ NOTICE**n Situations where shift control system malfunctions are possible**

If any of the following situations occurs, shift control system malfunctions are possible. Immediately stop the vehicle in a safe place on level ground, apply the parking brake, and then contact your Toyota dealer.

- ! When the warning message indicating the shift control system appears on the multi-information display. (→P.578)
- ! The display indicates that no shift position is selected for more than a few seconds.

Shift position display and how to change the shift position**A Rotary shifter**

Operate the rotary shifter slowly and securely.

To switch to N, hold down the rotary shifter and hold it for a while.

To switch to R or D, hold down the rotary shifter and turn left or right according to the arrow on the shift position indicator.

Release the rotary shifter after each shifting operation to allow it to return to its regular position.

When shifting from P to N, D or R, from N, D or R to P, from D to R, or from R to D, ensure that the brake pedal is being depressed and the vehicle is stationary.

B Shift position indicator

Meter display:

The current shift position is illumi-

nated.

Rotary shifter display:

The current shift position is illuminated.

When selecting the shift position, make sure that the shift position has been changed to the desired position by checking the shift position indicator provided on the instrument cluster.

C P position switch

Fully stop the vehicle and set the parking brake, and then press the P position switch.

When the shift position is changed to P, the switch illuminates.

Check that the shift position indicator shows P.

n Changing the shift position in each power switch mode

- | The shift position cannot be changed when the power switch is in ACC or off.
- | When the power switch is in ON, if the “READY” indicator is not illuminated, the shift position can only be changed to N.
- | When the “READY” indicator is illuminated, the shift position can be changed from P to D, N, or R.
- | When the “READY” indicator is flashing, the shift position cannot be changed from P to any other position, even if the rotary shifter is operated. Operate the rotary shifter again after the “READY” indicator changes from flashing to illuminated.

n Shifting the shift position from P to other positions

- | While depressing the brake pedal firmly, operate the rotary shifter. If the rotary shifter is operated without depressing the brake pedal, the buzzer will sound and the

shifting operation will be disabled.

- | When selecting the shift position, make sure that the shift position has been changed to the desired position by checking the shift position indicator provided on the instrument cluster.

n The shift position cannot be changed when

In the following situations, a buzzer will sound to inform you that the shift position cannot be changed. Use the appropriate operation to attempt to change the shift position again.

- | When attempting to change the shift position from P with the brake pedal not depressed
- | When attempting to change the shift position from P with the accelerator pedal depressed
- | When attempting to change the shift position from N while stopped or driving at an extremely low speed with the brake pedal not depressed
- | When attempting to change the shift position from N while stopped or driving at an extremely low speed with the accelerator pedal depressed
- | When the P position switch is pressed while driving

When driving at an extremely low speed, the shift position may change to P.

n The shift position automatically changes to N when

In the following situations, a buzzer will sound to inform you that the shift position has been changed to N. Use the appropriate operation to attempt to change the shift position again.

- | When attempting to change the shift position to R while the vehicle is moving forward

When driving at a low speed, the shift position may change to R.

- | When attempting to change the shift position to D while the vehicle is moving backward

When driving at a low speed, the shift position may change to D.

n If the N shift position is selected while driving

If the rotary shifter is moved to N while driving above a certain speed, the shift position will change to N without holding the rotary shifter in the N position. In this situation, a buzzer will sound and a message will be displayed on the multi-information display to inform you that the shift position has been changed to N.

n Reverse warning buzzer

When shifting into R, a buzzer will sound to inform the driver that the shift position is in R.

n Automatic P position selection function

In the following situations, the shift position is automatically changed to P.

- | When pressing the power switch with the vehicle stopped while the power switch is in ON and the shift position is in a position other than P (after the shift position has changed to P, the power switch will turn off)*
- | If the driver's door is opened and all of the following conditions are met, while the shift position is in a position other than P:
 - The power switch is in ON.
 - The driver is not wearing the seat belt.
 - The brake pedal is not depressed.

To start off the vehicle after the shift position is changed to P, operate the rotary shifter again.

- | When the vehicle is stopped after the EV system has been stopped in an emergency while driving.
- | When voltage of the 12-volt bat-

tery drops while the shift position is in a position other than P.

- *: When the power switch is pressed while driving at extremely slow speeds, such as immediately before stopping the vehicle, the shift position may automatically change to P. Make sure that the vehicle is completely stopped before pressing the power switch.

n If the shift position cannot be shifted from P

There is a possibility that the 12-volt battery is discharged. Check the 12-volt battery in this situation. (→P.600)

n Customization

Some functions can be customized. (→P.632)

⚠ WARNING

n For the rotary shifter

- | Do not remove the rotary shifter knob or use anything but a genuine Toyota rotary shifter knob. Also, do not hang anything on the rotary shifter. Doing so could prevent the rotary shifter from returning to position, causing unexpected accidents to occur when the vehicle is in motion.
- | In order to prevent the shift position from accidentally being changed, do not touch the rotary shifter when not using them.

WARNING

n P position switch

I Do not press the P position switch while the vehicle is moving.

If the P position switch is pressed when driving at very low speeds (for example, directly before stopping the vehicle), the vehicle may stop suddenly when the shift position switches to P, which could lead to an accident.

I In order to prevent the shift position from accidentally being changed, do not touch the P position switch when not using them.

NOTICE

n When exiting the vehicle (driver's seat only)

Check that the shift position indicator shows P and that the parking brake indicator is illuminated before opening the door and exiting the vehicle.

Keeping the shift position in N without activating the automatic P position selection function

- By performing the following operation, the shift position can be held in N until the shift position switches to P without activating the automatic P position selection function.

- 1 Stop the vehicle completely.
- 2 Turn off the brake hold system. (→P.249)

- 3 Press and hold the parking brake switch until a message is shown on the multi-information display. (Turn automatic mode off)
- 4 Operate the rotary shifter and change the shift position to N when the EV system is operating.
- 5 Return the rotary shifter to its regular position.
- 6 Operate the rotary shifter to N and hold it there until the buzzer sounds.
- 7 Press the power switch within 5 seconds after the buzzer sounds.

The EV system stops with the shift position in N*.

Make sure to check that the buzzer sounds and "Holding N Push P Switch When Done" is displayed on the multi-information display.

- In order to shift to a position other than N, first press the P position switch to change the shift position to P.

*: To keep this state, do not operate the power switch. If the power switch is operated repeatedly, the power switch will turn off after the shift position has automatically changed to P.

Selecting the drive mode

n "X-MODE"

→P.434


Selecting Eco mode

It is suited for driving that suppress vehicle driving power and improves electricity consumption.

Press the switch to switch over to Eco mode.

Press the switch again to return to Normal driving mode.

The Eco mode ON state is memorized even if the power switch is turned off.



n Eco mode drive automatic cancellation

Eco mode is automatically canceled when snow mode or "X-MODE" is selected and the vehicle returns to normal mode. (if equipped)

n When Eco mode is not available

Eco mode cannot be activated when "X-MODE" is selected. (if equipped)

How to operation the regenerative braking force selection mode

By setting the shift position to D and operating the paddle shift switches, the vehicle can drive with the regenerative braking

force fixed when the accelerator pedal is released.

Regenerative braking force can be selected among 4 levels:


By operating the "-" side of the paddle shift switch, the regenerative braking force can be made stronger than the current one.

By operating the "+" side of the paddle shift switch, the regenerative braking force can be made weaker than the current one.

The regenerative braking power becomes strong as the number

of the arrows  of 

(regenerative braking power indicator) on the multi-information display increases.



A Paddle shift switch "-"

B Paddle shift switch "+"

C Indicator

n How to cancel the regenerative braking force selection mode

In the following conditions, the regenerative braking force selection mode is canceled.

- l The shift position is shifted to a position other than D


- | The “+” paddle shift switch is pressed and held
- | When “X-MODE” is activated

n Using regenerative brake

- | When driving at a high speed, the feeling of deceleration with regenerative braking is less than that on conventional vehicles.
- | If “Regenerative braking limited. Press brake to decelerate.” appears on the multi-information display, firmly depress the brake pedal to decelerate the vehicle.

Turn signal lever

Operating instructions



- 1** Right turn
- 2** Lane change to the right (move the lever partway and release it)

The right hand signals will flash 3 times.

- 3** Lane change to the left (move the lever partway and release it)

The left hand signals will flash 3 times.

- 4** Left turn

n Turn signals can be operated when

The power switch is in ON.

n If the indicator flashes faster than usual

Have the vehicle inspected by your Toyota dealer.

- n If the turn signals stop flashing before a lane change has been performed

Operate the lever again.

Parking brake

The parking brake can be set or released automatically or manually.


In automatic mode, the parking brake can be set or released automatically.

Also, even in automatic mode, the parking brake can be set or released manually.

Operating instructions

- n **Using the manual mode**

The parking brake can be set and released manually.



A Parking brake indicator (U.S.A.)

B Parking brake indicator (Canada)

- 1** Pull the switch to set the parking brake.

The parking brake indicator light will turn on.

Pull and hold the parking brake switch if an emergency occurs and it is necessary to operate the parking brake while driving.

2 Press the switch to release the parking brake.

- Operate the parking brake switch while depressing the brake pedal.
- Using the parking brake automatic release function, the parking brake can be released by depressing the accelerator pedal. When using this function, slowly depress the accelerator pedal. (→P.246)

Make sure that the parking brake indicator light turn off.

If the parking brake indicator light flash, operate the switch again. (→P.575)

n Turning the automatic mode on

While the vehicle is stopped, pull and hold the parking brake switch until a buzzer sounds and a message is shown on the multi-information display.

When the automatic mode is turned on, the parking brake operates as follows.

- When the shift position is shifted from P, the parking brake will be released, and the parking brake indicator light will turn off.
- When the shift position is shifted to P, the parking brake will be set, and the parking brake indicator light will turn on.

Operate the shift position and P position switch with the vehicle stopped and the brake pedal depressed.

The auto function may not operate if the shift position is moved extremely quickly or the brake pedal is not firmly depressed. In this situation, apply the parking brake manually. (→P.245)

n Turning the automatic mode off

While the vehicle is stopped and depressing the brake pedal, press and hold the parking brake switch until a buzzer sounds and a message is shown on the multi-information display.

n Parking brake operation

- | When the power switch is not in ON, the parking brake cannot be released using the parking brake switch.
- | When the power switch is not in ON, automatic mode (automatic brake setting and releasing) is not available.

n Parking brake automatic release function

When all of the following conditions are met, the parking brake can be released by depressing the accelerator pedal.

- | The driver's door is closed
- | The driver is wearing the seat belt
- | The shift position is in a forward driving position or reverse driving position
- | The brake system warning light (Yellow) is not illuminated.

When depressing the accelerator

pedal, depress it slowly.

If the parking brake is not released when the accelerator pedal is depressed, release the parking brake manually.

When the shift position is shifted from P, the parking brake will be released automatically.

n Parking brake automatic lock function when EV system is off

The parking brake will be set automatically under the following conditions:

- | The EV system is off
- | Automatic mode ON
- | The brake system warning light (Yellow) are not illuminated

n Parking brake automatic lock function when exiting the vehicle

The parking brake will be set automatically under the following conditions:

- | The brake pedal is not depressed
- | The driver's door is open
- | The driver's seat belt is not fastened
- | The brake system warning light (Yellow) are not illuminated

n When the parking brake is not automatically set in the shift position N, such as when using car wash.

"Parking brake automatic lock function when exiting the vehicle" will be disabled by doing the following:

- 1** Stop the vehicle.
- 2** Turn off the brake hold system.
- 3** Press and hold the parking brake switch until a buzzer sounds and a message is shown on the multi-information display.
- 4** The shift position to N
- 5** Press and hold the parking brake switch until a buzzer sounds and a message is shown on the multi-information display.

The parking brake indicator light will flash.

6 Disable the automatic P position selection function. Refer to P.242

When any of the following conditions are met, the vehicle will return to automatic mode ON.

The parking brake indicator light will turn off or light up.

- | The shift position other than N
- | The parking brake switch is pulled
- | The EV system is turned off and then started again

n If "Parking Brake Temporarily Unavailable" is displayed on the multi-information display

If the parking brake is operated repeatedly over a short period of time, the system may restrict operation to prevent overheating. If this happens, refrain from operating the parking brake. Normal operation will return after about 1 minute.

n If "Parking Brake Unavailable" is displayed on the multi-information display

Operate the parking brake switch. If the message does not disappear after operating the switch several times, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

n Parking brake operation sound

When the parking brake operates, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

n Parking brake indicator light

- | Depending on the power switch mode, the parking brake indicator light will turn on and stay on as described below:

ON: Comes on until the parking brake is released.

Not in ON: Stays on for approximately 15 seconds.

- | When the power switch is turned off with the parking brake set, the

parking brake indicator light will stay on for about 15 seconds. This does not indicate a malfunction.

n When the parking brake switch malfunctions

Automatic mode (automatic brake setting and releasing) will be turned on automatically.

n Parking the vehicle

→P.213

n Parking brake engaged warning buzzer

A buzzer will sound if the vehicle is driven with the parking brake engaged.

"Parking Brake ON" is displayed on the multi-information display (with the vehicle reaching a speed of 3 mph [5 km/h]).

n If the brake system warning light (Yellow) comes on

→P.568

n Usage in winter time

→P.445



WARNING

n When parking the vehicle

Do not leave a child in the vehicle alone. The parking brake may be released unintentionally by a child and there is the danger of the vehicle moving that may lead to an accident resulting in death or serious injury.

n Parking brake switch

Do not set any objects near the parking brake switch. Objects may interfere with the switch and may lead the parking brake to unexpectedly operate.

n Parking brake automatic lock function

Never use the automatic parking brake engagement function in place of normal parking brake operation. This function is designed to reduce the risk of a collision due to the driver forgetting to engage the parking brake. Over-reliance on this function to park the vehicle safely may lead to an accident resulting in death or serious injury.



NOTICE

n When parking the vehicle

Before you leave the vehicle, shift the shift position to P, set the parking brake and make sure that the vehicle does not move.

n When the system malfunctions

Stop the vehicle in a safe place and check the warning messages.

n When the vehicle 12-volt battery is discharged

The parking brake system cannot be activated. (→P.600)

n When the parking brake cannot be released due to a malfunction

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear. Have the vehicle inspected by your Toyota dealer immediately if this occurs.


Brake Hold

The brake hold system keeps the brake applied when the shift position is in D, N or P with the system on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift position in D to allow smooth start off.

Enabling the system

Turns the brake hold system on

The brake hold standby indicator (green) **A** comes on. While the system is holding the brake, the brake hold operated indicator (yellow) **B** comes on.



Brake hold system operating conditions

The brake hold system cannot be turned on in the following conditions:

- l The driver's door is not closed.
- l The driver is not wearing the seat belt.

- l "Parking Brake Unavailable" or "Parking Brake Malfunction Visit Your Dealer" is displayed on the multi-information display.

If any of the conditions above are detected when the brake hold system is enabled, the system will turn off and the brake hold standby indicator light will go off. In addition, if any of the conditions are detected while the system is holding the brake, a warning buzzer will sound and a message will be shown on the multi-information display. The parking brake will then be set automatically.

Brake hold function

- l If the brake pedal is left released for a period of about 3 minutes after the system has started holding the brake, the parking brake will be set automatically. In this case, a warning buzzer sounds and a message is shown on the multi-information display.

- l To turn the system off while the system is holding the brake, firmly depress the brake pedal and press the button again.

- l The brake hold function may not hold the vehicle when the vehicle is on a steep incline. In this situation, it may be necessary for the driver to apply the brakes. A warning buzzer will sound and the multi-information display will inform the driver of this situation. If a warning message is shown on the multi-information display, read the message and follow the instructions.

- l When do not wish for the parking brake to operate automatically, press and hold the brake hold switch until the standby indicator (green) turns off, and then turn the power switch off.

When the parking brake is set automatically while the system is holding the brakes

Perform any of the following opera-

tions to release the parking brake.

- l Depress the accelerator pedal.
(The parking brake will not be released automatically if the seat belt is not fastened.)
- l Operate the parking brake switch with the brake pedal depressed.

Make sure that the parking brake indicator light goes off. (→P.245)

n When an inspection at your Toyota dealer is necessary

When the brake hold standby indicator (green) does not illuminate even when the brake hold switch is pressed with the brake hold system operating conditions met, the system may be malfunctioning. Have the vehicle inspected at your Toyota dealer.

n If “Brake Hold Malfunction Press Brake to Deactivate Visit Your Dealer” or “Brake Hold Malfunction Visit Your Dealer” is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

n Warning messages and buzzers

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution. If a warning message is shown on the multi-information display, read the message and follow the instructions.

n If the brake hold operated indicator flashes

→P.575



WARNING

n When the vehicle is on a steep incline

Take care when using the brake hold system on a steep incline, exercise caution. The brake hold function may not hold brakes in such situations.

Also, the system may not activate depending on the angle of the slope.

n When stopped on a slippery road

The system cannot stop the vehicle when the gripping ability of the tires has been exceeded. Do not use the system when stopped on a slippery road.



NOTICE

n When parking the vehicle


The brake hold system is not designed for use when parking the vehicle for a long period of time. Turning the power switch off while the system is holding the brake may release the brake, which would cause the vehicle to move. When operating the power switch, depress the brake pedal, shift the shift position to P and set the parking brake.

Headlight switch

The headlights can be operated manually or automatically.

Turning on the headlights

Operating the  switch turns on the lights as follows:



A U.S.A.

B Canada

1  The side marker, parking, tail, license plate, instrument panel lights, and daytime running lights (→P.251) turn on.

2  The headlights and all lights listed above (except daytime running lights) turn on.

3 **AUTO** The headlights, daytime running lights (→P.251) and all the lights listed above turn

on and off automatically.

4  The daytime running lights turn off. (for the U.S.A. only)

n **AUTO mode can be used when**
The power switch is in ON.

n **Daytime running light function**

| The daytime running lights illuminate using the same lights as the headlights but at a lower intensity.

| To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically when all of the following conditions are met. (The daytime running lights are not designed for use at night.)

- The EV system is operating
- The parking brake is released
- The headlight switch is in the **AUTO**

or  position

• The surroundings are bright


| The daytime running lights remain on after they illuminate, even if the parking brake is set again.

| For the U.S.A.: Daytime running lights can be turned off by operating the switch.

| Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve electricity consumption.

n **Headlight control sensor**

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield. Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



n Automatic light off system

- I When the headlights are on: The lights turn off 30 seconds after the power switch is turned to ACC or off and a door is opened and closed. (The lights turn off immediately if  on the key is pressed after all the doors are closed.)
- I When only the tail lights are on: The tail lights turn off automatically if the power switch is turned to ACC or off and the driver's door is opened.

To turn the lights on again, turn the power switch to ON, or turn the light switch to the **AUTO** or **DRL OFF** position

once and then back to  or  position.

n Light reminder buzzer

A buzzer sounds when the power switch is turned off and the driver's door is opened while the lights are turned on.

n Automatic headlight leveling system

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

n Windshield wiper linked headlight illumination

When driving during daytime with the headlight switch turned to **AUTO**, if the windshield wipers are used, the headlights will turn on automatically

after several seconds to help enhance the visibility of your vehicle.

n 12-volt battery-saving function

In order to prevent the 12-volt battery of the vehicle from discharging, if the headlights and/or tail lights are on when the power switch is turned to off, the battery saving function will operate and automatically turn off all the lights after approximately 10 minutes.

When any of the following are performed, the 12-volt battery-saving function is canceled once and then reactivated. All the lights will turn off automatically 10 minutes after the 12-volt battery-saving function has been reactivated:

- I When the headlight switch is operated
- I When a door is opened or closed

n If “Headlight System Malfunction Visit Your Dealer” is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

n Customization

Some functions can be customized. (→P.633)




NOTICE

n To prevent 12-volt battery discharge

Do not leave the lights on longer than necessary when the EV system is not operating.

Turning on the high beam headlights



- 1** With the headlights on, push the lever away from you to turn on the high beams.

Pull the lever toward you to the center position to turn the high beams off.

- 2** Pull the lever toward you and release it to flash the high beams once.

You can flash the high beams with the headlights on or off.

AHB (Automatic High Beam)

The Automatic High Beam uses a front camera located on the upper portion of the windshield to detect the brightness of the lights of vehicles ahead, streetlights, etc., and automatically changes the head lights between the high beams and low beams.

WARNING

n For safe use


Do not overly rely on the Automatic High Beam. Always drive safely, taking care to observe your surroundings and turning the high beams on or off manually if necessary.

n To prevent unintentional operation of the Automatic High Beam System

When it is necessary to disable the system: →P.263


Using the Automatic High Beam system

- 1** Press the Automatic High Beam switch.



- 2** Turn the headlight switch to the AUTO or  position.

When the headlight switch lever is in the low beam position, the AHB system will be enabled and the AHB indicator will illuminate.



n Automatic operating conditions of the high beams

| When all of the following conditions are met, the high beams will illuminate automatically:

- The vehicle speed is approximately 21 mph (34 km/h) or more.
- The area ahead of the vehicle is dark.
- There are no vehicles ahead with lights on.
- There are few streetlights or other lights on the road ahead.

| If any of the following conditions are met, the headlights will change to the low beams:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- There is a vehicle ahead with lights on.
- There are many streetlights or other lights on the road ahead.

n Front camera detection

| In the following situations, the high beams may not be automatically changed to the low beams:

- When a vehicle cuts in front of your vehicle
- When another vehicle crosses in front of the vehicle

- When vehicles ahead are repeatedly detected and then hidden due to repeated curves, road dividers or roadside trees
- When a vehicle ahead approaches from a far lane
- When a vehicle ahead is far away
- When a vehicle ahead has no lights
- When the lights of a vehicle ahead are dim
- When a vehicle ahead is reflecting strong light, such as own headlights
- Situations in which the sensors may not operate properly: →P.268

| The headlights may change to the low beams if a vehicle ahead that is using fog lights without its headlights turned on is detected.

| House lights, street lights, traffic signals, and illuminated billboards or signs may cause the high beams to change to the low beams, or the low beams to remain on.

| The following may change the timing at which the headlights change to the low beams:

- The brightness of lights of vehicles ahead
- The movement and direction of vehicles ahead
- The distance between the vehicle and a vehicle ahead
- When a vehicle ahead only has lights illuminated on one side
- When a vehicle ahead is a two-wheeled vehicle
- The condition of the road (gradient, curve, condition of the road surface, etc.)
- The number of passengers and amount of luggage

| The headlights may change between the high beams and low beams unexpectedly.

| Bicycles and other small vehicles may not be detected.

| In the following situations, the system may not be able to correctly detect the brightness of the

surroundings. This may cause the low beams to remain on or the high beams to flash or dazzle pedestrians or vehicles ahead. In such a case, it is necessary to manually change between the high beams and low beams.

- When there are lights similar to headlights or tail lights in the surrounding area
- When headlights or tail lights of vehicles ahead are turned off, dirty, changing color, or not aimed properly
- When the headlights are repeatedly changing between the high beams and low beams.
- When use of the high beams is inappropriate or when the high beams may be flashing or dazzling pedestrians or other drivers.
- When the vehicle is used in an area in which vehicles travel on the opposite side of the road of the country for which the vehicle was designed, for example using a vehicle designed for right-hand traffic in a left-hand traffic area, or vice versa
- When it is necessary to disable the system: →P.263
- Situations in which the sensors may not operate properly: →P.268

n **Temporarily reducing front camera sensitivity**

The sensitivity of the front camera can be temporarily reduced.

- 1 Turn the power switch off with the following conditions met.
 - l The headlight switch is in the  or AUTO position.
 - l The headlight switch lever is in the low beam position.
 - l The Automatic High Beam switch is on.
- 2 Turn the power switch to ON.
- 3 Within 60 seconds after performing step 2, push the headlight switch lever to the high beam position then pull it to the original

position quickly 10 times, then leave the lever in its original position.

- 4 If the sensitivity is changed, the Automatic High Beam indicator will blink 3 times.


Turning the high beams on/off manually

n **Changing to the high beams**

Push the lever forward.

The AHB indicator will turn off and the high beam indicator will turn on.

Pull the lever to its original position to enable the Automatic High Beam system again.




n **Changing to the low beams**

Press the Automatic High Beam switch.

The AHB indicator will turn off.

Press the switch to enable the Automatic High Beam system again.




Temporarily changing to the low beams

It is recommended to switch to the low beams when use of the high beams is inappropriate or when the high beams may cause problems or distress to other drivers or pedestrians nearby.

Pull the lever rearward and then return it to its original position.

The high beams will illuminate while the lever is pulled, however, after the lever is returned to its original position, the low beams will remain on for a certain amount of time. After this, the Automatic High Beam system will operate.



Windshield wipers and washer

Operating the lever can change wiper operation to automatic/manual or squirt washer fluid.

⚠ NOTICE


n When the windshield is dry

Do not use the wipers, as they may damage the windshield.

Operating the wiper lever

Operating the  lever operates the wipers or washer as follows:

When AUTO is selected, the wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.



1 OFF (U.S.A.) or **0**

(Canada)
Off


2 **AUTO** Rain-sensing wiper operation

3 **LO** (U.S.A.) or ▼
(Canada)
Low speed operation

4 **HI** (U.S.A.) or ▼▼
(Canada)
High speed operation


5 **MIST** (U.S.A.) or ▲
(Canada)
Temporary operation

When AUTO is selected, the sensor sensitivity can be adjusted by turning the switch ring.



6 Increases the sensitivity

7 Decreases the sensitivity



8  Washer/wiper dual operation

Pulling the lever operates the wipers and washer.

The wipers will automatically operate a couple of times after the washer squirts.

(After operating several times, the wipers operate once more time after a short delay to prevent dripping. However, the dripping prevention does not operate while the vehicle is moving.)

When the power switch is in ON and the headlights are on, if the lever is pulled, the headlight cleaners will operate once. After this, the headlight cleaners will operate every 5th time the lever is pulled.

n **The windshield wipers and washer can be operated when**

The power switch is in ON.


n **Effects of vehicle speed on wiper operation**

With low speed windshield wiper operation selected, wiper operation will be switched from low speed to intermittent wiper operation when the vehicle is stationary. (However, when the sensor sensitivity is adjusted to the highest level, the mode will not switch.)

n **Raindrop sensor**

l The raindrop sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs, etc. are present on the windshield.



- | If the wiper switch is turned to the **AUTO** position while the power switch is in **ON**, the wipers will operate once to show that **AUTO** mode is activated.
- | If the wiper sensitivity is adjusted to higher, the wiper may operate once to indicate the change of sensitivity.
- | If the temperature of the raindrop sensor is 185°F (85°C) or higher, or 5°F (-15°C) or lower, the automatic operation may not occur. In this case, operate the wipers in any mode other than **AUTO**.

n If no windshield washer fluid sprays

Check that the washer nozzles are not blocked, if there is washer fluid in the washer fluid tank.

n Using the voice control system

The following operations can be performed using the voice control system:

- | Operating the windshield wipers only once
- | Operating the windshield cleaning washer (it can be performed only when the vehicle is stopped)

For details regarding the voice control system, refer to "MULTIMEDIA OWNER'S MANUAL".

! WARNING

n Caution regarding the use of windshield wipers in AUTO mode

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in **AUTO** mode. Take care that your fingers, etc. do not become caught in the windshield wipers.

n Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.

! NOTICE

n When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.

n When a nozzle becomes blocked

In this case, contact your Toyota dealer.

Do not try to clear it with a pin or other object. The nozzle will be damaged.

n To prevent 12-volt battery discharge

Do not leave the wipers on longer than necessary when the EV system is off.

Rear window wiper and washer




NOTICE

n When the rear window is dry


Do not use the wiper, as it may damage the rear window.

Operating the wiper lever

Operating the  switch operates the rear wiper as follows:



- 1 OFF** (U.S.A.) or  (Canada)
Off
- 2 INT** (U.S.A.) or **---** (Canada)
Intermittent operation
- 3 ON** (U.S.A.) or **—** (Canada)
Normal operation



4 Washer/wiper dual operation

Pushing the lever operates the wiper and washer.

The wiper will automatically operate a couple of times after the washer squirts.

The washer will automatically operate and clean the rear camera.*

*: Refer to "MULTIMEDIA OWNER'S MANUAL".

n The rear window wiper and washer can be operated when

The power switch is in ON.

n Using the voice control system

The following operations can be performed using the voice control system:

- | Operating the rear window wiper only once
- | Operating the rear window washer (it can be performed only when the vehicle is stopped)

For details regarding the voice control system, refer to "MULTIMEDIA OWNER'S MANUAL".

n If no washer fluid sprays

Check that the washer nozzle is not blocked if there is washer fluid in the washer fluid tank.

n Reverse-linked rear window wiper function

When the shift position is shifted to

When the front wipers are operating, the rear window wiper will operate once.

n Back door opening linked rear window wiper stop function

When the rear window wiper is operating, if the back door is opened while the vehicle is stopped, operation of the rear window wiper will be stopped to prevent anyone near the vehicle from being sprayed by water from the wiper. When the back door is closed, wiper operation will resume.



NOTICE

n When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.

n When a nozzle becomes blocked

In this case, contact your Toyota dealer.

Do not try to clear it with a pin or other object. The nozzle will be damaged.

n To prevent 12-volt battery discharge


Do not leave the wipers on longer than necessary when the EV system is off.

Headlight cleaner switch

Washer fluid can be sprayed on the headlights.

Enabling the system

Press the switch to clean the headlights.



n The headlight cleaners can be operated when

The power switch is in ON and the headlight switch is turned on.

n Windshield washer linked operation

When the power switch is in ON and the headlights are on, if the lever is pulled, the headlight cleaners will operate once. After this, the headlight cleaners will operate every 5th time the lever is pulled. (→P.256)



NOTICE

n When the washer fluid tank is empty

Do not press the switch continually as the washer fluid pump may overheat.

Toyota Safety Sense 3.0/Traffic Jam Assist software update

It is necessary to enter a connected services contract, provided by Toyota, to use these functions. For details, contact your Toyota dealer.



WARNING

n For safe use

When the Toyota Safety Sense 3.0/Traffic Jam Assist software is updated, the operating methods of functions may change. Using this system without knowing the correct operating methods may lead to an accident resulting in death or serious injury.

- l Make sure to read the Digital Owner's Manual which corresponds to the software version of the system, available at the Owner's Manual website, before using this system.

Content of the Toyota Safety Sense 3.0/Traffic Jam Assist Owner's Manual

This Owner's Manual contains information for Ver. 3. For the latest information about the controls, use, warnings/precautions, etc. of each function of Toyota

Safety Sense 3.0/Traffic Jam Assist, refer to the Digital Owner's Manual at the Owner's Manual website.

Before using this system, be sure to read the Owner's Manual which corresponds to the software version of the system.

n Precautions for use

- l Be aware that some functions may temporarily be disabled if a legal or safety related issue occurs.
- l If a connected services contract has not been entered or has expired, software updates will not be able to be performed wirelessly.

Checking your vehicle's Toyota Safety Sense 3.0/Traffic Jam Assist version


To access the appropriate Owner's Manual, it is necessary to check the software version of the system and then visit the Owner's Manual website.

Checking the version using Toyota App

The software version of the system can be checked using Toyota App.

Selecting your vehicle's Toyota Safety Sense 3.0/Traffic Jam Assist version

- 1 Access the following URL using a computer or smartphone:

Language		URL	QR code
For the U.S.A. owner's	English	https://www.toyota.com/owners/resources/warranty-owners-manuals/manual?om=om42d57u.bZ-woodland.2026.2608.bev.vh	
	French	https://www.toyota.ca/toyota/owners/manual?om=om42d57u.bZ-woodland.2026.2608.bev.vh	
For Canadian owner's	English	https://www.toyota.ca/toyota/owners/manual?om=om42d57u.bZ-woodland.2026.2608.bev.vh	
	French	https://www.toyota.ca/toyota/owners/manual?om=om42d57d.bZ-woodland.2026.2608.bev.vh	

2 Select the file which includes the previously checked system version.

Updating the software

If a software update is available, a notification will be displayed by Toyota App. Follow the instructions displayed on the screen.

n What can be checked using the Toyota App

The following items can be checked or performed.

- l Software version, update details, precautions, use methods, etc.
- l Software update

n Software update precautions

- l After a software update has been performed, it will not be possible to revert to a previous version.
- l Depending on the communication environment and the content of an update, a software update may take several hours. Although an update will be suspended when the power switch is turned off, it will resume when the power switch is changed back to ON.
- l Toyota Safety Sense 3.0/Traffic Jam Assist can still be used while a software update is being performed.

Toyota Safety Sense 3.0

The Toyota Safety Sense 3.0 consists of the driving assist systems and contributes to a safe and comfortable driving experience:

WARNING

n Toyota Safety Sense 3.0

The Toyota Safety Sense 3.0 operates under the assumption that the driver will drive safely, and is designed to help reduce the impact to the occupants in a collision and assist the driver under normal driving conditions.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. The driver is solely responsible for paying attention to the vehicle's surroundings and driving safely.

n For safe use

- I** Do not overly rely on this system. The driver is solely responsible for paying attention to the vehicle's surroundings and driving safely. This system may not operate in all situations and provided assistance is limited. Over-reliance on this system to drive the vehicle safely may lead to an accident resulting in death or serious injury.
- I** Do not attempt to test the operation of the system, as it may not operate properly, possibly leading to an accident.

I If attention is necessary while performing driving operations or a system malfunction occurs, a warning message or warning buzzer will be operated. If a warning message is displayed on the display, follow the instructions displayed.

I Depending on external noise, the volume of the audio system, etc. it may be difficult to hear the warning buzzer. Also, depending on the road conditions, it may be difficult to recognize the operation of the system.

n When it is necessary to disable the system

In the following situations, make sure to disable the system.

Failure to do so may lead to the system not operating properly, possibly leading to an accident resulting in death or serious injury.

- I** When the vehicle is tilted due to being overloaded or having a flat tire
- I** When driving at extremely high speeds
- I** When towing another vehicle
- I** When the vehicle is being transported by a truck, ship, train, etc.
- I** When the vehicle is raised on a lift and the tires are allowed to rotate freely
- I** When inspecting the vehicle using a drum tester such as a chassis dynamometer or speedometer tester, or when using an on vehicle wheel balancer
- I** When the vehicle is driven in a sporty manner or off-road
- I** When using an automatic car wash

**WARNING**

- ! When a sensor is misaligned or deformed due to a strong impact being applied to the sensor or the area around the sensor
- ! When accessories which obstruct a sensor or light are temporarily installed to the vehicle
- ! When a compact spare tire or tire chains are installed to the vehicle or an emergency tire puncture repair kit has been used
- ! When the tires are excessively worn or the inflation pressure of the tires is low
- ! When tires other than the manufacturer specified size are installed
- ! When the vehicle cannot be driven stably, due to a collision, malfunction, etc.

Driving assist systemsn **AHB (Automatic High Beam)**

→P.253

n **PCS (Pre-Collision System)**

→P.273

n **LTA (Lane Tracing Assist)**

→P.285

n **LDA (Lane Departure Alert)**

→P.293

n **LCA (Lane Change Assist)***

→P.290

*: If equipped

n **FCTA (Front Cross Traffic Alert)***

→P.306

*: If equipped

n **PDA (Proactive driving assist)**

→P.300

n **RSA (Road Sign Assist)***

→P.308

*: If equipped

n **Dynamic radar cruise control**

→P.311

n **Cruise control**

→P.322

n **Emergency Driving Stop System**

→P.326

n **Traffic Jam Assist***

→P.329

*: If equipped

n **Driver monitor**


→P.271

Sensors used by Toyota Safety Sense 3.0

Various sensors are used to obtain the necessary information for system operation.

n Sensors which detect the surrounding conditions


► Front



- A** Front radar sensor
- B** Front camera
- C** Front side radar sensors *


*: If equipped

► Rear



- A** Rear side radar sensors

n Sensors which detect the driver condition



- A** Driver monitor camera

! WARNING


n To prevent malfunction of the radar sensors

Observe the following precautions. Failure to do so may lead to a radar sensor not operating properly, possibly leading to an accident resulting in death or serious injury.

Keep the radar sensors and radar sensor covers clean at all times.


Clean the front of a radar sensor or the front or back of a radar sensor cover if it is dirty or covered with water droplets, snow, etc.

When cleaning the radar sensor and radar sensor cover, use a soft cloth to remove dirt so as to not damage them.



- A** Radar sensor
- B** Radar sensor cover

Vehicles with front side radar sensors: Keep the surrounding area of the front side radar sensors on the front bumper clean at all times.



WARNING

- I Do not attach accessories, stickers (including transparent stickers), aluminum tape, etc. to a radar sensor or radar sensor cover and their surrounding area.
- I Do not subject a radar sensor or its surrounding area to impact. If a radar sensor, the front grille, or front bumper has been subjected to a impact, have the vehicle inspected by your Toyota dealer.
- I Do not disassemble the radar sensors.
- I Do not modify or paint the radar sensors or radar sensor cover, or replace them with anything other than Toyota genuine parts.
- I In the following situations, recalibration of the radar sensors will be necessary. For details, contact your Toyota dealer.
 - When a radar sensor is removed and installed, or replaced
 - When the front bumper or the front grille has been replaced


n To prevent malfunction of the front camera

Observe the following precautions.

Failure to do so may lead to the front camera not operating properly, possibly leading to an accident resulting in death or serious injury.

- I Always keep the windshield clean.
- If the windshield is dirty or covered with an oily film, water droplets, snow, etc., clean the windshield.

- Even if a glass coating agent is applied to the windshield, it will still be necessary to use the windshield wipers to remove water droplets, etc. from the area of the windshield in front of the front camera.
- If the inner side of the windshield where the front camera is installed is dirty, contact your Toyota dealer.
- I Do not attach stickers (including transparent stickers) or other items to the area of the windshield in front of the front camera (shaded area in the illustration).



A Approximately 1.6 in. (4 cm)

B Approximately 1.6 in. (4 cm)

- I If the part of the windshield in front of the front camera is fogged up or covered with condensation or ice, use the windshield defogger to remove the fog, condensation, or ice.
- I If water droplets cannot be properly removed from the area of the windshield in front of the front camera by the windshield wipers, replace the wiper insert or wiper blade.
- I Do not attach window tint to the windshield.

**WARNING**

- I Replace the windshield if it is damaged or cracked. If the windshield has been replaced, recalibration of the front camera will be necessary. For details, contact your Toyota dealer.
- I Do not allow liquids to contact the front camera.
- I Do not allow bright lights to shine into the front camera.
- I Do not damage the lens of the front camera or allow it to become dirty. When cleaning the inside of the windshield, do not allow glass cleaner to contact the lens of the front camera. Do not touch the lens of the front camera. If the lens of the front camera is dirty or damaged, contact your Toyota dealer.
- I Do not subject the front camera to a strong impact.
- I Do not change the position or orientation of the front camera or remove it.
- I Do not disassemble the front camera.
- I Do not modify any parts around the front camera, such as the inside rear view mirror or ceiling.
- I Do not attach accessories which may obstruct the front camera to the hood, front grille, or front bumper. For details, contact your Toyota dealer.
- I If a surfboard or other long object is to be mounted on the roof, make sure that it will not obstruct the front camera.

- I Do not modify or change the headlights and other lights.

n Front camera installation area on the windshield

If the system determines that the windshield may be fogged up, it will automatically operate the heater to defog the part of the windshield around the front camera. When cleaning, etc., be careful not to touch the area around the front camera until the windshield has cooled sufficiently, as touching it may cause burns.

n Precautions for the driver monitor camera

Observe the following precautions.

Failure to do so may lead to malfunction of the driver monitor camera and the systems not operating properly, possibly leading to an accident resulting in death or serious injury.

- I Do not subject the driver monitor camera or its surrounding area to strong impact. If subjected to a strong impact, the driver monitor camera may move out of alignment and the driver may no longer be detected correctly. In this case, have the vehicle inspected by your Toyota dealer.
- I Do not disassemble or modify the driver monitor camera.
- I Do not attach accessories, stickers (including transparent stickers), etc. to the driver monitor camera or its surrounding area.
- I Do not allow the driver monitor camera or its surrounding area to get wet.

**WARNING**

Do not cover the driver monitor camera or place anything in front of it.

Keep the lens of the driver monitor camera free from damage.

Do not touch the lens of the driver monitor camera or allow it to become dirty.

When there is dirt or fingerprints on the camera lens, clean it with a dry, soft cloth so as to not mark or damage it.

When cleaning the lens, do not use detergents or organic solvents that may damage plastic.

n Situations in which the sensors and the systems may not operate properly

When the height or inclination of the vehicle has been changed due to modifications

When the windshield is dirty, fogged up, cracked or damaged

When the ambient temperature is high or low

When mud, water, snow, dead insects, foreign matter, etc., is attached to the front of the sensor

When in inclement weather such as heavy rain, fog, snow, or a sandstorm

When water, snow, dust, etc. is thrown up in front of the vehicle, or when driving through mist or smoke

When the headlights are not illuminated while driving in the dark, such as at night or when in a tunnel

When the lens of a headlight is dirty and illumination is weak

When the headlights are misaligned

When a headlight is malfunctioning

When the headlights of another vehicle, sunlight, or reflected light shines directly into the front camera

When the brightness of the surrounding area changes suddenly

When driving near a TV tower, broadcasting station, electric power plant, radar equipped vehicles, etc., or other location where strong radio waves or electrical noise may be present

When a wiper blade is blocking the front camera

When in a location or near objects which strongly reflect radio waves, such as the following:


- Tunnels
- Truss bridges
- Gravel roads
- Rutted, snow-covered roads
- Walls
- Large trucks
- Manhole covers
- Guardrail
- Metal plates

When near a step or protrusion


When a detectable vehicle is narrow, such as a small mobility vehicle

When a detectable vehicle has a small front or rear end, such as an unloaded truck

When a detectable vehicle has a low front or rear end, such as a low bed trailer



When a detectable vehicle has extremely high ground clearance



- | When a detectable vehicle is carrying a load which protrudes from its cargo area
- | When a detectable vehicle has little exposed metal, such as a vehicle which is partially covered with cloth, etc.
- | When a detectable vehicle is irregularly shaped, such as a tractor, sidecar, etc.
- | When the distance between the vehicle and a detectable vehicle has become extremely short
- | When a detectable vehicle is at an angle
- | When snow, mud, etc. is attached to a detectable vehicle
- | When driving on the following kinds of roads:
 - Roads with sharp curves or winding roads
 - Roads with changes in grade, such as sudden inclines or declines
 - Roads which is sloped to the left or right
 - Roads with deep ruts
 - Roads which are rough and unmaintained
 - Roads which frequently undulate or are bumpy
- | When the steering wheel is being operated frequently or suddenly
- | When the vehicle is not in a constant position within a lane
- | When parts related to this system, the brakes, etc. are cold or extremely hot, wet, etc.
- | When the wheels are misaligned
- | When driving on slick road sur-

faces, such as when it is covered with ice, snow, gravel, etc.

- | When the course of the vehicle differs from the shape of a curve
- | When the vehicle speed is excessively high when entering a curve
- | When entering/exiting a parking lot, garage, car elevator, etc.
- | When driving in a parking lot
- | When driving through an area where there are obstructions which may contact your vehicle, such as tall grass, tree branches, a curtain, etc.
- | When driving in strong wind
- n **Situations in which the lane may not be detected**
 - | When the lane is extremely wide or narrow
 - | Immediately after changing lanes or passing through an intersection
 - | When driving in a temporary lane or lane regulated by construction
 - | When there are structures, patterns, shadows which are similar to lane lines in the surrounding
 - | When there are multiple white lines for a lane line
 - | When the lane lines are not clear or driving on a wet road surface
 - | When a lane line is on a curb
 - | When driving on a bright, reflective road surface, such as concrete
- n **Situations in which some or all of the functions of the system cannot operate**
 - | When a malfunction is detected in this system or a related system, such as the brakes, steering, etc.
 - | When the VSC, TRAC, or other safety related system is operating
 - | When the VSC, TRAC, or other safety related system is off

n **Changes in brake operation sound and pedal response**

- | When the brakes have been operated, brake operation sounds may be heard and the brake pedal response may change, but this does not indicate a malfunction.
- | When the system is operating, the brake pedal may feel stiffer than expected or sink. In either situation the brake pedal can be depressed further. Further depress the brake pedal as necessary.

n **Situations in which the driver monitor may not operate properly**

In situations such as the following, the driver monitor camera may not be able to detect the driver's face, and the function may not operate properly.

- | When the inside of the vehicle is hot, such as after the vehicle has been parked in the sun
- | When a very bright light, such as the sun or the headlights of following vehicle, shines onto the driver monitor camera
- | When the brightness inside the vehicle changes frequently due to the shadows of surrounding structures, etc.
- | When a very bright light, such as the sun or the headlights of an oncoming vehicle, is shining onto the driver's face
- | When light, either inside or outside of the vehicle, is being reflected from the lenses of eyeglasses or sunglasses
- | When there are multiple faces in the detection range of the driver monitor camera, such as when a front or rear passenger is leaning toward the driver's seat
- | When the driver's face is outside of the detection range of the driver monitor camera, such as when

leaned forward or when their head is outside of the window

- | When the driver monitor camera is being blocked by the steering wheel, a hand holding the steering wheel, an arm, etc.
- | When the driver is wearing a hat
- | When the driver is wearing an eyepatch
- | When the driver is wearing eyeglasses or sunglasses that do not easily transmit infrared rays
- | When the driver is wearing contact lenses
- | When the driver is wearing a face mask
- | When the driver is laughing or the driver's eyes are only slightly open
- | When the driver's eyes, nose, mouth, or shape of their face is blocked
- | When the driver is wearing makeup which makes it difficult to detect their eyes, nose, mouth, or shape of their face
- | When the driver's eyes are blocked by the frame of eyeglasses, sunglasses, hair, etc.
- | When there is a device inside the vehicle that radiates near infrared rays, such as a non-genuine driver monitoring system.

n **Certification**


→P.671

Driver monitor

Basic functions

During controlled driving, the driver monitor camera detects the position and direction the driver is facing, and whether their eyes are opened or closed. Through this, the system determines if the driver is checking their surroundings and if the driver can perform driving operations.

In order to operate properly, the driver monitor camera requires an unobstructed view of the driver's face. If the steering column or seat position is either too high or too low, or if any other condition is present that obstructs the driver monitor camera's view of the driver's face, some driving support systems may not operate properly, or a warning message may be displayed.



n Warning function

In situations such as the following, a buzzer will sound and a

message will be displayed to warn the driver.

- When the system determines that the driver is not paying attention to the road or their eyes are closed
- When the driver's face cannot be detected or the system determines that the driver has poor driving posture

When the position of the steering wheel/driver's seat is too high or too low, the driver monitor camera may not be able to recognize the whole face of the driver which can limit feature functionality and possibly trigger an alarm. Adjust the steering wheel/seat position to achieve a proper seating position where the whole meter is visible. Confirm proper seat belt routing, head restraint positioning, and appropriate distance from the steering wheel and frontal airbag as described in this manual.

If the alarm continues even after making the recommended adjustments, contact your Toyota dealer.

n Face identification

The driver monitor is used as a device to identify faces in order to identify an individual.

For information about how to use the face identification function, priorities among other

devices of individual identification, and linked vehicle settings, see "My Settings". (→P.209)



WARNING

n For safe use

! The driver monitor is not designed to prevent the driver from driving carelessly or having a poor driving posture. Pay careful attention to the surrounding conditions in order to ensure safe driving.

! The driver monitor cannot reduce drowsiness. If you feel unable to concentrate or drowsy, take a break and sleep as necessary in order to ensure safe driving.

n Warning function

These functions may not operate when the vehicle speed is low.

n Face identification

Face identification starts when the door is opened then closed.

In face identification, facial traits are digitized and stored in a built-in computer, to be used for identification in My Settings.

- ! Face image or video are not stored. Voice is not stored either.
- ! Digitized face information is not used for any purpose other than identification in My Settings. Additionally, face information cannot be decoded and will not be disclosed or provided to a third party.
- ! Face information can be deleted by yourself.
- ! For the handling of face information, please consent to the following before using it:
 - Face identification does not guarantee a complete identity authentication, collation, or identification.
 - When face information registration

fails frequently or face identification fails frequently, the driver cameras should be cleaned or face information should be registered again.

- Face information stored in the vehicle computer cannot be decoded or moved to another media. Therefore, it is necessary to register face information again once it is deleted or relevant parts are replaced.
- Once deleted, face information cannot be restored. It is necessary to register face information again.

n Situations where face identification may not be performed correctly

This system is designed for use to identify facial traits. In the following situations, face information may not be able to be registered or identified correctly:

- ! When a part of the driver's face (eyebrows, eyes, nose, or mouth) is not visible
- ! When the driver is wearing glasses/sun glasses, a face mask, muffler, etc.
- ! When the driver is not facing front
- ! When part of driver's face is covered with hair, beard, a hand, clothes, jewelry, etc.
- ! When the driver is closing eyes
- ! When a non-registered driver is a twin, etc. with a registered driver, whose face looks quite alike with each other

n Situations in which the driver monitor may not operate properly

→P.270

Changing Driver monitor settings

The Warning function of Driver monitor can be enabled/dis-

abled through the customize setting. (→P.627)

PCS (Pre-Collision System)

The pre-collision system uses sensors to detect objects (→P.274) in the path of the vehicle. When the system determines that the possibility of a frontal collision with a detectable object is high, a warning operates to urge the driver to take evasive action and the potential brake pressure is increased to help the driver avoid the collision. If the system determines that the possibility of a collision is extremely high, the brakes are automatically applied to help avoid the collision or help reduce the impact of the collision.

The pre-collision system can be disabled/enabled and the warning timing can be changed. (→P.284)

⚠ WARNING

n For safe use

Driving safely is solely the responsibility of the driver. Pay careful attention to the surrounding conditions in order to ensure safe driving.

Never use the pre-collision system in place of normal braking operations. This system cannot help avoid or reduce the impact of a collision in every situation. Over-reliance on this system to drive the vehicle safely may lead to an accident resulting in death or serious injury.

Although the pre-collision system is designed to help avoid or help reduce the impact of a collision, its effectiveness may change according to various conditions. Therefore, it may not always be able to achieve the same level of performance. Read the following items carefully. Do not overly rely on this system and always drive carefully.

- For safe use: →P.263

n When to disable the pre-collision system

When it is necessary to disable the system: →P.263

Detectable objects

The system can detect the following as detectable objects. (Detectable objects differ depending on the function.)

- Vehicles
- Bicycles*
- Pedestrians
- Motorcycles*

● Walls


*: Detected as a detectable object only when being ridden.

System functions

n Pre-collision warning


When the system determines that the possibility of a collision is high, a buzzer will sound and an icon and warning message will be displayed on the multi-information display to urge the driver to take evasive action.

If the detectable object is a vehicle, there may be cases where moderate braking will be performed with the warning.



A “Pre-Collision System”

If the system determines that the accelerator pedal is strongly depressed, the following icon and message will be displayed on the multi-information display.



A “Accelerator Pedal is Pressed”

n **Pre-collision brake assist**

If the system determines that the possibility of a collision is high and the brake operation by the driver is insufficient, the braking power will be increased.

n **Pre-collision brake control**

If the system determines that the possibility of a collision is extremely high, the brakes are automatically applied to help avoid the collision or reduce the impact of the collision.

n **Emergency steering assist**

If the system determines that the following conditions are met, assistance will be provided to help enhance vehicle stability and prevent lane departure. During assistance, in addition to the pre-collision warning, the following icon will be displayed on the multi-information display.


- The possibility of a collision is high
- There is sufficient space within the lane to perform

evasive steering maneuvers

- The driver is operating the steering wheel

Vehicles with active steering function: The brakes and steering are controlled to help avoid a collision or reduce the impact of a collision, regardless of the evasive steering maneuvers performed by the driver.

During assistance, the pre-collision warning will operate and a message will be displayed to warn the driver.




n **Intersection collision avoidance support (left/right turn)**

In situations such as the following, if the system determines that the possibility of a collision is high, the pre-collision warning and pre-collision braking will operate.


Depending on the intersection, assistance may not operate correctly.

- When turning left/right at an intersection and crossing the path of an oncoming vehi-

cle/motorcycle




- When turning left/right and a pedestrian or bicycle is detected



n Intersection collision avoidance support (crossing vehicles)


At an intersection, etc., if the system determines that the possibility of a collision with an approaching vehicle or motorcycle is high, the pre-collision warning and pre-collision braking will operate.

Depending on the intersection, assistance may not operate correctly.



n Acceleration Suppression at Low Speed

When driving at a low speed, if the accelerator pedal is strongly depressed and the system determines that there is a possibility of a collision, EV system output will be restrained or the brakes will be applied weakly to restrict acceleration. During operation, a buzzer will sound and a warning indicator and message will be displayed on the multi-information display.



- A "Accelerator Pedal is Pressed"

⚠ WARNING

n Pre-collision braking

- I When the pre-collision braking function is operating, a large amount of braking force will be applied.

**WARNING**

I The pre-collision braking function is not designed to hold the vehicle stopped. If the vehicle is stopped by pre-collision brake control, the driver should operate the brakes immediately as necessary.

I The pre-collision braking function may not operate if certain operations are performed by the driver. If the accelerator pedal is being depressed strongly or the steering wheel is being turned, the system may determine that the driver is taking evasive action and possibly prevent the pre-collision braking function from operating.

I If the brake pedal is being depressed, the system may determine that the driver is taking evasive action and possibly delay the operation timing of the pre-collision brake control.

n Acceleration Suppression at Low Speed

If the steering wheel is being turned, the system may determine that the driver is taking evasive action and possibly prevent the Acceleration Suppression at Low Speed function from operating or possibly causing its operation to be canceled.

n Emergency steering assist

I The emergency steering assist will be canceled when the system determines that lane departure prevention control has completed.

I Depending on operations performed by the driver, emergency steering assist may not operate or operation may be canceled.

- If the accelerator pedal is depressed strongly, the steering wheel is turned heavily, the brake pedal is depressed, or the turn signal lever is operated, the system may determine that the driver is taking evasive action and the emergency steering assist may not operate.

- While the emergency steering assist is operating, if the accelerator pedal is depressed strongly, the steering wheel is turned heavily, or the brake pedal is depressed, the system may determine that the driver is taking evasive action and emergency steering assist operation may be canceled.

- While the emergency steering assist is operating, if the steering wheel is held or turned in the opposite direction of system operation, emergency steering assist operation will be canceled.

n Operating conditions of each function of the pre-collision system

The pre-collision system is enabled and the system determines that the possibility of a frontal collision with a detected object is high.

However, the system will not operate in the following situations:

- | When the vehicle has not been driven a certain amount after a terminal of the 12-volt battery has been disconnected and reconnected
- | When the shift position is in R
- | When the VSC OFF indicator is illuminated (only the pre-collision warning function will be operational)

The following are the operational speeds and cancelation conditions of each function:

- | Pre-collision warning

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Preceding vehicles, stopped vehicles	Approximately 3 to 110 mph (5 to 180 km/h)	Approximately 3 to 110 mph (5 to 180 km/h)
Oncoming vehicles	Approximately 20 to 110 mph (30 to 180 km/h)	Approximately 50 to 130 mph (80 to 220 km/h)
Bicycles	Approximately 3 to 50 mph (5 to 80 km/h)	Approximately 3 to 50 mph (5 to 80 km/h)
Pedestrians	Approximately 3 to 50 mph (5 to 80 km/h)	Approximately 3 to 50 mph (5 to 80 km/h)
Preceding motorcycles, stopped motorcycles	Approximately 3 to 110 mph (5 to 180 km/h)	Approximately 3 to 50 mph (5 to 80 km/h)
Oncoming motorcycles	Approximately 20 to 110 mph (30 to 180 km/h)	Approximately 20 to 110 mph (30 to 180 km/h)

While the pre-collision warning is operating, if the steering wheel is operated heavily or suddenly, the pre-collision warning may be canceled.

- | Pre-collision brake assist

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Preceding vehicles, stopped vehicles	Approximately 20 to 110 mph (30 to 180 km/h)	Approximately 7 to 110 mph (10 to 180 km/h)
Bicycles	Approximately 20 to 50 mph (30 to 80 km/h)	Approximately 20 to 50 mph (30 to 80 km/h)

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Pedestrians	Approximately 20 to 50 mph (30 to 80 km/h)	Approximately 20 to 50 mph (30 to 80 km/h)
Preceding motorcycles, stopped motorcycles	Approximately 20 to 110 mph (30 to 180 km/h)	Approximately 7 to 50 mph (10 to 80 km/h)

I Pre-collision braking

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Preceding vehicles, stopped vehicles	Approximately 3 to 110 mph (5 to 180 km/h)	Approximately 3 to 110 mph (5 to 180 km/h)
Oncoming vehicles	Approximately 20 to 110 mph (30 to 180 km/h)	Approximately 50 to 130 mph (80 to 220 km/h)
Bicycles	Approximately 3 to 50 mph (5 to 80 km/h)	Approximately 3 to 50 mph (5 to 80 km/h)
Pedestrians	Approximately 3 to 50 mph (5 to 80 km/h)	Approximately 3 to 50 mph (5 to 80 km/h)
Preceding motorcycles, stopped motorcycles	Approximately 3 to 110 mph (5 to 180 km/h)	Approximately 3 to 50 mph (5 to 80 km/h)
Oncoming motorcycles	Approximately 20 to 110 mph (30 to 180 km/h)	Approximately 20 to 110 mph (30 to 180 km/h)

If either of the following occur while the pre-collision braking function is operating, it will be canceled:

- The accelerator pedal is strongly depressed
- The steering wheel is operated heavily or suddenly

I Emergency steering assist

The emergency steering assist will not operate when the turn signal lights are flashing.

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Preceding vehicles, stopped vehicles, bicycles, pedestrians, motorcycles	Approximately 25 to 50 mph (40 to 80 km/h) Active steering function: * to 50 mph (* to 80 km/h)	Approximately 25 to 50 mph (40 to 80 km/h) Active steering function: * to 50 mph (* to 80 km/h)

*: Minimum vehicle speed: Vehicle speed at which evasion using pre-collision brake control is difficult

While the emergency steering assist is operating, if any of the following are performed, emergency steering assist operation may be canceled:

- The accelerator pedal is strongly depressed
- The steering wheel is operated heavily or suddenly
- The brake pedal is depressed

| Intersection collision avoidance support (left/right turn)

The intersection collision avoidance support (for left/right turning vehicles) will not operate when the turn signal lights are not flashing.

Detectable objects	Vehicle speed	Oncoming vehicle speed	Relative speed between your vehicle and object
Oncoming vehicles	Approximately 3 to 25 mph (5 to 40 km/h)	Approximately 3 to 45 mph (5 to 75 km/h)	Approximately 7 to 70 mph (10 to 115 km/h)
Pedestrians	Approximately 3 to 20 mph (5 to 30 km/h)	—	Approximately 3 to 25 mph (5 to 40 km/h)
Bicycles	Approximately 3 to 20 mph (5 to 30 km/h)	—	Approximately 3 to 30 mph (5 to 50 km/h)
Oncoming motorcycles	Approximately 3 to 25 mph (5 to 40 km/h)	Approximately 3 to 45 mph (5 to 75 km/h)	Approximately 7 to 70 mph (10 to 115 km/h)

| Intersection collision avoidance support (crossing vehicles)

► Vehicles without front side radars

Detectable objects	Vehicle speed	Crossing vehicle speed	Relative speed between your vehicle and object
Vehicles, Motorcycles (side)	Approximately 3 to 38 mph (5 to 60 km/h)	<ul style="list-style-type: none">• Your vehicle speed or less• Approximately 25 mph or less (40 km/h or less)	Approximately 3 to 38 mph (5 to 60 km/h)

The system operates only when the crossing vehicle speed is same as or less than the vehicle speed.

When driving at approximately 25 mph (40 km/h) or more, this system will

only operate when the speed of the other vehicle is approximately 25 mph (40 km/h) or less.

► Vehicles with front side radars

Detectable objects	Vehicle speed	Crossing vehicle speed	Relative speed between your vehicle and object
Vehicles, Motorcycles (side)	Approximately 3 to 38 mph (5 to 60 km/h)	Approximately 31mph or less (50 km/h or less)	Approximately 3 to 38 mph (5 to 60 km/h)

l Acceleration Suppression at Low Speed

The Acceleration Suppression at Low Speed function will not operate when the turn signal lights are flashing.

Detectable objects	Vehicle speed	Relative speed between your vehicle and object
Preceding vehicles, stopped vehicles, Pedestrians, Bicycles, Wall	Approximately 0 to 9 mph (0 to 15 km/h)	Approximately 0 to 9 mph (0 to 15 km/h)

While the Acceleration Suppression at Low Speed function is operating, if any of the following are performed, the low speed sudden acceleration suppression function operation will be canceled:


- The accelerator pedal is released.
- The steering wheel is operated heavily or suddenly

n **Detection of detectable objects**

Objects are detected based on their size, shape, and movement.


Depending on the ambient brightness, movement, posture and direction of a detectable object, it may not be detected and the system may not operate properly.

The system detects shapes, such as the following, as detectable objects.




n **Situations in which the system may operate even though the possibility of a collision is not high**


- l In certain situations, such as the following, the system may determine that the possibility of a collision is high and operate:
 - When passing a detectable object
 - When changing lanes while overtaking a detectable object
 - When suddenly approaching a detectable object
 - When approaching a detectable object or other object on the roadside, such as guardrails, utility poles, trees, walls, etc.
 - When there is a detectable object or other object by the roadside of a curve




- When there are patterns or a painting ahead of the vehicle that may be mistaken for a detectable object
- When passing a detectable object that is changing lanes or turning left/right




- When passing a detectable object which is stopped to make a left/right turn




- When a detectable object stops immediately before entering the path of the vehicle
- When passing through a location with a structure above the road (traffic sign, billboard, etc.)



- When approaching an electric toll gate barrier, parking lot barrier, or other barrier that opens and closes
- When turning left/right and an oncoming vehicle, oncoming motorcycle, pedestrian or bicycle crosses in front of the vehicle
- When attempting to turn left/right in front of an oncoming vehicle, oncoming motorcycle, pedestrian or bicycle
- When turning left/right and an oncoming vehicle, oncoming motorcycle, pedestrian or bicycle stops or changes course immediately before entering the path of the vehicle
- When turning left/right and an oncoming vehicle/motorcycle turns left/right in front of the vehicle



- When the steering wheel is operated toward the path of an oncoming vehicle
- When there is an object moving above or under the road




n Situations in which the system may not operate properly

- l In certain situations, such as the following, a detectable object may not be detected by the front sensors, and the system may not operate properly:


- When a detectable object is approaching your vehicle
- When your vehicle or a detectable object is wandering
- When a detectable object makes an abrupt maneuver (such as sudden swerving, acceleration or deceleration)
- When suddenly approaching a detectable object
- When the detectable object is near a wall, fence, guardrail, manhole cover, steel plate on the road surface, or another vehicle
- When there is a structure above a detectable object
- When part of a detectable object is hidden by another object (large luggage, umbrella, guardrail, etc.)
- When multiple detectable objects are overlapping
- When a bright light, such as the sun, is reflecting off of a detectable object
- When a detectable object is white and looks extremely bright
- When the color or brightness of a detectable object causes it to blend in with its surroundings
- When a detectable object cuts in front of or suddenly emerges in front of your vehicle
- When approaching a vehicle which is diagonal
- If a bicycle is a child sized bicycle, is carrying a large load, is carrying an extra passenger, is carrying a forward leaning rider, or has an unusual shape (bicycles equipped with a child seat, tandem bicycles, etc.)
- If a pedestrian or bicycle is shorter than approximately 3.2 ft. (1 m) or taller than approximately 6.5 ft. (2 m).
- When the silhouette of a pedestrian or bicycle is unclear (such as when they are wearing a raincoat, long skirt, etc.)
- When a pedestrian is bending forward or squatting
- When a pedestrian or bicycle is moving at high speed
- When a pedestrian is pushing a

stroller, wheelchair, bicycle or other vehicle

- When a detectable object blends in with the surrounding area, such as when it is dim (at dawn or dusk) or dark (at night or in a tunnel)
- When the vehicle has not been driven for a certain amount of time after the EV system was started
- While turning left/right or a few seconds after turning left/right
- While driving around a curve and a few seconds after driving around a curve
- When turning left/right and an oncoming vehicle/motorcycle is driving in a lane 3 or more lanes from the vehicle
- When turning left/right and the direction of the vehicle differs greatly from the direction traffic flows in the oncoming lane



- When turning left/right, a pedestrian or bicycle behind the vehicle comes in front of it as if it overtakes the vehicle



- When at an intersection, the approaching crossing vehicle is long in overall length, such as a large truck, towing trailer, etc.
- In addition to the preceding, in certain situations, such as the following, the emergency steering assist may not operate properly:

- When a detectable object is too close to the vehicle
- When there is insufficient space to perform evasive steering maneuvers or an obstruction exists in the evasion direction
- When there is an oncoming vehicle
- In addition to the preceding, in certain situations, such as the following, walls may not be detected as a target object and the Acceleration Suppression at Low Speed function may not operate properly:
 - When scenery behind the wall is visible, such as a glass door, grid fence, etc.
 - When the wall is slanted or low
 - When the wall is narrow, such as a pole, etc.
 - When the wall is made of plants, such as a hedge, etc.
 - When the road, etc. is reflected on the wall
 - When the vehicle is approaching the wall at an angle

Changing the pre-collision setting

- The pre-collision system can be enabled/disabled through a customize setting. (→P.627)

The system is enabled each time the power switch is turned to ON.

- When the system is disabled, the PCS warning light will illuminate and a message will be displayed on the multi-information display.
- The pre-collision setting can be changed on the customize settings. (→P.633)
- When the pre-collision warning timing is changed, the emergency steering assist

timing will also be changed.

Vehicles without front side radar sensors: When “Later” is selected, the emergency steering assist will not operate in most cases.

Vehicles with front side radar sensors: When “Later” is selected, the emergency steering assist (excluding the active steering function) will not operate in most cases.

- When the system determines that the driver is not facing forward, the pre-collision warning and emergency steering assist will operate at the “Earlier” timing, regardless of the user setting.
- When the dynamic radar cruise control is operating, the pre-collision warning will operate at the “Earlier” timing, regardless of the user setting.
- Vehicles with Traffic Jam Assist: When the Traffic Jam Assist is operating, the pre-collision warning will operate at the “Earlier” timing, regardless of the user setting.

LTA (Lane Tracing Assist)

LTA functions

- When driving on a road with clear lane lines with the dynamic radar cruise control operating, lane lines and preceding and surrounding vehicles are detected using the front camera and radar sensor, and the steering wheel is operated to maintain the vehicle's lane position.


Use the this function only on highways and expressways.

If the dynamic radar cruise control is not operating, the function will not operate.

In situations where the lane lines are difficult to see or are not visible, such as when in a traffic jam, support will be provided using the path of preceding and surrounding vehicles.


If the system determines that the steering wheel has not been operated for a certain amount of time or the steering wheel is not being firmly gripped, the driver will be alerted and this function will be temporarily canceled.

If the steering wheel is firmly gripped, the function will begin operating again.



- When the function is operating, if the vehicle is likely to depart from its lane, the driver will be alerted via a display and buzzer.

When the buzzer sounds, check the area around the vehicle and carefully operate the steering wheel to move the vehicle back to the center of the lane.



⚠ WARNING

n Before using the LTA system

l Do not overly rely on the LTA system. The LTA system is not a system which provides automated assistance in driving and it is not a system which reduces the amount of attention necessary for safe driving. The driver is solely responsible for paying attention to their surroundings and operating the steering wheel as necessary to ensure safety. Also, the driver is responsible for taking adequate breaks when fatigued, such as when driving for a long time.

l Failure to perform appropriate driving operations and pay careful attention may lead to an accident.

l When not using the LTA system, turn it off using the LTA switch.

n Operating conditions of function

This function is operable when all of

the following conditions are met:

- l The LTA system detects lane lines or the path of preceding or surrounding vehicles.
- l The dynamic radar cruise control is operating.
- l The lane width is approximately 10 to 13 ft. (3 to 4 m).
- l The turn signal lever is not being operated.
- l The vehicle is not being driven around a sharp curve.
- l The vehicle is not accelerating or decelerating more than a certain amount.
- l The steering wheel is not being turned with a large force.
- l The hands off steering wheel warning (→P.287) is not operating.
- l The vehicle is being driven in the center of a lane.

n Temporary cancelation of functions

- l When the operating conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function will automatically be restored. (→P.286)
- l If the operating conditions of a function are no longer met while the function is operating, a buzzer may sound to indicate that the function has been temporarily canceled.
- l The steering assist operation of the function can be overridden by the steering wheel operation of the driver.

n Lane departure warning function when the LTA is operating


- l Even if the LDA warning method is changed to vibration of the steering wheel, if the vehicle deviates from the lane while the LTA is operating, the warning buzzer will

sound to alert the driver.

- l If steering wheel operation equivalent to that necessary for a lane change is detected, the system will determine the vehicle is not deviating from the lane and the warning will not operate.

n Hands off steering wheel warning operation

- l When the system determines the driver is not holding the steering wheel, a message urging the driver to grip the steering wheel and the icon shown in the illustration will be displayed on the multi-information display to warn the driver. If the system detects that the steering wheel is held, the warning will be canceled. When using the system, make sure to grip the steering wheel firmly, regardless of whether the warning is operating or not.



- l If no operations are detected for a certain amount of time, the warning will operate and the function will be temporarily canceled. This warning may also operate if the driver only operates steering wheel a small amount continuously.

n Situations in which the hands off steering wheel warning may not operate properly


- l Depending on the condition of the vehicle, handle control condition and road surface, the warning function may not operate.
- l Vehicles with LCA: In the following situations, the system may not be able to detect when the driver's hands are off the steering wheel.

- When a steering wheel cover is installed
- When the driver is wearing gloves
- When foreign matter is attached to the steering wheel
- When the driver is gripping the wood trim, seam of the leather, spokes, or other part of the steering wheel that does not have sensors
- l Vehicles with LCA: In the following situations, the hands off steering wheel warning may not operate and the LTA function may continue operating even though the driver's hands are off the steering wheel:
 - When something other than a hand is contacting the steering wheel
 - When a wide object or arms are held across the steering wheel

Enabling/disabling the system

The LTA will change between ON/OFF each time the LTA switch is pressed.

When the LTA is ON, the LTA indicator will illuminate.




**WARNING**

n Situations in which the functions may not operate properly

In the following situations, the functions may not operate properly and the vehicle may depart from its lane. Do not overly rely on these functions. The driver is solely responsible for paying attention to their surroundings and operating the steering wheel as necessary to ensure safety.

- I When a preceding or surrounding vehicle changes lanes (Your vehicle may follow the preceding or surrounding vehicle and also change lanes)



- I When a preceding or surrounding vehicle is swaying (Your vehicle may sway accordingly and depart from the lane)

- I When a preceding or surrounding vehicle departs from a lane (Your vehicle may follow the preceding or surrounding vehicle and also depart from the lane)
- I When a preceding or surrounding vehicle is being driven extremely close to the left/right lane line (Your vehicle may follow the preceding or surrounding vehicle accordingly and depart from the lane)
- I When there are moving objects or structures in the surrounding area (Depending on the position of the moving object or structure relative to your vehicle, your vehicle may sway)
- I When the vehicle is struck by a crosswind or the turbulence of other nearby vehicles
- I Situations in which the sensors may not operate properly: →P.268
- I Situations in which the lane may not be detected: →P.269
- I When it is necessary to disable the system: →P.263

Operation display of steering wheel operation support

The operating state of the LTA system is indicated.

Indicator	Lane display	Steering icon	Situation
 White	 Gray/White	 Gray	LTA is on standby
 Green	 Green	 Green	LTA is operating
 Yellow Flashing	 Yellow Flashing	 Green	The vehicle is departing the lane toward the side which the lane display is flashing

LCA (Lane Change Assist)*

*: If equipped


LCA functions

This function is linked to the LTA and provides assistance in performing lane changes through steering wheel operations.

Use this function only on highways and expressways.

The steering assist operation can be overridden by the steering wheel operation of the driver.

The lane change assist function is not designed to operate when changing lanes at a junction.



⚠ WARNING

n Before using the LCA system

Do not overly rely on the LCA system.

The LCA system is not a system which provides automated assistance in driving and it is not a system which reduces the need for checking an adjacent lane for other vehicles, approaching vehicles, etc. when changing lanes. The driver is solely responsible for paying attention to their surroundings and operating the steering wheel as necessary to ensure safety.

Also, do not use the LCA to change lanes into which a lane change should not be performed (oncoming lanes, road shoulders, etc.).

Failure to perform appropriate driving operations and pay careful attention may lead to an accident.

n Operating conditions of function

This function is operable when all of the following conditions are met:

- l The LTA is operating.
- l The lane change assist function is enabled by a customize setting.
- l The vehicle speed is between approximately 55 and 85 mph (90 and 140 km/h).
- l The system detects a broken white line on the side which the lane change is to be performed.
- l A vehicle is not detected in the lane toward which the turn signal is operated.
- l The steering wheel is not being turned with a large force.

- | The hands off steering wheel warning (→P.287) is not operating.

n Cancellation of functions

In the following situations, operation of the LCA may be canceled with the display and buzzer:

- | When the operating conditions (→P.290) are no longer met
- | When the system can no longer detect lane lines
- | When the turn signal lever is operated to the second position (→P.291)
- | When the turn signal lever is operated in the opposite direction of the lane change
- | When the system detects operation of the steering wheel, brake pedal or accelerator pedal by the driver.

If the system detects that a vehicle is quickly approaching in the lane toward which the turn signal is operated a buzzer will sound and a message will be displayed to alert the driver. At the same time the steering wheel may be slightly operated to help keep the vehicle away from the approaching vehicle.

n Hands off steering wheel warning operation

When the system determines the driver is not holding the steering wheel, a message urging the driver to grip the steering wheel and the icon shown in the illustration will be displayed on the multi-information display to warn the driver. If the system detects that the steering wheel is held, the warning will be canceled. When using the system, make sure to grip the steering wheel firmly, regardless of whether the warning is operating or not.




n Situations in which the hands off steering wheel warning may not operate properly

- | Depending on the condition of the vehicle, handle control condition and road surface, the warning function may not operate.
- | In the following situations, the system may not be able to detect when the driver's hands are off the steering wheel.
 - When a steering wheel cover is installed
 - When the driver is wearing gloves
 - When foreign matter is attached to the steering wheel
 - When the driver is gripping the wood trim, seam of the leather, spokes, or other part of the steering wheel that does not have sensors
- | In the following situations, the hands off steering wheel warning may not operate and the LCA function may continue operating even though the driver's hands are off the steering wheel:
 - When something other than a hand is contacting the steering wheel
 - When a wide object or arms are held across the steering wheel

Operating the LCA

If the turn signal lever is held in the lane change position (1) until a buzzer sounds, the lane change direction will be displayed and the function will operate.

To change lanes by holding the turn signal lever in the first position without using the LCA, turn the customize setting of the LCA off.



- 1 First position: LCA is operational
- 2 Second position: LCA is not operational

 **WARNING**

n

Situations in which the LCA should not be used

I

When driving on a one lane road

I

When there is no broken white line between the current lane and the lane to be changed to

Enabling/disabling the system

LCA can be enabled/disabled through a customize setting. (→P.634)

Displays and system operation

The operating state of the LCA system is indicated.

LCA display	Steering icon	Condition
 Blue arrow and white line	 Green	LCA is operating
 Gray line	 Gray	Approaching vehicle detected while LCA is operating
 Gray line	 Gray	Lane line no longer detected while LCA is operating

LDA (Lane Departure Alert)

Basic functions

The LDA system warns the driver if the vehicle may deviate from the current lane or course*, and also can slightly operate the steering wheel to help avoid deviation from the lane or course*.

The front camera is used to detect lane lines or a course*.

*: Boundary between the asphalt and grass, soil, etc., or structures, such as a curb, guardrail, etc.


n Lane departure alert function

When the system determines that the vehicle might depart from its lane or course*, a warning is displayed on a display, and either a warning buzzer will sound or the steering wheel will vibrate to alert the driver.

Check the area around your vehicle and carefully operate the steering wheel to move the vehicle back to the center of the lane or course*.

If the system determines that the vehicle may collide with a vehicle in an adjacent lane, the lane departure alert will operate even if the turn signals are operating.

*: Boundary between the asphalt and grass, soil, etc., or structures, such as a curb, guardrail, etc.



n Lane departure prevention function


If the system determines that the vehicle is likely to depart from its lane or course*, it provides assistance through steering wheel operations to help avoid deviation from the lane or course*.

If the system determines that the steering wheel has not been operated for a certain amount of time or the steering wheel is not being firmly gripped, a warning message may be displayed and a warning buzzer may sound to alert the driver.

If the system determines that the vehicle may collide with a vehicle in an adjacent lane, the lane departure prevention function will operate even if the turn signals are operating.


*: Boundary between the asphalt

and grass, soil, etc., or structures, such as a curb, guardrail, etc.



n Break suggestion function

If the vehicle is swaying, a message will be displayed and a buzzer will sound to urge the driver to take a break.



⚠ WARNING

n Before using the LDA system

Do not overly rely on the LDA system. The LDA system is not a system which provides automated assistance in driving. However, as it is not a system which reduces the amount of attention necessary for safe driving. The driver is solely responsible for paying attention to their surroundings and operating the steering wheel as necessary to ensure safety. Also, the driver is responsible for taking adequate breaks when fatigued, such as when driving for a long time.

Failure to perform appropriate driving operations and pay careful attention may lead to an accident.

n Operating conditions of each function

l Lane departure alert/prevention function

This function is operable when all of the following conditions are met:

- The vehicle speed is approximately 30 mph (50 km/h) or more.

Operation may be possible when the vehicle speed is approximately 25 mph (40 km/h) or more if vehicles, motorcycles, bicycles, or pedestrians are detected near the lane.

- The system recognizes a lane or course*. (When recognized on only one side, the system will operate only for the recognized side.)
- The lane width is approximately 9.8 ft. (3 m) or more.
- The turn signal lever is not being operated.

(Except when a vehicle is detected

in the direction that the turn signal lever is operated.)

- The vehicle is not being driven around a sharp curve.
- The vehicle is not accelerating or decelerating more than a certain amount.
- The steering wheel is not being turned sufficiently to perform a lane change.
- The VSC or TRAC system is not turned off.

*: Boundary between the asphalt and grass, soil, etc., or structures, such as a curb, guardrail, etc.

n Temporary cancellation of functions

When the operating conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function will automatically be restored. (→P.294)


n Operation of the lane departure alert function/lane departure prevention function

- l Depending on the vehicle speed, road conditions, lane departure angle, etc., operation of the lane departure prevention function may not be felt or the function may not operate.
- l Depending on the conditions, the warning buzzer may operate even if vibration is selected through a customize setting.
- l If a course* is not clear or straight, the lane departure alert function or lane departure prevention function may not operate.
- l The lane departure alert function or lane departure prevention function may not operate if the system judges that the vehicle is intentionally being steered to avoid a pedestrian or parked vehicle.
- l It may not be possible for the system to judge if there is danger of a

collision with a vehicle in an adjacent lane.

- l Depending on the driver condition, the lane departure alert function or lane departure prevention function changes the timing of operation.
- l The steering assist operation of the lane departure prevention function can be overridden by the steering wheel operation of the driver.
- *: Boundary between the asphalt and grass, soil, etc., or structures, such as a curb, guardrail, etc.
- n **Hands off steering wheel warning operation**

In the following situations, a message urging the driver to operate the steering wheel and an icon will be displayed and a buzzer will sound to warn the driver. When using the system, make sure to grip the steering wheel firmly, regardless of whether the warning is operating or not.



- l When the system determines that the driver is not securely holding the steering wheel, or the steering wheel is not being operated when the steering assist operation of the lane departure prevention function is operating

Except for Puerto Rico: The length of time that the warning buzzer operates will become longer as the frequency of the steering assist operating increases. If the system judges that the steering wheel has been operated, the warning buzzer will stop.

For Puerto Rico: The length of time that the warning buzzer operates will become longer as the frequency of the steering assist operating increases. Even if the system judges that the steering wheel has been operated, the warning buzzer will sound for a certain amount of time.*

*: The countries and areas for each region listed in the table are current as of January 2026. However, depending on when the vehicle was sold, the countries and areas of each region may be different. Contact your Toyota dealer for details.

n Break suggestion function

This function is operable when all of the following conditions are met:

- l The vehicle speed is approximately 40 mph (65 km/h) or more.*^{1, 3}
- l The vehicle speed is approximately 32 mph (50 km/h) or more.*^{2, 3}
- l The lane width is approximately 9.8 ft. (3 m) or more.

Depending on the condition of the vehicle and road surface, the break suggestion function may not operate.



Press the  meter control switch to turn off the message.*^{1, 3}

Unless  or  is pressed, the message of the break suggestion

function will remain displayed.*^{1, 3}

*¹: For Puerto Rico

*²: Except for Puerto Rico

*³: The countries and areas for each region listed in the table are current as of January 2026. However, depending on when the vehicle was sold, the countries and areas of each region may be different. Contact your Toyota dealer for details.

Changing LDA settings

- The LDA system can be enabled/disabled through a customize setting. (→P.627)
- The settings of the LDA can be changed on the customize settings. (→P.627)
- When the system determines that the driver is tired, the lane departure warning function will operate at the “Earlier” timing, regardless of the customized setting. Also, this setting will be kept until the power switch is turned off.



WARNING

n Situations in which the system may not operate properly

In the following situations, the system may not operate properly and the vehicle may depart from its lane. Do not overly rely on these functions. The driver is solely responsible for paying attention to their surroundings and operating the steering wheel as necessary to ensure safety.

**WARNING**

- | When the boundary between the asphalt and grass, soil, etc., or structures, such as a curb, guardrail, etc. is not clear or straight
- | When the vehicle is struck by a crosswind or the turbulence of other nearby vehicles
- | Situations in which the lane may not be detected: →P.269
- | Situations in which the sensors may not operate properly: →P.268
- | Situations in which some or all of the functions of the system cannot operate: →P.269
- | When it is necessary to disable the system: →P.263

Displays and system operation

The operating state of the lane departure alert function and steering assist operation of the lane departure prevention function are indicated.

► Except for Puerto Rico

Indicator	Lane display	Steering icon	Situation
Not illuminated	Not illuminated	Not illuminated	System disabled
 White	 Gray	Not illuminated	Lane lines are not detected by the system
 White	 White	Not illuminated	Lane lines are detected by the system

Indicator	Lane display	Steering icon	Situation
 Yellow Flashing	 Yellow Flashing	Not illuminated	Lane departure alert function is operating for the side which the lane display is flashing
 Green	 Green	 Green	Lane departure prevention function is operating for the side which the lane display is illuminated
 Yellow Flashing	 Yellow Flashing	 Green	Lane departure alert function/lane departure prevention function is operating for the side which the lane display is flashing

► For Puerto Rico

Indicator	Lane display	Steering icon	Situation
 Yellow Illuminated	Not illuminated	Not illuminated	System disabled
Not illuminated	 Gray	Not illuminated	Lane lines are not detected by the system
Not illuminated	 White	Not illuminated	Lane lines are detected by the system
 Yellow Flashing	 Yellow Flashing	Not illuminated	Lane departure alert function is operating for the side which the lane display is flashing

Indicator	Lane display	Steering icon	Situation
 Green	 Green	 Green	Lane departure prevention function is operating for the side which the lane display is illuminated
 Yellow Flashing	 Yellow Flashing	 Green	Lane departure alert function/lane departure prevention function is operating for the side which the lane display is flashing

PDA (Proactive driving assist)

When a detectable object (→P.301) is detected, the proactive driving assist operates the brakes and steering wheel to help prevent the vehicle from approaching too close to the object.



WARNING

n For safe use

Driving safely is solely the responsibility of the driver.

I The proactive driving assist is designed to provide some assistance for regular braking and steering operations, as well as helping to prevent the vehicle from approaching too close to a detectable object. However, the scope of this assistance is limited.

The driver should perform brake and steering operations as necessary. Read the following items carefully. Do not overly rely on the proactive driving assist and always drive carefully. (→P.302)

I The proactive driving assist is not a system which reduces the amount of attention necessary for safe driving. Even if the system is operating correctly, the surrounding conditions as recognized by the driver and detected by the system may differ. It is necessary for the driver to pay attention, assess risks, and ensure safety. Over-reliance on this system to drive the vehicle safely may lead to an accident resulting in death or serious injury.

I Proactive driving assist is not a system which allows for inattentive driving and is not a system which assists in poor visibility conditions. The driver is solely responsible for paying attention to their surroundings and driving safely.

n When turning proactive driving assist off

I Situations in which the sensors may not operate properly: →P.268

I When it is necessary to disable the system: →P.263

System operating conditions and detectable objects

According to the driving conditions, the operation and detectable objects of the proactive driving assist will change as follows.

Function	Conditions	Operation	Detectable objects
Obstacle Anticipation Assist (OAA)	A detectable object is detected crossing the road	Assistance with some brake operations is provided in order to reduce the possibility of a collision.	<ul style="list-style-type: none"> • Pedestrians • Bicyclists
	A detectable object is detected on the side of the road	<p>Assistance with some brake and steering wheel operations are provided according to the surrounding conditions to help prevent the vehicle from approaching too close to a detected object.</p> <p>Assistance with steering wheel operations is provided within a range that the vehicle will not deviate from its current lane.</p>	<ul style="list-style-type: none"> • Pedestrians • Bicyclists • Parked vehicles
Deceleration Assist (DA)	A preceding vehicle or an adjacent vehicle cutting in front of the vehicle is detected	The vehicle is gently decelerated so that the vehicle-to-vehicle distance will not be excessively short.	<ul style="list-style-type: none"> • Preceding vehicles • Motorcycles
	A curve is detected ahead of the vehicle	The vehicle is gently decelerated if the vehicle speed is determined to be too high for the curve ahead.	None

n Vehicle speeds at which the system can operate

- | Detectable object crossing the road assistance

Approximately 20 to 35 mph (30 to 60 km/h)

- | Detectable object on the side of the road assistance

Approximately 20 to 35 mph (30 to 60 km/h)

- | Preceding vehicle deceleration assistance

Approximately 15 mph (20 km/h) or more

- | Curve deceleration assistance

Approximately 15 mph (20 km/h) or more

n System operation will be canceled when

- | In the following situations, system operation will be canceled:

- When the dynamic radar cruise control or cruise control is operating
- When the PCS is off
- Situations in which some or all of the functions of the system cannot operate: →P.269
- When the P, R or N shift position is selected
- The driver's seat belt is unfastened

- | In the following situations, the brake operation assist will be canceled:

- Approximately 9 mph (15 km/h) or less
- When a certain vehicle speed has been reached, as judged by the system, according to the surrounding conditions

- | In the following situations, system operation may be canceled:

- When the brake control or output restriction control of a driving support system operates

(For example: PCS, drive-start control)

- When the system determines that a detected object has moved away from the vehicle
- When lane lines can no longer be detected
- When the brake pedal has been depressed
- When the accelerator pedal has been depressed
- When the steering wheel has been operated with more than a certain amount of force
- When the turn signal lever is operated to the left/right turn position



WARNING

n Situations in which the system may not operate properly

- | Situations in which the lane may not be detected: →P.269

- | When a detectable object stops immediately before entering the path of the vehicle

- | When passing extremely close to a detectable object behind a guardrail, fence, etc.

- | When changing lanes while overtaking a detectable object

- | When passing a detectable object that is changing lanes or turning left/right

- | When there are objects (guardrails, power poles, trees, walls, fences, poles, traffic cones, mailboxes, etc.) in the surrounding area

- | When there are patterns or a painting ahead of the vehicle that may be mistaken for a detectable object

- | When passing through a place with a low structure above the road (tunnel with a low ceiling, traffic sign, signboard, etc.)

**WARNING**

- | When driving on snowy, icy, or rutted roads
- | When a detectable object is approaching your vehicle
- | When your vehicle or a detectable object is wandering
- | When the movement of a detectable object changes (change in direction, sudden acceleration or deceleration, etc.)
- | When suddenly approaching a detectable object
- | When a preceding vehicle or motorcycle is not directly in front of your vehicle
- | When there is a structure above a detectable object
- | When part of a detectable object is hidden by another object (large luggage, umbrella, guardrail, etc.)
- | When multiple detectable objects are overlapping
- | When a bright light, such as the sun or headlights of another vehicle, is reflecting off of the detectable object
- | When the detectable object is white and looks extremely bright
- | When the color or brightness of the detectable object causes it to blend in with its surroundings
- | When a detectable object cuts in front of or emerges from beside a vehicle
- | When approaching a vehicle ahead which is perpendicular or at an angle to the vehicle, or is facing the vehicle
- | If a parked vehicle is perpendicular or at an angle to the vehicle
- | When a bicycle is a child sized bicycle, is carrying a large load, is carrying an extra passenger, or has an unusual shape (bicycles equipped with a child seat, tandem bicycles, etc.)
- | When a pedestrian or bicyclist is shorter than approximately 3.2 ft. (1 m) or taller than approximately 6.5 ft. (2 m)
- | When the silhouette of a pedestrian or bicyclist is unclear (such as when they are wearing a raincoat, long skirt, etc.)
- | When a pedestrian or bicyclist is bending forward or squatting
- | When a pedestrian or bicyclist is moving at high speed
- | When a pedestrian is pushing a stroller, wheelchair, bicycle or other vehicle
- | When a detectable object blends in with the surrounding area, such as when it is dim (at dawn or dusk) or dark (at night, in a tunnel, etc.)
- | When the lane width is 13.1 ft. (4 m) or more
- | When the lane width is 8.2 ft. (2.5 m) or less
- | When the vehicle has not been driven for a certain amount of time after the EV system was started
- | While turning left or right or a few seconds after turning left or right
- | While changing lanes or a few seconds after changing lanes

⚠ WARNING

When entering a curve, driving around a curve and a few seconds after driving around a curve

- can be enabled/disabled through a customize setting. (→P.635)
- The following settings of the proactive driving assist can be changed through customize settings. (→P.635)

Changing proactive driving assist settings

- The proactive driving assist

System operation display

Depending on the situation, the following indicators or icons will be displayed.


Some icons cannot be displayed unless the display is changed to the driving safety support function information screen.

Icon	Meaning
	<ul style="list-style-type: none">• White: Monitoring for detectable objects• Green: Detectable object crossing the road or detectable object on the side of the road assistance operating
	A pedestrian has been detected as crossing the road or on the side of the road and brake or steering assistance is operating
 	A vehicle has been detected on the side of the road and brake or steering operation assistance is being performed
	Steering operation assistance is being performed to prevent the vehicle from approaching too close to a detectable object on the side of the road
	Preceding vehicle deceleration assistance is being performed

Icon	Meaning
	Warning to maintain appropriate vehicle-to-vehicle distance
	Curve deceleration assistance is being performed

n Hands off steering wheel warning operation

In the following situations, a message urging the driver to grip the steering wheel and the icon shown in the illustration will be displayed on the display to warn the driver. If the system detects that the steering wheel is held, the warning will be canceled. When using the system, make sure to grip the steering wheel firmly, regardless of whether the warning is operating or not.



- l When assistance to a detectable object crossing the road or assistance to a detectable object on the side of the road is performed and the system determines the driver is not holding the steering wheel

If no operations are detected for a certain amount of time, a buzzer will sound, the warning will operate.

This warning may also operate if the driver only operates steering wheel a small amount continuously.

n Warning operation after preceding vehicle deceleration assistance has ended

After preceding vehicle deceleration assistance has ended, if the

driver does not operate the brake pedal or accelerator pedal and the vehicle approaches the preceding vehicle, the display will flash and a buzzer will sound to urge the driver to decelerate. If the system determines that the driver is operating the brake pedal or accelerator pedal, the warning will be canceled.



FCTA (Front Cross Traffic Alert) *

*: If equipped

When approaching an intersection, etc., at a low speed, vehicles approaching from the left and right of the front of the vehicle can be detected and the driver informed of these vehicles.

FCTA system control

- When the system detects a vehicle approaching from the left or right in front of your vehicle when approaching an intersection, a notification will be displayed.
- When the system determines that your vehicle may be about to enter an intersection even though a vehicle is approaching from the left or right in front of your vehicle, a buzzer will sound and a message will be displayed to urge you to depress the brake pedal.
- Multi-information display



WARNING

n For safe use

Driving safely is solely the responsibility of the driver. Pay careful attention to the surrounding conditions in order to ensure safe driving.

The FCTA system is a supplementary system that informs the driver of vehicles approaching from the left and right of the front of the vehicle.

Over-reliance on this system may lead to an accident resulting in death or serious injury.

The details of the warning display may differ from the actual traffic conditions.

Although the warning display will stop being displayed after a certain amount of time, this does not necessarily indicate that there are no longer any vehicles or pedestrians around your vehicle.

n FCTA system operating conditions

The system will operate when all of the following conditions are met:

- | A shift position other than P or R is selected
- | The vehicle speed is approximately 10 mph (15 km/h) or less
- | A vehicle is approaching from the left or right in front of your vehicle at a speed between approximately 7 to 37 mph (10 to 60 km/h)


- | There are no vehicles in front of your vehicle
- | The accelerator pedal is not being strongly depressed
- | The brake pedal is not being strongly depressed

n Situations in which the system may operate even though no vehicles are approaching

In certain situations, such as the following, the system may operate even though no vehicles are approaching:

- | When approaching objects on the roadside, such as guardrails, traffic signs, utility poles, street lights, trees, tall grass, walls, etc.
- | When passing an object on the side of the road, such as a parked vehicle
- | When a vehicle or pedestrian is approaching from the left or right in front of your vehicle in the distance
- | When a vehicle or pedestrian is moving within a parking spot, etc., next to the lane your vehicle is in
- | When a pedestrian or bicyclist is approaching on a sidewalk
- | When a vehicle or pedestrian is moving away from your vehicle
- | When an approaching vehicle is decelerating or stops
- | When an approaching vehicle makes a left/right turn immediately in front of your vehicle
- | When a pedestrian is approaching your vehicle
- | When an oncoming vehicle makes a right/left turn
- | When your vehicle enters an intersection before a vehicle approaching from the left or right in front of your vehicle
- | When stopped at traffic light and a vehicle approaches from the left or right in front of your vehicle

- | When making a left/right turn in front of an approaching vehicle




- | When an oncoming vehicle approaches and passes
- | When being overtaken by another vehicle
- | When driving next to another vehicle or a pedestrian
- | When a vehicle or pedestrian approaches the side of your vehicle

n Situations in which the system may not operate properly

In situations such as the following, a vehicle may not be detected by a front side radar sensor and the system may not operate properly:

- | If an approaching vehicle moves suddenly (sudden steering, acceleration, deceleration, etc.)



- | If a vehicle is approaching from the left or right of the front of your vehicle diagonally
- | When a vehicle is approaching from the left or right in front of your vehicle in the distance
- | When there is an object between your vehicle and an approaching vehicle
- | When several vehicles are approaching with little space

between them

- | Situations in which the sensors may not operate properly: →P.268
- | Situations in which some or all of the functions of the system cannot operate: →P.269

Changing FCTA settings

- The FCTA can be enabled/disabled through a customize setting. (→P.633)
- The following settings of the FCTA can be changed through customize settings. (→P.633)

RSA (Road Sign Assist)*

*: If equipped

The RSA system detects specific road signs using the front camera and/or navigation system (when speed limit information is available) and warns the driver via displays and buzzers.

WARNING

n For safe use

- | Driving safely is solely the responsibility of the driver. Pay careful attention to the surrounding conditions in order to ensure safe driving.
- | Do not rely solely upon the RSA. The RSA assists the driver by providing road sign information, but it is not a replacement for the driver's own vision and awareness. Driving safely is solely the responsibility of the driver. Pay careful attention to the surrounding conditions in order to ensure safe driving.

n Situations in which the RSA should not be used

- | When it is necessary to disable the system: →P.263

n Situations in which the system may not operate properly

- | Situations in which the sensors may not operate properly: →P.268

Display Function

- When the front camera

detects a sign or information of a sign is available from the navigation system, the sign will be displayed on the display.

- Multiple signs can be displayed.

Depending on the specifications of the vehicle, the number of displayed signs may be limited.

n **Operating conditions of sign display**

Signs will be displayed when the following conditions are met:

- | The system has detected a sign

In the following situations, a displayed sign may stop being displayed:

- | When a new sign has not been detected for a certain distance
- | When the system determines that the road being driven on has changed, such as after a left or right turn

n **Situations in which the display function may not operate properly**

In the following situations, the RSA system may not operate properly and may not detect signs or may display the incorrect sign. However, this does not indicate a malfunction.

- | When a sign is dirty, faded, tilted or bent
- | When the contrast of an electronic sign is low
- | When all or part of a sign is hidden by a tree, utility pole, etc.
- | When a sign is detected by the front camera for a short amount of time
- | When the driving state (turning, changing lanes, etc.) is judged incorrectly

- | When a sign is immediately after a freeway junction or in an adjacent lane just before merging
- | When stickers are attached to the rear of a preceding vehicle
- | When a sign similar to a system compatible sign is detected as a system compatible sign
- | When a speed limit sign for a frontage road is within detection range of the front camera
- | When driving around a roundabout
- | When a sign intended for trucks, etc. is detected
- | When a sign has a supplemental sign (end point, day of week, time of day, etc.)
- | When there is a sign within a traffic restricted area, such as a roadworks area
- | When the navigation system map data is out of date
- | When the navigation system cannot be used

In this case, the speed limit signs displayed on the multi-information display and navigation system display may differ.

Notification function

In the following situations, the RSA system will output a warning to notify the driver.

- If the vehicle speed exceeds the speed warning threshold of the speed limit sign displayed on the display, the sign display will be emphasized and a buzzer will sound.
- When the RSA system detects a do not enter sign and determines that the vehi-

cle has entered a no-entry area, the do not enter sign displayed on the display will flash and a buzzer will sound.

n **Operating conditions of the notification functions**

| Excess speed notification function

This function will operate when the following condition is met:

- A speed limit road sign is recognized by the system.

| No entry notification function

This function will operate when all of the following conditions are met:

- More than one no entry road signs are recognized by the system simultaneously.
- The vehicle is passing between no entry road signs recognized by the system.

Types of road signs supported

- The following types of road signs can be displayed.

However, non-standard or recently introduced traffic signs may not be displayed.

	Speed limit
	
	Do Not Enter

	No U-turn
	No Turn On Red
	Stop
	Yield
	Warning

Changing RSA settings

The following settings of the RSA can be changed through customize settings. (→P.635)

Dynamic radar cruise control

This dynamic radar cruise control detects the presence of vehicles ahead, determines the current vehicle-to-vehicle distance, and operates to maintain a suitable distance from the vehicle ahead. The desired vehicle-to-vehicle distance can be set by operating the vehicle-to-vehicle distance switch.

Use the dynamic radar cruise control only on highways and expressways.



WARNING

n For safe use

- l Driving safely is solely the responsibility of the driver. Do not overly rely on this system, and pay careful attention to the surrounding conditions in order to ensure safe driving.
- l The dynamic radar cruise control provides driving assistance to reduce the driver's burden. However, there are limitations to the assistance provided.

Read the following items carefully. Do not overly rely on this system and always drive carefully.

Conditions under which the system may not operate correctly:

→P.317

l Set the speed appropriately according to the speed limit, traffic flow, road conditions, weather conditions, etc. The driver is responsible for confirming the set speed.

l Even if the system is operating correctly, the condition of a preceding vehicle as recognized by the driver and detected by the system may differ. Therefore, it is necessary for the driver to pay attention, assess risks, and ensure safety. Over-reliance on this system to drive the vehicle safely may lead to an accident resulting in death or serious injury.

n Precautions for the driving assist systems

Observe the following precautions, as there are limitations to the assistance provided by the system. Over-reliance on this system may lead to an accident resulting in death or serious injury.

l Details of support provided for the driver's vision

The dynamic radar cruise control is only intended to help the driver in determining the distance between the driver's own vehicle and a designated preceding vehicle. It is not a system which allows for careless or inattentive driving, and is not a system which assists in poor visibility conditions.

The driver must pay attention to their surroundings, even when the vehicle stops.

**WARNING**

- I Details of support provided for the driver's judgement

The dynamic radar cruise control determines whether the distance between the driver's own vehicle and a designated preceding vehicle is within a set range. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger.

- I Details of support provided for the driver's operation

The dynamic radar cruise control does not include functions which will prevent or avoid collisions with vehicles ahead of your vehicle. Therefore, if there is ever any possibility of danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure safety.


n Situations in which the dynamic radar cruise control should not be used

Do not use the dynamic radar cruise control in the following situations. As the system will not be able to provide appropriate control, using it may lead to an accident resulting in death or serious injury.

- I Roads where there are pedestrians, cyclists, etc.
- I When driving on a highway or expressway entrance or exit
- I When the approach warning sounds frequently
- I Situations in which the sensors may not operate properly:
→P.268

- I When it is necessary to disable the system: →P.263

Basic functions



A Constant speed cruising:

When there are no vehicles ahead

The vehicle drives at the speed set by the driver.

If the set vehicle speed is exceeded while driving down a hill, the set vehicle speed display will blink and a buzzer will sound.

B Deceleration and follow-up cruising:

When a preceding vehicle driving slower than the set vehicle speed is detected

When a vehicle is detected driving ahead of your vehicle, the vehicle automatically decelerates and if a greater reduction in vehicle speed is necessary, the brakes are applied (the stop lights will come on at this time). The vehicle is controlled to maintain the vehicle-to-vehicle distance set by the driver, in accordance with changes in the speed of the preceding vehicle. If vehicle deceleration is not sufficient and the vehicle approaches the vehicle ahead, the approach warning will sound.

C Acceleration:

When there are no longer any preceding vehicles driving slower than the set vehicle speed

The vehicle accelerates until the set vehicle speed is reached and then resumes constant speed cruising.


D Starting off:

If a preceding vehicle stops, the vehicle will also stop (controlled stop). After the preceding vehicle starts off, pressing the “RES” switch or depressing the accelerator pedal will resume follow-up cruising (start off operation). If a start off operation is not performed, the controlled stop will continue.

Vehicles with Traffic Jam Assist: While driving on a highway or expressway, if a preceding vehicle stops, your vehicle will stop accordingly. On some highways and expressways, if the system determines that the preceding vehicle starts off within approximately 3 minutes of stopping, a buzzer will sound and a message will be displayed on the multi-information display to notify the driver, and your vehicle will start off accordingly following the preceding vehicle. (Extended resume time)


System components

n Meter display



- A** Multi-information display
- B** Set vehicle speed
- C** Indicators

n Switches



- A** Driving assist switch
- B** Driving assist mode select switch
- C** Cancel switch
- D** Vehicle-to-vehicle distance switch

E “-” switch


F “+” switch/“RES” switch

Using the dynamic radar cruise control

Setting the vehicle speed

- 1** Press the driving assist mode select switch to select Adaptive Cruise Mode.

The dynamic radar cruise control indicator will illuminate.




- 2** Using the accelerator pedal, accelerate or decelerate to the desired vehicle speed (approximately 20 mph [30 km/h] or more), and press the driving assist switch to set the set vehicle speed.

The set vehicle speed will be displayed on the multi-information display.

The vehicle speed at the moment


the switch is released will be the set vehicle speed.



Adjusting the set vehicle speed

- Adjusting the set vehicle speed using the switches

To change the set vehicle speed, press the “+” switch or “-” switch until the desired speed is displayed.



- 1 Increase set vehicle speed
- 2 Decrease set vehicle speed

Short press adjustment: Press the switch

Long press adjustment: Press and hold the switch until the desired set vehicle speed is reached.

The set vehicle speed will increase or decrease as follows:

- Except for Canada

Short press adjustment: Increases or decreases by 1 mph (1.6 km/h) each time the switch is pressed

Long press adjustment: Increases or decreases in 1 mph (1.6 km/h) increments continuously while the switch is pressed and held

- For Canada


Short press adjustment: By 1 km/h (0.6 mph) or 1 mph (1.6 km/h) each time the switch is pressed

Long press adjustment: Increases or decreases in 5 km/h (3.1 mph) or 5 mph (8 km/h) increments continuously while the switch is pressed and held

- Increasing the set vehicle speed using the accelerator pedal

- 1 Depress the accelerator pedal to accelerate the vehicle to the desired vehicle speed.
- 2 Press the “+” switch.

Canceling/resuming control



- 1 Press the cancel switch or driving assist switch to cancel control.

Control will also be canceled if the brake pedal is depressed.
(If the vehicle has been stopped by system control, depressing the brake pedal will not cancel control.)

- 2 Press the “RES” switch to resume control.

Changing the vehicle-to-vehicle distance

Each time the switch is pressed, the vehicle-to-vehicle distance setting will change as follows:
If a preceding vehicle is detected, the preceding vehicle mark **A** will be displayed.




Illustration Number	Vehicle-to-vehicle distance	Approximate Distance (Vehicle Speed: 60 mph [100 km/h])
1	Short	Approximately 85 ft. (25 m)
2	Medium	Approximately 100 ft. (30 m)

Illustration Number	Vehicle-to-vehicle distance	Approximate Distance (Vehicle Speed: 60 mph [100 km/h])
3	Long	Approximately 145 ft. (45 m)
4	Extra long	Approximately 200 ft. (60 m)

The actual vehicle-to-vehicle distance varies in accordance with the vehicle speed. Also, when the vehicle is stopped by system control, it will be stopped at a certain distance from the preceding vehicle, depending on the situation, regardless of the setting.

- n **Operating conditions**
- l The D shift position is selected.
- l The desired set speed can be set when the vehicle speed is approximately 20 mph (30 km/h) or more.
- If the vehicle speed is set while driving at below approximately 20 mph (30 km/h), the set vehicle speed will be approximately 20 mph (30 km/h).
- If the vehicle speed is set while driving at a speed that exceeds the system's upper limit, the set vehicle speed will be the system's upper limit.
- n **Accelerating after setting the vehicle speed**
- As with normal driving, acceleration can be performed by depressing the accelerator pedal. After accelerating, the vehicle will return to the set vehicle speed. However, while in vehicle-to-vehicle distance control mode, the vehicle speed may decrease to below the set vehicle speed in order to maintain the distance from the preceding vehicle.

n When the vehicle is stopped by system control during follow-up cruising

- | When the "RES" switch is pressed while the vehicle is stopped by system control, if the preceding vehicle starts off within approximately 3 seconds, follow-up cruising will resume.
- | If the preceding vehicle starts off within approximately 3 seconds of the vehicle being stopped by system control, follow-up cruising will resume.

n Automatic cancelation of vehicle-to-vehicle distance control mode

In the following situations, vehicle-to-vehicle distance control mode will be canceled automatically:

- | When the brake control or output restriction control of a driving support system operates (For example: Pre-Collision System, drive-start control)
- | When the parking brake has been operated
- | When the driver's seat belt is unfastened while driving
- | When the Pre-Collision System is disabled
- | When the vehicle is stopped by system control on a steep incline
- | When any of the following are detected while the vehicle is stopped by system control:
 - The driver's seat belt is unfastened
 - The driver's door is opened
 - Approximately 3 minutes have elapsed since the vehicle was stopped

The parking brake may be activated automatically.

- | Situations in which some or all of the functions of the system cannot operate: →P.269

n Dynamic radar cruise control system warning messages and buzzers

For safe use: →P.263

n Preceding vehicles that the sensor may not detect correctly

In the following situations, depending on the conditions, if the system cannot provide sufficient deceleration or acceleration is necessary, operate the brake pedal or accelerator pedal.

As the sensor may not be able to correctly detect these types of vehicles, the approach warning (→P.318) may not operate.

- | When a vehicle cuts in front of your vehicle or changes lanes away from your vehicle extremely slowly or quickly
- | When changing lanes
- | When a preceding vehicle is driving at a low speed
- | When a vehicle is stopped in the same lane as the vehicle
- | When a motorcycle is traveling in the same lane as the vehicle

n Conditions under which the system may not operate correctly

In the following situations, operate the brake pedal (or accelerator pedal, depending on the situation) as necessary.

As the sensor may not be able to correctly detect a vehicle, the system may not operate properly.

- | When a preceding vehicle brakes suddenly
- | When changing lanes at low speeds, such as in a traffic jam

n Conditions for extended resume time (vehicles with Traffic Jam Assist)

Extended resume time is activated when all of the following conditions are satisfied:

- | The connected service that Toyota provides is subscribed to. Contact your Toyota dealer for details.
- | The vehicle is driving on a vehicle-only road, such as an expressway.
- | There is a preceding vehicle and the system is able to detect it.
- | No vehicle interruptions occur.
- | The preceding vehicle has not been replaced.
- | Clearance sonar and FCTA are not detecting the object in front of you.
- | The driver monitor judges that the driver is looking forward.
- | The steering wheel has not been operated.
- | The brake pedal has not been operated.

Approach warning

In situations where the vehicle approaches a preceding vehicle and the system cannot provide sufficient deceleration, such as if a vehicle cuts in front of the vehicle, a warning display will flash and a buzzer will sound to alert the driver. Depress the brake pedal to ensure appropriate vehicle-to-vehicle distance.

n Warnings may not occur when

In the following situations, the warning may not operate even though the vehicle-to-vehicle distance is short.

- When the preceding vehicle is traveling at the same speed or faster than your vehicle

- When the preceding vehicle is traveling at an extremely low speed
- Immediately after the vehicle speed has been set
- When the accelerator pedal is depressed

Curve speed reduction function

When a curve is detected, the vehicle speed will begin being reduced. When the curve ends, the vehicle speed reduction will end.

Depending on the situation, the vehicle speed will then return to the set vehicle speed.

In situations where vehicle-to-vehicle distance control needs to operate, such as when a preceding vehicle cuts in front of your vehicle, the curve speed reduction function will be canceled.



n Situations in which the curve speed reduction function may not operate

In situations such as the following, the curve speed reduction function may not operate:

- | When the vehicle is being driven around a gentle curve
- | When the accelerator pedal is being depressed
- | When the vehicle is being driven around an extremely short curve

Driver Monitor support function

While a warning of the driver monitor is being displayed, the vehicle acceleration will be restrained.

When the warning of the driver monitor disappears, the restrained acceleration control will end.

Support for lane change

If your vehicle is being driven at approximately 50 mph (80 km/h) or more and a lane change to the passing lane is performed, when the turn signal lever is operated and the lane is changed, the vehicle will accelerate up to the set speed to assist in overtaking.

The system's recognition of which lane is the passing lane may be based solely on the location of the

steering wheel in the vehicle (left-hand drive/right-hand drive). If the vehicle is driven in a location where the passing lane is on the opposite side of that where the vehicle was originally sold, the vehicle may accelerate when the turn signal lever is operated away from the passing lane. (e.g. The vehicle was manufactured for a right-hand traffic location, but is being driven in a left-hand traffic location. The vehicle may accelerate when the turn signal lever is operated to the right.)

If your vehicle is being driven at approximately 50 mph (80 km/h) or more and the lane is changed to that with a vehicle traveling slower than your vehicle, when the turn signal lever is operated the vehicle will gradually decelerate to assist in changing lanes.


Changing Dynamic radar cruise control settings

- The settings of Dynamic radar cruise control can be changed through customize settings. (→P.634)

Display and system operation state

The operating state of Dynamic radar cruise control is indicated.

Indicator	Multi-information display		Situation
 White		Vehi- cle-to-vehi- cle distance setting: Gray	Dynamic radar cruise control being OFF
 Green		Vehi- cle-to-vehi- cle distance setting: Blue Set vehicle speed: Green	Constant speed cruis- ing
 Green		Vehi- cle-to-vehi- cle distance setting: Blue Set vehicle speed: Green Preceding vehicle: White	Follow-up cruising
 Green		Vehi- cle-to-vehi- cle distance setting: Orange flashing Set vehicle speed: Green Preceding vehicle: Orange flashing	Approach warning

Indicator	Multi-information display		Situation
 Green		Vehicle-to-vehicle distance setting: Gray Set vehicle speed: White Preceding vehicle: Gray	Accelerating with the accelerator pedal
 Green		Set vehicle speed: Green in reverse display	Set vehicle speed being exceeded
 Green		Vehicle-to-vehicle distance setting: Gray Set vehicle speed: White Preceding vehicle: Gray	Vehicle in controlled stop

Cruise control

The vehicle can be driven at a set speed even if the accelerator pedal is not depressed.

Use the cruise control only on highways and express-ways.

! WARNING

n For safe use

Driving safely is solely the responsibility of the driver. Therefore, do not overly rely on this system. The driver is solely responsible for paying attention to the vehicle's surroundings and driving safely.

Set the speed appropriately according to the speed limit, traffic flow, road conditions, weather conditions, etc. The driver is responsible for confirming the set speed.

n Situations in which cruise control should not be used

Do not use the cruise control in the following situations. As the system will not be able to provide appropriate control, using it may lead to an accident resulting in death or serious injury.

- ! On roads with sharp bends
- ! On winding roads
- ! On slippery roads, such as those covered with rain, ice or snow


! On steep downhills, or where there are sudden changes between sharp up and down gradients

Vehicle speed may exceed the set speed when driving down a steep hill.

! When it is necessary to disable the system: →P.263

System Components


n Meter display



A Set vehicle speed

B Cruise control indicator

n Switches



A Driving assist switch

B Driving assist mode select switch

C Cancel switch

D “-” switch


E “+” switch/“RES” switch

Using the cruise control

Setting the vehicle speed


- 1 Press the driving assist mode select switch to select Cruise Control Mode.

The cruise control indicator will illuminate.



- 2 Using the accelerator pedal, accelerate to the desired vehicle speed (approximately 20 mph [30 km/h] or more), and press the driving assist switch to set the set vehicle speed.


The vehicle speed at the moment the switch is released will be the set vehicle speed.



Adjusting the set vehicle speed

- Adjusting the set vehicle speed using the switches

To change the set vehicle speed, press the “+” switch or “-” switch until the desired speed is displayed.



- 1 Increase set vehicle speed
- 2 Decrease set vehicle speed


The set vehicle speed will increase or decrease as follows:

Fine adjustment: By 1 mph (1.6 km/h) or 1 km/h (0.6 mph) each time the switch is pressed

Large adjustment: Increases continuously while the switch is pressed and held

- Increasing the set vehicle speed using the accelerator pedal
- 1 Depress the accelerator pedal to accelerate the vehicle to the desired vehicle speed.
 - 2 Press the “+” switch.

Canceling/resuming control



1 Press the cancel switch or driving assist switch to cancel control.

Control will also be canceled if the brake pedal is depressed.

2 Press the “RES” switch to resume control.

n Automatic cancellation of the cruise control


In the following situations, the cruise control will be canceled automatically:

- | When the vehicle speed drops approximately 10 mph (16 km/h) or more below the set vehicle speed
- | When the vehicle speed drops below approximately 20 mph (30 km/h)
- | When the brake control or output restriction control of a driving support system operates
(For example: PCS, drive-start control)
- | When the parking brake has been operated
- | When the driver's seat belt is unfastened
- | Situations in which some or all of the functions of the system cannot operate: →P.269

Display and system operation state

The operating state of cruise control is indicated.

Indicator	Multi-information display		Situation
 White		Blank	Cruise control being OFF

Indicator	Multi-information display		Situation
 <p>Green</p>			<p>Set vehicle speed: Green</p> <p>Constant speed cruising</p>
 <p>Green</p>			<p>Set vehicle speed: Green in reverse display</p> <p>Set vehicle speed being exceeded</p>

Emergency Driving Stop System

The emergency driving stop system is a system which automatically decelerates and stops the vehicle within its lane if the driver becomes unable to continue driving the vehicle, such as if they have suffered a medical emergency, etc.

During LTA (Lane Tracing Assist) control, if the system does not detect driving operations, such as if the driver is not holding the steering wheel, and determines the driver is not responsive, the vehicle will be decelerated and stopped within its current lane to help avoid a collision or reduce the impact of a collision.

The vehicle will also decelerate/stop during the Traffic Jam Assist (if equipped) controls, when no driver's response to the vehicle's warning to hold the steering wheel is detected.

WARNING

n For safe use

- I Driving safely is solely the responsibility of the driver. Pay careful attention to the surrounding conditions in order to ensure safe driving. The emergency driving stop system is designed to provide support in an emergency where it is difficult for the driver to continue driving, such as if they have had a medical emergency. It is not designed to support driving while drowsy or in poor physical health, or inattentive driving.
- I Although the emergency driving stop system is designed to decelerate the vehicle within its lane to help avoid or help reduce the impact of a collision if the system determines that it is difficult for the driver to continue driving, its effectiveness may change according to various conditions. Therefore, it may not always be able to achieve the same level of performance. Also, if the operating conditions are not met, this function will not operate.
- I After the emergency driving stop system operates, if driving becomes possible again, immediately begin driving again or, if necessary, park the vehicle on the shoulder of the road and set a warning reflector and flare to warn other drivers of your stopped vehicle.
- I After this system operates, passengers should attend to the driver as necessary and take appropriate hazard prevention measures, such as moving to a place where safety can be ensured, such as the shoulder of the road or behind a guard-rail.

**WARNING**

- | This system detects the condition of the driver through the operation of the steering wheel. This system may operate if the driver is aware but intentionally and continuously does not operate the vehicle. Also, the system may not operate if it cannot determine that the driver is not responsive, such as if they are leaning on the steering wheel.
- | Situations in which the driver monitor may not operate properly: →P.270

Summary of the system

Operation of this system is separated into 4 control states. Through control state “Warning phase 1” and “Warning phase 2”, the system determines if the driver is aware and responsive while outputting a warning and controlling the vehicle speed. If the system determines the driver is not responsive, it will operate in control state “Deceleration stop phase” and “Stop hold phase” and decelerate and stop the vehicle. It will then operate continuously in “Stop hold phase”.

n Operating conditions

This system operates when all of the following conditions are met:

- | When the LTA is on
- Or during the Traffic Jam Assist controls (if equipped)
- | When the vehicle speed is approximately 30 mph (50 km/h)

or more

During the Traffic Jam Assist (if equipped) controls, the system may operate at below 30 mph (50 km/h).

n Operation cancelation conditions

In the following situations, system operation will be canceled:

- | When LTA control has been canceled (the LTA switch has been pressed, etc.)
- | When the dynamic radar cruise control has been canceled
- | When driver operations are detected (the steering wheel is held, the brake pedal, accelerator pedal, parking brake, hazard light switch, or turn signal lever is operated)
- | When the driving assist switch is pressed while in the stop and hold phase
- | When the power switch has been turned from ON to off
- | Situations in which some or all of the functions of the system cannot operate: →P.269

n LTA control when operation is canceled

When emergency driving stop system operation is canceled, LTA control may also be canceled.

Warning phase 1

If driving operations are not detected after the hands off steering wheel warning operates, a buzzer will sound intermittently and a message will be displayed to warn the driver, and the system will judge if the driver is responsive or not. If driving operations, such as holding the steering wheel, are not per-

formed within a certain amount of time, the system will enter warning phase 2.

Depending on the type of detection of the driver's unresponsiveness, the system may skip warning phase 1 and start the control of warning phase 2.

Warning phase 2

After entering warning phase 2, a buzzer will sound in short intervals and a message will be displayed to warn the driver, and the vehicle will slowly decelerate. If driving operations, such as holding the steering wheel, are not performed within a certain amount of time, the system will determine that the driver is not responsive and enter the deceleration stop phase.

When the vehicle is decelerating, the brake lights may illuminate, depending on the road conditions, etc.

Deceleration stop phase

After entering the deceleration stop phase, a buzzer will sound continuously and a message will be displayed to warn the driver, and the vehicle will slowly decelerate and stop. After the vehicle stops, the system will enter the stop and hold phase.

Stop hold phase

After the vehicle is stopped, the parking brake will be applied automatically. After entering the stop and hold phase, the buzzer will continue sounding continuously and the emergency flashers (hazard lights) will flash to warn other drivers of the emergency.

n Restricted functions after the operation is canceled

After shifting to the deceleration stop phase, the following functions will not be available until the EV system is re-started even though the emergency driving stop system is canceled:

- | LTA
- | LCA (if equipped)
- | Traffic Jam Assist (if equipped)

Traffic Jam Assist*

*: If equipped

Function Outline

Traffic Jam Assist is a system which, through confirmation of the conditions by the driver, provides lane keeping, accelerating/decelerating, stopping, and starting off support on some highways and expressways. Also, in an emergency, the system can decelerate and stop, to help avoid a collision or help reduce the impact of a collision.

Sensors that support the Traffic Jam Assist

- Sensors which detect the surrounding conditions (→P.265)
- Sensors which detect the driver condition (→P.265)

n Situations in which some or all of the functions of the system cannot operate

→P.269

n Changes in brake operation sound and pedal response

→P.270

n Situations in which the driver monitor may not operate properly

→P.270

Emergency Driving Stop System

→P.326

Extended resume time of Dynamic radar cruise control

→P.317

Traffic Jam Assist Function

The Traffic Jam Assist function, through confirmation of the conditions by the driver, provides lane keeping, accelerating/decelerating and stopping support on some highways and expressways.

This function is operable when all of the operation conditions are met.

When this function is operating, it is possible to take your hands off of the steering wheel. (→P.332)

Before using the Traffic Jam Assist function, familiarize yourself with the content of the dynamic radar cruise control and the LTA (Lane Tracing Assist).

Make sure that the driver steers the vehicle when entering a service area/parking area or toll gate, or when changing lanes.

Driver monitor camera recording

When the operation of Traffic Jam Assist is started, the following message will be displayed:

- “Allow Driver Monitor Camera Recording?”

When recording is approved, the system records images of the area around the driver in certain crash or near crash-like situations, such as an SRS airbag being deployed or the vehicle hitting an object on the road. (→P.7)



WARNING

n For safe use

Driving safely is solely the responsibility of the driver. Do not overly rely on this system, and pay careful attention to the surrounding conditions in order to ensure safe driving.

The Traffic Jam Assist function is not an automated driving system.

This function provides the driver with information and driving assistance according to the road shape and conditions, traffic conditions, and the condition of the driver themselves. Always pay careful attention to the surrounding conditions as use of the system is the responsibility of the driver.

Depending on the condition of the surrounding area, the road, or the driver, the Traffic Jam Assist function may not operate or operation may be suspended. Also, it may not always be able to achieve the same level of performance. Read the operating conditions of the function carefully. Do not overly rely on this function and always drive carefully.

As the recognition performance and control performance of the Traffic Jam Assist function are limited, driver operation is necessary to ensure safety while the system is operating. Also, the steering assist of this system is designed to operate only for slow steering operations during a traffic jam. While this function is operating, the lane deviation control function of the LDA will not operate. If, for some reason, the vehicle is about to deviate the lane, it is the driver's responsibility to drive properly.

Even if Traffic Jam Assist is operating properly, the surrounding conditions as recognized by the driver and detected by the system may differ. Therefore, it is necessary for the driver to pay attention, assess risks, and ensure safety. Over-reliance on this system to drive the vehicle safely may lead to an accident resulting in death or serious injury.

While the Traffic Jam Assist function is operating, as driver operation may become necessary, the driver must ensure they have clear visibility of their surroundings.

**WARNING**

In certain situations, a message urging the driver to hold the steering wheel may be displayed by the Traffic Jam Assist function. In this case, hold the steering wheel and drive the vehicle manually to ensure safety.

The Traffic Jam Assist function cannot detect the following objects. Operate the steering wheel, accelerator pedal, or brake pedal as necessary to avoid a collision. As the function will not be able to provide appropriate control, using it may lead to an accident resulting in death or serious injury.

- Objects on the road surface
- Vehicles outside of a lane (such as on the shoulder of the road)
- Potholes, cracks, ruts, or other road damage
- Road construction zones
- Vehicles running in parallel with your vehicle or nearby walls
- Animals

n Situations in which Traffic Jam Assist Function should not be used

Do not use Traffic Jam Assist Function in situations such as the following. As the system will not be able to provide appropriate control, using it may lead to an accident resulting in death or serious injury.

- When it is necessary to disable the system

→P.263

- Situations in which the sensors may not operate properly

→P.268

- Situations in which the lane may not be detected

→P.269

n Situations in which the function may not operate properly

In situations such as the following, the Traffic Jam Assist function may not operate properly. Manually operate the vehicle as necessary.

- When a sensor is splashed by water

- When the ambient temperature is high or low

- When a vehicle cuts in front of your vehicle

- When another lane merges into the lane in the same traveling direction as your vehicle

- When driving in low visibility conditions

- When the vehicle posture is changing

- When the traction on the road surface differs greatly between the left and right side tires

- When driving on an expressway with no median strips or when driving on an expressway equipped with temporary median markers, such as poles.

- When there is a significant difference in speed between your vehicle and the other vehicle

- The map data has not been updated properly.

**WARNING**

n To prevent malfunction of the radar sensors

→P.265

n To prevent malfunction of the front camera

→P.266

n Front camera installation area on the windshield

→P.267

n Operating conditions of the function

This function is operable when all of the following conditions are met:

- | The system detects lane lines and the path of preceding or surrounding vehicles.
- | The dynamic radar cruise control and the lane tracing assist are operating.
- | The turn signal lever is not being operated.
- | The vehicle is not being driven around a sharp curve.
- | The vehicle is being driven in the center of a lane.
- | The driver monitor camera is detecting that the driver is facing front of the vehicle.
- | The vehicle is driving in traffic jam on a highway or expressway at approximately 25 mph (40 km/h) or less. (In some situations, such as when a traffic jam starts, this function may be operational at approximately 20 mph [30 km/h] or less.)
- | The driver's door is closed.
- | The driver's seat belt is fastened.
- | Customized setting of the Traffic Jam Assist is not set to off.
- | Functions and components composing the system are in proper

condition.

- | Customized setting of the PCS (Pre-Collision System) is not set to off.
- | Customized setting of the dynamic radar cruise control (re-start time extension) is not set to off.
- n Temporary cancelation of the function**
 - | When the operating conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function will automatically be restored.
 - | If the operating conditions of a function are no longer met while the function is operating, a buzzer may sound with a display to indicate that the function has been temporarily canceled. If no driver's responses to the indication are detected, the driver emergency stop assist function may operate. For types of display and action to be taken, see the page mentioned below. (→P.333)
- n Driving operations during controlled driving**
 - | Accelerator pedal

As with normal driving, acceleration can be performed by depressing the accelerator pedal. When the accelerator pedal is depressed at approximately 6 mph (10 km/h) or more, this function will be canceled.
 - | Brake pedal

As with normal driving, deceleration can be performed by depressing the brake pedal. However, controlled driving will be cancelled.
 - | Steering wheel

As with normal driving, the steering wheel can be operated. If the steering wheel is operated more than a certain amount, controlled driving

will be cancelled.

n When a warning message is displayed

l “Traffic Jam Asst System Malfunction Visit Your Dealer”

The Traffic Jam Assist function may not be operating properly.

l “Traffic Jam Asst Unavailable Stop Assist Activated”

The system temporarily cannot be used as the driver emergency stop assist function has operated.

Changing Traffic Jam Assist settings

- The setting of Traffic Jam Assist can be enabled/disabled through a customize setting. (→P.636)
- The setting of driver monitor camera recording can be enabled/disabled through a customize setting. (→P.636)

Displays and system operation

The following displays indicate the operating status of the Traffic Jam Assist function:

Display	Status	Action to be taken
	Traffic Jam Assist function is operating	—
 (Gray)	Traffic Jam Assist function is about to end	Hold the steering wheel.
 (Orange)	Traffic Jam Assist function has ended	Hold the steering wheel.
 (Red)	Operation of either or both of dynamic radar cruise control/LTA (Lane Tracing Assist) ended	Manually operate the steering wheel immediately.

Display	Status	Action to be taken
 (Yellow)	Indicates that driving actions are necessary to cope with cut-in or other behavior of surrounding vehicles	The driver must operate the steering wheel, accelerator pedal and brake pedal in accordance with the surrounding environment.
	Indicates that the recording function of the driver monitor camera is operational (Blinking of this icon indicates that recording is undergoing, and constant illumination indicates ready for recording.)	—

BSM (Blind Spot Monitor)


The Blind Spot Monitor is a system that uses rear side radar sensors installed on the inner side of the rear bumper on the left and right side to assist the driver in confirming safety when changing lanes.

⚠ WARNING

n Cautions regarding the use of the system

- I The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.
- I The Blind Spot Monitor is a supplementary function which alerts the driver that a vehicle is in a blind spot of the outside rear view mirrors or is approaching rapidly from behind into a blind spot. Do not overly rely on the Blind Spot Monitor. As the function cannot judge if it is safe to change lanes, over reliance could lead to an accident resulting in death or serious injury. As the system may not function correctly under certain conditions, the driver's own visual confirmation of safety is necessary.

System components



A Multimedia display

Turning the Blind Spot Monitor on/off.

B Outside rear view mirror indicators

When a vehicle is detected in a blind spot of the outside rear view mirrors or approaching rapidly from behind into a blind spot, the outside rear view mirror indicator (→P.136) on the detected side will illuminate. If the turn signal lever is operated toward the detected side, the outside rear view mirror indicator will flash and a buzzer will sound.

C Driving assist information indicator

Illuminates when the Blind Spot Monitor is turned off. At this time, a message will be displayed on the multi-information display.

n Outside rear view mirror indicator visibility

In strong sunlight, the outside rear view mirror indicator may be difficult to see.

n Buzzer

If the volume setting of the audio system is high or the surrounding area is loud, it may be difficult to hear the buzzer.

n Customization

Some functions can be customized.
(→P.627)

n Certification

→P.671




WARNING

n To ensure the system can operate properly

Blind Spot Monitor sensors are installed behind the left and right sides of the rear bumper respectively. Observe the following to ensure the Blind Spot Monitor can operate correctly.

- ! Keep the sensors and the surrounding areas on the rear bumper clean at all times.

If a sensor or its surrounding area on the rear bumper is dirty or covered with snow, the Blind Spot Monitor may not operate and a warning message will be displayed. In this situation, clear off the dirt or snow and drive the vehicle with the operation conditions of the BSM function (→P.338) satisfied for approximately 10 minutes. If the warning message does not disappear, have the vehicle inspected by your Toyota dealer.



- ! Do not attach accessories, stickers (including transparent stickers), aluminum tape, etc. to a sensor or its surrounding area on the rear bumper.

! Do not paint the surrounding area of a sensor on the rear bumper.

- ! Do not subject a sensor or its surrounding area on the rear bumper to a strong impact. If a sensor is moved even slightly off position, the system may malfunction and vehicles may not be detected correctly. In the following situations, have your vehicle inspected by your Toyota dealer.
 - A sensor or its surrounding area is subject to a strong impact.
 - If the surrounding area of a sensor is scratched or dented, or part of them has become disconnected.
- ! Do not disassemble the sensor.
- ! Do not modify the sensor or surrounding area on the rear bumper.
- ! If a sensor or the rear bumper needs to be removed/installed or replaced, contact your Toyota dealer.
- ! The sensors are likely to be affected by paint on the rear bumper. If the rear bumper is not repaired correctly, the Blind Spot Monitor may not operate with a warning message displayed. If any paint repair is needed, contact your Toyota dealer.

Turning the Blind Spot Monitor on/off

The Blind Spot Monitor can be enabled/disabled through a customize setting. (→P.627)

When the Blind Spot Monitor is off, the driving assist information


indicator (→P.136) will illuminate and a message will be displayed on the multi-information display.

Each time the power switch is turned to ON, the Blind Spot Monitor is enabled.

Blind Spot Monitor operation

n Objects that can be detected while driving


The Blind Spot Monitor uses rear side radar sensors to detect the following vehicles traveling in adjacent lanes and advises the driver of the presence of such vehicles via the indicators on the outside rear view mirrors.



- A** Vehicles that are traveling in areas that are not visible using the outside rear view mirrors (the blind spots)
- B** Vehicles that are approaching rapidly from behind in areas that are not visible using the outside rear view mirrors (the blind spots)

n Detection range while driving

The areas that vehicles can be detected in are outlined below.



The range of each detection area is:

- A** Approximately 1.6 ft. (0.5 m) to 11.5 ft. (3.5 m) from either side of the vehicle^{*1}

- B** Approximately 3.3 ft. (1 m) forward of the rear bumper^{*2}
- C** Approximately 9.8 ft. (3 m) from the rear bumper
- D** Approximately 9.8 ft. (3 m) to 230 ft. (70 m) from the rear bumper^{*3}

^{*1}: The area between the side of the vehicle and 1.6 ft. (0.5 m) from the side of the vehicle cannot be detected.

^{*2}: While the vehicle is to being overtaken, up to approximately 9.8 ft. (3 m) forward of the rear bumper will be detected.

^{*3}: The greater the difference in speed between your vehicle and the detected vehicle is, the farther away the vehicle will be detected, causing the outside rear view mirror indicator to illuminate or flash.

n The Blind Spot Monitor linked function

The LDA (Lane Departure Alert) has a function that uses information of detected vehicles driving in an adjacent lane. For details about the function and its operating conditions, P.293.

n The Blind Spot Monitor is operational when

The Blind Spot Monitor is operational when all of the following conditions are met:

- | The power switch is in ON.
- | The Blind Spot Monitor is on.
- | The shift position is in a position other than R.
- | The vehicle speed is approximately 7 mph (10 km/h) or more.

n The Blind Spot Monitor will detect a vehicle when

The Blind Spot Monitor will detect a vehicle present in the detection area in the following situations:

- | A vehicle in an adjacent lane overtakes your vehicle.
- | You overtake a vehicle in an adjacent lane slowly.
- | Another vehicle enters the detection area when it changes lanes.

n Situations in which the Blind Spot Monitor cannot detect vehicles

The Blind Spot Monitor cannot detect the following vehicles and other objects:

- | Small motorcycles, bicycles, pedestrians, etc.*
- | Vehicles traveling in the opposite direction
- | Guardrails, walls, signs, parked vehicles and similar stationary objects*
- | Following vehicles that are in the same lane*
- | Vehicles traveling 2 lanes away from your vehicle*
- | Vehicles which are being overtaken rapidly by your vehicle*

^{*}: Depending on the conditions, detection of a vehicle and/or object may occur.

n Conditions in which a buzzer may not sound

In situations such as the following,

while the turn signal lever is being operated, the indicator will flash but a buzzer may not sound.

- | When a second vehicle is detected while the turn signal lever is being held
- | When overtaking a vehicle in the adjacent lane at a much higher speed than it*

*: Depending on the situations, a buzzer may sound.

n Conditions under which the system may not function correctly

| The Blind Spot Monitor may not detect vehicles correctly in the following situations:

- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When mud, snow, ice, a sticker, etc. is covering the sensor or surrounding area on the rear bumper
- When driving on a wet road surface, such as in a puddle, while in inclement weather, such as heavy rain, snow, fog, etc.
- When multiple vehicles are approaching with only a small gap between each vehicle
- When the distance between your vehicle and a following vehicle is short
- When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area
- When the difference in speed between your vehicle and another vehicle is changing
- When a vehicle enters a detection area traveling at about the same speed as your vehicle
- As your vehicle starts from a stop, a vehicle remains in the detection area
- When driving up and down consecutive steep inclines, such as hills, dips in the road, etc.
- When driving on roads with sharp bends, consecutive curves, or

uneven surfaces

- When vehicle lanes are wide, or when driving on the edge of a lane, and the vehicle in an adjacent lane is far away from your vehicle
- When an accessory (such as a bicycle carrier) is installed to the rear of the vehicle
- When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
- Immediately after the Blind Spot Monitor is turned on
- When towing with the vehicle
- | Instances of the Blind Spot Monitor unnecessarily detecting a vehicle and/or object may increase in the following situations:
- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When the distance between your vehicle and a guardrail, wall, etc. that enters the detection area is short
- When driving up and down consecutive steep inclines, such as hills, dips in the road, etc.
- When vehicle lanes are narrow, or when driving on the edge of a lane, and a vehicle traveling in a lane other than the adjacent lanes enters the detection area
- When driving on roads with sharp bends, consecutive curves, or uneven surfaces
- When the tires are slipping or spinning
- When the distance between your vehicle and a following vehicle is short
- When an accessory (such as a bicycle carrier) is installed to the rear of the vehicle
- When towing with the vehicle

Safe Exit Assist

The safe exit assist (with door opening control) is a system that uses rear side radar sensors installed on the inner side of the rear bumper to help occupants judge if an approaching vehicle or bicycle may collide with a door when exiting or cancel opening of a door, to help reduce the possibility of a collision.

WARNING


n Cautions regarding the use of the system

I The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

I The safe exit assist is a supplementary system that, when the vehicle is stopped, informs occupants of the existence of approaching vehicles and bicycles. As this system alone cannot be used to judge safety, over-reliance on this system may lead to an accident resulting in death or serious injury.

In certain situations, this system may not function to its fullest extent. Therefore it is necessary for the occupants to visually check for safety directly and using the mirrors.

System components



A Multimedia display

Turning the safe exit assist on/off.

B Outside rear view mirror indicators

When a vehicle or bicycle which may collide with a door (other than the back door) when opened is detected, the outside rear view mirror indicator (→P.136) on the detected side will illuminate. If the door on the detected side is open, or opening of the door is canceled, the outside rear view mirror indicator will blink.

C Multi-information display

If collision with a door is likely and the door is opened or opening of the door is canceled, the door will be displayed on the multi-information display. Also, if a door is opened when an outside rear view mirror indicator is illuminated, a

buzzer will sound as a warning.

D Driving assist information indicator

Illuminates when the safe exit assist is turned off. At this time, a message will be displayed on the multi-information display.

E Speakers

When the outside rear view mirror indicator blinks, the driver is informed through voice guidance that the system has operated. After the notification through voice guidance is made, no more voice guidance notifications will be made again until the door is fully closed.

F Door Illumination

When a vehicle or bicycle which may collide with a door (other than the back door) when opened is detected, the door Illumination (red) on the detected side will illuminate. If the door on the detected side is opened, the door Illumination (red) will blink.

n Outside rear view mirror indicator visibility

In strong sunlight, the outside rear view mirror indicator may be difficult to see.

n Buzzer

If the volume setting of the audio system is high or the surrounding area is loud, it may be difficult to hear the buzzer.

n Voice notifications

In the following situations, voice notifications will not be output:

- l When it is estimated that no occupants are on board*
- l After opening a door and entering the vehicle, until the EV system is

started

- l When 3 minutes or more have elapsed since the EV system was stopped
- l When the language setting of the multimedia display has been set to a language that does not support voice notifications
- l When all of the doors have been locked from outside the vehicle
- l When a door remains open for 1 minute or more after the EV system is stopped
- l When the ACC mode (→P.627) has been enabled through a customize setting on the multimedia display and the EV system has been stopped
- l When the parking assist volume setting on the multimedia display has been set to off
- *: For each seating position, judgment is made based on the opening and closing of a door, before driving for ingress and after driving for egress.

n Customization

Some functions can be customized. (→P.637)

WARNING

n To ensure the system can operate properly

→P.336

Turning the safe exit assist system ON/OFF

The safe exit assist system can be enabled/disabled through a customize setting. (→P.627)

When the safe exit assist is off, the driving assist information indicator will illuminate and a


message will be displayed on the multi-information display. Each time the power switch is turned to ON, the safe exit

assist is enabled.*
*: When the power switch is turned off and then to ON immediately after that, the safe exit assist may not be enabled.

Safe exit assist operation

n Objects that can be detected by the safe exit assist


When the safe exit assist detects the following vehicles or bicycles behind your vehicle using a rear side radar sensor, the occupants of the vehicle are informed through an outside rear view mirror indicator, door illumination (red), buzzer, multi-information display, and voice notification.



A Vehicle or bicycle which has a high possibility of colliding with a door (other than the back door) when opened

n The safe exit assist detection areas

The areas that vehicles can be detected in are outlined below.



A Approximately 145 ft. (45 m) rearward from the front door*

*: The faster a vehicle or bicycle is approaching, the distance at which an outside rear view mirror indicator and door illumination (red) will illuminate

or blink will become further.

n **The safe exit assist is operational when**

The safe exit assist is operational when all of the following conditions are met:

- l When the power switch is ON, less than 3 minutes have elapsed since the EV system was off, or less than 3 minutes have elapsed since a door was opened and someone has entered the vehicle (the time which operation is possible may be extended if a door is opened and closed)
- l Safe exit assist is on
- l The vehicle is stopped.
- l The shift position is in a position other than R.

n **The safe exit assist will detect a vehicle when**

The safe exit assist will detect a vehicle present in the detection area in the following situations:

- l When the vehicle is stopped and a vehicle or bicycle, which is traveling parallel to the vehicle, is approaching within the area that a door opens (other than the back door)

n **Conditions under which the system will not detect a vehicle**

- l Safe exit assist does not detect the following objects, vehicles, and bicycles:
 - Vehicles or bicycles which are approaching slowly*
 - Vehicles or bicycles which are determined to have a low possibility of colliding with a door (other than the back door) when opened*
 - Vehicles or bicycles which are approaching from directly behind*
 - Vehicles or bicycles which are approaching from the front*
 - Guardrails, walls, signs, parked vehicles, and other stationary

objects*

- Pedestrians, animals, etc.*

*: Depending on the conditions, detection of a vehicle and/or object may occur.

- l In situations such as the following, safe exit assist will not operate:

- When 3 minutes or more have elapsed since the EV system off (the time which operation is possible may be extended if a door is opened and closed)
- When your vehicle is not completely stopped

n **Conditions under which the system may not function correctly**

- l The safe exit assist may not detect vehicles correctly in the following situations:

- When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- When mud, snow, ice, a sticker, etc. is covering the sensor or surrounding area on the rear bumper
- When the vehicle is stopped on a wet road surface, such as in a puddle, while in inclement weather, such as heavy rain, snow, fog, etc.
- When a vehicle or bicycle approaches from behind a nearby parked vehicle
- When an approaching vehicle or bicycle suddenly changes direction
- Immediately after a vehicle or bicycle starts moving
- When the back door is open
- When a bicycle carrier, ramp, or other accessory is installed to the back of the vehicle
- When a parked vehicle, wall, sign, person or other stationary object is behind the vehicle
- When the vehicle is stopped at an angle to the road
- When a vehicle is traveling near


- an approaching vehicle or bicycle
- When an approaching vehicle or bicycle is traveling along a stationary object, such a wall or sign
- When a vehicle or bicycle is approaching at high speed
- When towing with the vehicle
- When stopped on a steep slope
- When stopped on a curve or at the exit of a curve
- | Instances of the safe exit assist unnecessarily detecting a vehicle and/or object may increase in the following situations:
 - When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
 - When a vehicle or bicycle approaches your vehicle from directly behind in an offset position
 - When the vehicle is stopped at an angle to the road
 - When a vehicle or bicycle approaches from behind a parked vehicle at an angle
 - When a parked vehicle, wall, sign, person or other stationary object is behind the vehicle
 - When an approaching vehicle or bicycle suddenly changes direction
 - When an approaching vehicle or bicycle is traveling along a stationary object, such a wall or sign
 - When the back door is open
 - When a bicycle carrier, ramp, or other accessory is installed to the back of the vehicle
 - When a vehicle or bicycle is approaching at high speed
 - When towing with the vehicle
 - When stopped on a steep slope
 - When stopped on a curve or at the exit of a curve
 - When a vehicle or bicycle approaches from behind a vehicle stopped in an adjacent lane

Intuitive parking assist

The intuitive parking assist function detects the approximate distance from the vehicle and an object such as a wall using ultrasonic sensors and informs the driver with the multimedia display distance display and buzzer.

System components

n Type of sensors



A Front corner sensors

B Front center sensors

C Rear corner sensors

D Rear center sensors

n Display

When the sensors detect an object, such as a wall, a graphic is shown on the multimedia display depending on the position and distance to the object.

Vehicles without multimedia display or rear camera: When detecting a stationary object, the

intuitive parking assist detection indicator illuminates. (→P.136)

The illustration is an example for explanation and may differ depending on the specifications.

► Multimedia display



Turning the intuitive parking assist function ON/OFF

The intuitive parking assist function can be enabled/disabled through a customize setting. (→P.627)

When the intuitive parking assist function is disabled, the intuitive parking assist OFF indicator (→P.136) illuminates on the multi-information display.

If the system switches to OFF (disabled) and the intuitive parking assist is stopped, the intuitive parking assist will not be re-enabled until ON (enabled) is selected again from the customize setting (→P.627).

(It remains off even if the power switch is turned to ON again after the power switch has been turned off.)

Vehicles without the multimedia display or rear camera: However, the system will automatically turn on (enabled) and the intuitive parking assist OFF indicator will turn off if the shift position is changed to R.

When the shift position is R, the intuitive parking assist cannot be turned on or off.

The setting of intuitive parking assist itself will not change.

WARNING

n Cautions regarding the use of the system

There is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. The driver is always responsible for paying attention to the vehicle's surroundings and driving safely.

n To ensure the system can operate properly

Make sure to observe the following precautions. The system may not operate properly and may lead to an unexpected accident. When these precautions cannot be observed, turn the system off.

- I** Do not damage the sensors, and always keep them clean.
- I** Do not attach a sticker or install a component, such as a backlit license plate (especially fluorescent type), fog lights, fender pole or wireless antenna near a radar sensor.

**WARNING**

Do not subject the surrounding area of the sensor to a strong impact. If subjected to an impact, have the vehicle inspected by your Toyota dealer. If the front or rear bumper needs to be removed/installed or replaced, contact your Toyota dealer.

Do not modify, disassemble or paint the sensors.

Do not attach a license plate cover.

Keep your tires properly inflated.

Do not install a suspension other than a genuine suspension.

n Notes when washing the vehicle

When using a high pressure washer to wash the vehicle, do not spray the sensors directly, as doing so may cause a sensor to malfunction.

When using steam to clean the vehicle, do not direct steam too close to the sensors, as doing so may cause a sensor to malfunction.

n The system can be operated when

- | The power switch is in ON.
- | The intuitive parking assist is on.
- | The vehicle speed is less than about 6 mph (10 km/h).
- | Front corner sensors:

The shift position is in a position other than P.

- | Front center sensors:

The shift position is in a position other than P or R.

- | Rear corner and rear center sensors:

- The shift position is in R.

- | Vehicles without the multimedia display or rear camera: The system will automatically turn on (enabled) and the intuitive parking assist OFF indicator will turn off if the shift position is changed to R.

The setting of intuitive parking assist itself will not change.

n Sensor detection information

- | The sensor's detection areas are limited to the areas around the vehicle's front and rear bumpers.

- | Certain vehicle conditions and the surrounding environment may affect the ability of a sensor to correctly detect an object.

- | Objects may not be detected if they are too close to the sensor.

- | There will be a short delay between object detection and display.

Even at low speeds, there is a possibility that the object will come within the sensor's detection areas before the display is shown and the warning beep sounds.

- | It might be difficult to hear the buzzer due to the volume of the audio system or air flow noise of the air conditioning system.

- | It may be difficult to hear the sound of this system due to the buzzers of other systems.

- | If the meter malfunctions, the buzzer may not sound.

n Objects which the system may not be properly detected

The shape of the object may prevent the sensor from detecting it. Pay particular attention to the following objects:

- | Wires, fences, ropes, etc.


- | Cotton, snow and other materials that absorb sound waves
- | Sharply-angled objects
- | Low objects
- | Tall objects with upper sections projecting outwards in the direction of your vehicle

People may not be detected if they are wearing certain types of clothing.


n **Situations in which the system may not operate properly**

Certain vehicle conditions and the surrounding environment may affect the ability of a sensor to correctly detect objects. Particular instances where this may occur are listed below.


- | There is dirt, snow, water drops or ice on a sensor. (Cleaning the sensors will resolve this problem.)
- | A sensor is frozen. (Thawing the area will resolve this problem.) In especially cold weather, if a sensor is frozen the sensor display may be displayed abnormally, or objects, such as a wall, may not be detected.
- | When a sensor or the area around a sensor is extremely hot or cold.



- | If objects draw too close to the sensor.
 - | When a pedestrian is wearing clothing that does not reflect ultrasonic waves (ex. skirts with gathers or frills).
 - | When objects that are not perpendicular to the ground, not perpendicular to the vehicle traveling direction, uneven, or waving are in the detection range.
 - | When strong winds are blowing
 - | When driving in inclement weather such as fog, snow or a sandstorm
 - | When an object that cannot be detected is between the vehicle and a detected object
 - | If an object such as a vehicle, motorcycle, bicycle or pedestrian cuts in front of the vehicle or runs out from the side of the vehicle
 - | If the orientation of a sensor has been changed due to a collision or other impact
 - | When equipment such as a towing eyelet, transport hook, bumper protector, bumper trim, bicycle carrier or snow-removal device (snow plow) is installed near the sensor
 - | If the front of the vehicle is raised or lowered due to the carried load
 - | If the vehicle cannot be driven in a stable manner, such as when the vehicle has been in an accident or is malfunctioning
 - | When tire chains, compact spare tire or an emergency tire puncture repair kit are used
 - | When towing with the vehicle
 - n **Situations in which the system may operate even if there is no possibility of a collision**
- In some situations, such as the following, the system may operate even though there is no possibility of a collision.
- | When driving on a narrow road
- | On an extremely bumpy road, on an incline, on gravel, or on grass.
 - | When vehicle horns, vehicle detectors, motorcycle engines, air brakes of large vehicles, the clearance sonar of other vehicles or other devices which produce ultrasonic waves are near the vehicle
 - | A sensor is coated with a sheet of spray or heavy rain




- | When driving toward a banner, flag, low-hanging branch or boom barrier (such as those used at railroad crossings, toll gates and parking lots)
- | When there is a rut or hole in the surface of the road
- | When driving on a metal cover (grating), such as those used for drainage ditches
- | When driving up or down a steep slope
- | If a sensor is hit by a large amount of water, such as when driving on a flooded road
- | There is dirt, snow, water drops or ice on a sensor. (Cleaning the sensors will resolve this problem.)
- | A sensor is coated with a sheet of spray or heavy rain
- | When driving in inclement weather such as fog, snow or a sandstorm
- | When strong winds are blowing



- | When vehicle horns, vehicle detectors, motorcycle engines, air brakes of large vehicles, the clearance sonar of other vehicles or other devices which produce ultrasonic waves are near the vehicle
- | If the front of the vehicle is raised or lowered due to the carried load


- | If the orientation of a sensor has been changed due to a collision or other impact
- | The vehicle is approaching a tall or curved curb
- | Driving close to columns (H-shaped steel beams, etc.) in multi-story parking garages, construction sites, etc.
- | If the vehicle cannot be driven in a stable manner, such as when the vehicle has been in an accident or is malfunctioning
- | On an extremely bumpy road, on an incline, on gravel, or on grass



- | When tire chains, compact spare tire or an emergency tire puncture repair kit are used
- | When towing with the vehicle

Sensor detection display, object distance

n Detection range of the sensors



A Approximately 3.3 ft. (100 cm)

B Approximately 4.9 ft. (150 cm)

C Approximately 2.0 ft. (60 cm)

The diagram shows the detection range of the sensors. Note that the sensors cannot detect objects that are extremely close to the vehicle.

The range of the sensors may change depending on the shape of the object, etc.

n The distance and buzzer

Approximate distance to obstacle	Buzzer
Front center sensor: Approximately 3.3 ft. (100 cm) to 2.0 ft. (60 cm)* Rear center sensor: Approximately 4.9 ft. (150 cm) to 2.0 ft. (60 cm)*	Slow
Approximately 2.0 ft. (60 cm) to 1.5 ft. (45 cm)*	Medium
Approximately 1.5 ft. (45 cm) to 1.0 ft. (30 cm)*	Fast
Approximately less than 1.0 ft. (30 cm)	Continuous

*: Automatic buzzer mute function is enabled. (→P.349)

Intuitive parking assist buzzer

A buzzer sounds when the sensors are operating.

- The buzzer beeps faster as

the vehicle approaches a static object. When the vehicle comes within the approximately 1.0 ft. (30 cm) of the object, the buzzer will sound continuously.

- When 2 or more sensors simultaneously detect a static object, the buzzer sounds for the nearest object.
- After an intermittent buzzer begins sounding, if the distance between the vehicle and the detected static object does not become shorter, the buzzer will be muted automatically. (automatic buzzer mute function)

- When the power switch is turned off.

n **Adjusting the buzzer volume**

The buzzer volume of the intuitive parking assist, RCTA and RCD can all be changed at once from the customize settings. (→P.627)

n **Muting a buzzer**

When the temporary mute switch is displayed on the multimedia display, this switch can be pressed to temporarily mute the buzzer.

Select the switch to mute a buzzer of the intuitive parking assist, RCTA and RCD all together.

- | Mute will be automatically canceled in the following situations:
 - When the shift position is changed.
 - When the vehicle speed exceeds a certain speed.
 - When there is a malfunction in a sensor or the system is temporarily unavailable.
 - When the operating function is disabled manually.

RCTA (Rear cross traffic alert) function

The RCTA function uses the BSM rear side radar sensors installed behind the rear bumper. This function is intended to assist the driver in checking areas that are not easily visible when backing up.

WARNING


n Cautions regarding the use of the system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings. The RCTA function is only a supplementary function which alerts the driver that a vehicle is approaching from the right or left at the rear of the vehicle. As the RCTA function may not function correctly under certain conditions, the driver's own visual confirmation of safety is necessary. Over reliance on this function may lead to an accident resulting death or serious injury.

n To ensure the system can operate properly

→P.336

System components



A Multimedia display

Turning the RCTA function on/off in multimedia display. If a vehicle approaching from the right or left at the rear of the vehicle is detected, the RCTA icon (→P.352) for the detected side will be displayed on the multimedia display. This illustration* shows an example of a vehicle approaching from both sides of the vehicle.

*: Depending on the vehicle grade and equipped options, the actual screen may be different from this illustration.

B Outside rear view mirror indicators

If a vehicle is detected as approaching from the left or right behind the vehicle, both outside rear view mirror indicators (→P.136) will blink and a buzzer will sound.

C Driving assist information indicator

Illuminates when the RCTA is

turned off. At this time, a message will be displayed on the multi-information display.

Turning the RCTA function on/off

The RCTA can be enabled/disabled through a customize setting. (→P.627)

When the RCTA function is off, the driving assist information indicator (→P.136) will illuminate and a message will be displayed on the multi-information display. Each time the power switch is turned to ON, the RCTA function is enabled.

n Outside rear view mirror indicator visibility

In strong sunlight, the outside rear view mirror indicator may be difficult to see.

n Hearing the RCTA buzzer

The RCTA buzzer may be difficult to hear over loud noises, such as if the audio system volume is high.

n Rear side radar sensors


→P.336

RCTA function

n Operation of the RCTA function

The RCTA function uses rear side radar sensors to detect vehicles approaching from the right or left at the rear of the vehicle and alerts the driver of the presence of such vehicles

by flashing the outside rear view mirror indicators and sounding a buzzer.




A Approaching vehicles

B Detection areas of approaching vehicles

n RCTA icon display


When a vehicle approaching from the right or left at the rear of the vehicle is detected, the following will be displayed on the multimedia display.

Example: Vehicles are approaching from both sides of the vehicle



n RCTA function detection areas

The areas that vehicles can be detected in are outlined below.



The buzzer can alert the driver of faster vehicles approaching from farther away.

Example:

Approaching vehicle speed	A Approximate alert distance
34 mph (56 km/h) (fast)	98 ft. (30 m)
5 mph (8 km/h) (slow)	13 ft. (4 m)

n The RCTA function is operational when

The RCTA function operates when all of the following conditions are met:

- | The power switch is ON.
- | The RCTA function is on.
- | The shift position is in R.
- | The vehicle speed is less than approximately 9 mph (15 km/h).
- | The approaching vehicle speed is between approximately 5 mph (8 km/h) and 34 mph (56 km/h).

n Setting the buzzer volume

The buzzer volume of the RCTA, intuitive parking assist, and RCD can be adjusted all together through a customize setting. (→P.627)

n Muting a buzzer temporarily

When an object is detected, the temporary mute switch is displayed

on the multimedia display. Select the switch to mute the buzzer of the intuitive parking assist, RCTA, and RCD all together.


Mute will be canceled automatically in the following situations:

- | When the shift position is shifted.
- | When the vehicle speed exceeds a certain speed.
- | When there is a malfunction in a sensor or the system is temporarily unavailable.
- | When the operating function is disabled manually.
- | When the power switch is turned off.

n Conditions under which the system will not detect a vehicle

The RCTA function is not designed to detect the following types of vehicles and/or objects:

- | Vehicles approaching from directly behind
- | Vehicles backing up in a parking space next to your vehicle
- | Vehicles that the sensors cannot detect due to obstructions



- | Guardrails, walls, signs, parked vehicles and similar stationary objects*
- | Small motorcycles, bicycles, pedestrians, etc.*
- | Vehicles moving away from your vehicle
- | Vehicles approaching from the parking spaces next to your vehicle*


- | The distance between the sensor and approaching vehicle gets too close

* Depending on the conditions, detection of a vehicle and/or object may occur.


n Situations in which the system may not operate properly

The RCTA function may not detect vehicles correctly in the following situations:


- | When the sensor is misaligned due to a strong impact to the sensor or its surrounding area
- | When mud, snow, ice, a sticker, etc. is covering the sensor or surrounding area on the rear bumper
- | When driving on a wet road surface, such as in a puddle, while in inclement weather, such as heavy rain, snow, fog, etc.
- | When multiple vehicles are approaching with only a small gap between each vehicle
- | When a vehicle is approaching at high speed
- | When equipment that may obstruct a sensor is installed, such as a towing eyelet, bumper protector (an additional trim strip, etc.), bicycle carrier, or snow plow
- | When backing up on a slope with a sharp change in grade




- | When backing out of a sharp angle parking spot



- | Immediately after the RCTA function is turned on
- | Immediately after the EV system is started with the RCTA function on
- | When the sensors cannot detect a vehicle due to obstructions
- | When towing with the vehicle
- | When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
- | When a sensor or the area around a sensor is extremely hot or cold
- | If the suspension has been modified or tires of a size other than specified are installed
- | If the front of the vehicle is raised or lowered due to the carried load
- | When turning while backing up




- | When a vehicle turns into the detection area




- n **Situations in which the system may operate even if there is no possibility of a collision**

Instances of the RCTA function unnecessarily detecting a vehicle and/or object may increase in the following situations:


- | When the parking space faces a street and vehicles are being driven on the street




- | When the distance between your vehicle and metal objects, such as a guardrail, wall, sign, or parked vehicle, which may reflect electrical waves toward the rear of the vehicle, is short



- | When equipment that may obstruct a sensor is installed, such as a towing eyelet, bumper protector (an additional trim strip, etc.), bicycle carrier, or snow plow
- | When a vehicle passes by the side of your vehicle



- | When a detected vehicle turns while approaching the vehicle



- | When there are spinning objects near your vehicle such as the fan of an air conditioning unit
- | When water is splashed or sprayed toward the rear bumper, such as from a sprinkler
- | Moving objects (flags, exhaust fumes, large rain droplets or snowflakes, rain water on the road surface, etc.)
- | When the distance between your vehicle and a guardrail, wall, etc., that enters the detection area is short
- | Gratings and gutters

- | When a sensor or the area around a sensor is extremely hot or cold
- | If the suspension has been modified or tires of a size other than specified are installed
- | If the front of the vehicle is raised or lowered due to the carried load
- | When towing with the vehicle

RCD (Rear camera detection)

When the vehicle is backing up, the rear camera detection function can detect pedestrians in the detection area behind the vehicle. If a pedestrian is detected, a buzzer will sound and an icon will be displayed on the multimedia display to inform the driver of the pedestrian.



WARNING

n Cautions regarding the use of the system

The recognition and control capabilities for this system are limited. The driver should always drive safely by always being responsible without over relying on the system and have a understanding of the surrounding situations.

n To ensure the system can operate properly

Observe the following, otherwise there is the danger that could lead to an accident.

- | Always clean the camera without damaging it.
- | Do not install market parts (such as illuminated license plate, fog lamps, etc.) in the camera vicinity.
- | Do not subject the camera vicinity to strong impacts. If the vicinity is subjected to a strong impact, have the vehicle inspected by your Toyota dealer.

**WARNING**

- | Do not disassemble, remodel or paint the camera.
- | Do not attach accessories or stickers to the camera.
- | Do not install market protection parts (bumper trim, etc.) to the rear bumper.
- | Maintain suitable tire air pressure.
- | Make sure the back door is completely closed.


n When to disable the RCD function

In the following situations, disable the system. The RCD function may not operate properly, possibly leading to an accident.


- | The contents mentioned above are not observed.
- | Suspensions other than the genuine parts are installed.

System component

Location of the rear camera



RCD display



- A** Pedestrian detection icon
Displayed automatically when a pedestrian is detected behind the vehicle.

Turning the RCD function on/off

The RCD function can be enabled/disabled through a customize setting. (→P.627)


When the RCD function is disabled, the driving assist information indicator (→P.136) illuminates, and a message is displayed on the multi-information display.

Each time the power switch is turned off then changed to ON, the RCD function will be enabled automatically.

When a pedestrian is detected

If a pedestrian is in the area behind the vehicle or if the rear camera detected that a pedestrian is approaching the vehicle

from behind, the system urges caution from the driver by sounding the buzzer and displaying the detection of a pedestrian on the multimedia display as follows:



A If a pedestrian is detected in area **A**

Buzzer: Sounds repeatedly
Pedestrian detection icon:
Blinks

B If a pedestrian is detected in area **B**

Buzzer (When the vehicle is stationary): Sounds 3 times
Buzzer (When the vehicle is backing up, when a pedestrian approaches the rear of the vehicle): Sounds repeatedly
Pedestrian detection icon:
Blinks

C If the system determines that your vehicle may collide with a pedestrian in area **C**
Buzzer: Sounds repeatedly

Pedestrian detection icon:
Blinks

n The rear camera detection function is operational when

- l The power switch is in ON.
- l RCD function is on.
- l The shift position is in R.

n Setting the buzzer volume

The buzzer volume of the intuitive parking assist, RCTA and RCD can all be changed at once from the customize settings. (→P.627)

n Muting a buzzer temporarily

When an object is detected, the temporary mute switch is displayed on the multimedia display.

Select the switch to mute a buzzer of the intuitive parking assist, RCTA and RCD all together.

Mute will be automatically canceled in the following situations:

- l When the shift position is changed.
- l When the vehicle speed exceeds a certain speed.
- l When there is a malfunction in a sensor or the system is temporarily unavailable.
- l When the operating function is disabled manually.
- l When the power switch is turned off.

n Situations in which the system may not operate properly

- l Some pedestrians, such as the following, may not be detected by the rear camera detection function, preventing the function from operating properly:
 - Pedestrians who are bending forward or squatting
 - Pedestrians who are lying down
 - Pedestrians who are running
 - Pedestrians who suddenly appear from the shadow of the vehicle or

- a building
- Pedestrians who are riding moving objects such as a bicycle or skateboard
- Pedestrians wearing oversized clothing such as a rain coat, long skirt, etc., making their silhouette obscure
- Pedestrians whose body is partially hidden by an object, such as a cart or umbrella
- Pedestrians which are obscured by darkness, such as at night
- | In some situations, such as the following, pedestrians may not be detected by the rear camera detection function, preventing the function from operating properly:
 - When backing up in inclement weather (rain, snow, fog, etc.)
 - The lens is dirty (by dirt or snow-melting agent, etc.) or scratched
 - When a very bright light, such as the sun, or the headlights of another vehicle, shines directly into the rear camera
 - When backing up in a place where the surrounding brightness changes suddenly, such as at the entrance or exit of a garage or underground parking lot
 - When backing up in a dim environment such as during dusk or in an underground parking lot
 - When the camera position and direction are deviated
 - When a towing hook is attached
 - When water droplets are flowing on the camera lens
 - When the vehicle height is extremely changed (nose up, nose down, etc.)
 - When tire chains or an emergency tire puncture repair kit are used
 - When the suspension has been lowered or tires that have a different size than the genuine tires are installed
 - When an aftermarket part (backlit license plate, fog light, etc.) is installed near the rear camera
 - If a bumper protector, such as an additional trim strip, is installed to

the rear bumper

n **Situations in which the system may operate unexpectedly**

- | Even though there are no pedestrians in the detection area, some objects, such as the following, may be detected, possibly causing the rear camera detection function to operate.
 - Three dimensional objects, such as a pole, traffic cone, fence, or parked vehicle
 - Moving objects, such as a car or motorcycle
 - Objects moving toward your vehicle when backing up, such as flags or puddles (or airborne matter, such as smoke, steam, rain, or snow)
 - Cobblestone or gravel roads, tram rails, road repairs, white lines, pedestrian crossings or fallen leaves on the road
 - Metal covers (gratings), such as those used for drainage ditches
 - Objects reflected in a puddle or on a wet road surface
 - Shadows on the road
- | In some situations, such as the following, the rear camera detection function may operate even though there are no pedestrians in the detection area.
 - When backing up toward the roadside or a bump on the road
 - When backing up toward an incline/decline
 - When the vehicle height is extremely changed (nose up, nose down, etc.)
 - When an aftermarket part (backlit license plate, fog light, etc.) is installed near the rear camera
 - If a bumper protector, such as an additional trim strip, is installed to the rear bumper
 - If the orientation of the rear camera has been changed due to a collision or other impact, or removal and installation
 - If a towing eyelet is installed to the rear of the vehicle
 - When water is flowing over the

- rear camera lens
- The lens is dirty (by dirt or snow-melting agent, etc.)
- If there is a flashing light in the detection area, such as the emergency flashers of another vehicle
- When tire chains or an emergency tire puncture repair kit are used
- | Situations in which the rear camera detection function may be difficult to notice
- The buzzer may be difficult to hear if the surrounding area is noisy or the audio system volume is high.
- If the temperature in the cabin is extremely high or low, the multi-media display may not operate correctly.

PKSB (Parking Support Brake)

The PKSB (Parking Support Brake) is a system that issues warnings and automatically performs braking to help reduce collision damage with operation targets that were detected when traveling at a low speed such as when parking.

PKSB (Parking Support Brake) system

The system has detected the following as operation targets. (The operation targets vary depending on the function.)

- Parking Support Brake function (static objects front and rear of the vehicle):

→P.365

- Parking Support Brake function (moving vehicles rear of the vehicle):

→P.367

- Parking Support Brake function (pedestrians rear of the vehicle):

→P.369

**WARNING****n Cautions regarding the use of the system**

Do not overly rely on the system, as doing so may lead to an accident. Always drive while checking the safety of the surroundings of the vehicle.

Depending on the vehicle and road conditions, weather, etc., the system may not operate.

The detection capabilities of sensors and radars are limited.

Always drive while checking the safety of the surroundings of the vehicle.

I The driver is solely responsible for safe driving. Always drive carefully, taking care to observe your surroundings. The Parking Support Brake system is designed to provide support to lessen the severity of collisions. However, it may not operate in some situations.

I The Parking Support Brake system is not designed to stop the vehicle completely. Additionally, even if the system has stopped the vehicle, it is necessary to depress the brake pedal immediately as brake control will be canceled after approximately 2 seconds.

I It is extremely dangerous to check the system operations by intentionally driving the vehicle into the direction of a wall, etc. Never attempt such actions.

n When to disable the Parking Support Brake

In the following situations, disable the Parking Support Brake as the system may operate even though there is no possibility of a collision.

- I When inspecting the vehicle using a chassis roller, chassis dynamo or free roller
- I When loading the vehicle onto a boat, truck or other transport vessel
- I If the suspension has been modified or tires of a size other than specified are installed
- I If the front of the vehicle is raised or lowered due to the carried load
- I When equipment such as a towing hook, transport hook, bumper protector, bumper trim, bicycle carrier or snow-removal device (snow plow) is installed near the sensor
- I When using automatic car washing devices
- I If the vehicle cannot be driven in a stable manner, such as when the vehicle has been in an accident or is malfunctioning
- I When the vehicle is driven in a sporty manner or off-road
- I When the tires are not properly inflated
- I When the tires are very worn
- I When tire chains, a compact spare tire or an emergency tire puncture repair kit are used.
- I When towing with the vehicle

n Precautions for the suspension

Do not modify the suspension of the vehicle. If the height or tilt of the vehicle is changed, the sensors may not be able to detect detectable objects and the system may not operate correctly, possibly leading to an accident.

Enabling/Disabling the Parking Support Brake

The Parking Support Brake function can be enabled/disabled through a customize setting. (→P.627)

When the PKSB (Parking Support Brake) is disabled, the driving assist information indicator (→P.136) illuminates, and a message is displayed on the multi-information display.

If the PKSB (Parking Support Brake) is switched to OFF (disabled), the system will not be re-enabled until ON (enabled) is selected again from the customize setting (→P.638).

(It remains off even if the power switch is turned to ON again after the power switch has been turned off.)

Display and buzzer for EV system output restriction control and brake control

If the EV system output restriction control or brake control operates, a buzzer will sound and a message that indicates limited acceleration or prompts the driver to brake will be displayed on the multimedia display and multi-information display, to alert the driver.

Depending on the situation, output restriction control operates to either limit acceleration or restrict output

as much as possible.

- EV system output restriction control is operating (acceleration restriction)

Acceleration greater than a certain amount is restricted by the system.

Multimedia display: No warning displayed

Message example on the multi-information display: "Object Detected Acceleration Reduced"

Driving assist information indicator: Not illuminated

Buzzer: Does not sound

- EV system output restriction control is operating (output restricted as much as possible)

The system has determined that stronger-than-normal brake operation is necessary.

Message example on the multimedia display*: "BRAKE!"

Message example on the multi-information display: "BRAKE!"

Driving assist information indicator: Not illuminated

Buzzer: Short beep

- Brake control is operating

The system determined that emergency braking is necessary.

Message example on the multimedia display*: "BRAKE!"

Message example on the multi-information display: "BRAKE!"

Driving assist information indicator: Not illuminated

Buzzer: Short beep

- Vehicle stopped by system operation

The vehicle has been stopped by brake control operation.

Message example on the multimedia display*: "Switch to Brake"

Message example on the multi-information display: "Accelerator Pedal is Pressed Press Brake Pedal", "Press Brake Pedal"

Driving assist information indicator: Illuminated

Buzzer: Sounds repeatedly


*: This may not be displayed depending on the specification of the panoramic view monitor.

System overview

If the Parking Support Brake determines that a collision with a detected object or pedestrian is possible, the EV system output will be restricted to restrain any increase in the vehicle speed. (EV system output restriction control: See figure 2 below.)

Additionally, if the accelerator pedal continues to be depressed, the brakes will be applied automatically to reduce the vehicle speed. (Brake control: See figure 3.)

- Figure 1: When the PKSB (Parking Support Brake) is not operating




A EV system output

B Braking force

C Time

- Figure 2: When EV system output restriction control operates




A EV system output

B Braking force

C Time

- D** EV system output restriction control begins operating (System determines that possibility of collision with detected object is high)

- Figure 3: When EV system output restriction control and brake control operates



- A** EV system output
- B** Braking force
- C** Time
- D** EV system output restriction control begins operating (System determines that possibility of collision with detected object is high)
- E** Brake control begins operating (System determines that possibility of collision with detected object is extremely high)

n If the Parking Support Brake has operated

If the vehicle is stopped due to operation of the Parking Support Brake, the Parking Support Brake will be disabled and the driving assist information indicator will illuminate.

In addition, even when the PKSB (Parking Support Brake) operates, the brake control is canceled after approximately 2 seconds to start off.

Furthermore, the brake control also can be canceled by depressing the brake pedal. Depressing the accelerator pedal again after that allows the vehicle to start off.

n Re-enabling the Parking Support Brake

To re-enable the Parking Support Brake when it is disabled due to

operation of the PKSB (Parking Support Brake), either enable the system again, or turn the power switch off and then back to ON.

Additionally, if any of the following conditions are met, the system will be re-enabled automatically and the driving assist information indicator will turn off (→P.136):

- l The P shift position is selected
- l Drive with no operation targets in the traveling direction of the vehicle
- l Change the traveling direction of the vehicle

n Buzzer

Regardless of whether the intuitive parking assist sensor is enabled or not (→P.345), if the PKSB (Parking Support Brake) system is enabled (→P.362), the buzzer will sound to notify the driver of the approximate distance to the object when the brake control and the EV system output restriction control are operated.


Parking Support Brake function (static objects front and rear of the vehicle)

If the sensors detect a static object, such as a wall, in the traveling direction of the vehicle and the system determines that a collision may occur due to the vehicle suddenly moving forward due to an accidental accelerator pedal operation, the vehicle moving the unintended direction due to the wrong shift position being selected, or while parking or traveling at low speeds, the system will operate to lessen the impact with the detected static object and reduce the resulting damage.


Examples of function operation (static objects front and rear of the vehicle)

This function will operate in situations such as the following if an object is detected in the traveling direction of the vehicle.


- n When traveling at a low speed and the brake pedal is not depressed, or is depressed late



- n When the accelerator pedal is depressed excessively



- n **When the vehicle moves forward due to the incorrect shift position being selected**



Types of sensors

→P.344

! WARNING

- n **To ensure the system can operate properly**

→P.345

- n **If the Parking Support Brake function operates unnecessarily, such as at a railroad crossing**

→P.364

- n **Notes when washing the vehicle**

→P.346

- n **The Parking Support Brake function (static objects front and rear of the vehicle) will operate when**

The function will operate when the driving assist information indicator is not illuminated (→P.134) and all of the following conditions are met:

- l EV system output restriction control
- The Parking Support Brake is enabled.
- The vehicle speed is approximately 9 mph (15 km/h) or less.
- There is a static object in the traveling direction of the vehicle and approximately 6 to 13 ft. (2 to 4 m) away.
- The Parking Support Brake determines that a stronger-than-normal brake operation is necessary to avoid a collision.

- l Brake control

- EV system output restriction control is operating.
- The Parking Support Brake determines that an immediate brake operation is necessary to avoid a collision.

- n **The Parking Support Brake function (static objects front and rear of the vehicle) will stop operating when**

The function will stop operating if any of the following conditions are met:

- l EV system output restriction control
- The Parking Support Brake is disabled.
- The system determines that the collision has become avoidable with normal brake operation.
- The static object is no longer approximately 6 to 13 ft. (2 to 4 m) away from the vehicle or in the traveling direction of the vehicle.

- l Brake control

- The Parking Support Brake is disabled.
- Approximately 2 seconds have elapsed since the vehicle was stopped by brake control.
- The brake pedal is depressed after the vehicle is stopped by brake control.
- The static object is no longer approximately 6 to 13 ft. (2 to 4 m) away from the vehicle or in the traveling direction of the vehicle.

n Detection range of the Parking Support Brake function (static objects front and rear of the vehicle)

The detection range of the Parking Support Brake function (static objects front and rear of the vehicle) differs from the detection range of the intuitive parking assist (→P.349). Therefore, even if the intuitive parking assist detects an object and provides a warning, the Parking Support Brake function (static objects front and rear of the vehicle) may not start operating.

n Situations in which the system may not operate properly

→P.347

n Situations in which the system may operate even if there is no possibility of a collision

→P.347


Parking Support Brake function (moving vehicles rear of the vehicle)

If a rear radar sensor detects a vehicle approaching from the right or left at the rear of the vehicle and the system determines that the possibility of a collision is high, this function will perform brake control to reduce the likelihood of an impact with the approaching vehicle.

Examples of the function operation

This function will operate in situations such as the following if a vehicle is detected in the traveling direction of the vehicle.

- n When reversing, a vehicle is approaching and the brake pedal is not depressed, or is depressed late**



Types of sensors

→P.336



WARNING

n To ensure the system can operate properly

→P.336

n The Parking Support Brake function (moving vehicles rear of the vehicle) will operate when

The function will operate when the driving assist information indicator is not illuminated (→P.134) and all of the following conditions are met:

- | EV system output restriction control
- The Parking Support Brake is enabled.
- The vehicle speed is approximately 9 mph (15 km/h) or less.
- Vehicles are approaching from the right or left at the rear of the vehicle at a traveling speed of approximately 5 mph (8 km/h) or more.
- The shift position is in R.
- The Parking Support Brake determines that a stronger than normal brake operation is necessary to avoid a collision with an approaching vehicle.
- | Brake control
- EV system output restriction control is operating.
- The Parking Support Brake determines that an emergency brake operation was necessary to avoid a collision with a vehicle approaching from the rear.

n The Parking Support Brake function (moving vehicles rear of the vehicle) will stop operating when

The function will stop operating if any of the following conditions are met:

- | EV system output restriction control
- The Parking Support Brake is disabled.
- The collision becomes avoidable with normal brake operation.
- A vehicle is no longer approaching from the right or left at the rear of the vehicle.
- | Brake control
- The Parking Support Brake is disabled.
- Approximately 2 seconds have elapsed since the vehicle was stopped by brake control.
- The brake pedal is depressed after the vehicle is stopped by brake control.

n Situations in which the system may not operate properly

→P.354

n Situations in which the system may operate even if there is no possibility of a collision


→P.355

Parking Support Brake function (pedestrians rear of the vehicle)

If the rear camera sensor detects a pedestrian behind the vehicle while backing up and the system determines that the possibility of colliding with the detected pedestrian is high, a buzzer will sound. If the system determines that the possibility of colliding with the detected pedestrian is extremely high, the brakes will be applied automatically to help reduce the impact of the collision.


Examples of system operation

The system operates when an approaching pedestrian is detected behind the vehicle while backing up, and when the brake pedal is not depressed or is depressed late.



Screen display of pedestrians rear of the vehicle

Displays a message to prompt the driver to brake when a pedestrian is detected in the detection area behind the vehicle.



A Pedestrian detection icon

B Example: "BRAKE!"



WARNING

n If the Parking Support Brake function (pedestrians rear of the vehicle) operates unnecessarily

Depress the brake pedal immediately after the Parking Support Brake function (pedestrians rear of the vehicle) operates. (Operation of the function is canceled by depressing the brake pedal.)

n Correct use of the Parking Support Brake function (pedestrians rear of the vehicle)

→P.356

n The Parking Support Brake function (pedestrians rear of the vehicle) will operate when

The function will operate when the driving assist information indicator is not illuminated (→P.134) and all of

the following conditions are met:

- | EV system output restriction control
- The Parking Support Brake is enabled.
- The vehicle speed is 9 mph (15 km/h) or less.
- The shift position is in R.
- When a pedestrian is to the rear of the vehicle
- The PKSB (Parking Support Brake) determines that a stronger-than-normal-brake operation is necessary to avoid a collision.
- | Brake control
- EV system output restriction control is operating.
- The Parking Support Brake determines that an emergency brake operation is necessary to avoid a collision with a pedestrian.

n The Parking Support Brake function (pedestrians rear of the vehicle) will stop operating when

The function will stop operating if any of the following conditions are met:

- | EV system output restriction control
- The Parking Support Brake is disabled.
- The collision becomes avoidable with normal brake operation.
- The pedestrian is no longer detected behind your vehicle.
- | Brake control
- The Parking Support Brake is disabled.
- Approximately 2 seconds have elapsed since the vehicle was stopped by brake control.
- The brake pedal is depressed after the vehicle is stopped by brake control.

n Re-enabling the Parking Support Brake function (pedestrians rear of the vehicle)

→P.364

n Detection area of the Parking Support Brake function (pedestrians rear of the vehicle)

The detection area of the Parking Support Brake function (pedestrians rear of the vehicle) differs from the detection area of the RCD function (→P.357). Therefore, even if the RCD function detects a pedestrian and provides an alert, the Parking Support Brake function (pedestrians rear of the vehicle) may not start operating.

n Situations in which the system may not operate properly

→P.358

n Situations in which the system may operate unexpectedly

→P.359

Multi-terrain Monitor

The Multi-terrain Monitor helps the driver to check the vehicle surroundings. It assists in determining the conditions around the driver in a variety of situations, such as when judging conditions during off-road driving or checking for obstacles when parking.

- I The screen illustrations used in this text are intended as examples, and may differ from the image that is actually displayed on the screen.



WARNING

n When using the Multi-terrain Monitor system

Observe the following precautions to avoid an accident that could result in death or serious injuries.

- I Never rely solely on the Multi-terrain Monitor. As with unequipped vehicles, drive carefully while directly confirming the safety of your surroundings and the area to the rear of the vehicle. Take particular care to avoid parked cars and other obstacles.
- I Due to the characteristics of the camera lens, the actual position and distance of people and other obstacles will differ from those shown on the Multi-terrain Monitor screen. Directly confirm the safety of your surroundings before driving.

I Always make sure to visually check behind you and your surroundings while you are driving.

- I Never drive while looking only at the screen as the image on the screen is different from actual conditions. If you are driving while looking only at the screen, you may hit a person or an object, resulting in an accident. When driving, be sure to check the vehicle's surroundings with your own eyes and the vehicle's mirrors.

- I The position of the guide lines displayed on the screen may change due to factors such as number of passengers, load capacity, and road gradient. Always make sure to visually check behind you and your surroundings while you are driving.

- I In low temperatures, the screen may darken or the images may become faint. Images of moving objects in particular may distort or disappear from the screen. Therefore, make sure to drive carefully while directly visually confirming the safety of your surroundings.

- I If you replace your tires, the position of the guide lines displayed on the screen may be incorrect.



NOTICE

n Multi-terrain Monitor

When the camera malfunctions, the screen may be displayed as follows:

**NOTICE**

- ! When the shift position is in any position other than R, the camera image continue to be displayed
- ! When the shift position is in R, part or all of the screen may appear black
- ! When the shift position is in R, the screen may not change to the camera image
- ! The guide lines are not displayed on the camera image, and attention symbols and caution notices are displayed


Multi-terrain Monitor screens

The following screens can be selected according to driving conditions.

- Screens that can be selected vary depending on conditions such as shift position and vehicle speed. (→P.375)
- Depending on the displayed screen, the display can be switched from normal to full screen display.


n Screens when the “X-MODE” switch is in on.

- When checking the area to the front and sides of the vehicle
- Front view & dual side views



→P.380


► Front view (magnified)



→P.380


- When checking the condition of the road surface under the vehicle

► Under vehicle terrain view & dual side views




→P.383

► Under vehicle terrain view (magnified)




→P.383

- Under vehicle terrain view (rear wheel) & dual side views




→P.390

- Wide rear view & dual side views




→P.386

- Under vehicle terrain view (rear wheel) (magnified)




→P.390

- Under vehicle terrain view (rear side) & dual side views




→P.386

- When checking the area to the rear of the vehicle
- Rear view & dual side views



→P.393

- Under vehicle terrain view (rear side) (magnified)




→P.393

n Screens when the “X-MODE” switch is off.


- When checking the area to the around of the vehicle

► Moving view



→P.396


► See-through view



→P.396


- When checking the area to the front of the vehicle

► Wide front view & panoramic view




→P.398

► Side Clearance View & panoramic view



→P.398


► Cornering View & panoramic view



→P.398


- When checking the area to the rear of the vehicle

► Rear view & panoramic view




→P.406

► Wide rear view & panoramic view



→P.414


► Side view & Wide rear view



→P.406

- When folding the outside rear view mirrors


► Side view & Wide front view



→P.414


Camera switch

The camera switch is located as shown in the illustration.



→P.414

► Side view & Rear view




How to switch the screen

When you press the camera switch while the power switch is in ON, the monitor display operates.

The monitor displays various views of the position of the vehicle.
(The following is an example)

“X-MODE” switch is in on

n When the shift position is in the P, D or N position




- A** Audio screen, etc.
- B** Front view & dual side views
- C** Under vehicle terrain view & dual side views
- D** Front view (magnified)
- E** Under vehicle terrain view (magnified)
- F** Under vehicle terrain view (rear wheel) (magnified)
- G** Under vehicle terrain view (rear wheel) & dual side views
- H** Press the camera switch
- I** Select the Multi-terrain Monitor screen
- J** Select the under vehicle terrain view (rear wheel) button

K Select the return button

L Select the display mode button

n When the shift position is in the R position



A Rear view & dual side views

B Wide rear view & dual side views

C Under vehicle terrain view (rear side) & dual side views

D Under vehicle terrain view (rear side) (magnified)

E Select the under vehicle terrain view (rear side) button


F Select the return button

G Select the Multi-terrain Monitor screen

H Select the display mode button

“X-MODE” switch is in off

n When the shift position is in the P position



A Navigation screen, audio screen, etc.


B Pressing the camera switch

C Moving view

D See-through view


E Touch the display mode switching button

n When the shift position is in the D or N position



- A** Navigation screen, audio screen, etc.
- B** Wide front view & panoramic view
- C** Side clearance view & panoramic view
- D** Cornering view & panoramic view
- E** Pressing the camera switch
- F** Touch the display mode switching button
- G** When the steering wheel is turned by 180 degrees or more from the center (straight-line) position

n When the shift position is in the R position



- A** Rear view & panoramic view
- B** Wide rear view & panoramic view
- C** Touch the display mode switching button

n Multi-terrain Monitor screen display

- I** The amount of time that the Multi-terrain Monitor screen is displayed changes as follows according to the vehicle speed at the time the camera switch was pressed.
- I** The Multi-terrain Monitor screen is displayed if the vehicle speed is approximately 7 mph (12 km/h) or less when the camera switch is pressed.
- I** If the vehicle speed exceeds approximately 7 mph (12 km/h), the Multi-terrain Monitor display is canceled.
- I** Display settings such as guide lines mode can be saved as the

my settings by registering a driver, and then applied when entering the vehicle.

- I** The Intelligent Assistant can be used to display the panoramic view monitor screen, change the screen mode and for other operations.

Screen display and functions

When the “X-MODE” switch is in on, the various screens display information to support several different driving situations, such as when checking for obstacles when moving forward or in

reverse, or when judging road surface conditions during off-road driving.

Front view & dual side views

Front view & dual side views can be used to check the area around the front of the vehicle.


To display the screen, press the camera switch when the shift position is in the P, D or N position.

- In addition to an image of the front of the vehicle, guide

lines are displayed in a composite view to provide reference for when deciding a direction to move forward in.

- If the front view display is selected while the screen is displayed, the screen switches from normal to magnified display. (Selecting the display again returns the screen to the normal display)
- If the steering wheel is turned 270° or more, guide lines and other features to support turning are automatically displayed.

Screen display



A If the steering wheel is turned 270° or more

B Selecting the display

C 1.5 ft. (0.5 m) distance guide line (red)

D 3 ft. (1 m) distance guide line (blue)

E 6 ft. (2 m) distance guide line (blue)

Items **C** to **E** indicate the estimated distance from the front end of the vehicle.

F Front tire course line (yellow)

Indicates the estimated course of the front tires according to steering wheel position.

G Vehicle width lines (blue)

Indicate the width of the vehicle including the outside rear view mirrors.

H Front tire contact line (blue)**I** Rear tire contact line (blue)

Items **H** and **I** indicate estimated tire positions on the image.

J Rear tire course line (yellow)

Indicates the estimated course of the rear tires.

K Forward movement guide line (blue)

Indicates the estimated tire course of the tightest possible turn.

L Intuitive parking assist/slip display

Indicates tire spinning by changing color and flashing the tire displayed. If the intuitive parking assist detects a static object when the system is enabled, the indicator is displayed on the screen. (→P.382)

M Display off button

Changes the screen back to the previously displayed screen, such as the audio screen.

N Display mode switching button

Switches display mode every time touch the button.

O Under vehicle terrain view (rear wheel) selection button

Switch the under vehicle terrain view (rear wheel) & dual side views (→P.386)

P Automatic display mode selection button

→P.382

Q Setting button


Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

R Tilt meter

Displays the vehicle's estimated degree of incline. (→P.381)

n Tilt meter

Tilt meter displays the vehicle inclination to the front, rear, left and right within a range of 0° to approximately 30°.



A Degree markers of incline to the front and rear

Indicates the vehicle inclination in degrees in the front and rear directions.

B Degree markers of incline to the left and right


Indicates the vehicle inclination in degrees in the left and right directions.

C Pointer

Indicates the degree of the vehicle inclination in comparison to a parallel line.

n Intuitive parking assist/slip display

Indicates the tire that is spinning when tire spinning is detected.



A Tire icon

The tire that is spinning flashes in orange.

B Intuitive parking assist

pop-up display

Displayed if an obstacle is detected while the intuitive parking assist is enabled.

Automatic display mode

In addition to screen switching by operating the camera switch, automatic display mode is available. In this mode, the screen is switched automatically in response to vehicle speed.

In automatic display mode, the monitor will automatically display images in the following situations:

- Touching the automatic display button  turns on auto display mode.
- Turning on auto display mode automatically displays the views in the following situations:
 - When the shift position is in D or N
 - The vehicle decelerates to less than 6 mph (10 km/h) (the shift position is in any position other than R)

n Front view & dual side views display

The screen can be displayed when the shift position is in P, D or N.

n Tilt meter display

- l The display indicates the incline of the vehicle in degrees shown by the movement of the pointer and the rotation of the vehicle image.

- | The color of the degree markers of incline to the front, rear, left and right changes according to the current incline of the vehicle.
 - | After the power switch is turned to ON, the degree of incline is not displayed until such information is determined
 - | The degree of incline showed on the tilt meter is only an approximate indication, and may differ from the degree of incline measured using other equipment.
 - | When the degree of incline is larger than 30°, the pointer will be displayed beyond 30°.
 - | If the system malfunctions, the vehicle image and pointer are not displayed. In this case, have the vehicle inspected by your Toyota dealer.
- n Slip display**
- If the system malfunctions, the tire icon is not displayed. In this case, have the vehicle inspected by your Toyota dealer.


Under vehicle terrain view & dual side views

Lines indicating current vehicle and tire position are displayed in a composite view on an image taken behind the current vehicle position and assists the driver to check conditions underneath the vehicle or determine the position of the front tires.

To display the screen, press the camera switch when the shift position is in the P, D or N position.

- It is necessary to drive a certain distance or more for the image to be displayed.
- If the under vehicle terrain view display is selected while the screen is displayed, the screen switches from normal to magnified display. (Selecting the display again returns the screen to the normal display)

Screen display



- A** Current vehicle position
- B** Image displayed in the under vehicle terrain view (image taken behind the current vehicle position)
- C** Vehicle position at the time the image was taken (behind the current vehicle position)
- D** Selecting the display

E Vehicle width lines (blue)

Indicate the width of the vehicle including the outside rear view mirrors.

F Front tire contact line (blue)

G Rear tire contact line (blue)

Items **F** and **G** indicate estimated tire positions on the image.

H 1.5 ft. (0.5 m) distance guide line (red, black)

Indicate the estimated distance from the front end of the vehicle.

I Rear tire course line (yellow)

Indicates the estimated course of the rear tires.

J Tire position indicator lines (black, white)

Indicates the estimated position of the front tires.

K Vehicle position indicator lines (blue)

Indicates the estimated position of the vehicle.

L Intuitive parking assist/slip display

Indicates tire spinning by changing color and flashing the tire displayed. If the intuitive parking assist detects a static object when the system is

enabled, the indicator is displayed on the screen. (→P.382)

M Display off button

Changes the screen back to the previously displayed screen, such as the audio screen.

N Display mode switching button

Switches display mode every time touch the button.

O Under vehicle terrain view (rear wheel) selection button

Switch the under vehicle terrain view (rear wheel) & dual side views (→P.386)

P Automatic display mode selection button

→P.385

Q Setting button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

R Tilt meter

Displays the vehicle's estimated degree of incline. (→P.381)

Automatic display mode

In addition to screen switching by operating the camera switch, automatic display mode is available. In this mode, the screen is switched automatically in response to vehicle speed.

In automatic display mode, the monitor will automatically display images in the following situations:

- Touching the automatic display button  turns on auto display mode.
- Turning on auto display mode automatically displays the views in the following situations:
 - When the shift position is in D or

N

- The vehicle decelerates to less than 6 mph (10 km/h) (the shift position is in any position other than R)

n Under vehicle terrain view & dual side views

- | The screen can be displayed when the shift position is in P, D or N.
- | In the following situations, under vehicle terrain view will disappear.
 - When the vehicle is driven with the steering wheel turned almost all the way to one side
 - After the EV system starts or the system returns to normal, a fixed distance or more has not yet been driven
 - When the tires are slipping or spinning
 - ABS is activated
 - When there is a malfunction in the system
- | If the outside rear view mirrors are

folded while the under vehicle terrain view is being displayed, a separate screen is displayed.

- | If the vehicle is driven with the steering wheel turned to a certain steering angle or greater, a part of the screen may disappear. However, this is not a malfunction.
- | In the following situations, the system may not operate normally.
 - The road is covered with snow
 - When there are shadows due to light sources such as sunlight or illumination
 - When driving on slippery roads or tires are spinning
 - Dirt or foreign matter is adhering to the camera lens
 - There is water in front of the vehicle (a river, puddle, sea water, etc.)
 - Optional equipment has been installed
 - When the camera is covered or there is an object in the image capture range
 - Tires have been replaced
 - When the back door is open
 - When the steering wheel is operated at or more than a specified steering angle
 - On roads that are not flat, such as slopes
- | As vision that was captured in the past is being displayed, the screen and the actual situation may differ in the following cases:
 - An obstacle appears or moves

after vision is captured.

- Sand or snow crumbles and moves after vision is captured.
- Mud or puddles are in the display range.
- When the vehicle slips.



WARNING

n Guide lines

The tire position indicator lines and vehicle position indicator lines may differ from actual vehicle positions depending on the number of passengers, cargo weight, road grade, road surface conditions, brightness of the surrounding environment, whether tires or suspension parts other than those specified are equipped, etc. Always drive the vehicle while confirming the safety of your surroundings.

n Under vehicle terrain view display

The image displayed is one that was previously taken at a point behind the current vehicle position. In cases such as when objects move after the image is taken, the image displayed on the screen may differ from the actual state. In addition, when driving in the dark such as at night, there are cases when obstacles cannot be confirmed from the image.


Under vehicle terrain view (rear wheel) & dual side views

Lines indicating current vehicle and tire position are displayed in a composite view on an image taken behind the current vehicle position and assists the driver to check conditions underneath the vehicle or determine the position of the rear tires.

To display the screen, press the camera switch when the shift position is in the P, D or N position, select the under vehicle terrain view (rear wheel) selection switch.

- It is necessary to drive a certain distance or more for the image to be displayed.
- If the under vehicle terrain view display is selected while the screen is displayed, the screen switches from normal to magnified display. (Selecting the display again returns the screen to the normal display)

Screen display



- A** Current vehicle position
- B** Image displayed in the under vehicle terrain view (rear wheel)
(image taken behind the current vehicle position)
- C** Vehicle position at the time the image was taken (behind the current vehicle position)
- D** Selecting the display
- E** Tire position indicator lines (black, white)
Indicates the estimated position of the rear tires.
- F** Vehicle position indicator lines (blue)
Indicates the estimated position of the vehicle.
- G** 1.5 ft. (0.5 m) distance guide line (red, black)
Indicate the estimated distance from the front end of the vehicle.
- H** Front tire contact line (blue)
Indicate estimated tire positions on the image.
- I** Vehicle width lines (blue)
Indicate the width of the vehicle including the outside rear view mirrors.

J Rear tire contact line (blue)

Indicate estimated tire positions on the image.

K Intuitive parking assist/slip display

Indicates tire spinning by changing color and flashing the tire displayed. If the intuitive parking assist detects a static object when the system is enabled, the indicator is displayed on the screen. (→P.382)

L Display off button

Changes the screen back to the previously displayed screen, such as the audio screen.

M Return button

Return to the previous screen

N Automatic display mode selection button

→P.388

O Setting button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

P Tilt meter

Displays the vehicle's estimated degree of incline. (→P.381)

Automatic display mode

In addition to screen switching by operating the camera switch, automatic display mode is available. In this mode, the screen is switched automatically in response to vehicle speed. In automatic display mode, the monitor will automatically display images in the following situations:

- Touching the automatic display button  turns on auto display mode.
- Turning on auto display mode automatically displays the views in the following situations:

- When the shift position is in D or N
- The vehicle decelerates to less than 6 mph (10 km/h) (the shift position is in any position other than R)

n Under vehicle terrain view (rear wheel)

- l The screen can be displayed when the shift position is in P, D or N.
- l In the following situations, the display of the under vehicle terrain view (rear wheel) ends and the screen automatically returns to the most recently used camera screen. In addition, the under vehicle terrain view (rear wheel) selection switch cannot be operated until the next screen can be displayed.
- When vehicle speed reaches or

- exceeds approximately 3 mph (5 km/h)
- When the vehicle is driven with the steering wheel turned almost all the way to one side
- When the tires are slipping or spinning
- ABS is activated
- When there is a malfunction in the system
- When the steering wheel is operated at or more than a specified steering angle
- | If the outside rear view mirrors are folded while the under vehicle terrain view (rear wheel) is being displayed, a separate screen is displayed.
- | If the vehicle is driven with the steering wheel turned to a certain steering angle or greater, a part of the screen may disappear. However, this is not a malfunction.
- | In the following situations, the system may not operate normally or may not be able to switch to the under vehicle terrain view (rear wheel). In addition, the under vehicle terrain view (rear wheel) selection switch cannot be operated until the next screen can be displayed.
 - The road is covered with snow
 - When there are shadows due to light sources such as sunlight or illumination
 - When driving on slippery roads or tires are spinning
 - Dirt or foreign matter is adhering to the camera lens
 - There is water in front of the vehicle (a river, puddle, sea water, etc.)
 - Optional equipment has been installed
 - When the camera is covered or there is an object in the image capture range
 - Tires have been replaced
 - When the back door is open
 - When the steering wheel is operated at or more than a specified steering angle
- On roads that are not flat, such as slopes
 - | As vision that was captured in the past is being displayed, the screen and the actual situation may differ in the following cases:
 - An obstacle appears or moves after vision is captured.
 - Sand or snow crumbles and moves after vision is captured.
 - Mud or puddles are in the display range.
- When the vehicle slips.



WARNING

n Guide lines

The tire position indicator lines and vehicle position indicator lines may differ from actual vehicle positions depending on the number of passengers, cargo weight, road grade, road surface conditions, brightness of the surrounding environment, whether tires or suspension parts other than those specified are equipped, etc.

Always drive the vehicle while confirming the safety of your surroundings.

n Under vehicle terrain view (rear wheel) display


The image displayed is one that was previously taken at a point behind the current vehicle position. In cases such as when objects move after the image is taken, the image displayed on the screen may differ from the actual state. In addition, when driving in the dark such as at night, there are cases when obstacles cannot be confirmed from the image.

Rear view & dual side views/wide rear view & dual side views

The rear view & dual side views and the wide rear view & dual side views screen provide support when checking the areas of behind the vehicle and around the vehicle while backing up, for example while parking.

The screens will be displayed when the shift position is in the R position.

Screen display



A Display mode switching button

Each time the display mode switching button is selected, the mode will change between the rear view & dual side views mode and the wide rear view & dual side views mode.

B Front tire contact line (blue)

C Rear tire contact line (blue)

Items **B** and **C** indicate estimated tire positions on the image.

D Vehicle width extension guide line (blue)

Indicates the estimated vehicle width including the outside rear view mirrors.

E Projected course lines (yellow)

Indicate the estimated course of the vehicle according to steering operations.

F Distance guide line

Shows the distance behind the vehicle when the steering wheel is turned.

- The guide lines move in conjunction with the estimated course lines.

- The guide lines display points approximately 1.5 ft. (0.5 m) (red) and approximately 3 ft. (1 m) (yellow) from the center of the edge of the bumper.

G Rear Camera Detection

Displayed automatically when a pedestrian is detected.

H Rear Cross Traffic Alert/Rear Camera Detection

The indicator is displayed on the screen in the following situations.

- When the rear radar detects an approaching vehicle or obstacle from the rear
- When the rear camera detects a pedestrian to the rear

I Intuitive parking assist/slip display

Indicates tire spinning by changing color and flashing the tire displayed. If the intuitive parking assist detects a static object when the system is enabled, the indicator is displayed on the screen. (→P.382)

J Under vehicle terrain view (rear side) selection button

Switch the under vehicle terrain view (rear side) & dual side views (→P.393)

K PKSB (Parking Support Brake)

When the system determines that the possibility of a collision with detected target objects is high, a warning message is displayed. (→P.362)

L Setting button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

M Guide line switching button

Each time the guide line switching button is selected, the mode will change between the estimated course line mode and the vehicle center estimated course line mode.

N Vehicle center estimated course line

Shows a vehicle center estimated course when the steering wheel is turned.

O Tilt meter

Displays the vehicle's estimated degree of incline. (→P.381)

n Rear view & dual side views/wide rear view & dual side views

- l The monitor is canceled when the shift position is shifted into any position other than the R position.
- l For details about the intuitive parking assist (→P.344), Rear Cross Traffic Alert function (→P.351) and Parking Support Brake function (→P.360).
- l The display position of the intuitive parking assist and the position of obstacles displayed in the camera image do not match.

n Guide lines

If the back door is not closed, guide lines will not be displayed. If the guide lines do not display even when the back door is closed, have the vehicle inspected at your Toyota dealer.

! WARNING

n Intuitive parking assist display

When a sensor indicator on the intuitive parking assist display illuminates in red or a buzzer sounds continuously, be sure to check the area around the vehicle immediately and do not proceed any further until safety has been ensured, otherwise an unexpected accident may occur.

n Rear view & dual side views/wide rear view & dual side views display


As the intuitive parking assist display and Rear Cross Traffic Alert display are displayed over the camera view, it may be difficult to see the intuitive parking assist display and Rear Cross Traffic Alert display depending on the color and brightness of the surrounding area.

Parking

When parking in a space which is in the reverse direction to the space described in the procedure below, the steering directions will be reversed.

- 1 Shift the shift position to the R position.
- 2 Turn the steering wheel so that the estimated course

lines are within the parking space, and back up slowly.




A Parking space

B Estimated course lines

- 3 When the rear position of the vehicle has entered the park-

ing space, turn the steering wheel so that the vehicle width guide lines are within the left and right dividing lines of the parking space.



A Estimated course lines

- 4** Once the estimated course lines and the parking space lines are parallel, straighten the steering wheel and back up slowly until the vehicle has completely entered the parking space.
- 5** Stop the vehicle in an appropriate place, and finish parking.


Under vehicle terrain view (rear side) & dual side views

Lines indicating current vehicle and tire position are displayed in a composite view on an image taken in front of the current vehicle position and assists the driver to check conditions underneath the vehicle or determine the position of the rear tires.

To display the screen, when the shift position is in the R position, select the under vehicle terrain view (rear side) selection switch.

- It is necessary to drive a certain distance or more for the image to be displayed.
- If the under vehicle terrain view display is selected while the screen is displayed, the screen switches from normal to magnified display. (Selecting the display again returns the screen to the normal display)

Screen display



A Current vehicle position

B Image displayed in the under vehicle terrain view (rear side)
(image taken in front of the current vehicle position)

C Vehicle position at the time the image was taken (in front of the current vehicle position)

D Front tire contact line (blue)

Indicate estimated tire positions on the image.

E Vehicle width lines (blue)

Indicate the width of the vehicle including the outside rear view mirrors.

F Rear tire contact line (blue)

Indicate estimated tire positions on the image.

G Tire position indicator lines (black, white)

Indicates the estimated position of the rear tires.

H Vehicle position indicator lines (blue)

Indicates the estimated position of the vehicle.

I Intuitive parking assist/slip display

Indicates tire spinning by changing color and flashing the tire displayed. If the intuitive parking assist detects a static object when the system is enabled, the indicator is displayed on the screen. (→P.382)

J Return switch

Return to the previous screen

K Selecting the display

L Setting button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

M Tilt meter

Displays the vehicle's estimated degree of incline. (→P.381)

n Under vehicle terrain view (rear side)

- | The screen can be displayed when the shift position is in R.
- | While the under vehicle terrain view (rear side) is displayed, if the vehicle speed reaches or exceeds approximately 3 mph (5 km/h), the screen automatically returns to the previous display.
- | In the following situations, the display of the under vehicle terrain view (rear side) ends and the screen automatically returns to the most recently used camera screen. In addition, the under vehicle terrain view (rear side) selection switch cannot be operated until the next screen can be displayed.
 - When the tires are slipping or spinning
 - ABS is activated
 - When there is a malfunction in the system
 - Rear Cross Traffic Alert, Rear Camera Detection or Parking Support Brake is activated
 - When the back door is open
- | If the outside rear view mirrors are folded while the under vehicle terrain view (rear side) is being displayed, a separate screen is displayed.
- | If the vehicle is driven with the steering wheel turned to a certain steering angle or greater, a part of the screen may disappear. However, this is not a malfunction.
- | In the following situations, the system may not operate normally or may not be able to switch to the under vehicle terrain view (rear side). In addition, the under vehicle terrain view (rear side) selection switch cannot be operated until the next screen can be displayed.
 - The road is covered with snow
 - When there are shadows due to light sources such as sunlight or illumination
 - When driving on slippery roads or tires are spinning
 - Dirt or foreign matter is adhering to the camera lens
 - There is water in front of the vehicle (a river, puddle, sea water, etc.)
 - Optional equipment has been installed
 - When the camera is covered or there is an object in the image capture range
 - Tires have been replaced
 - When the back door is open
 - When the steering wheel is operated at or more than a specified steering angle
 - On roads that are not flat, such as slopes

**WARNING****n Guide lines**

The tire position indicator lines and vehicle position indicator lines may differ from actual vehicle positions depending on the number of passengers, cargo weight, road grade, road surface conditions, brightness of the surrounding environment, whether tires or suspension parts other than those specified are equipped, etc.

Always drive the vehicle while confirming the safety of your surroundings.

n Under vehicle terrain view (rear side) display

I The image displayed is one that was previously taken at a point in front of the current vehicle position. In cases such as when objects move after the image is taken, the image displayed on the screen may differ from the actual state. In addition, when driving in the dark such as at night, there are cases when obstacles cannot be confirmed from the image.

I The area covered by the camera is limited. When driving, be sure to check the vehicle's surroundings with your own eyes and the vehicle's mirrors.

Screen display and functions

When the "X-MODE" switch is in off, the various screens display information to support several different driving situations, such as when checking for obstacles when moving forward

Display mode when the shift position is in P

This is a mode that displays images combined from the cameras to enable you to check obstacles around the vehicle. Images are displayed as if seen from the driver's seat and on an angle from above the vehicle.


Screen display

- 1 Shift the shift position to P.

2 Press the camera switch.

- The mode changes every time the display mode switching button is touched.
- Pressing the camera switch again returns the display to the previous screen, such as the navigation screen.

► Moving view



A Screen off button

Turns off the camera screen and returns the previous screen, such as the audio screen.

B Display mode switching button

Switches between see-through view and moving view.

C Rotation pause/resume button

Pauses and resumes the rotation of the display.


D Customize settings button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

E Voice recognition icon

This icon is displayed when the Intelligent Assistant is in operation.

► See-through view



A Screen off button

Turns off the camera screen and returns the previous screen, such as the audio screen.

B Display mode switching button

Switches between see-through view and moving view.

C Rotation pause/resume button

Pauses and resumes the rotation of the display.

D Customize settings button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

E Voice recognition icon

This icon is displayed when the Intelligent Assistant is in operation.

-
- | When the intuitive parking assist (→P.344) is turned on, you can display see-through view or moving view.
 - | You can also pause and resume the rotation of the see-through view and moving view screen by touching any point on the screen.


Display mode when the shift position is in D or N

You can check for nearby pedestrians, bicycles, and vehicles at intersections with poor visibility and T-junctions by displaying vision of your surroundings on the screen. This mode also provides support to check both sides of the vehicle for safety, avoid collisions on narrow roads, and pulling over to the side of the road.

Screen display

- 1 Shift the shift position to D or N.
 - 2 Press the camera switch.
- The mode changes every time you press the camera switch.
 - If the cornering view mode is on and you turn the steering wheel more than 180 degrees from the straight position, the display will change from side clearance view & panoramic view to cornering view & panoramic view.

► Wide front view & panoramic view

**A** Front distance guide lines

Displays about 3 ft. (1 m) in front of the vehicle.

B Forward estimated course lines

Displays course lines that are linked to operation of the steering wheel.
(Yellow)

These lines are displayed when the steering wheel is turned more than 90 degrees from the straight position.

C Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is detected by a sensor.

D FCTA (Front Cross Traffic Alert) (if equipped)

If FCTA detects nearby vehicles and/or obstacles from the front or side of the vehicle, an indicator is displayed on the screen.

E Screen off button

Turns off the camera screen and returns the previous screen, such as the navigation.

F Display mode switching button

Switches display mode every time you touch the button.

G Guide line switching button

Switches guide line mode every time you touch the button. (→P.403)

H Automatic display button

Turns the auto display mode on or off. When the shift position is in D or N, wide front view & panoramic view or side clearance view/cornering view & panoramic view will be automatically displayed in accordance with the vehicle speed. (→P.404)

I Customize settings button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

J Camera dirt detection icon

This icon is displayed when dirt is detected on the camera.

K PKSB (Parking Support Brake)

If an obstacle that you may collide with is detected, a message is displayed on the screen. (→P.362)


L Voice recognition icon

This icon is displayed when the Intelligent Assistant is in operation.

M Intuitive parking assist mute button

This button temporarily mutes the intuitive parking assist sound.

► Side clearance view & panoramic view

**A** Forward estimated course lines

Displays course lines that are linked to operation of the steering wheel. (Yellow)

These lines are displayed when the steering wheel is turned more than 90 degrees from the straight position.

B Vehicle width guide lines

Shows guide lines of the vehicle's width including the outside rear view mirrors.

C Front distance guide lines

Displays about 3 ft. (1 m) in front of the vehicle.

D Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is

detected by a sensor.

E Front tire guide lines

Displays the position of the front tires.

F FCTA (Front Cross Traffic Alert) (if equipped)

If FCTA detects nearby vehicles and/or obstacles from the front or side of the vehicle, an indicator is displayed on the screen.

G Screen off button

Turns off the camera screen and returns the previous screen, such as the navigation.

H Display mode switching button

Switches display mode every time you touch the button.

I Guide line switching button

Switches guide line mode every time you touch the button. (→P.403)

J Automatic display button

Turns the auto display mode on or off. When the shift position is in D or N, wide front view & panoramic view or side clearance view/cornering view & panoramic view will be automatically displayed in accordance with the vehicle speed.

K Customize settings button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

L Camera dirt detection icon

This icon is displayed when dirt is detected on the camera.

M PKSB (Parking Support Brake)

If an obstacle that you may collide with is detected, a message is displayed on the screen. (→P.362)


N Voice recognition icon

This icon is displayed when the Intelligent Assistant is in operation.

O Intuitive parking assist mute button

This button temporarily mutes the intuitive parking assist sound.

► Cornering view & panoramic view

**A** Forward estimated course lines

Displays course lines that are linked to operation of the steering wheel.
(Yellow)

These lines are displayed when the steering wheel is turned more than 90 degrees from the straight position.

B Vehicle width guide lines

Shows guide lines of the vehicle's width including the outside rear view mirrors.

C Front distance guide lines

Displays about 3 ft. (1 m) in front of the vehicle.

D Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is detected by a sensor.

E Front tire guide lines

Displays the position of the front tires.

F FCTA (Front Cross Traffic Alert) (if equipped)

If FCTA detects nearby vehicles and/or obstacles from the front or side of the vehicle, an indicator is displayed on the screen.

G Screen off button

Turns off the camera screen and returns the previous screen, such as the navigation.

H Display mode switching button

Switches display mode every time you touch the button.

I Guide line switching button

Switches guide line mode every time you touch the button. (→P.403)

J Automatic display button

Turns the auto display mode on or off. When the shift position is in D or N, wide front view & panoramic view or side clearance view/cornering view & panoramic view will be automatically displayed in accordance with the vehicle speed.

K Customize settings button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

L Camera dirt detection icon

This icon is displayed when dirt is detected on the camera.

M PKSB (Parking Support Brake)

If an obstacle that you may collide with is detected, a message is displayed on the screen. (→P.362)

N Voice recognition icon

This icon is displayed when the Intelligent Assistant is in operation.

O Intuitive parking assist mute button

This button temporarily mutes the intuitive parking assist sound.

n Side Clearance View & panoramic view screen/Cornering View & panoramic view display

- I When the intuitive parking assist (→P.344) is turned on, you can display side clearance view & panoramic view/cornering view.
- I The display position of the intuitive parking assist may not match the position of the obstacle displayed in the camera image.



WARNING

n Guide line

The position of the guide lines displayed on the screen may change due to factors such as number of passengers, load weight, and road gradient. Always make sure to visually check behind you and your surroundings while you are driving.

n Intuitive parking assist and FCTA (Front Cross Traffic Alert) (if equipped) display


The intuitive parking assist and Front Cross Traffic Alert (FCTA) displays are superimposed on the camera image, so it may be difficult to see depending on the brightness of the surroundings and colors.

Changing the guide line display mode

The guide line display mode changes every time the guide


line display mode button is touched.

► Distance guide lines mode



Displays about 3 ft. (1 m) in front of the vehicle. (blue)

► Estimated course lines mode



Displays course lines that are linked to operation of the steering wheel. (Yellow) These lines are displayed when the steering wheel is turned more than 90 degrees from the straight position.

Auto display mode

Although you can display wide front view & panoramic view and side clearance view & panoramic view/cornering view by pressing the camera switch, you can also set auto display mode to display the views automatically in accordance with the

vehicle speed.

- Touching the automatic display button  turns on auto display mode.
- Turning on auto display mode automatically displays the views in the following situations:
 - When the shift position is in D or N
 - The vehicle decelerates to less than 6 mph (10 km/h) (the shift position is in any position other than R)

Cornering view auto display

You can set the cornering view auto display mode to automatically display cornering view & panoramic view in accordance with the operation of the steering wheel.

- Turning on cornering view auto display mode automatically displays cornering view in the following situations:
 - When the shift position is in D or N
 - The vehicle decelerates to less than 7 mph (12 km/h)
 - When the steering wheel is turned by 180 degrees or more from the center (straight-line) position

n Cornering view auto display

You can change cornering view auto mode in the custom settings.

Intuitive parking assist linked display

Depending on the intuitive parking assist detection state, wide front view & panoramic view/Side clearance view/Cornering view & panoramic view will be displayed.

- The views are displayed automatically when the intuitive parking assist detects an obstacle (when the shift position is in D or N).
- The display returns to the previous screen automatically when the intuitive parking assist stops detecting an obstacle.

n Intuitive parking assist linked display

- | You can also return to the previous screen by pressing the camera switch displayed on the screen.
- | If the panoramic view monitor screen is canceled when an obstacle is detected, the panoramic view monitor screen can be displayed again by touching the intuitive parking assist mark shown on the multimedia system screen.


Using the vehicle width guide lines

n Side Clearance View & panoramic view


- Check the positional relationship between the vehicle

width guide lines and an obstacle.

- Turn the steering wheel and drive forward so that the vehicle width guide lines do not overlap the actual obstacle.



- Check the positional relationship between the vehicle width guide lines and an object such as curbs on the shoulder of a road.
- Pull the vehicle over so that the vehicle width guide lines do not overlap the obstacle as shown in the figure.
- By driving with the vehicle width guide lines parallel to the object, you can park alongside the object.




Using the forward estimated course lines

- n **Cornering View & panoramic view**
- Check the positional relationship between the forward esti-

mated course lines and an obstacle.

- Turn the steering wheel and drive forward so that the forward estimated course lines do not overlap the actual obstacle.



Display mode when the shift position is in R


To check for safety when parking the vehicle, an image is displayed from above the vehicle and from the rear camera.

Screen display

- 1 Shift the shift position to R.

The mode changes every time you touch the display mode switching button.

► Rear view & panoramic view

**A** Camera dirt detection icon

This icon is displayed when dirt is detected on the camera.

B Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is detected by a sensor.

C Display mode switching button

Switches display mode every time you touch the button.

D Guide line switching button

Switches guide line mode every time you touch the button. (→P.409)

E RCTA (Rear Cross Traffic Alert)/RCD (Rear Camera Detection)

The indicator is displayed on the screen in the following situations.

- When the rear radar detects an approaching vehicle or obstacle from the rear
- When the rear camera detects a pedestrian to the rear

F Customize settings button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

G RCD (Rear Camera Detection)

If the rear camera detects a pedestrian behind the vehicle, an indicator is displayed on the screen.

H PKSB (Parking Support Brake)

If an obstacle that you may collide with is detected, a message is displayed on the screen. (→P.362)


I Voice recognition icon

This icon is displayed when the Intelligent Assistant is in operation.

J Intuitive parking assist/RCTA (Rear Cross Traffic Alert)/RCD (Rear Camera Detection) mute button

This button temporarily mutes the intuitive parking assist, RCTA (Rear Cross Traffic Alert) and RCD (Rear Camera Detection) buzzer sound. Operating the shift automatically cancels mute.

► Wide rear view & panoramic view



A Camera dirt detection icon

This icon is displayed when dirt is detected on the camera.

B Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is detected by a sensor.

C Display mode switching button

Switches display mode every time you touch the button.

D Guide line switching button

Switches guide line mode every time you touch the button. (→P.409)

E RCTA (Rear Cross Traffic Alert)/RCD (Rear Camera Detection)

The indicator is displayed on the screen in the following situations.

- When the rear radar detects an approaching vehicle or obstacle from the rear
- When the rear camera detects a pedestrian to the rear

F Customize settings button

Changes settings, such as the automatically display cornering view, the vehicle body color, the intuitive parking assist detection distance. (→P.418)

G RCD (Rear Camera Detection)

If the rear camera detects a pedestrian behind the vehicle, an indicator is displayed on the screen.

[H] PKSB (Parking Support Brake)

If an obstacle that you may collide with is detected, a message is displayed on the screen. (→P.362)

[I] Voice recognition icon

This icon is displayed when the Intelligent Assistant is in operation.

[J] Intuitive parking assist/RCTA (Rear Cross Traffic Alert)/RCD (Rear Camera Detection) mute button

This button temporarily mutes the intuitive parking assist, RCTA (Rear Cross Traffic Alert) and RCD (Rear Camera Detection) buzzer sound. Operating the shift automatically cancels mute.

n Rear view & panoramic view/wide rear view & panoramic view display

- l Pressing the camera switch when the shift position is in R enables you to change to panoramic view & wide front view.
- l The display position of the intuitive parking assist (→P.344) may not match the position of the obstacle displayed in the camera image.



WARNING

n Guide line

The position of the guide lines displayed on the screen may change due to factors such as number of passengers, load weight, and road gradient. Always make sure to visually check behind you and your surroundings while you are driving.

n Intuitive parking assist, RCTA (Rear Cross Traffic Alert) and RCD (Rear Camera Detection) display


The intuitive parking assist, RCTA (Rear Cross Traffic Alert) and RCD (Rear Camera Detection) displays are overlapped and displayed on the camera image, so it may be difficult to see depending on the brightness of the surroundings and colors.

Changing the guide line display mode

The guide line display mode changes every time you touch the guide line switching button.

► Estimated course lines mode

This mode displays estimated course lines that move in accordance with the operation of the steering wheel.



A Front distance guide lines

Displays about 3 ft. (1 m) (blue) in front of the vehicle.

B Side estimated course lines

Displays course lines (yellow) that are linked to operation of the steering wheel.

C Reverse estimated course lines

Displays course lines (yellow) that are linked to operation of the steering wheel.

D Rear distance guide lines

Displays the distance behind the vehicle.

- The distance guide line is linked to the estimated course lines.
- Displays about 1.5 ft. (0.5 m) (red) and 3 ft. (1 m) (yellow) from the center end of the rear bumper.

E Rear distance guide line

Displays about 1.5 ft. (0.5 m) (blue) from the end of the rear bumper.

F Vehicle width guide lines

Displays course lines when the vehicle is being reversed in a straight line.


- The lines are wider than the actual width of the vehicle.
- When the vehicle is straight, the guide lines will overlap with the estimated course lines.

G Vehicle center guide line

Displays the center of the vehicle width guide lines.

► Parking assist guide lines mode

This mode displays the steering wheel return points (parking assist guide lines). This mode is recommended for those who have a sense of the vehicle and can park the vehicle without the aid of the estimated course lines.



A Front distance guide lines

Displays about 3 ft. (1 m) (blue) in front of the vehicle.

B Rear distance guide lines

Displays the distance behind the vehicle.

- Displays about 1.5 ft. (0.5 m) (red) from the center end of the rear bumper.

C Vehicle center guide line

Displays the center of the vehicle width guide lines.

D Vehicle width guide lines

Displays course lines when the vehicle is being reversed in a straight line.

- The lines are wider than the actual width of the vehicle.


E Parking assist guide lines

Displays the course lines of the smallest turn possible behind the vehicle.

- Use the position of operating the steering wheel when parking as a guide.

► Distance guide lines mode

This mode only displays the distance guide lines. It is recommended for those who do not need the guide lines.



A Front distance guide lines

Displays about 3 ft. (1 m) (blue) in front of the vehicle.

B Rear distance guide lines


Displays the distance behind the vehicle.

- Displays about 1.5 ft. (0.5 m) (red) from the center end of the rear bumper.

► Estimated course center line mode

This mode displays estimated course lines and a vehicle center guide line that move in accordance with the operation of the steering wheel.

Use this mode when approaching a signpost or pole with the center of the rear bumper.



A Front distance guide lines

Displays about 3 ft. (1 m) (blue) in front of the vehicle.

B Side estimated course lines

Displays course lines (yellow) that are linked to operation of the steering wheel.

C Rear distance guide lines

Displays the distance behind the vehicle.

- The distance guide line is linked to the estimated course lines.
- Displays about 1.5 ft. (0.5 m) (red) and 3 ft. (1 m) (yellow) from the center end of the rear bumper.

D Reverse estimated course lines

Displays course lines (yellow) that are linked to operation of the steering wheel.

E Estimated course center line

Displays the vehicle center guide line (green) that is linked to operation of the steering wheel.

n Guide line display mode

The guide lines will not be displayed if the back door is not closed. If the back door is closed but the guide lines are still not displayed, have the vehicle inspected by your Toyota dealer.


WARNING

n Guide line display mode

The rear vehicle width guide lines are wider than the actual width of the vehicle. Always make sure to visually check behind you and your surroundings when you are reversing.


Parking using the estimated course lines mode

- 1** Shift the shift position to R.
- 2** Turn the steering wheel so that the estimated course lines are within the parking space and then reverse slowly.



- A** Parking space
- B** Estimated course lines
- 3** When the rear of the vehicle has entered the parking space, turn the steering wheel so that the vehicle width guide lines are within

the left and right dividing lines of the parking space.




- A** Vehicle width guide lines
- 4** Once the vehicle width guide lines and the parking space lines are parallel, straighten the steering wheel and reverse slowly until the vehicle has completely entered the parking space.
 - 5** Stop the vehicle in an appropriate place to finish parking.

Parking using the parking assist guide lines mode

- 1** Shift the shift position to R.

- 2** Reverse until the parking assist guide lines align with the right-hand dividing line of the parking space.




- A** Parking assist guide lines
B Parking space dividing lines
3 Turn the steering wheel all the way to the left, and reverse slowly.
4 Once the vehicle is parallel with the parking space, straighten the steering wheel and reverse slowly until the vehicle has completely entered the parking space.
5 Stop the vehicle in an appropriate place to finish parking.

The screen when the outside rear view mirrors are folded

When the outside rear view mirrors are folded, an image from the side cameras rather than panoramic view will be displayed. This can assist you in confirming that the vicinity of the vehicle is safe when you are parking in a narrow place.

Screen display

- Side view & Wide front view




A Side views**B** Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is detected by a sensor.

C Wide front view


► Side view & Rear view

**A** Side views**B** Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is detected by a sensor.

C Rear view

► Side view & Wide rear view

**A** Side views**B** Intuitive parking assist

Displays an indicator on the screen and sounds a buzzer when an object is detected by a sensor.

C Wide rear view**n Intuitive parking assist display**

The display position of the intuitive parking assist (→P.344) may not match


the position of the obstacle displayed in the camera image.

Zooming in on the screen

Zooming in on the screen can be done if the image on the screen is too small and hard to see.

Touch the area that you want to zoom in on the panoramic view.

Screen display



- The selected area is zoomed in on.
- You can zoom in on either the area in front of the vehicle or the area behind it in panoramic view.
- To cancel the zoom, touch the screen again.

n Zooming in on the screen

| The zoom feature is enabled when all of the following conditions are met:

- The vehicle speed is below 7 mph (12 km/h)
- The intuitive parking assist (→P.344) is turned on

| In any of the following situations, the zoom feature will be canceled automatically:


- The vehicle speed is above 7 mph (12 km/h)
- The intuitive parking assist is turned off

| The guide lines will not be displayed when the panoramic view is zoomed.

Displaying transparent underfloor vision

A composite of camera vision captured in the past from the current vehicle position to assist understanding of the situation under the vehicle, tire positions, and so on can be displayed. The vision is displayed in panoramic view, side clearance view, or cornering view.

Screen display



A Tire tracks

Displays the tire position guides linked to the steering wheel.

B Vehicle guide lines

Displays the exterior of the vehicle.

n Transparent underfloor vision

| Transparent underfloor vision is displayed when the setting on the customized setting screen is turned on and the vehicle is moving forward or backward.

| Transparent underfloor vision is not displayed in the following cases:

- The vehicle speed is above 12 mph (20 km/h)
- The vehicle stops and a certain amount of time passes.
- If the vehicle does not move a certain distance after it is started.
- The side mirrors are folded.
- ABS is operating.
- The system is not functioning correctly.

| The system may not function correctly in the following situations:

- Snow covered roads.
- There are shadows from lights and so forth.
- There is dirt or a foreign object on the camera lens.
- Water (river, sea, etc.).
- Optional equipment has been installed.
- There is an obstacle in front of the camera.
- The tires were replaced.
- The back door is open and the camera is not in the correct position.
- The road surface is slippery or the wheels slip.
- The vehicle is on a hill or other steep roads.

| As vision that was captured in the past is being displayed, the screen and the actual situation may differ in the following cases:

- An obstacle appears or moves after vision is captured.
- Sand or snow crumbles and moves after vision is captured.
- Mud or puddles are in the display range.
- When the vehicle slips.

| Part or all of the transparent underfloor vision may appear black in the following cases:

- The vehicle starts moving with no captured vision.
- The steering wheel is turned more than a certain angle.
- The vehicle stops and a certain amount of time passes.



WARNING


n Transparent underfloor vision

- ! The tire and vehicle guide lines may not align correctly with the actual vehicle position due to the number of passengers, vehicle load, road gradient, road surface conditions, brightness of the surroundings, optional equipment, tire replacements, and other reasons. Always make sure to check your surroundings while you are driving.
- ! Displayed vision is vision that was captured in the past. Therefore, if obstacles and other objects move after being captured, the transparent underfloor vision and the actual situation may not always match.

Changing the Multi-terrain Monitor settings

Settings related to Multi-terrain Monitor such as the cornering view auto display and vehicle body color can be changed.

- 1 Touch the .



- 2 Select the desired item.

- **Cornering view**

Automatically display the cornering view.

- **View Under Vehicle**

Turn the transparent underfloor vision display setting on or off. Setting it to on and moving the vehicle forward or backwards displays a

composite of camera vision captured in the past from the current vehicle position to assist understanding of the situation under the vehicle, front tire positions, and so on. The vision is displayed in panoramic view, side clearance view, or cornering view.

- **Intuitive Park Assist 3D Display**

Show or hide the intuitive parking assist 3D display.

- **Intuitive Park Assist Distance**

Change the distance that the intuitive parking assist starts detecting obstacles.

- **Vehicle Body Color**

Change the vehicle body color displayed on the screen.

n **Suspension of the settings display**

For safety purposes, you cannot display the custom settings screen while the vehicle is moving.

When using the Multi-terrain Monitor

Observe the following precautions. Failure to do so may result in an unexpected accident. Also, when driving, make sure to directly confirm the safety of your surroundings and the area to the rear of the vehicle.



WARNING

n Conditions under which the Multi-terrain Monitor should not be used

Do not use the Multi-terrain Monitor in the following situations. The system may not operate properly, resulting in an unexpected accident.

- | On icy or slick road surfaces, or in snow
- | When using tire chains or emergency tires
- | When the front door(s) or back door are not closed completely
- | On roads that are not flat, such as hills
- | If the tires of a size other than specified by Toyota are installed
- | If the suspension has been modified
- | If a non-Toyota product is installed on the area displayed on the screen

n Guide lines

The tire position indicator lines and vehicle position indicator lines may differ from actual vehicle positions depending on the number of passengers, cargo weight, road grade, road surface conditions, brightness of the surrounding environment, etc. Always drive the vehicle while confirming the safety of your surroundings.



NOTICE

n Panoramic view

- | See-through view, moving view, panoramic view, side clearance view, and cornering view produce an image that is a composite of images captured by the front camera, rear camera, and side cameras. As there is a limit to the displayable range and content, make sure you fully understand the features of the panoramic view monitor before you use it.
- | The four corners of the see-through view, moving view, panoramic view, side clearance view, and cornering view have a video composition processing region centered on borders of the cameras, and image clarity may decline. However this is not a fault.
- | Depending on lighting conditions near each camera, bright and dark patches may appear on the see-through view, moving view, panoramic view, side clearance view, and cornering view.




NOTICE

- I See-through view, moving view, panoramic view, side clearance view, and cornering view does not extend higher than the installation position and image capture range of each camera.
 - I There are blind spots around the vehicle and as such there are regions not displayed on the panoramic view monitor.
 - I Three-dimensional objects displayed in wide front view, rear view, wide rear view or side view may not be displayed in see-through view, moving view, panoramic view, side clearance view, and cornering view.
 - I People and other three-dimensional obstacles may appear differently when displayed on the panoramic view monitor. (These differences include cases in which displayed objects appear to have fallen over, disappear near image processing regions, appear from video composition processing areas, or when the actual distance to an object differs from the displayed position.)
 - I When the back door, which is equipped with the rear camera, or front doors, which are equipped with side mirrors that have the built-in side cameras, are open, images will not be displayed properly on the panoramic view monitor.
- I The vehicle icon displayed in see-through view, moving view, panoramic view, side clearance view, and cornering view is a computer generated image, so the color, shape and size will differ from the actual vehicle. Therefore, nearby three-dimensional objects may appear to be touching the vehicle, and actual distances to three-dimensional objects may differ from those displayed.

Area displayed on the screen


There are blind spots around the vehicle and as such there are regions not displayed on the screen. Even if nothing around the vehicle is displayed on the screen, there may actually be obstacles on the road, which you may collide with. Always make sure to visually check your surroundings.



A Area displayed on the screen

B Objects not displayed on the screen

Objects in the black areas do not appear on the screen.




A Area displayed on the screen

B Parts of objects not displayed on the screen


Parts higher than the road do not appear on the screen.

n Area displayed on screen

- | The black parts around the vehicle icon are not displayed by the camera. Visually check those areas.
- | As the images are obtained from four cameras and displayed on the standard of a flat road surface, see-through view, moving view, panoramic view (including zoomed display), side clearance view, and cornering view may be displayed as follows:
 - Objects may look collapsed; thinner or bigger than usual.
 - An object with a higher position than the road surface may look further away than it actually is or may not appear at all.
 - Tall objects may appear protruding from the non-displayed areas of the image.
- | Variations in the brightness of the image may appear for every camera due to lighting conditions.
- | The displayed image may be misaligned due to inclination of the vehicle body or change in vehicle height caused by the number of passengers, vehicle load.
- | If the doors are not completely closed, the image and the guide lines may not be displayed correctly.
- | The positional relationship of the road surface and objects with the vehicle icon displayed on see-through view, moving view, panoramic view (including zoomed display), side clearance view, and cornering view may differ to the actual positions.
- | Light from a back-lit license plate may appear on the screen.
- | Images indicated by  in the figure are a composite, and hence some areas may be difficult to see.



n Wide front view



A Area displayed on the screen

B Objects not displayed on the screen

Areas close to both corners of the bumpers will not appear on the screen.


n Display range

- | The area covered by the camera is limited. Objects that are close to either corner of the bumper or under the bumper cannot be displayed on the screen.
- | The depth perception of the image displayed on the screen differs to

the actual distance.

- | The wide front view camera uses a special lens, so the depth perception of the image displayed on the screen differs to the actual distance.

- ▶ Side view & Rear view (when the side mirrors are folded)




- A** Area displayed on the screen

n Display range

- | The range that is displayed on the screen may differ due to the state of the vehicle and road surface.
- | The area covered by the camera is limited. Objects that are close to the bumper on the passenger's side or under the bumper cannot be displayed on the screen.
- | The depth perception of the image displayed on the screen differs to the actual distance.
- | The cameras on side view & rear view use a special lens, so the depth perception of the image displayed on the screen differs to the actual distance.


▶ Rear view



- A** Area displayed on the screen
- B** Objects not displayed on the screen

Areas close to both corners of the bumpers will not appear on the screen.

► Wide rear view



A Area displayed on the screen

B Objects not displayed on the screen

Areas close to both corners of the bumpers will not appear on the screen.

n Display range

- | The range that is displayed on the screen may differ due to the state of the vehicle and road surface.
- | The area covered by the camera is limited. Objects that are close to either corner of the bumper or under the bumper cannot be displayed on the screen.
- | The depth perception of the image displayed on the screen differs to the actual distance.
- | The rear view and wide rear view cameras use a special lens, so the depth perception of the image displayed on the screen differs to the actual distance.
- | Objects that are higher than the


rear camera may not appear in the monitor.

- | Light from a back-lit license plate may appear on the screen.


Camera position

The Multi-terrain Monitor cameras are in the locations shown in the figures.


n Front camera



n Side cameras



n Rear camera



Cleaning the camera

If dirt or foreign matter, such as water droplets, snow, or mud, has stuck to the camera, you will not be able to see the image clearly. If that happens, splash the camera with a large amount of water and then wipe the camera lens clean with a soft, damp cloth.



NOTICE

n How to use the cameras


- I The Multi-terrain Monitor may stop functioning correctly. Take note of the following items:
 - Do not hit or apply a forceful impact on the camera. Doing so may change the position and mounting angle of the camera.
 - The camera is designed to be waterproof. Do not detach, disassemble, or modify it.
 - When washing the camera lens, splash the camera with a large amount of water and then wipe the camera lens clean with a soft, damp cloth. Rubbing the camera lens forcibly may scratch the camera lens and you may no longer be able to see images clearly.
 - The camera cover is made of resin. Do not allow an organic solvent, car wax, window cleaner, or glass coating to adhere to the camera. If this happens, wipe it off immediately.
 - Do not pour hot water on the vehicle in cold weather or apply other rapid changes of temperature.

- If you wash the vehicle with a high pressure car washer, do not point the hose directly at the camera or camera area. Applying strong water pressure may result in the camera malfunctioning.

I If the camera is hit, it may cause a camera malfunction. If this happens, have the vehicle inspected by your Toyota dealer as soon as possible.

Parking assist lights

The parking assist lights of the Multi-terrain Monitor system are installed in the locations shown in the figure.



NOTICE

n Parking assist lights

- I Make sure to observe the following precautions, otherwise the Multi-terrain Monitor system may not operate correctly:
 - Do not apply excessive force to a light or subject it to a strong impact. Doing so may cause the position or installation angle of the light to deviate.
 - Do not remove, disassemble, or modify the lights as they have a waterproof construction.

**NOTICE**

- When cleaning the lights, wash them with a large amount of water, and then wipe them with a soft wet cloth.
 - Do not apply organic solvents, waxes, oil removing solvents, glass coatings, etc. to the covers of the lights, as they are made of resin. If such is applied, remove it immediately.
 - Do not expose the lights to sudden temperature changes, such as applying hot water to them when it is cold.
 - When washing the vehicle with a high-pressure washer, do not spray water directly on the lights or their surrounding area. High-pressure water can damage the lights and cause them to not operate correctly.
- I** If a light has been subjected to a strong impact, it may be damaged. Have the vehicle inspected by your Toyota dealer as soon as possible.


Difference between the screen and the actual road

The composite images on the Multi-terrain Monitor and guide lines give a distance guide for flat road surfaces. Therefore, there is a margin of error between the guide lines on the screen and the actual distance and course on the road.

When the ground behind the vehicle slopes up sharply


The distance guide lines will

appear to be closer to the vehicle than the actual distance. Thus, objects on up-slopes will appear to be farther away than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance and course on the road.



When the ground behind the vehicle slopes down sharply


The distance guide lines will appear to be further from the vehicle than the actual distance. Thus, objects on down-slopes will appear to be closer than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance and course on the road.



When any part of the vehicle sags

When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the guide lines on the screen and the actual distance


and course on the road.



A Margin of error

Estimated course center line

As the guide lines are shown midair near the rear bumper, there are times that they may look like they are off-center.



Differences between the screen and actual 3D objects

Since the guide lines displayed on the screen are for a flat road surface, it is not possible to determine the position of three-dimensional objects. When approaching a three-dimensional object that extends outward (such as the flatbed of a truck), take note of the following cautions.


⚠ WARNING

n Intuitive parking assist pop-up display

When the intuitive parking assist display is red, make sure to visually check before moving the vehicle any further. There is the danger that you may collide with another vehicle or have some other unforeseen accident.


Displaying panoramic view (including zoom display)

On the screen, it appears that there is a gap between the vehicle's bumper and another object or vehicle, and it does not look as if the vehicle will collide with the object or vehicle. However, the vehicle is over the course lines, so the vehicle may collide with the object or vehicle. Make sure to visually check your surroundings.



Estimated course lines


- On the screen, it appears that the vehicle's bumper is outside of the estimated course lines, and it does not look as if the vehicle will collide with the object or vehicle. However, the vehicle is over the course lines, so the vehicle may collide with the object or vehicle. Make sure to visually check your surroundings.



A Estimated course lines


- Three-dimensional objects in high positions (such as the

overhang of a wall or loading platform of a truck) may not appear on the screen. Make sure to visually check your surroundings.



A Overhang of a wall


- On the screen, a truck flatbed may appear to be outside of the estimated course lines and the vehicle does not look as if it will collide with the truck. However, the flatbed may actually cross over the estimated course lines and if you reverse as guided by the estimated course lines, the vehicle may hit the truck. Make sure to visually check your surroundings.



A Estimated course lines


Distance guide lines

On the screen, the distance guide lines shows that a truck is parking at point **B**. However, in reality if you reverse to point **A**, you will collide with the truck. On the screen, it appears that point **A** is closest followed by points **B** and **C**. However, in reality, the distance to points **A** and **C** is the same, and point **B** is farther than **A** and **C**. Make sure to visually check behind you and your surroundings. The distance to point **D** is about 1 m (3 ft.).




Overhang of a diagonal beam

In panoramic view, a diagonal beam may appear straight and seems likely not to be struck, however, since the top part of the beam is actually overhanging, the vehicle may hit it. Make sure to visually check the rear and surroundings.



Magnifying function

Unlike the normal panoramic view, the panoramic view magnifying function zooms in on the vehicle icon. Therefore, white lines on the road, walls, and other objects may look bent.



Under vehicle terrain view

The tire position indicator lines and vehicle position indicator lines may differ from actual vehicle positions depending on the number of passengers, weight of the load, road grade, road surface conditions, brightness of the surrounding environment, etc. Always drive the vehicle while directly confirming the safety of your surroundings.

n Using under vehicle terrain view

- | The images displayed were previously taken behind the current vehicle position.
Therefore, actual conditions may differ from those shown on the screen in the following situations.
 - When conditions changed such as when an object moved or entered the frame after the image was taken.
 - Loose material like sand or snow has crumbled or shifted
 - An obstacle has moved
 - There is a puddle, tract of mud, etc., within the display range
 - The vehicle slips
- | In the following situations, actual tire positions and vehicle position may differ from those indicated by the tire position indicator lines and vehicle position indicator lines.
 - Tires have been replaced
 - Optional equipment has been installed

WARNING

n Guide lines

The displayed guide lines are composed with the image that was previously taken and may differ from the actual state. Always drive the vehicle while confirming the safety of your surroundings.

Things you should know

If you notice any symptoms

If you notice or are troubled by any of the symptoms below, check the issue again referring to the likely cause and solution.

If the symptom is not resolved by the solution, have the vehicle inspected by your Toyota dealer.

Symptom	Likely cause	Solution
The screen is difficult to see	<ul style="list-style-type: none">• The vehicle is in a dark area or it is night.• The temperature around the lens is either high or low• The outside temperature is low• There are water droplets on the camera• It is raining or humid• Foreign matter (mud, etc.) is stuck to the camera• Sunlight or headlights are shining directly into the camera• The vehicle is under fluorescent lights, sodium lights, mercury lights, etc.	<p>Visually check the vehicle's surroundings while you are driving.</p> <p>Use the Multi-terrain Monitor again once the camera and conditions have improved.</p> <p>The procedure for adjusting the picture quality of the Multi-terrain Monitor system is the same as the procedure for adjusting the screen display. Refer to the "MULTIMEDIA OWNER'S MANUAL".</p>
The image is blurry	Dirt or foreign matter, such as water droplets, snow, or mud, has stuck to the camera lens.	Splash the camera with a large amount of water and then wipe the camera lens clean with a soft, damp cloth.
The screen is misaligned	The camera has received a strong impact.	Have the vehicle inspected by your Toyota dealer.
The guide lines are significantly misaligned	The camera position is misaligned.	Have the vehicle inspected by your Toyota dealer.
	<ul style="list-style-type: none">• The vehicle is tilted. (There is a heavy load on the vehicle, tire pressure is low due to a tire puncture, etc.)• The vehicle is on an incline.	Visually check the vehicle's surroundings while you are driving.

Symptom	Likely cause	Solution
The estimated course lines move even though the steering wheel is straight (the vehicle width guide lines and estimated course lines are out of alignment).	There is a malfunction in the signals being output by the steering sensor.	Have the vehicle inspected by your Toyota dealer.
The guide lines are not displayed	The back door is open.	Close the back door. If this does not resolve the symptom, have the vehicle inspected by your Toyota dealer.
The panoramic view display cannot be enlarged. The see-through view/moving view, side clearance view, and cornering view cannot be displayed.	The intuitive parking assist may be malfunctioning or dirty.	Follow the correction procedures for malfunctions of the intuitive parking assist. (→P.344)
Rear camera image is difficult to see.	Foreign matters (such as water droplets, mud, snow and snow melting agents.) is on the camera lens.	Rinse the camera with a large quantity of water, wipe it clean with a soft cloth dampened with water.
	Foreign matters (such as Ice, snow and mud) is attached to surrounding parts of the camera lens.	Remove foreign matters.

X-MODE

This mode has improved road handling ability off roads.

Select between the 2 types of mode, SNOW/DIRT and D.SNOW/MUD.

During “X-MODE”, the downhill assist control will control the brakes to maintain a constant vehicle speed when driving on steep descents.

Grip Control supports the driver’s operation by maintaining a low vehicle speed on steep inclines and slippery roads without having to step on the accelerator pedal or brake pedal.

⚠ WARNING

n Be sure to observe the following before using “X-MODE”

If not observed, there is the danger that it may lead to an unexpected accident.

| Drive the vehicle after checking that the SNOW/DIRT indicator/D.SNOW/MUD indicator turns on.


| “X-MODE” is not a device that enhances the limited performance of the vehicle. Carefully check the road surface conditions and the driving route in advance, and then drive with caution.

n Conditions in which it may not function correctly

When driving on the following road surfaces, it may not be possible to maintain a constant speed of the vehicle, which may lead to an unexpected accident.

- |** Extremely steep inclines
- |** Rough road surfaces
- |** Slippery road surfaces such as snowy roads and frozen road surfaces

System Components



A “X-MODE” switch

B Grip Control switch (→P.436)


C Indicators

Selecting the Drive Mode

Press the “X-MODE” switch repeatedly until the system switches to the desired driving mode while the vehicle is stopped or traveling at a speeds less than approximately 13 mph

(20 km/h).

When the drive mode is switched, the buzzer sounds.



1 Normal mode

Has a good balance of electrical consumption performance, quietness, and driving performance, and is suitable for driving in urban areas.

2 SNOW/DIRT mode

When the tires are likely to slip or slip on slippery roads such as snowy roads, gravel roads, etc., the tire spinning is reduced, making it easier to drive.

At this time, the SNOW/DIRT mode indicator lights up in green on the meter.

3 D.SNOW/MUD mode

In special cases such as the tires being buried in deep snow or mud, the TRAC (Traction Control) function is temporarily canceled, and the tires are idled as needed to make it easier to start.

At this time, the D.SNOW/MUD mode indicator lights up in green on the meter. In addition, the VSC OFF

indicator and PCS warning light will be turned on in the meter.

n When “X-MODE” is not available

In the following cases, the system does not operate.

- | When the EV system is not started
- | When SNOW/DIRT mode or D.SNOW/MUD mode is not selected
- | When the EV system is malfunctioning

n About Dynamic Radar Cruise Control or Cruise Control

Dynamic radar cruise control and cruise control cannot be used during “X-MODE”. If dynamic radar cruise control or cruise control are being used, it will be automatically canceled.

n During “X-MODE”

- | In “X-MODE”, VSC does not switch ON/OFF even if the VSC OFF switch is operated. It is fixed as ON in SNOW/DIRT mode and OFF in D.SNOW/MUD mode.
- | During “X-MODE”, operating the Eco mode switch will not change the mode.
- | The SNOW/DIRT and D.SNOW/MUD modes control the vehicle so that it can maximize the drive force and improve the drive force on rough roads. As a result, electricity consumption may diminish when compared to driving in normal mode.

n “X-MODE” Automatic Release

- | “X-MODE” is automatically canceled when the power switch is turned off.
- | When the vehicle speed exceeds about 25 mph (40 km/h), the “X-MODE” is canceled, the “X-MODE” indicator on the meter lights up in white, and switches to the normal mode.

l When the vehicle speed is approximately 22 mph (35 km/h) or less, X-MODE indicator lights up in green and switches to "X-MODE" again.

n Cautions regarding the use of the system

For safety, the following operations are not accepted when "X-MODE" is ON.

l Eco mode switch operations

When selecting "X-MODE", Downhill Assist Control

When the "X-MODE" switch is pressed and SNOW/DIRT mode or D.SNOW/MUD mode is selected, the Downhill Assist Control automatically enters the standby state and operates under the following conditions.

- When the vehicle speed is approximately 18 mph (30 km/h) or less
- Neither the accelerator pedal or brake pedal are not operated

n When changing the target vehicle speed

When changing the target vehicle speed, adjust it with the accelerator pedal or the brake pedal. When the foot is removed from the pedal, the system will operate at the vehicle speed at that time.

n Downhill Assist Control during "X-MODE"

l In SNOW/DIRT mode or D.SNOW/MUD mode, the downhill assist control can be set to standby state. The operation indicator changes depending on the operating status of the downhill assist control.

l When the system is not operating, the indicator turns on white.

n When Downhill Assist Control is not available when selecting "X-MODE"

In the following cases, the system does not operate.

- l When SNOW/DIRT mode or D.SNOW/MUD mode is not selected
- l When the shift position is in P
- l When the Grip Control is operating
- l When the brake system or EV system is malfunctioning

When using Grip Control


With SNOW/DIRT mode or D.SNOW/MUD mode selected, press down on the Grip Control switch.

At this time, the downhill assist control system indicator turns off and the Grip Control indicator turns on.

When the vehicle is stopped, press the brake pedal firmly and operate the switch. The vehicle may start moving unintentionally on an incline.

n Set the speed of the Grip Control

Press the Grip Control switch up or down to set the desired speed (approximately 2 to 6 mph [2 to 10 km/h]). The set speed is shown on the multi-information display.



- A** Increase Speed
- B** Decrease Speed
- C** Indicator Lights

n Grip Control Operations

During system operations, the Grip Control indicator turns on green. If the Grip Control indicator is white, release the brake pedal to activate the system.

While the system is operating, the accelerator pedal and brake pedal can be used to temporarily accelerate or decelerate. If operating the accelerator pedal or brake pedal is stopped, the speed will return to the set speed.

n When Grip Control is released

● Press the “X-MODE” Switch

When the Grip Control is released, the Grip Control operation light turns off, and after a while, the downhill assist control system indicator light turns on.

Drive carefully when releasing Grip Control while driving.

n Grip Control Operations Conditions

- | When in “X-MODE”
- | When the shift position is in D
- | When the parking brake has been released
- | When the driver side door is closed
- | When the vehicle is stopped by stepping on the brake or the vehicle speed is approximately 2 to 6 mph [2 to 10 km/h]

n Automatic Releasing the Grip Control

In case of any of the following, the Grip Control is released.

- | When the vehicle is stopped by stepping on the brake pedal
- | When the vehicle speed exceeds more than 13 mph (20 km/h)
- | When the shift position in a position other than D
- | When the parking brake is operated
- | When the driver side door is opened
- | ABS/VSC is activated.
- | When brake control and output suppression by the driving support device are activated (example: Pre-Collision System, Parking Support Brake)
- | When the system determines it

cannot continue in the current environment

- | When the power switch is turned off

n When Grip Control is not available

In the following conditions, Grip Control is not available.

- | When the brake system or EV system is malfunctioning
- | After the EV system is started and until the vehicle has been running for a while

n Brake hold system

The brake hold system turns OFF when the Grip Control is being used. Press the brake pedal firmly and operate the switch.

When using the brake hold system again, turn ON the brake hold system after releasing the Grip Control.



NOTICE

n Long term usage

If used continuously for a long periods of time, the temperature of the brakes may rise the system may temporarily stop.

n Operation noises and vibrations

- | Operating noise may be heard from motor room, however this is not a malfunction.
- | When the brake pedal is depressed, it may become harder than usual or it may feel different from normal, but this is not a malfunction.

n When the operation indicator does not turn on in the meter even after operating the switch

The system may not be working properly. Have the vehicle inspected at your Toyota dealer.

Driving assist systems

To keep driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

Summary of the driving assist systems

n ECB (Electronically Controlled Brake System)

The electronically controlled system generates braking force corresponding to the brake operation

n ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

n Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

n **VSC (Vehicle Stability Control)**

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces.

n **Enhanced VSC (Enhanced Vehicle Stability Control)**

Provides cooperative control of the ABS, TRAC, VSC and EPS. Helps to maintain directional stability when swerving on slippery road surfaces by controlling steering performance.

n **Trailer Sway Control**

Helps the driver to control trailer sway by selectively applying brake pressure for individual wheels and reducing driving torque when trailer sway is detected.

n **TRAC (Traction Control)**

Helps to maintain drive power and prevent the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

n **Active Cornering Assist (ACA)**

Helps to prevent the vehicle from drifting to the outer side by performing inner wheel brake control when attempting to accelerate while turning

n **Hill-start assist control**

Helps to reduce the backward movement of the vehicle when

starting on an uphill

n **EPS (Electric Power Steering)**


Employs an electric motor to reduce the amount of effort needed to turn the steering wheel

n **The Secondary Collision Brake (Secondary collision reduction at the time of a frontal collision)**

When the SRS airbag sensor detects a collision and the system operates, the brakes and brake lights are automatically controlled to reduce the vehicle speed and help reduce the possibility of further damage due to a secondary collision.

n **When the TRAC/VSC/ABS/Trailer Sway Control systems are operating**

The slip indicator light will flash while the TRAC/VSC/ABS/Trailer Sway Control systems are operating.



n **Disabling the TRAC system**


If the vehicle gets stuck in mud, dirt or snow, the TRAC system may reduce power from the EV system to the wheels. Pressing  to turn the system off may make it easier for you to rock the vehicle in order to

free it.

To turn the TRAC system off, quickly press and release .

The “Traction Control Turned OFF” will be shown on the multi-information display.

Press  again to turn the system back on.



n **Turning off both TRAC, VSC and Trailer Sway Control systems**

To turn the TRAC, VSC and Trailer Sway Control systems off, press

and hold  for more than 3 seconds while the vehicle is stopped.

The VSC OFF indicator light will come on and the “Traction Control Turned OFF” will be shown on the multi-information display.*

Press  again to turn the system back on.

*: PCS (Pre-Collision System) will also be disabled (only pre-collision warning is available). The PCS warning light will come on and a message will be displayed on the multi-information display.
(→P.274)

- n **When the message is displayed on the multi-information display showing that TRAC has been disabled even if  has not been pressed**

TRAC is temporary deactivated. If the information continues to show, contact your Toyota dealer.

n **Operating conditions of hill-start assist control**

When all of the following conditions are met, the hill-start assist control will operate:

- l The shift position is in a position other than P or N (when starting off forward/backward on an upward incline)
- l The vehicle is stopped
- l The accelerator pedal is not depressed
- l The parking brake is not engaged
- l Power switch is turned to ON

n **Automatic system cancelation of hill-start assist control**

The hill-start assist control will turn off in any of the following situations:

- l Shift the shift position to P or N
- l The accelerator pedal is depressed
- l The brake pedal is depressed and the parking brake is engaged
- l A maximum of 2 seconds have elapsed after the brake pedal is released
- l Power switch is turned to off

n **Sounds and vibrations caused by the ABS, brake assist, VSC, Trailer Sway Control, TRAC and hill-start assist control systems**

- l A sound may be heard from the motor compartment when the brake pedal is depressed repeatedly, when the EV system is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has

occurred in any of these systems.

- | Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
- Vibrations may be felt through the vehicle body and steering.
- A motor sound may be heard also after the vehicle comes to a stop.

n **ECB operating sound**

ECB operating sound may be heard in the following cases, but it does not indicate that a malfunction has occurred.

- | Operating sound heard from the motor compartment when the brake pedal is operated.
- | Motor sound of the brake system heard from the front part of the vehicle when the driver's door is opened.
- | Operating sound heard from the motor compartment when one or two minutes passed after the stop of the EV system.

n **Active Cornering Assist operation sounds and vibrations**

When the Active Cornering Assist is operated, operation sounds and vibrations may be generated from the brake system, but this is not a malfunction.

n **Reduced effectiveness of the EPS system**

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the EV system off. The EPS system should return to normal within 10 minutes.

n **Automatic reactivation of TRAC, Trailer Sway Control and VSC systems**

After turning the TRAC, Trailer Sway Control and VSC systems off, the systems will be automatically re-enabled in the following situations:

- | When the power switch is turned off
- | If only the TRAC system is turned off, the TRAC will turn on when vehicle speed increases
- | If both the TRAC and VSC systems are turned off, automatic re-enabling will not occur when vehicle speed increases.

n **Operating conditions of Active Cornering Assist**

The system operates when the following occurs.

- | TRAC/VSC can operate
- | The driver is attempting to accelerate while turning
- | The system detects that the vehicle is drifting to the outer side
- | The brake pedal is released

n **Secondary Collision Brake (Secondary collision reduction at the time of a frontal collision) operating conditions**

The system operates when the SRS airbag sensor detects a collision while the vehicle is in motion. However, the system does not operate when the components are damaged.

n **Secondary Collision Brake (Secondary collision reduction at the time of a frontal collision) automatic cancellation**

The system is automatically canceled in any of the following situations.

- | The vehicle speed drops to approximately 0 mph (0 km/h).
- | A certain amount of time elapses during operation

- I The accelerator pedal is depressed a large amount

**WARNING****n The ABS does not operate effectively when**

- I The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
- I The vehicle hydroplanes while driving at high speed on wet or slick roads.

n Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations:

- I When driving on dirt, gravel or snow-covered roads
- I When driving with tire chains
- I When driving over bumps in the road
- I When driving over roads with potholes or uneven surfaces

n TRAC/VSC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRAC/VSC system is operating. Drive the vehicle carefully in conditions where stability and power may be lost.

n Active Cornering Assist does not operate effectively when

- I Do not overly rely on Active Cornering Assist. Active Cornering Assist may not operate effectively when accelerating down slopes or driving on slippery road surfaces.
- I When Active Cornering Assist frequently operates, Active Cornering Assist may temporarily stop operating to ensure proper operation of the brakes, TRAC and VSC.

n Hill-start assist control does not operate effectively when

- I Do not overly rely on hill-start assist control. Hill-start assist control may not operate effectively on steep inclines and roads covered with ice.
- I Unlike the parking brake, hill-start assist control is not intended to hold the vehicle stationary for an extended period of time. Do not attempt to use hill-start assist control to hold the vehicle on an incline, as doing so may lead to an accident.

n When the TRAC/ABS/VSC/Trailer Sway Control is activated

The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes.

**WARNING****n When the TRAC/VSC/Trailer Sway Control systems are turned off**

- i** Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help ensure vehicle stability and driving force, do not turn the TRAC/VSC/Trailer Sway Control systems off unless necessary.
- i** Trailer Sway Control is part of the VSC system and will not operate if VSC is turned off or experiences a malfunction.

n Replacing tires

Make sure that all tires are of the specified size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS, TRAC, Trailer Sway Control and VSC systems will not function correctly if different tires are installed on the vehicle. Contact your Toyota dealer for further information when replacing tires or wheels.

n Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause a system to malfunction.

n Trailer Sway Control precaution

The Trailer Sway Control system is not able to reduce trailer sway in all situations. Depending on many factors such as the conditions of the vehicle, trailer, road surface and driving environment, the Trailer Sway Control system may not be effective. Refer to your trailer owner's manual for information on how to tow your trailer properly.

n If trailer sway occurs

Observe the following precautions.

Failing to do so may cause death or serious injury.

- i** Firmly grip the steering wheel. Steer straight ahead. Do not try to control trailer sway by turning the steering wheel.
- i** Begin releasing the accelerator pedal immediately but very gradually to reduce speed. Do not increase speed. Do not apply vehicle brakes.

If you make no extreme correction with the steering or brakes, your vehicle and trailer should stabilize. (→P.223)

n Secondary Collision Brake (Secondary collision reduction at the time of a frontal collision)

Do not rely solely upon the Secondary Collision Brake (Secondary collision reduction at the time of a frontal collision). This system is designed to help reduce the possibility of further damage due to a secondary collision, however, that effect changes according to various conditions. Overly relying on the system may result in death or serious injury.

Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

Preparation for winter

- Use fluids that are appropriate to the prevailing outside temperatures.
- Power control unit coolant
- Heater coolant
- Washer fluid
- Have a service technician inspect the condition of the 12-volt battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires*.

Ensure that all tires are the specified size and brand, and that chains match the size of the tires.

*: Tire chains cannot be mounted on vehicles with 235/65R18 tires.



WARNING

n Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in a loss of vehicle control and cause death or serious injury.

- I Use tires of the specified size.

- I Maintain the recommended level of air pressure.

- I Do not drive in excess of 75 mph (120 km/h), regardless of the type of snow tires being used.

- I Use snow tires on all, not just some wheels.

n Driving with tire chains (except 235/65R18 tires)

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- I Do not drive in excess of the speed limit specified for the tire chains being used, or 30 mph (50 km/h), whichever is lower.

- I Avoid driving on bumpy road surfaces or over potholes.

- I Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden regenerative braking.

- I Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.

- I Do not use LTA (Lane Tracing Assist) system.



NOTICE

n Repairing or replacing snow tires

Request repairs or replacement of snow tires from Toyota dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen. Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, outside rear view mirrors, windows, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.

When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

When parking the vehicle

- Turn automatic mode of the

parking brake off. Otherwise, the parking brake may freeze and not be able to be released automatically.

Also, avoid using the following as the parking brake may operate automatically, even if automatic mode is off.

- Brake hold system
- Park the vehicle and shift the shift position to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If the vehicle is parked without setting the parking brake, make sure to block the wheels.

Failure to do so may be dangerous because it may cause the vehicle to move unexpectedly, possibly leading to an accident.

- If the vehicle is parked without setting the parking brake, confirm that the shift position cannot be moved out of P.
- If the vehicle is left parked with the brakes damp in cold temperatures, there is a possibility of the brakes freezing.



WARNING

n When parking the vehicle


When parking the vehicle without applying the parking brake, make sure to chock the wheels. If you do not chock the wheels, the vehicle may move unexpectedly, possibly resulting in an accident.

- Turn automatic mode of the

Selecting tire chains

- Vehicles with 235/60R18 tires

Use the correct tire chain size when mounting the tire chains. Chain size is regulated for each tire size.



- A** Side chain (0.12 in. [3 mm] in diameter)
- B** Side chain (0.39 in. [10 mm] in width)
- C** Side chain (1.18 in. [30 mm] in length)
- D** Cross chain (0.16 in. [4 mm] in diameter)
- E** Cross chain (0.55 in. [14 mm] in width)
- F** Cross chain (0.98 in. [25 mm] in length)

- Vehicles with 235/65R18 tires

Tire chains cannot be mounted.

Snow tires should be used instead.

Regulations on the use of tire chains (except 235/65R18 tires)

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

n Tire chain installation

Observe the following precautions when installing and removing chains:

- | Install and remove tire chains in a safe location.
- | Install tire chains on the front tires only. Do not install tire chains on the rear tires.
- | Install tire chains on the front tires as tightly as possible. Retighten chains after driving 1/4—1/2 mile (0.5—1.0 km).
- | Install tire chains following the instructions provided with the tire chains.



NOTICE

n Fitting tire chains (except 235/65R18 tires)

The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

Utility vehicle precautions

This vehicle belongs to the utility vehicle class, which has higher ground clearance and narrower tread in relation to the height of its center of gravity to make it capable of performing in a wide variety of off-road applications.

Utility vehicle feature

- Specific design characteristics give it a higher center of gravity than ordinary passenger cars. This vehicle design feature causes this type of vehicle to be more likely to rollover. And, Utility vehicles have a significantly higher rollover rate than other types of vehicles.
- An advantage of the higher ground clearance is a better view of the road allowing you to anticipate problems.
- It is not designed for cornering at the same speeds as ordinary passenger cars any more than low-slung sports cars are designed to perform satisfactorily under off-road conditions. Therefore, sharp turns at excessive speeds may cause the vehicle to rollover.

WARNING

n Utility vehicle precautions

Always observe the following precautions to minimize the risk of death, serious injury or damage to your vehicle:

- | In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt. Therefore, the driver and all passengers should always fasten their seat belts.
- | Avoid sharp turns or abrupt maneuvers, if at all possible. Failure to operate this vehicle correctly may result in loss of control or vehicle rollover causing death or serious injury.
- | Loading cargo on the roof luggage carrier will make the center of the vehicle gravity higher. Avoid high speeds, sudden starts, sharp turns, sudden braking or abrupt maneuvers, otherwise it may result in loss of control or vehicle rollover due to failure to operate this vehicle correctly.
- | Always slow down in gusty crosswinds. Because of its profile and higher center of gravity, your vehicle is more sensitive to side winds than an ordinary passenger car. Slowing down will allow you to have better control.
- | Do not drive horizontally across steep slopes. Driving straight up or straight down is preferred. Your vehicle (or any similar off-road vehicle) can tip over sideways much more easily than forward or backward.

Off-road driving

When driving your vehicle off-road, please observe the following precautions to ensure your driving enjoyment and to help prevent the closure of areas to off-road vehicles:

- Drive your vehicle only in areas where off-road vehicles are permitted to travel.
- Respect private property. Get owner's permission before entering private property.
- Do not enter areas that are closed. Honor gates, barriers and signs that restrict travel.
- Stay on established roads. When conditions are wet, driving techniques should be changed or travel delayed to prevent damage to roads.

n Additional information for off-road driving

- For owners in U.S. mainland, Hawaii and Puerto Rico:

To obtain additional information pertaining to driving your vehicle off-road, consult the following organizations:

- | State and Local Parks and Recreation Departments
- | State Motor Vehicle Bureau
- | Recreational Vehicle Clubs
- | U.S. Forest Service and Bureau of Land Management



WARNING

n Off-road driving precautions

Always observe the following precautions to minimize the risk of death, serious injury or damage to your vehicle:

- | Drive carefully when off the road. Do not take unnecessary risks by driving in dangerous places.
- | Do not grip the steering wheel spokes when driving off-road. A bad bump could jerk the wheel and injure your hands. Keep both hands and especially your thumbs on the outside of the rim.
- | Always check your brakes for effectiveness immediately after driving in sand, mud, water or snow.
- | After driving through tall grass, mud, rock, sand, rivers, etc., check that there is no grass, bush, paper, rags, stone, sand, etc. adhering or trapped on the underbody. Clear off any such matter from the underbody. If the vehicle is used with these materials trapped or adhering to the underbody, a breakdown or fire could occur.
- | When driving off-road or in rugged terrain, do not drive at excessive speeds, jump, make sharp turns, strike objects, etc. This may cause loss of control or vehicle rollover causing death or serious injury. You are also risking expensive damage to your vehicle's suspension and chassis.

**NOTICE****n To prevent the water damage**

Take all necessary safety measures to ensure that water damage to the traction battery, EV system or other components does not occur.

- I** Water entering the motor compartment may cause severe damage to the EV system.
- I** Water entering the transmission will cause deterioration in transmission quality. The malfunction indicator may come on, and the vehicle may not be drivable.
- I** Water can wash the grease from wheel bearings, causing rusting and premature failure, and may also enter the transaxle case, reducing the gear oil's lubricating qualities.

n When you drive through water

If driving through water, such as when crossing shallow streams, first check the depth of the water and the bottom of the riverbed for firmness. Drive slowly and avoid deep water.

n Inspection after off-road driving

- I** Sand and mud that has accumulated around brake discs may affect braking efficiency and may damage brake system components.
- I** Always perform a maintenance inspection after each day of off-road driving that has taken you through rough terrain, sand, mud, or water. For scheduled maintenance information, refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".

Interior features

6

6-1. Using the air conditioning system and defogger

ALL AUTO (ECO) control
..... **452**

Automatic air conditioning
system..... **454**

Heated steering wheel/seat
heaters/seat ventila-
tors/radiant heaters ... **463**

6-2. Using the interior lights

Interior lights list **466**

6-3. Using the storage features

List of storage features
..... **469**

Luggage compartment fea-
tures **472**

6-4. Using the other interior features

Electronic sunshade.... **477**

Other interior features . **478**

Power outlets (120 VAC
1500 W)..... **490**

When the power outlet (AC
120V/1500 W) cannot be
used properly **497**

Garage door opener.... **499**

ALL AUTO (ECO) control

The seat heaters/radiant heaters (if equipped), seat ventilators (if equipped) and heated steering wheel are each automatically controlled according to the set temperature of the air conditioning system, the outside and cabin temperature, etc. ALL AUTO (ECO) controls the electricity consumption in order to both extend the cruising range and maintain comfortable conditions.

Turning on ALL AUTO (ECO) control

Select the “AUTO” switch.

The indicator on the AUTO switch illuminates, and the automatic air conditioning system, seat heaters/radiant heaters (if equipped), seat ventilators (if equipped) and heated steering wheel operate in automatic mode.

If the fan speed control switch or airflow mode control switch is operated, the indicator turns off. However, all other functions continue to operate in automatic mode.

Even if ALL AUTO (ECO) control is turned off, the air conditioner, seat heaters and heated steering wheel will not be turned off.

Also, during ALL AUTO (ECO) control operation, pressing the ECO

switch turns off the eco air conditioning control.

If the front window glass becomes cloudy due to a drop in the outside air temperature while the ALL AUTO (ECO) control is operating, you can remove the cloudiness by selecting the “A/C” switch or windshield defogger switch on the multi-media display.

Operation of each system

n Automatic air conditioning system (→P.454)

The temperature can be adjusted independently for each seat.

n Seat heaters/radiant heaters (if equipped) and seat ventilators (if equipped) (→P.463)

Heating or ventilation is automatically selected according to the set temperature of the air conditioning system, the outside temperature, etc.

n Heated steering wheel (→P.463)

Heated steering wheel operates automatically according to the set temperature of the air conditioning system, the outside temperature, etc.

n Passenger detection functions

When a passenger is detected in the front passenger seat, the seat heater/radiant heater (if equipped) and seat ventilator (if equipped) will operate automatically.

n Seat heaters/radiant heaters (if equipped) and seat ventilators (if equipped) operation

If the passenger side seat heaters/radiant heaters (if equipped) or seat ventilator (if equipped) is operating under ALL AUTO (ECO) control when the power switch is turned off, the seat heater/radiant heaters (if equipped) or seat ventilator (if equipped) will automatically turn on the next time the power switch is turned on. To detect the occupant again, select the "AUTO" switch.

n Rear seat heaters operation


The rear seat heaters are not controlled by the ALL AUTO (ECO) control.

Automatic air conditioning system

When the “AUTO” switch is on, the air outlets and fan speed will automatically be changed according to the set temperature.

The button positions and shapes will differ for right-hand drive vehicles. Also, the display and button positions will differ depending on the type of the system.

Air conditioning controls



A Left-hand side temperature control switch

B Airflow mode control switch

C Option screen switch

D Shortcut screen switch

Select to display shortcut icons for various functions.

E “SYNC” switch

F Right-hand side temperature control switch

G “A/C” switch

H Outside/recirculated air mode switch

I Fan speed control switch

J “OFF” switch

K “AUTO” switch

n Adjusting the temperature

Turn temperature control dial clockwise to increase the temperature and turn the dial

counterclockwise to decrease the temperature.

When the indicator on the “SYNC” switch is illuminated,

the temperature setting for the front passenger's side will match the setting for the driver's side.

When the indicator on the "SYNC" switch is off, turning the "SYNC" switch on will illuminate the "SYNC" switch indicator and the temperature setting for the front passenger's side will become the same as that for the driver's side.

When the front passenger's side temperature control switch is operated, the indicator on the "SYNC" switch will turn off and the temperature setting for the front passenger's side will be able to be adjusted.

If the "A/C" indicator is turned off, the system will blow ambient temperature air or heated air.

n **Setting the fan speed**

To increase the fan speed, select the "+" fan speed adjustment switch or slide the icon of the fan speed adjustment switch right. To decrease the fan speed, select the "-" fan speed adjustment switch or slide the icon of the fan speed adjustment switch left.

Select the "OFF" switch to turn the fan off.

The fan can also be stopped by touching and holding the "-" fan speed adjustment switch or sliding the icon of the fan speed adjustment switch to the leftmost position

and holding it.

n **Changing the air flow mode**

Select the airflow mode control switch.

The airflow mode changes each time the switch is selected.

The air outlets and air volume changes according to the selected air flow mode.



: Air flows to the upper body



: Air flows to the upper body and feet



: Air flows to the feet



: Air flows to the feet and the windshield defogger operates

n **Switching between outside air and recirculated air modes**

Temporarily changing the air mode to recirculated air mode is recommended to prevent dirty air from entering the vehicle, such as when in a tunnel or heavy traffic, and to help cool the interior when the outside air temperature is high.

Select the outside/recirculated air mode switch.

The mode switches between outside air mode (the indicator is off) and recirculated air mode (the indicator is on) each time the switch is selected.

The air mode may change automatically depending on the temperature setting, temperature inside the vehicle, etc.

n Set cooling and dehumidification function

Select the “A/C” switch.

When the function is on, the indicator illuminates on the “A/C” switch.

n Eco air conditioning mode

The air conditioning is controlled with low electricity consumption efficiency prioritized such as reducing fan speed, etc.

1 Select the option screen switch. (→P.454)

2 Select the “Eco heat/cool” switch.

- In Eco drive mode, the air conditioning system is controlled as follows to prioritize electricity consumption efficiency. To improve air conditioning performance, turn off Eco air conditioning mode.
- Electric motor speed and compressor operation controlled to restrict heating/cooling capacity.
- Fan speed restricted when automatic mode is selected.
- When the driving mode is set to Eco driving mode, the Eco

air conditioning mode will be turned on automatically. Even in this case, the Eco air conditioning mode can be turned off by selecting the “Eco heat/cool”.

n Warming the interior quickly (Max heat)

When “MAX heat” is turned on, in order to warm the interior quickly, the settings of the air conditioning system will be changed immediately.

1 Select the shortcut screen switch. (→P.454)

2 Select the “MAX heat” switch.

- The driver’s side temperature setting of the air conditioning system will be set to “Hi” and the “AUTO” switch will be turned on.
- Driver’s side seat heater/radiant heater (if equipped) will be set to Hi.
- Heated steering wheel will be set to Hi.
- When the system determines that a passenger is in the front passenger seat, the front passenger’s side seat heater/radiant heater (if equipped), seat ventilator (if equipped) will be set to “AUTO”.
- When the indicator on the “Sync” switch is illuminated, the temperature setting for the

front passenger's side will also be set to "Hi".

n **Cooling the interior quickly (Max cool) (if equipped)**


When "MAX cool" is turned on, in order to cool the interior quickly, the settings of the air conditioning system will be changed immediately.

- 1 Select the shortcut screen switch. (→P.454)
- 2 Select the "Max cool" switch.
 - The temperature setting of the air conditioning system will be set to "Lo" and the "AUTO" switch will be turned on.
 - Seat ventilators will be set to Hi.
 - When the system determines that a passenger is in the front passenger seat, the front passenger's side seat heater/seat ventilator will be set to "AUTO".
 - When the indicator on the "Sync" switch is illuminated, the temperature setting for the front passenger's side and the rear seats side will also be set to "Lo".

n **Defogging the windshield**

Defoggers are used to defog the windshield and front side windows.

Press the windshield defogger switch.



The dehumidification function will operate and the air flow will increase.

Set the outside/recirculated air mode button to outside air mode if the recirculated air mode is used. (It may switch automatically.)

To defog the windshield and the side windows early, turn the air flow and temperature up.


To return to the previous mode, press the windshield defogger switch again when the windshield is defogged.

When the windshield defogger switch is on, the indicator illuminates on the windshield defogger switch.

n **Defogging the rear window and outside rear view mirrors**

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press the rear window and outside rear view mirror defoggers switch.



The rear window defogger and outside rear view mirror defoggers will operate and defog the rear window and outside rear view mirrors.

When the rear window and outside rear view mirror defoggers switch is on, the indicator illuminates on the rear window and outside rear view mirror defoggers switch.

The defoggers will automatically turn off after a period of time.

n **Windshield wiper de-icer**

Use the windshield wiper de-icer to help prevent the windshield wiper blades from freezing to the windshield.

1 Select the option screen switch. (→P.454)

2 Select the “Deicer” switch.

The windshield wiper de-icer will automatically turn off after a period of time.

n **Fogging up of the windows**

l The windows will easily fog up when the humidity in the vehicle is high. Turning “A/C” switch on will dehumidify the air from the outlets and defog the windshield effectively.

l If you turn “A/C” off, the windows may fog up more easily.

l The windows may fog up if the

recirculated air mode is used.

n **When driving on dusty roads**

Close all windows. If dust thrown up by the vehicle is still drawn into the vehicle after closing the windows, it is recommended that the air intake mode be set to outside air mode and the fan speed to any setting except off.

n **Outside/recirculated air mode**

l Setting to the recirculated air mode temporarily is recommended in preventing dirty air from entering the vehicle interior and helping to cool the vehicle when the outside air temperature is high.

l Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.

n **When the outside temperature exceeds 75°F (24°C) and the air conditioning system is on**

l In order to reduce the air conditioning power consumption, the air conditioning system may switch to recirculated air mode automatically. This may also reduce electricity consumption.

l Recirculated air mode is selected as a default mode when the power switch is turned to ON.

l It is possible to switch to outside air mode at any time by pressing the outside/recirculated air mode switch.

n **When the outside temperature is low**

The dehumidification function may not operate even when “A/C” is selected.

n **“MAX heat”**

l The “MAX heat” switch cannot be used to turn the setting off.

l After the “MAX heat” switch has been operated, the temperature setting can be adjusted using the

temperature control switches of the air conditioning system.

- | Each function can also be adjusted to the desired setting.

n **“MAX cool” (if equipped)**

- | The “MAX cool” switch cannot be used to turn the setting off.
- | After the “MAX cool” switch has been operated, the temperature setting can be adjusted using the temperature control switches of the air conditioning system.
- | Each function can also be adjusted to the desired setting.

n **Ventilation and air conditioning odors**

- | To let fresh air in, set the air conditioning system to the outside air mode.
- | During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- | To reduce potential odors from occurring:
 - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
 - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.
- | When parking, the system automatically switches to outside air mode to encourage better air circulation throughout the vehicle, helping to reduce odors that occur when starting the vehicle.


n **Air conditioning filter**

→P.551

n **Air conditioning system refrigerant**

- | A label regarding the refrigerant of the air conditioning system is

attached to the hood at the location shown in the following illustration.



- | The meaning of each symbol on the label are as follows:

	Caution
	Air conditioning system
	Air conditioning system lubricant type
	Requires registered technician to service air conditioning system
	Flammable refrigerant

n **Noise from air conditioning system**

Approximately 90 seconds after the power switch turned to off, you may hear sound coming from air conditioning system. This is the sound of a air conditioning system initialize and, it does not indicate a malfunction.


n **Customization**

Some functions can be customized. (Customizable features: →P.627)

WARNING

n To prevent the windshield defogger from operating improperly

- I** Do not use the windshield defogger in extremely humid areas when the air conditioning system is set to a low temperature. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- I** Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



n To prevent burns

- I** Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.
- I** Vehicles with windshield wiper deicer: Do not touch the glass at lower part of the windshield or to the side of the front pillars when the windshield wiper de-icer is on.

NOTICE

n To prevent 12-volt battery discharge

Do not leave the air conditioning system on longer than necessary when the EV system is off.

n When repairing/replacing parts of the air conditioning system

Have repair/replacement performed by your Toyota dealer. When a part of the air conditioning system, such as the evaporator, is to be replaced, it must be replaced with a new one.

Using automatic mode

- 1** Select the "AUTO" switch. (→P.454)
- 2** Adjust the temperature setting.
- 3** To stop the operation, select the "OFF" switch.

If the fan speed setting or airflow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated is maintained.

n Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and the ambient conditions.

Therefore, the fan may stop for a while until warm or cool air is ready to flow immediately after the automatic mode switch is selected.

Cool air may blow around the upper body even when the heater is on due to sunlight.

Front seat concentrated airflow mode (S-FLOW)

This function automatically controls the air conditioning airflow so that priority is given to the

front seats. Unnecessary air conditioning is suppressed, contributing to increased electricity consumption efficiency.

Front seat concentrated airflow mode operates in the following situations.

- No passengers are detected in the rear seats
- The windshield defogger is not operating

The “S-Flow” switch is  (ON) on the option screen.

In front seat concentrated airflow mode, directing airflow to the front seats only and to all seats can be switched via switch operation. When the mode has been switched manually, automatic airflow control stops operating.

- 1 Select the option screen switch. (→P.454)
 - 2 Select the “S-Flow” switch.
- Indicator illuminated: Airflow to the front seats only
 - Indicator off: Airflow to all the seats

n Operation of automatic airflow control

- 1 In order to maintain a comfortable interior, airflow may be directed to seats without passengers immediately after the EV system is started and at other times depending on the outside temperature.
- 1 After the EV system is started, if passengers move around inside

or enter/exit the vehicle, the system cannot accurately detect the presence of passengers and automatic airflow control will not operate.

n Operation of manual airflow control

Even if the function is manually switched to directing airflow to only the front seats, when a rear seat is occupied, it may automatically direct airflow to all seats.


n To return to automatic airflow control

- 1 With the indicator off, turn the power switch off.
- 2 After 60 minutes or more elapse, turn the power switch to ON.

Air outlet layout and operations

n Location of air outlets

The air outlets and air volume change according to the selected air flow mode.




n Adjusting the position of and opening and closing the air outlets

To adjust the position of and opening and closing the air outlets, perform the following operations:


► Front

close the vent



Direct air flow to the left or right, up or down


Move the knob fully to the inside to close the vent.



Direct air flow to the left or right, up or down

Move the knob fully to the outside to close the vent.

► Rear



1 Direct air flow to the left or right, up or down

2 Turn the knob to open or

Heated steering wheel/seat heaters/seat ventilators*/radiant heaters*

*: If equipped

● Heated steering wheel

Warms up the grip of the steering wheel

● Seat heaters

Warm up the seat upholstery

● Seat ventilators

Maintain good airflow on the seat upholstery by sucking air into the seats

● Radiant heaters

Warm up the feet of the front seats

WARNING

n To prevent minor burn injuries

Care should be taken if anyone in the following categories comes in contact with the steering wheel or seats when the heater is on:

- | Babies, small children, the elderly, the sick and the physically challenged
- | Persons with sensitive skin
- | Persons who are fatigued
- | Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)

NOTICE

n To prevent damage to the seat heaters/radiant heaters and seat ventilators

Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.

n To prevent 12-volt battery discharge

Do not use the functions when the EV system is off.

Heated steering wheel

Select  on the multimedia display.

Each time the switch is selected, the operation condition changes as follows.

AUTO (lit)→Hi (2 segments lit)→Lo(1 segment lit)→Off

The level indicator (red) lights up during operation. "AUTO" indicator lights up during automatic operation.

n The heated steering wheel can be used when

The power switch is in ON.

Seat heaters

n Front

Vehicles without radiant heaters:

Select  or  on the multimedia display.

Vehicles with radiant heaters:

Select  or  on the multimedia display.

dia display.

Each time the switch is selected, the operation condition changes as follows.

AUTO→Hi (3 segments lit)→Mid (2 segments lit)→Lo (1 segment lit)→Off

The level indicator (red) lights up during operation. "AUTO" indicator lights up during automatic operation.


n **Rear (outboard rear seats) (if equipped)**

Each time the switch is pressed, the operation condition changes as follows.

Hi (3 segments lit)→Mid (2 segments lit)→Lo (1 segment lit)→Off

When not in use, put the switch in the neutral position. The indicator

A will turn off.



n **The seat heaters can be used when**

The power switch is in ON.



WARNING

n **To prevent overheating and minor burn injuries**

Observe the following precautions when using the seat heaters.

Do not cover the seat with a blanket or cushion when using the seat heater.

Do not use seat heater more than necessary.

Seat ventilators (front seats)

Select  or  on the multi-media display.

Each time the switch is pressed, the operation condition changes as follows.

AUTO→Hi (3 segments lit)→Mid (2 segments lit)→Lo (1 segment lit)→Off

The level indicator (blue) lights up during operation. "AUTO" indicator lights up during automatic operation.


n **The seat ventilators can be used when**

The power switch is in ON.

n **Air conditioning system-linked control mode**

When a seat ventilator is set to Hi, the fan speed of the seat ventilator may increase according to the fan speed of the air conditioning system.

Radiant heaters (if equipped)



A Front passenger's side radiant heater

B Driver's side radiant heater

Select  or  on the multimedia display.

Each time the switch is selected, the operation condition changes as follows.

AUTO→Hi (3 segments lit)→Mid (2 segments lit)→Lo (1 segment lit)→Off

The level indicator (red) lights up during operation. "AUTO" indicator lights up during automatic operation.

WARNING

n To prevent causes of overheating and minor burn injuries

Observe the following precautions when using a radiant heater:

- I** Do not use radiant heaters more than necessary.

- I** Do not let blankets, cushions, luggage, etc., to touch the radiant heaters.

n Use while driving

Do not touch the radiant heater or hold your hand or foot over it by releasing a hand from the handle or a foot from the pedal.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.


NOTICE

n To prevent damage to the radiant heaters

Do not pierce with uneven objects or sharp objects such as wires or needles.

Interior lights list

Location of the interior lights



- A** Outer foot lights (if equipped)
- B** Inside door handle lights
- C** Rear interior light (→P.467)
- D** Footwell lights
- E** Front interior lights/personal lights (→P.467)
- F** Shift lights
- G** Instrument panel ornament lights (→P.468)
- H** Center console light
- I** Console box light
- J** Door trim ornament lights

n **Personal lights/interior lights automatic on/off**

I Illuminated entry system: The lights automatically turn on/off according to power switch mode, the presence of the electronic key,

whether the doors are locked/unlocked, and whether the doors are opened/closed.

I If the interior lights remain on when the power switch is turned off, the lights will go off automatically after 10 minutes.

n Automatic illumination of the interior lights

If any of the SRS airbags deploy (inflate) or in the event of a strong rear impact, the interior lights will turn on automatically. The interior lights will turn off automatically after approximately 20 minutes.

The interior lights can be turned off manually. However, in order to help prevent further collisions, it is recommended that they be left on until safety can be ensured. (The interior lights may not turn on automatically depending on the force of the impact and conditions of the collision.)

n Customization

Setting (e.g. the time elapsed before the lights turn off) can be changed. (Customizable features: →P.638)




NOTICE

n To prevent 12-volt battery discharge

Do not leave the lights on longer than necessary when the EV system is off.

Operating interior lights

n Front interior lights




- 1 Turns the door-linked function off
- 2 Turns the door-linked function on (door position)

The lights turn on/off according to the opening/closing of the doors.

- 3 Turns the lights on/off

Press the switch to turn on/off the front interior lights/personal lights and rear interior lights.

n Rear interior light




- 1 Turns the light on
- 2 Turns the door-linked function on (door position)

The light turns on/off according to the opening/closing of the doors. The rear interior light turn on/off together the front interior light.

Operating personal lights

Turns the lights on/off



Changing the illumination color


Using the multimedia display, the color and brightness of the interior lights in the vehicle can be changed.

- Inside door handle lights
- Instrument panel ornament lights

- 1 Select .
- 2 Select "Vehicle customize".
- 3 Select "Illumination".
- 4 Select the desired color.

List of storage features

Location of the storage features



- A** Bottle holders (→P.470)
- B** Ticket holders (→P.471)
- C** Cup holders (→P.470)
- D** Console box (→P.469)
- E** Open tray (→P.471)

! WARNING

n Items that should not be left in the vehicle

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:


- I** Glasses may be deformed by heat or cracked if they come into contact with other stored items.

- I** Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Console box

Press a button to open the console box.

The console box can be opened from either side.



⚠ WARNING

n Caution while driving

Keep the console box closed. Injuries may result in the event of an accident or sudden braking.


⚠ NOTICE

n To prevent damage to the console box

Do not apply excessive force to the armrest.


Cup holders

► Front



► Rear

Pull down the armrest.



⚠ WARNING


n Items unsuitable for the cup holder

Do not place anything other than cups or aluminum cans in the cup holders.


Other items may be thrown out of the holders in the event of an accident or sudden braking, possibly causing injury. If possible, cover hot drinks to prevent burns.

Bottle holders

► Front



► Rear



n Bottle holders

- | When storing a bottle, close the cap.
- | The bottle may not be stored depending on its size or shape.




NOTICE

n Items that should be not stowed in the bottle holders


Do not place open bottles or glass and paper cups containing liquid in the bottle holders. The contents may spill and glasses may break.

Ticket holders

Flip down the visor.



Open tray



WARNING

n Caution while driving

Observe the following precautions when putting items in the open tray. Failure to do so may cause items to be thrown out of the tray in the event of sudden braking or steering. In these cases, the items may interfere with pedal operation or cause driver distraction, resulting in an accident.


- | Do not store items in the tray that can easily shift or roll out.
- | Do not stack items in the tray higher than the edge of tray.
- | Do not put items in the tray that may protrude over the edge of tray.

Luggage compartment features

Cargo hooks

Pull down the hook to use.

The cargo hooks are provided for securing loose items.




WARNING

n When cargo hooks are not in use

To avoid injury, always return the hooks to their stowed positions when not in use.

Grocery bag hooks



NOTICE


n To prevent damage to the grocery bag hooks

Do not hang any object heavier than 8.8 lb. (4 kg) on the grocery bag hooks.

Deck board

n Changing the deck board positions (vehicles with an emergency tire puncture repair kit)


Height of the deck floor can be changed by setting the deck board under the floor.




A Upper

B Lower

- 1 Pull up the tab to raise the deck board and move it toward you to remove.



- 2 Place the deck board through the groove and move forward.




n Setting the deck board upright


When taking out the tools, the deck board can be set upright.

When the back surface (resin surface) of the deck board is facing up, flip it back to the original position.

- 1 Pull up the tab to raise the deck board and fold it forward.



- 2 Deck board in a standing state, put the edge into the holes.



! WARNING

n When operating the deck board


Do not place anything on the deck board when operating the board. Otherwise, your fingers may be caught or an accident may result causing injuries.

n Caution while driving

Keep the deck board closed. In the event of sudden braking, an accident may occur due to an occupant being struck by the deck board or the items stored under the deck board.

Deck under tray

Pull up the tab to raise the deck board and fold it forward.



n Warning reflector

Depending on the size and shape of the warning reflector case, you may not be able to store it.

! WARNING

n Caution while driving

Keep the deck board closed. In the event of sudden braking, an accident may occur due to an occupant being struck by the deck board or the items stored under the deck board.


Luggage cover

n Removing the luggage cover unit

- 1 Pull up the tab to raise the deck board and fold it forward. (→P.473)
- 2 Pull the strap to lift up the right deck board and remove it.


► Vehicle with woofer

Pull the strap to lift up the right deck board and remove it.




► Vehicle without woofer

Pull the strap to lift up both deck boards and remove them.




3 Take out the luggage cover unit.

► Vehicle with woofer




► Vehicle without woofer




n **Installing the luggage cover**

- 1 Compress the both ends of the luggage cover and insert into the recess to install.




- 2 Pull out the luggage cover and hook it on to the anchors.




n **Removing the luggage cover**

- 1 Release the cover from the left and right anchors and allow it to retract.



- 2 Compress the end of the luggage cover and lift the luggage cover up.




n **Stowing the luggage cover unit**

- 1 Pull up the tab to raise the deck board and fold it forward. (→P.473)
- 2 Pull the strap to lift up the right deck board and remove it.


► Vehicle with woofer

Pull the strap to lift up the right deck board and remove it.




► Vehicle without woofer

Pull the strap to lift up both deck boards and remove them.



- 3** To store the luggage cover unit, compress both ends until they lock.


► Vehicle with woofer



- 1** Insert the left end of the luggage cover unit into the groove on the left side of the deck.
- 2** Insert the right end of the luggage cover unit into the

groove on the right side of the deck side.

► Vehicle with woofer



- 1** Insert the left end of the luggage cover unit into the groove on the left side of the deck.
- 2** Insert the right end of the luggage cover unit into the groove on the right side of the deck side.

! WARNING

n Luggage cover


- I** When installing/stowing the luggage cover, make sure that the luggage cover is securely installed/stowed. Failure to do so may result in serious injury in the event of sudden braking or a collision.
- I** Do not place anything on the luggage cover. In the event of sudden braking or turning, the item may go flying and strike an occupant. This could lead to an unexpected accident, resulting in death or serious injury.
- I** Do not allow children to climb on the luggage cover. Climbing on the luggage cover could result in damage to the luggage cover, possibly causing death or serious injury to the child.

Electronic sunshade*

*: If equipped

Use the overhead switches to operate the electronic sunshade.

Operating the electronic sunshade



1 Open*

2 Close*

*: To stop the electronic sunshade partway, lightly press the either end of the switch.

n The electronic sunshade can be operated when

The power switch is in ON.

n Jam protection function for the electronic sunshade

- l If an object becomes jammed between the electronic sunshade and the sunshade frame while the electronic sunshade is closing, the electronic sunshade movement is stopped and the electronic sunshade is opened slightly.
- l When the jam protection function has operated, even if the "CLOSE" side of the switch is pressed again, the electronic sunshade will not move in the close direction until the reverse opera-

tion has stopped completely.

- l The electronic sunshade may operate in reverse if the electronic sunshade is subject to an impact due to the surroundings or the driving conditions.

n When the electronic sunshade does not close normally

Perform the following initialization procedure.

- 1** Turn the power switch to ON.
- 2** Press and hold the "CLOSE" side of the switch.

It closes until it is near the fully closed position and then stops. After that, it operates in the opening direction then closes to the fully closed position.

If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.

If the automatic opening and closing function does not work normally even after performing the operations above, have the vehicle inspected by your Toyota dealer.

WARNING


Observe the following precautions.

Failure to do so may result in death or serious injury.

⚠ WARNING

n Opening and closing the electronic sunshade

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the electronic sunshade is being operated.



- Do not let a child operate the electronic sunshade. Closing the electronic sunshade on someone can cause death or serious injury.

n Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.


- The jam protection function may not work if something gets caught just before the electronic sunshade is fully closed. Also, the jam protection function is not designed to operate while the switch is being pressed. Take care so that your fingers, etc., do not get caught.

n To prevent burns or injuries

Do not touch the area between the underside of the panoramic moon roof and the electronic sunshade. Your hand may get caught and you could injure yourself. Also, if the vehicle is left in direct sunlight for a long time, the underside of the panoramic moon roof could become very hot and could cause burns.

Other interior features

Sun visors




- 1 To set the visor in the forward position, flip it down.
- 2 To set the visor in the side position, flip down, unhook, and swing it to the side.
- 3 To use the side extender (if equipped), place the visor in the side position, then slide it backward.

Vanity mirrors

Slide the cover to open.

The light turns on when the cover is opened.



n Vanity lights

If the vanity lights remain on when the power switch is turned off, the

lights will go off automatically after 20 minutes.



NOTICE

n To prevent 12-volt battery discharge


Do not leave the vanity lights on for extended periods while the EV system is off.

Power outlets

Please use as a power supply for electronic goods that use less than 12 VDC/10 A (power consumption of 120 W).

When connecting multiple devices, make sure that the total power consumption of all the connected devices is less than 120 W.

Open the lid.



n The power outlet can be used when

The power switch is in ACC or ON, or the multimedia system is on.

n When stopping the EV system

Disconnect electrical devices with charging functions, such as mobile battery packs.

If such devices are left connected, the EV system may not stop normally.



NOTICE

n When power outlet is not in use

To avoid damaging the power outlet, close the power outlet lid when the power outlet is not in use.

Foreign objects or liquids that enter the power outlet may cause a short circuit.

n To prevent 12-volt battery discharge

Do not use the power outlet longer than necessary when the EV system is off.

n To prevent incorrect operation of the vehicle

When turning the power switch off, make sure to disconnect accessories designed for charging, such as portable chargers, power banks, etc. from the power outlets.

If such an accessory is left connected, the following may occur:

- ! The doors will not be able to be locked.
- ! The opening screen will be displayed on the multi-information display.
- ! The interior lights, instrument panel lights, etc. will illuminate.

USB Type-C charging ports

The USB Type-C charging ports are used to supply electricity to external devices. Use the appropriate terminal for each charging port type.

The USB Type-C charging ports are for charging only. They are

not designed for data transfer or other purposes.


Depending on the external device, it may not charge properly.

Refer to the manual included with the device before using a USB Type-C charging port.

n Using the USB Type-C charging ports

► Center console

The USB Type-C charging ports are used to supply 3 A of electricity at 5 V to external devices.




► Vehicles without rear seat heaters

These USB Type-C charging ports are capable of high power output.

An output up to 60 W max on a single port or 60 W combined (shared) is possible.


The USB Type-C charging ports operate at multiple voltage and multiple wattage levels.



► Vehicles with rear seat heaters

These USB Type-C charging ports are capable of high power output. An output up to 60 W max on a single port or 60 W combined (shared) is possible.

The USB Type-C charging ports operate at multiple voltage and multiple wattage levels.



n The USB Type-C charging ports can be used when

The power switch is in ACC or ON, or the multimedia system is on.

n Situations in which the USB Type-C charging ports may not operate correctly

- | If a device which consumes more than 3 A at 5 V is connected (center console)
- | If a device which consumes more than 3 A at 20 V is connected (rear)
- | If a device designed to communicate with a personal computer,

such as a USB memory device, is connected

- I If the connected external device is turned off (depending on device)
- I If the temperature inside the vehicle is high, such as after the vehicle has been parked in the sun

n About connected external devices

Depending on the connected external device, charging may occasionally be suspended and then start again. This is not a malfunction.



NOTICE

n To prevent damage to the USB Type-C charging ports

- I Do not insert foreign objects into the ports.
- I Do not spill water or other liquids into the ports.
- I Do not apply excessive force to or impact the USB Type-C charging ports.
- I Do not disassemble or modify the USB Type-C charging ports.

n To prevent damage to external devices

- I Do not leave external devices in the vehicle. The temperature inside the vehicle may become high, resulting in damage to an external device.
- I Do not push down on or apply unnecessary force to an external device or the cable of an external device while it is connected.

n To prevent 12-volt battery discharge

Do not use the USB Type-C charging ports for a long period of time with the EV system stopped.

Wireless charger

A portable device can be charged by just placing Qi standard wireless charge compatible portable devices according to the Wireless Power Consortium, such as smart phones and mobile batteries, etc., on the charge area.

The compatible portable devices can be found on the following Wireless Power Consortium website. <https://www.wirelesspowerconsortium.com/>


This function cannot be used with portable devices that are larger than the charging tray. Also, depending on the portable device, it may not operate as normal. Please read the operation manual for portable devices to be used.

n The “Qi” logo

The Qi logo is a trademark of the Wireless Power Consortium. Qi ID: 14561



n Name for all parts



- A** Operation indicator light
- B** Charge area*
- C** Charging tray
- D** Approximately 1.0 in. (2.5 cm)
- E** Approximately 3.9 in. (10 cm)

*: The wireless charger detects the position of the charging coil inside the portable device and automatically moves its own coil within the charge area to align with it. Charging is possible if the center of the coil of the portable device is placed within the charge area. If 2 or more portable devices are placed on the charging tray, their charging coils may not be properly detected and they may not be charged.

n Using the wireless charger

Place the portable device on the


charging tray.

Place the charging side of the portable device down with the center of the device in the center of the charge area.

When charging, the operation indicator light (orange) on the wireless charger comes on.

If charging is not occurring, refer to “Situations in which the function may not operate normally” (→P.487)

When charging is complete, the operation indicator light (green) comes on.



n Recharging function

- When charging is complete and after a fixed time in the charge suspension state, charging restarts.
- When a portable device is moved significantly in the charge area, the charging coil is disconnected and charging is stopped momentarily. However, if there is a charging coil in the charge area, the charging coil inside the wireless charger will move toward it and then charging restarts. Place the mobile device near

the center of the charging area again.

n **Rapid charging function**

- The following portable devices support rapid charging.
- Portable devices compliant with WPC Ver1.3.2 and compatible with rapid charging
- iPhone's with an iOS version that

supports 7.5 W charging (iPhone 8 and later models)

- Portable devices compatible with Galaxy original rapid charging standard.
- When a portable device that supports rapid charging is charged, charging automatically switches to the rapid charging function.

n **Lighting conditions of operation indicator light**

Operation indicator light		Conditions
Charging tray side	Multimedia system screen side	
Turning off	Disappear	When the Multimedia power supply is off or power switch is off
Green (comes on)	Gray	On Standby (charging possible state) ^{*1}
		When charging is complete ^{*2}
Orange (comes on)	Blue	Charging

^{*1}: Charging power will not be output during standby. A metallic object will not be heated, if it is placed on the wireless charger in this state.

^{*2}: Depending on the portable device, there are cases where the operation indicator light will continue being lit up orange even after the charging is complete.

n **The wireless charger is not working properly**

The following are situations in which the wireless charger does not work properly and how to deal with the possible causes.

Operation indicator light	Multimedia system screen	Suspected causes/Handling method
Orange (Flashing repeatedly once every second)	Gray	<p>Vehicle to wireless charger communication failure</p> <p>→ If the EV system is operating, stop and then restart the EV system.</p> <p>If the power switch is in ACC, start the EV system. (→P.234)</p>
Green (Flashing repeatedly once every second)	Disappear	<p>Wireless charger and multimedia system communication failure</p> <p>→ If the EV system is operating, stop and then restart the EV system.</p> <p>If the power switch is in ACC, start the EV system. (→P.234)</p>
Green (comes on)	Blue	<p>AM radio stations are being automatically selected</p> <p>→ Wait until the system has completed the automatic selection of AM radio stations. In the case that automatic selection cannot be completed, stop automatic selection.</p> <p>The smart key system is detecting the key.</p> <p>→ Wait until the key detection is completed.</p>

Operation indicator light	Multimedia system screen	Suspected causes/Handling method
Green (comes on)	Gray	<p>Foreign substance detection: A metallic foreign substance is in the charge area, and so the abnormal heating prevention function of the metallic foreign substance operated → Remove the foreign substance from the charge area.</p>
		<p>Portable device misaligned/distanced from charging surface: The center of charging coil in the portable device moved outside of the charging area, or lens convex is large, or case is thick so the abnormal heating prevention function operated → Remove the portable device from the wireless charger, after 5 seconds, then place the portable device so that it is near the center of the wireless charger. Also, if a case or cover is installed to the portable device, remove it.</p>
		<p>Battery protection function of portable device: Before full charging, battery protection function of portable device operated → Confirm the setting of portable device.</p> <p>Continued detection of an electronic key: When a Multimedia function is used through vehicle customization, the electronic key is continually detected without being confirmed → In this case, turn the power switch ACC or ON to confirm the key.</p>

Operation indicator light	Multimedia system screen	Suspected causes/Handling method
Orange (Repeatedly flashes 4 times continuously)	Gray	Safety shutdown resulting when the temperature within the wireless charger exceeded the set value → Stop charging, remove the portable device from the charging tray wait for the temperature to drop, and then start charging again.

n **The wireless charger can be operated when**

The power switch is in ACC or ON, or the multimedia system is on.

n **Usable portable devices**

- | Qi standard wireless charge standard can be used on compatible devices. However, compatibility with portable devices that comply with Qi Ver. 1.0, 1.3.2 and later versions, and Qi2 MPP (Magnet Power Profile) is not guaranteed.
- | Starting with mobile phones and smartphones, it is aimed for low power electrically supplied portable devices of no more than 5 W.
- | However, charging exceeding 5 W is supported by the following portable devices.
 - Charging at 7.5 W or less is supported by iPhone's that support 7.5 W charging.
 - Charging at 10 W or less is supported by Galaxy device that support 10 W charging of original standard.
 - Charging at 15 W or less is supported by portable devices compliant with EPP output as defined by WPC standard Ver. 1.3.2.

n **Using the smart key system**

If the smart key system detects the electronic key while a device is being charged, charging will be temporarily stopped. When the electronic key is detected, charging will

automatically start again.

n **When covers and accessories are attached to portable devices**

Do not charge in situations where cover and accessories not able to handle Qi are attached to the portable device. Depending on the type of cover (including for certain genuine manufacturer parts) and accessory charging may not be possible. In addition, Qi2 is not supported. As a result, charging may not be possible when an accessory and cover that comply with Qi2 are installed. When charging is not performed even with the portable device placed on the charge area, remove the cover and accessories.

n **AM radio cooperation function during charging**

- | During charging, if noise occurs when listening to the AM radio, the charging frequency is automatically changed to reduce the noise.
- | When automatically seeking AM radio stations, charging will be suspended to prevent charging noise from being detected as a radio station. Charging will resume automatically when seek tuning is stopped.

n **Important points of the wireless charger**

- | If the electronic key cannot be detected within the vehicle interior, charging can not be done.

When the door is opened and closed, charging may be temporarily suspended.

- | When charging, the wireless charging device and portable device will get warmer, however this is not a malfunction. When a portable device gets warm while charging, charging may stop due to the protection function on the portable device side. In this case, when the temperature of the portable device drops significantly, charge again. The fan may start operating to lower the temperature inside the wireless charger, however this is not a malfunction.

n **Operation sounds**

A buzzing noise may be heard when pressing the power switch to turn to ACC or ON or when detecting a portable device. However, this is not a malfunction.

n **Cleaning the wireless charger**

→P.512

n **Situations in which the function may not operate normally**

Devices may not be charged normally in the following situations.

- | The portable device is fully charged
- | The portable device is being charged with a cable connected
- | There is foreign matter between the charge area and portable device
- | Charging has caused the portable device to heat up
- | The temperature around the wireless charger is 35°C (95°F) or higher, such as in extreme heat
- | The portable device is placed with its charging surface facing up
- | The small portable device such as foldable type is placed in an area misaligned from the charge area
- | The portable device is larger than

the charging tray

- | The camera lens protrudes 3 mm (0.12 in) or more from the surface of the portal device
- | The vehicle is in an area where strong electrical waves or noise are emitted, such as near a television tower, power plant, gasoline station, broadcasting station, large display, airport, etc.
- | The electronic key is not inside the vehicle
- | Any of the following objects is stuck or installed between the charging side of the portable device and the charge area.
 - Thick cases or covers
 - A case or cover attached with an uneven or tilted surface, so that the charging side is not flat
 - Thick decorations
 - Accessories, such as finger rings, straps, etc.
 - Cover to protect camera lens
- | When there is a gap between the charging side of the portable device and the charge area due to a protrusion such as a camera on the charging side of the portable device.
- | When the portable device is in contact with, or is covered by any of the following metallic objects:
 - A card that has metal on it, such as aluminum foil, etc.
 - A pack of cigarettes that includes aluminum foil
 - A wallet or bag that is made of metal
 - Coins
 - A heating pad
 - CDs, DVDs or other media
 - A metal accessory
 - A case or cover made of metal
 - A flip type case with a magnet on the charging side of the portable device
- | Electric wave type wireless remote controls are being used nearby
- | 2 or more portable devices are

placed on the charging tray at the same time

- | If you use a device with a built-in S-Pen (Galaxy Note series, etc.) and the device with the S-Pen inserted is on the tray.
- | When using an external power supply

If charging is abnormal or the operation indicator light continues to flash for any other reason, the wireless charger may be malfunctioning. Contact your Toyota dealer.

n If the smartphone OS has been updated

If the smartphone OS has been updated to a newer version, its charging specifications may have changed significantly. For details, check the information on the manufacturer's website.

n Trademark information

iPhone is a trademark of Apple Inc., registered in the U.S. and other countries.

Galaxy is a trademark or registered trademark of Samsung Electronics Co.,Ltd.

n Certification

→P.671



WARNING

n Caution while driving

When charging a portable device, for safety reasons, the driver should not operate the main part of the portable device while driving.

n Caution while in motion

Do not charge lightweight devices such as wireless headphones while in motion. These devices are very light and may be ejected from the charging tray, which may lead to unforeseen accidents.

n Caution regarding interference with electronic devices

People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverters, as well as any other electrical medical device, should consult their physician about the usage of the wireless charger.

n To prevent malfunctions or burns

Observe the following precautions.

Failure to do so may result in a equipment failure and damage, catch fire, burns due to overheat or electric shock.

- | Do not insert any metallic objects between the charge area and the portable device while charging
- | Do not attach metallic objects, such as aluminum stickers, to the charging area.
- | Do not attach an aluminum sticker or other metallic object to the side of the portable device (or to its case or cover) that touches the charge area
- | Do not use the charging tray as a small storage space
- | Do not subject to a strong force or impact
- | Do not disassemble, modify or remove
- | Do not charge devices other than specified portable devices
- | Keep away from magnetic items
- | Do not perform charging if the charging area is dirty
- | Do not cover with a cloth or similar material

**NOTICE**

n To prevent malfunctions and data corruptions


- i** When charging, bringing a credit, or other magnetic card, or magnetic storage media close to the charge area may clear any stored data due to magnetic influence. Furthermore, the electronic key may not operate due to magnetic interference if the electronic key for the vehicle is placed on the mobile phone terminal while charging or an open space. Also, do not bring a wristwatch or other precision instrument close to the charge area since doing so may cause it to malfunction.

- i** Do not charge with a non-contact IC card such as a transportation system IC card inserted between the charging side of a portable device and the charge area. The IC chip may become extremely hot and damage the portable device or IC card. Be especially careful not to charge a portable device inside a case or cover with a non-contact IC card attached.

- i** Do not leave portable devices inside the vehicle. The inside of the vehicle can become hot in extreme heat, which could cause a malfunction.

n To prevent 12-volt battery discharge

Do not use the wireless charger for a long period of time when the EV system is stopped.


**NOTICE**

n To prevent damage to the armrest

Do not apply too much load on the armrest.

Coat hooks

The coat hooks are provided with the rear assist grips.

**WARNING**

n Items that must not be hung on the hook

Do not hang coat hangers or other hard or sharp objects on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.


Armrest

Fold down the armrest for use.

Assist grips

An assist grip installed on the ceiling can be used to support

your body while sitting on the seat.

**WARNING****n Assist grip**

Do not use the assist grip when getting in or out of the vehicle or rising from your seat.

**NOTICE****n To prevent damage to the assist grip**

Do not hang any heavy object or put a heavy load on the assist grip.

Power outlets (120 VAC 1500 W)

This system allows the use of electrical devices with a total power consumption of 1500 W at 120 VAC in the vehicle.

Supplying power to electrical devices outside the vehicle is not recommended, as it may violate the laws and regulations of the country or region where it is used. When supplying power to electrical devices outside the vehicle, check the laws and regulations with the relevant local government of each country or region in advance. Also, be careful not to drag electrical devices and cords when moving the vehicle.

Precautions for using the power outlets while parked

Observe the following precautions before starting the power supply:

- Park the vehicle on a solid and level place.


Block the wheels as needed.

- Check that the hood is closed.
- Check that the parking brake is engaged.

- Check that the P shift position is selected.
- Check that the power switch is off.
- Note that the alarm system cannot be enabled during the power supply. For theft prevention, do not leave valuable items, etc. in the cabin or luggage compartment.
- Check that AC charging is not performed.

Names for all parts

n Switches




- A** Power switch (→P.234)
- B** Power outlet
- C** “AC 120 V” switch

Using the power outlets (1500 W)

- 1 Check that the parking brake is engaged. securely depress the brake pedal, and press the power switch. (→P.234)
- 2 Check that the READY indicator is illuminated, and press the “AC 120 V” switch.

The power outlet can be used when the indicator on the “AC 120 V” switch is illuminated.

The power outlet is turned off/on each time the “AC 120 V” switch is pressed.



- 3 Open the lid, and fully and securely insert the plug of the device into the power outlet. (→P.492)

Stopping the use of the power outlets (1500 W)

Follow the procedure described below:

- 1 Turn the connected devices off.
- 2 Press the “AC 120 V” switch to turn the power outlet off.

- 3 Disconnect each plug from the power outlets.
- 4 Close the lid of each power outlet.

Connecting a device

n When connecting a device

Make sure to read the instruction manual which came with a device and observe warnings on the device.

Before connecting a device to the power outlet, make sure that the device is turned off.

- 1 Open the lid, and fully and securely insert the plug of the device into the power outlet.

Do not leave the plug halfway inserted.

In the following situations, use cable extension, etc. and connect the plug securely to the power outlet:

- When the plug of a device is too large to allow it to be inserted fully and securely into the power outlet.
- When the plug of a device is heavy, possibly causing it to come off the power outlet.

If the device to be used has a ground wire, use a conversion adapter available on the market and connect the ground wire to the ground terminal of the conversion adapter.

n Power outlets

- | With these power outlets, use devices which operate on 120 VAC and have a combined maximum power consumption of 1500 W or less. If a device is connected and the power consumption is exceeded, a protection circuit may be activated and the power supply function may be stopped.
- | Some of the devices that consume a large amount of power, such as an electric grille, may require the exclusive use of the power outlets. When such a device is connected, do not connect other device(s) to the power outlets.
- | When multiple devices are connected, depending on the device, a connected device may not operate properly. For such a device, use exclusively the power outlets.
- | When a power outlet is being used, depending on the device to be used, the current flow may be high and the initial peak wattage may exceed 1500 W. In this situation, the protection function may activate and stop the power supply function.
- | When a power outlet is being used, depending on the device to be used, it may cause interference with TV and radio broadcasts.

n Devices which may not operate correctly

The following devices may not operate properly even if the combined power consumption is 1500 W or less:

- | Devices with high initial peak wattage
- | Devices requiring larger amount of power supply than the power consumption specified in its instruction manual
- | Measuring devices that process precise data

- | Devices that require an extremely stable power supply
- | Devices that require a constant power supply from the power outlet, such as a device with a timer.
- n **When the power outlets are used while the vehicle is parked or stopped**
 - | The doors cannot be locked/unlocked using the smart key system.
 - | The doors cannot be locked/unlocked using an electronic key. The doors can only be locked/unlocked using a mechanical key.
 - | When a door is opened/closed, a buzzer may sound or "Key Not Detected Check Key Location" may be displayed on the multi-information display. Check that an electronic key is carried with you.
 - | When the vehicle's surroundings become dark while supplying power, the headlights etc. turn on automatically. Refer to P.251 for information about the lights.
 - | AC charging or DC charging cannot be performed.




WARNING

n For safe use

Observe the following precautions. Failure to do so may lead to an accident, resulting in death or serious injury.

- | Do not allow children or other people not used to the operation to perform the power supply by themselves.

- | Do not disconnect the plug of a device while your hands are wet or insert a pin or other object into the power outlet. Also, if a liquid or snow is on the power outlet, dry the outlet before using it.
- | Do not attempt to modify, disassemble, or repair a Power outlet. For information on repairs, contact your Toyota dealer.
- | Keep the power outlets free of dust and foreign matter. Also, make sure to clean the power outlets periodically.
- | Hold the plug body to plug in/out of a power outlet. Do not touch the plug blades. Do not pull on a cord for unplugging, as otherwise the plug or cord may be damaged.
- | Stop the use immediately if abnormal heat is observed on a cord or power outlet. To prevent the cord or power outlet from becoming hot, observe the following precautions:
 - Do not connect 2 or more multi-point outlet adapters, such as dual adapters.



WARNING

- When an extension cord reel is used, make sure to draw the whole cord out of the reel.

If the device to be used has a ground wire, use a conversion adapter available on the market and connect the ground wire to the ground terminal of the conversion adapter.

If the plug of a device fits loosely in a power outlet, even though it is fully inserted, replace the power outlet. For information on replacement, contact your Toyota dealer.

n Cautions when power supply

People with implantable cardiac pacemakers or cardiac resynchronization therapy-pacemakers should not carry out the power supply procedure. Ask someone else to do it.

Do not approach the charger, charging cable and the vehicle during power supply. Power supply procedure may affect the operation of pacemakers.

Do not remain in the vehicle during power supply. Power supply procedure may affect the operation of pacemakers.

Do not enter the vehicle (including the luggage compartment) to retrieve something from it, or for any purpose. Power supply procedure may affect the operation of pacemakers.

n Devices to be connected

Make sure to read any instruction manual which came with a device and observe any warnings on the device.

Do not connect a device to a power outlet if the device is malfunctioning or its plug is damaged.

Otherwise, the device may be further malfunctioning, especially when the outside temperature is high or low.

Devices requiring to be installed on a level place may not operate properly.

Do not use devices, other than waterproof devices, in a place where water, such as rain, is splashed over or where it is humid.

Do not use a device that has been or likely to have been merged in water or absorbed water within.


Do not connect a medical device, as depending on the vehicle condition, the power supply function may be temporarily stopped.

n When the power outlets are used while the vehicle is parked or stopped

The power outlets are designed to be connected to electric devices, such as lighting devices. Do not use them as a generator that supplies power to a house, etc. Also, when they are to be used on an emergency power supply device for homes, such as an exclusive device having connection to an external power source, or a device whose power supply circuit for external power source is separate from electric wiring of power companies, consult with the manufacturer or a retailer of the device.

WARNING

- I When using a power outlet, make sure to securely engage the parking brake and shift the shift position to P. Otherwise, the vehicle may move, possibly leading to an accident.
- I When using a power outlet, do not move away from the vehicle.
- I Do not perform rapid charging during weather when lightning may occur. Stop supplying power if lightning is observed during power supply.
- I Do not use the power outlets if the vehicle has a vehicle cover installed.
- I Do not use a power outlet when the vehicle is parked on a slanted place or a slope. When a power outlet is being used, do not move the vehicle or cause it to be inclined.
- I Observe the following precautions when a connected cord is to be brought outside the vehicle:
 - Take due care for not allowing rain to enter. If the power outlet is wet with raindrops, dry it before use.
 - Prevent the cord from being caught in the window or door.
 - Allow slack in a connected cord. Do not cause it to be extraordinarily tense.



- Do not start off the vehicle by mistake.
- I Do not wash the vehicle when using a power outlet.
- I Make sure that the hood is closed.
- I Do not put your head or hands anywhere inside the motor compartment, as the cooling fan may operate suddenly. Keep hands and clothing (especially a tie, scarf, etc.) away from the fan as they may get caught in a fan.
- I Do not stop the vehicle near objects which burn easily.
- I Do not use in places where corrosive gases or fluids are generated.
- n **Use of a power outlet while driving**
 - I In situations such as the following, do not use an electric device while driving. Also, do not use a device if it cannot be secured within the vehicle.
 - When a device is likely to distract the driver and be a hindrance to safe driving, such as a TV, video/DVD player, etc.
 - When an inadequately secured device is likely to fall over in case of sudden braking or an accident
 - When a device is likely to cause fire if it falls or generates heat
 - When a device is likely to cause burns, such as a toaster, microwave, electric heater, electric kettle, coffee maker, etc.

**WARNING**

- When a device is likely to fall under the pedals and prevent the brake pedal from being depressed, such as a hair dryer, AC adapter, mouse, etc.

I Do not use devices which produce steam while the windows are closed. Doing so may cause the windows to fog up, reducing visibility and making it difficult to drive safely. Also, the steam may damage or negatively affect other devices. If the device must be used, stop the vehicle and open the windows before use.

n Onboard traction battery charger

The onboard traction battery charger is located in the motor compartment. Make sure to observe the following precautions regarding the onboard traction battery charger. Failure to observe these precautions may result in death or serious injury such as burns and electric shocks.

- I** The onboard traction battery charger is hot during power supply. Do not touch the onboard traction battery charger, as doing so may result in burns.
- I** Do not disassemble, repair or modify the onboard traction battery charger. When the onboard traction battery charger needs to be repaired, consult your Toyota dealer.

**NOTICE****n To avoid short circuit or malfunction**

Observe the following precautions. Failure to do so may lead to the power outlets not operating correctly or damage to the vehicle or a connected device.

- I** Do not set a toaster or other device which generates heat near the interior components or on a seat. Heat may cause these parts to melt or burn.
- I** Do not use devices which are sensitive to vibration or heat in the vehicle. These devices may malfunction due to vibration while driving or heat while the vehicle is parked in the sun.
- I** When not using a power outlet, make sure to close the lid. If foreign matter or a liquid enters the power outlet, it may cause a malfunction or short circuit.

When the power outlet (AC 120V/1500 W) cannot be used properly

When the power outlets cannot be used, even though the normal procedure is followed, check each of the following items.

When the power outlets cannot be used properly

When the power outlets cannot be used, even though the normal procedure is followed, check each of the following items.

n Power outlets cannot be used

Likely cause	Correction procedure
AC charging is in progress	Stop AC charging, disconnect the charging connector and restart the procedure from the beginning.
When the traction battery, onboard traction battery charger, etc. are hot in conditions such as when the outside temperature is especially high.	Wait for the outside temperature to decrease, and then press the "AC 120 V" switch again.
When the traction battery, onboard traction battery charger, etc. are cold in conditions such as when the outside temperature is especially low.	Wait for the outside temperature to increase, and then press the "AC 120 V" switch again.

Likely cause	Correction procedure
Electrical device does not operate	Disconnect the power source plug of the electrical device and check that the electrical device itself is not malfunctioning. Then, press the “AC 120 V” switch again. If the indicator on the “AC 120 V” switch does not illuminate, turn the power switch off and restart the procedure from the beginning. Check the instruction manual of the electrical device.

Likely cause	Correction procedure
Total power consumption exceeds 1500 W	Disconnect the power source plug of the electrical device and check that the total power consumption does not exceed 1500 W. Then, press the “AC 120 V” switch again.
Short circuit in the power outlet	Disconnect the power source plug of the electrical device and check the items below. Then, press the “AC 120 V” switch again. <ul style="list-style-type: none">• No foreign matter such as a pin has been inserted• No substances such as drinking water, rain or snow are adhered• No dirt or dust is adhered

If the power outlets cannot be used even after performing the procedures above, have the vehicle inspected by your Toyota dealer.

Garage door opener

The garage door opener can be programmed using the HomeLink® to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.

HomeLink® programming procedure

The programming procedures can also be found at the following URL.

Website: www.homelink.com/toyota




For support, contact customer support at the following.

Help Line: 1-800-355-3515

System components

The HomeLink® wireless control system in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming methods on the following pages to determine the method which is appropriate for the device.

- ▶ Vehicles with auto anti-glare inside rear view mirror




- A** HomeLink® indicator light
- B** Garage door operation indicators

- C** HomeLink® icon

Illuminates while HomeLink® is operating.

- D** Buttons

- ▶ Vehicles with Digital Rear-view Mirror



- A** HomeLink® indicator light
- Illuminates above each button selected.

- B** HomeLink® icon

- C** Garage door operation indi-

cators

[D] HomeLink® logo

Appears while HomeLink® is operating.

When the HomeLink® button is pressed, the logo disappears even while the HomeLink® is operating.

[E] Setting icon

Press the menu button to change the setting.

[F] Menu buttons

[G] HomeLink® buttons

n Codes stored in the HomeLink® memory

- l The registered codes are not erased even if the 12-volt battery cable is disconnected.
- l If learning failed when registering a different code to a HomeLink® button that already has a code registered to it, the already registered code will not be erased.

n Certification

→P.671



WARNING

n When programming a garage door or other remote control device

The garage door or other device may operate, so ensure people and objects are out of danger to prevent potential harm.

n Conforming to federal safety standards

Do not use the HomeLink® compatible transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an interfering object. A door or device without these features increases the risk of death or serious injury.

n When operating or programming HomeLink®

Never allow a child to operate or play with the HomeLink® buttons.

Programming the HomeLink®

n Before programming HomeLink®

- During programming, it is possible that garage doors, gates, or other devices may operate. For this reason, make sure that people and objects are clear of the garage door or other devices to prevent injury or other potential harm.
- It is recommended that a new battery be placed in the remote control transmitter for more accurate programming.
- Garage door opener motors manufactured after 1995 may be equipped with rolling code protection. If this is the case,

you may need a stepladder or other sturdy, safe device to reach the “Learn” or “Smart” button on the garage door opener motor.

n Programming HomeLink®

Steps **2** through **4** must be performed within 60 seconds, otherwise the HomeLink® indicator light will stop flashing and programming will not be successfully completed.

- 1** Vehicles with Digital Rear-view Mirror: Press the HomeLink® button or menu button

When the HomeLink® button is pressed: Homelink® Training Tutorial will be displayed to assist you programming the HomeLink®.

When Homelink® Training Tutorial is displayed, follow the instructions displayed.

When the menu button is pressed: Press the menu button  and select the “Set Up >”. Homelink® Training Tutorial will be displayed to assist you programming the HomeLink®.


When Homelink® Training Tutorial is displayed, follow the instructions displayed.

- 2** Press and release the HomeLink® button you want to program and check that the HomeLink® indicator light flashes (orange).
- 3** Point the remote control transmitter for the device at


the rear view mirror, 1 to 3 in. (25 to 75 mm) from the HomeLink® buttons.

Keep the HomeLink® indicator light in view while programming.


- Vehicles with auto anti-glare inside rear view mirror




- Vehicles with Digital Rear-view Mirror



- 4** Program a device.
- Vehicles with auto anti-glare inside rear view mirror



► Vehicles with Digital Rear-view Mirror



► Programming a device other than an entry gate (for U.S.A. owners)

Press and hold the remote control transmitter button until the HomeLink[®] indicator light changes from slowly flashing orange to rapidly flashing green (rolling code) or continuously lit green (fixed code), then release the button.

► Programming an entry gate (for U.S.A. owners)/Programming a device in the Canadian market

Press and release the remote control transmitter button at 2 second intervals, repeatedly, until the HomeLink[®] indicator light changes from slowly flashing orange to rapidly flashing (green) (rolling code) or continuously lit (green) (fixed code).

5 Test the HomeLink[®] operation by pressing the newly programmed button and observing the HomeLink[®] indicator light:

- HomeLink[®] indicator light illu-

minates: Programming of a fixed code device has completed. The garage door or other device should operate when a HomeLink[®] button is pressed and released.

- HomeLink[®] indicator light flashes rapidly: The garage door opener or other device is equipped with a rolling code. To complete programming, firmly press and hold the HomeLink[®] button for 2 seconds then release it.
- If the garage door or other device does not operate, proceed to “Programming a rolling code system”.
- 6** Repeat the steps above to program another device for any of the remaining HomeLink[®] buttons.


n Programming a rolling code system

Two or more people may be necessary to complete rolling code programming.


- 1** Locate the “Learn” or “Smart” button on the garage door opener motor in the garage.

This button can usually be found where the hanging antenna wire is attached to the unit. The name and color of the button may vary by manufacturer. Refer to the owner's manual supplied with the garage

door opener motor for details.




- 2** Press and release the “Learn” or “Smart” button. Perform **3** within 30 seconds after performing **2**.




- 3** Press and hold the desired HomeLink[®] button (inside the vehicle) for 2 seconds and release it. Repeat this sequence (press/hold/release) up to 3 times to complete programming. If the garage door opener motor operates when the HomeLink[®] button is pressed, the garage door opener motor recognizes the HomeLink[®] signal.

- Vehicles with auto anti-glare inside rear view mirror



- Vehicles with Digital Rear-view Mirror



- n** **Enabling 2-way communication with a garage door (only available for compatible devices)**

When enabled, 2-way communication allows you to check the status of the opening and closing of a garage door through indicators in your vehicle.

2-way communication is only available if the garage door opener motor used is a compatible device. (To check device compatibility, refer to www.homelink.com.)

- 1** Within 5 seconds after programming the garage door opener has been completed,

if the garage door opener motor is trained to HomeLink[®], both garage door operation indicators will flash rapidly (green) and the light on the garage door opener motor will blink twice, indicating that 2-way communication is enabled.

If the indicators do not flash, perform **2** and **3** within the first 10 presses of the HomeLink[®] button after programming has been completed.

- 2** Press a programmed HomeLink[®] button to operate a garage door.
- 3** Within 1 minute of pressing the HomeLink[®] button, after the garage door operation has stopped, press the “Learn” or “Smart” button on the garage door opener motor. Within 5 seconds of the establishment of 2-way communication with the garage door opener, both garage door operation indicators in the vehicle will flash rapidly (green) and the light on the garage door opener motor will blink twice, indicating that 2-way communication is enabled.

n Reprogramming a single HomeLink[®] button

When the following procedure is performed, buttons which already have devices registered

to them can be overwritten:

- 1** Press and hold the desired HomeLink[®] button.
- 2** When the HomeLink[®] indicator starts flashing orange, release the HomeLink[®] button and perform “Programming HomeLink[®]” 1 (it takes 20 seconds for the HomeLink[®] indicator to start flashing).

n Before programming


- | Install a new battery in the transmitter.
- | The battery side of the transmitter must be pointed away from the HomeLink[®] buttons.

Operating HomeLink[®]

Press the appropriate HomeLink[®] button. The HomeLink[®] indicator light should turn on.


The status of the opening and closing of a garage door is shown by the garage door operation indicators.

- Vehicles with auto anti-glare inside rear view mirror



- A** Opening
B Closing

- Vehicles with Digital Rear-view Mirror



- A** Opening
B Closing

This function is only available if the garage door opener motor used is a compatible device. (To check device compatibility, refer to www.homelink.com.)

Color	Status
Orange (flashing)	Currently opening/closing

Color	Status
Green	Opening/closing has completed
Red (flashing)	Feedback signals cannot be received

The indicators can operate within approximately 820 ft. (250 m) of the garage door. However, if there are obstructions between the garage door and the vehicle, such as houses and trees, feedback signals from the garage door may not be received.


To recall the previous door operation status, press and release either HomeLink® buttons  and  or  and  (vehicles with auto anti-glare inside rear view mirror),  and  or  and  (vehicles with Digital Rear-view Mirror), simultaneously. The last recorded status will be displayed for 3 seconds.

Erasing the entire HomeLink® memory (all three codes)


Press and hold the 2 outside buttons for 10 seconds until the HomeLink® indicator light changes from continuously lit (orange) to rapidly flashing (green).

If you sell your vehicle, be sure to erase the programs stored in the HomeLink® memory.

- Vehicles with auto anti-glare inside rear view mirror



- Vehicles with Digital Rear-view Mirror



7-1. Maintenance and care

Cleaning and protecting the
vehicle exterior **508**

Cleaning and protecting the
vehicle interior **512**

7-2. Maintenance

Maintenance requirements
..... **515**

General maintenance.. **516**

7-3. Do-it-yourself maintenance

Do-it-yourself service pre-
cautions..... **519**

Hood **521**

Positioning a floor jack
..... **523**

Motor compartment..... **524**

Tires **530**

Replacing the tire **542**

Tire inflation pressure.. **547**

Wheels **549**

Air conditioning filter.... **551**

Electronic key battery.. **553**

Checking and replacing
fuses..... **555**

Headlight aim **557**

Light bulbs..... **558**

Cleaning and protecting the vehicle exterior

Perform cleaning in a manner appropriate to each component and its material.

Cleaning instructions

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

n Automatic car washes

- | Before washing the vehicle:
 - Fold the mirrors
 - Turn off the power back door

Start washing from the front of the vehicle. Extend the mirrors before driving.

- | Brushes used in automatic car washes may scratch the vehicle surface, parts (wheel, etc.) and harm your vehicle's paint.

- | Rear spoiler (if equipped) may not be washable in some automatic car washes. There may also be an increased risk of damage to vehicle.

- | When using an automatic car washes, etc. the shift position needs to be held in N, refer to P.242.

n High pressure car washes

As water may enter the cabin, do not bring the nozzle tip near the gaps around the doors or perimeter of the windows, or spray these areas continuously.

n Note for a smart key system

- | If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:
 - Place the key in a position 6 ft. (2 m) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
 - Set the electronic key to battery-saving mode to disable the smart key system. (→P.175)
- | If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a buzzer may sound outside the vehicle and "Key Detected in Vehicle" may be shown on the multi-information display. To turn off the alarm, lock all the doors.

n Wheels and wheel ornaments

- | Remove any dirt immediately by using a neutral detergent.
- | Wash detergent off with water immediately after use.
- | To protect the paint from damage, make sure to observe the following precautions.
 - Do not use acidic, alkaline or abrasive detergent
 - Do not use hard brushes

- Do not use detergent on the wheels when they are hot, such as after driving or parking in hot weather

n **Wheels and wheel ornaments (vehicles with matte painted wheels)**

A different set of care is necessary for matte painted wheels and wheel ornaments. Contact your Toyota dealer for details.

- l Remove any dirt with water immediately.
If the wheels are excessively dirty, use diluted neutral detergent.
- l When using detergent, make sure to wash it off with water immediately. Then use a soft cloth to wipe off the water.
- l Use a sponge or soft cloth to remove the dirt by hand.
- l To prevent the matte paint from being damaged or glossy, make sure to observe the following precautions:
 - Do not apply any coatings or wax.
 - Do not use acidic, alkaline or abrasive detergents.
 - When using tire cleaners or tire wax, do not allow them to be applied to the wheels.
 - Do not scrub or polish the wheels using a brush or dry cloth, etc.
 - When using an automatic car wash, do not select the wheel brush function.
 - Do not use a high pressure washer or steam cleaner.
 - Do not use detergent on the wheels when they are hot, such as after driving or parking in hot weather.

n **Brake pads and calipers**

Rust may form if the vehicle is parked with wet brake pads or disc rotors, causing them to stick. Before parking the vehicle after it is washed, drive slowly and apply the brakes several times to dry the parts.

n **Bumpers**

Do not scrub with abrasive cleaners.

n **Plated portions**

If dirt cannot be removed, clean the parts as follows:

- l Use a soft cloth dampened with an approximately 5% solution of neutral detergent and water to clean the dirt off.
- l Wipe the surface with a dry, soft cloth to remove any remaining moisture.
- l To remove oily deposits, use alcohol wet wipes or a similar product.



WARNING


n **When washing the vehicle**

Do not apply water to the inside of the motor compartment. Doing so may cause the electrical components, etc. to catch fire.

WARNING

n When cleaning the windshield


Set the wiper switch to off.
If the switch is in “AUTO”, the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.



A Off

B AUTO


► Type A



A Off

B AUTO

► Type B



A Off

B AUTO

When the upper part of the windshield where the raindrop sensor is located is touched by hand

When a wet rag or similar is held close to the raindrop sensor

If something bumps against the windshield

If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor

n Precaution regarding the front and rear bumpers

If the paint of the front or rear bumper is chipped or scratched, the following systems may not function correctly. If this occurs, consult your Toyota dealer.

- When the upper part of the windshield where the raindrop sensor is located is touched by hand
- When a wet rag or similar is held close to the raindrop sensor
- If something bumps against the windshield
- If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor
- Toyota Safety Sense 3.0
- BSM (Blind Spot Monitor)
- Safe Exit Assist
- RCTA (Rear cross traffic alert)
- PKSB (Parking Support Brake)
- Intuitive parking assist

NOTICE

n To prevent paint deterioration and corrosion on the body and components (aluminum wheels, etc.)

Wash the vehicle immediately in the following cases:

- After driving near the sea coast
- After driving on salted roads
- If coal tar or tree sap is present on the paint surface
- If dead insects, insect droppings or bird droppings are present on the paint surface

**NOTICE**

- After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
- If the vehicle becomes heavily soiled with dust or mud
- If liquids such as benzene and gasoline are spilled on the paint surface

If the paint is chipped or scratched, have it repaired immediately.

To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

n Cleaning the exterior lights

Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.

Do not apply wax to the surfaces of the lights. Wax may cause damage to the lenses.

n When using an automatic car wash

Set the wiper switch to the off position.

If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

n When using a high pressure car wash

When washing the vehicle, do not spray the camera or its surrounding area directly with a high pressure washer. Shock applied from high pressure water may cause the device to not operate normally.

Do not spray water directly on the radar which is equipped behind the emblem. Otherwise it may cause the device to be damaged.

Do not bring the nozzle tip close to boots (rubber or resin manufactured cover), connectors or the following parts. The parts may be damaged if they come into contact with high-pressure water.

- Traction related parts
- Steering parts
- Suspension parts
- Brake parts

Keep the cleaning nozzle at least 11.9 in. (30 cm) away from the vehicle body. Otherwise resin section, such as moldings and bumpers, may be deformed and damaged. Also, do not continuously hold the nozzle in the same place.

Do not spray the lower part of the windshield continuously. If water enters the air conditioning system intake located near the lower part of the windshield, the air conditioning system may not operate correctly.

Do not wash the underside of the vehicle using a high pressure car washer. If water enters the traction battery, the EV system may malfunction.

Do not use the washer on the area around the charging port lid. Water could get into the charging inlet and could damage the vehicle.

n Cleaning aluminum parts

When cleaning the hood, do not push hard or put weight on it. The aluminum part may be dented.

Cleaning and protecting the vehicle interior

Perform cleaning in a manner appropriate to each component and its material.

Protecting the vehicle interior

- Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.
- If dirt cannot be removed, wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

n Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. Wipe dirty surfaces and let them dry. Excellent results are obtained by keeping the carpet as dry as possible.

n Handling the seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

n Front side windows with IR protective coating

The front side windows have IR protective coating. To prevent any dam-

age to the IR protective coating, observe the following:

- I If the windows are dirty, gently wipe them with a cloth soaked in water or lukewarm water as soon as possible.
- I If the windows are very dirty, do not open and close them repeatedly.



WARNING

n Water in the vehicle

- I Do not splash or spill liquid in the vehicle.
Doing so may cause electrical components, etc. to malfunction or catch fire.
- I Do not get any of the SRS components or wiring in the vehicle interior wet.
(→P.33)
An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.
- I Do not let the wireless charger (→P.481) get wet. Failure to do so may cause the charger to become hot and cause burns or could cause electric shock resulting in death or serious injury.

n Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

**NOTICE****n Cleaning detergents**

- i** Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
 - Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach
 - Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol
- i** Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

n Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

n When cleaning the inside of the windshield

Do not allow glass cleaner to contact the lens. Also, do not touch the lens. (→P.263)

n Cleaning the inside of the rear window

- i** Do not use a glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires.
- i** Be careful not to scratch or damage the heater wires.

n Cleaning the front side windows

Do not use any compound or abrasive product (e.g., glass cleaner, detergent, wax) to clean the windows. It may damage the coating.

Cleaning the areas with satin-finish metal accents

- Remove dirt using a water dampened soft cloth or synthetic chamois.
- Wipe the surface with a dry soft cloth to remove any remaining moisture.

n Cleaning the areas with satin-finish metal accents

The metal areas use a layer of real metal for the surface. It is necessary to clean them regularly. If dirty areas are left uncleaned for long periods of time, they may be difficult to clean.

Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe off any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5% neutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry,

soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area.

n Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.



NOTICE

n Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- I** Remove any dust or dirt from leather surfaces immediately.
- I** Do not expose the vehicle to direct sunlight for extended periods of time. Park the vehicle in the shade, especially during summer.
- I** Do not place items made of vinyl, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

Cleaning the synthetic leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of

detergent and water.

Cleaning fabric portions

- To remove dust from the fabric, use a vacuum cleaner or adhesive tape.

However, please remove the dust near the passenger airbag ornament by hand.

- Use a cloth dampened with water to gently wipe the fabric clean.

Do not use detergents to clean the fabric.

- Vehicles with radiant heaters: Do not hard scrub on the fabric portion of the radiant heaters (→P.465).

Cleaning the instrument panel surface

- Remove dirt and dust using a vacuum cleaner.
- Wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. It is the owner's responsibility to perform regular checks. Toyota recommends the following maintenance:

n Repair and replacement

It is recommended that genuine Toyota parts be used for repairs to ensure performance of each system. If non-Toyota parts are used in replacement or if a repair shop other than a Toyota dealer performs repairs, confirm the warranty coverage.

n Allow inspection and repairs to be performed by a Toyota dealer

- I Toyota technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operation of all systems on your vehicle.
- I Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Toyota dealer will promptly take care of it.



WARNING

n If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

n Handling of the 12-volt battery

- I Oils and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
- I 12-volt battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (→P.527)

General maintenance

General maintenance should be performed on a daily basis. This can be done by yourself or by a Toyota dealer.

Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".

n Resetting the message indicating maintenance is required

After the required maintenance is preformed according to the maintenance schedule, please reset the message.

To reset the message, follow the procedures described below:

- 1 Select  on the multimedia display.
- 2 Select “Vehicle customize”.
- 3 Select “Utility”.
- 4 Select “Scheduled maintenance”.
- 5 Select “Reset”.

Do-it-yourself maintenance

You can perform some maintenance procedures by yourself. Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Toyota repair manuals is recommended.

For details about warranty coverage, refer to the separate “Owner’s Warranty Information Booklet” or “Owner’s Manual Supplement”.

General maintenance

Listed below are the general maintenance items that should be performed at the intervals specified in the “Owner’s Warranty Information Booklet” or “Owner’s Manual Supplement/Scheduled Maintenance Guide”. It is recommended that any problem you notice should be brought to the attention of your Toyota dealer or qualified service shop for advice.



WARNING

n If the EV system is operating

Turn the EV system off and ensure that there is adequate ventilation before performing maintenance checks.

Motor compartment

Items	Check points
Brake fluid	Is the brake fluid at the correct level? (→P.526)
Power control unit/heater coolant	power control unit/heater coolant at the correct level? (→P.524, P.526)
12-volt battery	Check the connections. (→P.527)

Items	Check points
Radiator	The radiator should be free from foreign objects. (→P.525)
Washer fluid	Is there sufficient washer fluid? (→P.530)

Vehicle interior

Items	Check points
Accelerator pedal	<ul style="list-style-type: none"> The accelerator pedal should move smoothly (without uneven pedal effort or catching).
“Park” mechanism	<ul style="list-style-type: none"> When parked on a slope and the shift position is in P, is the vehicle securely stopped?
Brake pedal	<ul style="list-style-type: none"> Does the brake pedal move smoothly? Does the brake pedal have appropriate clearance from the floor? Does the brake pedal have the correct amount of free play?

Items	Check points
Brakes	<ul style="list-style-type: none"> The vehicle should not pull to one side when the brakes are applied. The brakes should work effectively. The brake pedal should not feel spongy. The brake pedal should not get too close to the floor when the brakes are applied.
Head restraints	<ul style="list-style-type: none"> Do the head restraints move smoothly and lock securely?
Indicators/buzzers	<ul style="list-style-type: none"> Do the indicators and buzzers function properly?
Lights	<ul style="list-style-type: none"> Do all the lights come on? Are the headlights aimed correctly?
Parking brake	<ul style="list-style-type: none"> Does the parking brake switch operate normally? When parked on a slope and the parking brake is on, is the vehicle securely stopped?

Items	Check points
Seat belts	<ul style="list-style-type: none">• Do the seat belts operate smoothly?• The seat belts should not be damaged.
Seats	<ul style="list-style-type: none">• Do the seat controls operate properly?
Steering wheel	<ul style="list-style-type: none">• Does the steering wheel rotate smoothly?• Does the steering wheel have the correct amount of free play?• There should not be any strange sounds coming from the steering wheel.

Vehicle exterior

Items	Check points
Doors	<ul style="list-style-type: none">• Do the doors operate smoothly?
Hood	<ul style="list-style-type: none">• Does the hood lock system work properly?
Fluid leaks	<ul style="list-style-type: none">• There should not be any signs of fluid leakage after the vehicle has been parked.

Items	Check points
Tires	<ul style="list-style-type: none">• Is the tire inflation pressure correct?• The tires should not be damaged or excessively worn.• Have the tires been rotated according to the maintenance schedule?• The wheel bolts should not be loose.
Windshield wipers	<ul style="list-style-type: none">• The wiper blades should not show any signs of cracking, splitting, wear, contamination or deformation.• The wiper blades should clear the windshield/rear window without streaking or skipping.

Do-it-yourself service precautions

If you perform maintenance by yourself, be sure to follow the correct procedure as given in these sections.

Maintenance

Items	Parts and tools
12-volt battery condition (→P.527)	<ul style="list-style-type: none"> • Warm water • Baking soda • Grease • Conventional wrench (for terminal clamp bolts)
Brake fluid level (→P.526)	<ul style="list-style-type: none"> • FMVSS No.116 DOT 3 or SAE J1703 brake fluid • FMVSS No.116 DOT 4 or SAE J1704 brake fluid • Rag or paper towel • Funnel (used only for adding brake fluid)

Items	Parts and tools
Power control unit coolant level (→P.526)	<ul style="list-style-type: none"> • In order to ensure maximum performance of the traction battery cooling system and limit risks of battery short circuit and other damage to your vehicle, Toyota recommends using “Toyota Genuine Traction Battery Coolant” or similar high-quality ethylene glycol-based, low electric conductivity coolant, non-amine and non-borate coolant with azole additives. • Funnel (used only for adding coolant)

Items	Parts and tools
Heater cool- ant level(→P.524)	<ul style="list-style-type: none">• “Toyota Super Long Life Cool-ant” or a similar high quality ethylene glycol-based, non-silicate, non-amine, non-nitrite and non-borate cool-ant with long-life hybrid organic acid technology “Toyota Super Long Life Cool-ant” is pre-mixed with 50% cool-ant and 50% deionized water.• Funnel (used only for adding coolant)
Fuses (→P.555)	<ul style="list-style-type: none">• Fuse with same amperage rating as original
Headlight aim (→P.557)	<ul style="list-style-type: none">• Phillips-head screwdriver
Radiator (→P.525)	—

Items	Parts and tools
Tire inflation pressure (→P.547)	<ul style="list-style-type: none">• Tire pressure gauge• Compressed air source
Washer fluid (→P.530)	<ul style="list-style-type: none">• Water or washer fluid containing antifreeze (for winter use)• Funnel (used only for adding water or washer fluid)



WARNING

The motor compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

n When working on the motor compartment

- l Make sure that “POWER ON” on the multi-information display and the “READY” indicator are both off.
- l Keep hands, clothing and tools away from the moving fan.
- l Be careful not to touch the motor, power control unit, radiator, etc., right after driving as they may be hot. Coolant and other fluids may also be hot.
- l Do not leave anything that may burn easily, such as paper and rags, in the motor compartment.
- l Do not smoke, cause sparks or expose an open flame to the 12-volt battery. 12-volt battery fumes are flammable.

**WARNING**

I Be extremely cautious when working on the 12-volt battery. It contains poisonous and corrosive sulfuric acid.

I Never touch, disassemble, remove or replace the high voltage parts, cables and their connectors. It can cause severe burns or electric shock that may result in death or serious injury.

n **When working near the electric cooling fan or radiator grille**

Be sure the power switch is off. With the power switch in ON, the electric cooling fan may automatically start to run if the air conditioning is on and/or the coolant temperature is high. (→P.525)


n **Safety glasses**

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.


Hood**Opening the hood**

- 1** Pull the hood lock release lever.


The hood will pop up slightly.



- 2** Push the auxiliary catch lever to the left and lift the hood.



- 3** Hold the hood open by inserting the supporting rod into the slot.

**NOTICE****n When closing the hood**

Be sure to return the support rod to its clip before closing the hood. Closing the hood without returning the support rod properly could cause the hood to bend.

**WARNING****n Pre-driving check**

Check that the hood is fully closed and locked.

If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

n After installing the support rod into the slot

Make sure the rod is properly inserted into the slot to prevent the hood from shutting on your head or body.


Positioning a floor jack

When using a floor jack, follow the instructions in the manual provided with the jack and perform the operation safely.


When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

Location of the jack point

n Front




n Rear



Motor compartment


Components



- A** Heater coolant reservoir (→P.524)
- B** Washer fluid tank (→P.530)
- C** Power control unit coolant reservoir (→P.526)
- D** 12-volt battery (→P.527)
- E** Brake fluid reservoir (→P.526)
- F** Fuse box (→P.555)
- G** Radiator (→P.525)
- H** Electric cooling fan

Checking the heater coolant

The coolant level is satisfactory if it is between the “MAX” and “MIN” lines on the reservoir when the EV system is cold.



A Reservoir cap

B "MAX" line

C "MIN" line

If the level is on or below the "MIN" line, add coolant up to the "MAX" line. (→P.604)

n Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene glycol-based, non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water.
(Minimum temperature: -31°F [-35°C])

For more details about coolant, contact your Toyota dealer.

n If the coolant level drops within a short time of replenishing

Visually check the radiator, hoses, power control unit coolant reservoir caps and water pump.

If you cannot find a leak, have your Toyota dealer, test the cap and check for leaks in the cooling system.



WARNING

n When the heater system is hot

Do not remove the heater coolant reservoir caps.

The heater system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.



NOTICE

n When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

n If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

Checking the radiator

Check the radiator and clear away any foreign objects.

If either of the above parts is extremely dirty or you are not sure of their condition, have your vehicle inspected by your Toyota dealer.



WARNING

n When the EV system is hot

Do not touch the radiator as they may be hot and cause serious injuries, such as burns.


n When the electric cooling fan is operating

Do not touch the motor compartment.

With the power switch in ON, the electric cooling fan may automatically start to run if the air conditioning is on and/or the coolant temperature is high. Be sure the power switch is off when working near the electric cooling fan or radiator grille.

Checking the power control unit coolant

The coolant level is satisfactory if it is between the “MAX” and “MIN” lines on the reservoir when the EV system is cold.



A Reservoir cap

B “MAX” line

C “MIN” line

If the level is on or below the “MIN” line, add coolant up to the “MAX” line.

n Coolant selection

In order to ensure maximum performance of the traction battery cooling system and limit risks of battery short circuit and other damage to your vehicle, Toyota recommends using “Toyota Genuine Traction Battery Coolant” or similar high-quality ethylene glycol-based, low electric conductivity coolant, non-amine and non-borate coolant with azole additives.

Toyota cannot guarantee that the use of a product other than “Toyota Genuine Traction Battery Coolant” will prevent risks of battery short circuit or other damage.

Never use water as it will cause damage.

Do not reuse coolant that has been removed from the radiator.

For more details about coolant, contact your Toyota dealer.

n If the coolant level drops within a short time of replenishing

Visually check the hoses, heater coolant reservoir caps, drain cock and water pump.

If you cannot find a leak, have your Toyota dealer, test the cap and check for leaks in the cooling system.

! WARNING

n When the EV system is hot

Do not remove the power control unit coolant reservoir caps.

The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.

! NOTICE

n When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.


n If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

Checking and adding the brake fluid

n Checking fluid level

The brake fluid level should be between the “MAX” and “MIN” lines on the tank.



A Reservoir cap

B "MAX" line

C "MIN" line

n Adding fluid

Make sure to check the fluid type and prepare the necessary item.

● Fluid type

FMVSS No.116 DOT 3 or
SAEJ1703 brake fluid

FMVSS No.116 DOT 4 or
SAEJ1704 brake fluid

● Item

Clean funnel

n Brake fluid can absorb moisture from the air

Excess moisture in the brake fluid can cause a dangerous loss of braking efficiency. Use only newly opened brake fluid.

⚠ WARNING

n When filling the reservoir

Take care as brake fluid can harm your hands and eyes and damage painted surfaces.

If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately. If you still experience discomfort, see a doctor.

⚠ NOTICE

n If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear out or when the fluid level in the accumulator is high.


If the reservoir needs frequent refilling, there may be a serious problem.

Checking the 12-volt battery

Check the 12-volt battery as follows.


n 12-volt battery exterior

Make sure that the 12-volt battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



A Terminals**B** Hold-down clamp**n Checking 12-volt battery fluid**

Check that the level is between the “UPPER LEVEL” and “LOWER LEVEL” lines.


**A** “UPPER LEVEL” line**B** “LOWER LEVEL” line

If the fluid level is at or below the “LOWER LEVEL” line, add distilled water.

n Adding distilled water

- 1** Remove the vent plug.
- 2** Add distilled water.

If the “UPPER LEVEL” cannot be seen, check the fluid level by looking directly at the cell.



- 3** Put the vent plug back on and close it securely.

n Before recharging

When recharging, the 12-volt battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following precautions before recharging:

- | If recharging with the 12-volt battery installed on the vehicle, be sure to disconnect the ground cable.
- | Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the 12-volt battery.

n After recharging/reconnecting the 12-volt battery

- | The EV system may not start. Follow the procedure below to initialize the system.
 - 1** Shift the shift position to P.
 - 2** Open and close any of the doors.
 - 3** Restart the EV system.
- | Unlocking the doors using the smart key system may not be possible immediately after reconnecting the 12-volt battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- | Start the EV system with the power switch in ACC*. The EV system may not start with the power switch turned off. However, the EV system will operate normally from the second attempt.
- | The power switch mode is recorded by the vehicle. If the 12-volt battery is disconnected and reconnected, the vehicle will return the power switch mode to the status it was in before the 12-volt battery was disconnected. Make sure to turn off the power switch before disconnecting the 12-volt battery. Take extra care when connecting the 12-volt battery if the power switch mode prior to the 12-volt battery being disconnected is unknown.

If the EV system will not start even after multiple attempts at all the methods above, contact your Toyota dealer.

*: ACC mode can be enabled/disabled on the customize menu. (→P.627)



WARNING

n Chemicals in the 12-volt battery

Batteries contain poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the 12-volt battery:

- l Do not cause sparks by touching the 12-volt battery terminals with tools.
- l Do not smoke or light a match near the 12-volt battery.
- l Avoid contact with eyes, skin and clothes.
- l Never inhale or swallow electrolyte.
- l Wear protective safety glasses when working near the 12-volt battery.
- l Keep children away from the 12-volt battery.

n Where to safely charge the 12-volt battery

Always charge the 12-volt battery in an open area. Do not charge the 12-volt battery in a garage or closed room where there is insufficient ventilation.

n Emergency measures regarding electrolyte

- l If electrolyte gets in your eyes
Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- l If electrolyte gets on your skin
Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- l If electrolyte gets on your clothes
It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- l If you accidentally swallow electrolyte
Drink a large quantity of water or milk. Get emergency medical attention immediately.

n When there is insufficient 12-volt battery fluid

Do not use if there is insufficient fluid in the 12-volt battery. There is a possible danger that the 12-volt battery may explode.



NOTICE

n When recharging the 12-volt battery

Never recharge the 12-volt battery while the EV system is operating. Also, be sure all accessories are turned off.

n When adding distilled water

Avoid overfilling. Water spilled during 12-volt battery recharging may cause corrosion.

Adding the washer fluid

If any washer does not work or the warning message appears on the multi-information display, the washer tank may be empty.

Add washer fluid.



WARNING

n When adding washer fluid

Do not add washer fluid when the EV system is hot or operating as washer fluid contains alcohol and may catch fire if spilled on the motor, etc.

NOTICE

n Do not use any fluid other than washer fluid

Do not use soapy water or anti-freeze instead of washer fluid.

Doing so may cause streaking on the vehicle's painted surfaces, as well as damaging the pump leading to problems of the washer fluid not spraying.

n Diluting washer fluid

Dilute washer fluid with water as necessary.


Refer to the freezing temperatures listed on the label of the washer fluid bottle.

Tires

Replace or rotate tires in accordance with maintenance schedules and treadwear.

Checking tires

Check if the treadwear indicators are showing on the tires. Also check the tires for uneven wear, such as excessive wear on one side of the tread.



A New tread

B Worn tread

C Treadwear indicator

The location of treadwear indicators is shown by a "TWI" or "△" mark, etc., molded into the sidewall of each tire.

Replace the tires if the treadwear

indicators are showing on a tire.

n When to replace your vehicle's tires

Tires should be replaced if:

- | The treadwear indicators are showing on a tire.
- | You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage.
- | A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage.

If you are not sure, consult with your Toyota dealer.

n Tire life


Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.

n Maximum load of tire

Check that the number given by dividing the maximum load by 1.10 of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.

For the GAWR, see the Certification Label.

For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire. (→P.617)



n Tire types

| Summer tires

Summer tires are high-speed perfor-

mance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

| All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions as well as for use year-round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving.

| Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restrictions. Snow tires should be installed on all wheels. (→P.444)

n If the tread on snow tires wears down below 0.16 in. (4 mm)

The effectiveness of the tires as snow tires is lost.

WARNING

n When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- |** Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- |** Do not use tire sizes other than those recommended by Toyota.
- |** Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- |** Do not mix summer, all season and snow tires.
- |** Do not use tires that have been used on another vehicle. Do not use tires if you do not know how they were used previously.
- |** Do not tow anything if a tire that has been repaired using the emergency tire puncture repair kit is installed. The load on the tire may cause unexpected damage to the tire.

NOTICE

n Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes.

These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.


n If tire inflation pressure of each tire becomes low while driving

Do not continue driving, or your tires and/or wheels may be ruined.

Tire rotation

Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Toyota recommends that tire rotation is carried out at the same interval as tire inspection.



A Front

n When rotating the tires

Make sure that the power switch is off. If the tires are rotated while the power switch is in ON, the tire posi-

tion information will not be updated. If this accidentally occurs, either turn the power switch to off and then to ON, or initialize the tire pressure warning system after checking that the tire pressure is properly adjusted.

Tire pressure warning system


Your vehicle is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise.

The tire pressure warning system of this vehicle adopts a 2-type warning system.
(→P.572)

► Multi-information display



► Multimedia display



● When “Adjust Pressure” is displayed (Normal Warning)

A warning with the tire pressure warning light and warning buzzer when there is an unknown level of low tire pressure with the appearance of the tire due to natural air leakage as well as the pressure lowering due to changes in the pressure according to the outside temperature.

● When “Immediately Check tire when Safe” is displayed on the multi-information display (Emergency Warning)

A warning with the tire pressure warning light and warning buzzer when there is a known level of low tire pressure with the appearance of the tire due to pressure suddenly lowering.

However, the system may not be able to detect sudden tire ruptures (bursting, etc.).

● The tire pressure detected by the tire pressure warning system can be displayed on the multi-information display and the multimedia display.

n Routine tire inflation pressure checks

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

n Tire inflation pressure

It may take a few minutes to display the tire inflation pressure after the power switch is turned to ON. It may also take a few min-

utes to display the tire inflation pressure after inflation pressure has been adjusted.

- | Tire inflation pressure changes with temperature. The displayed values may also be different from the values measured using a tire pressure gauge.
- n **Situations in which the tire pressure warning system may not operate properly**
 - | In the following cases, the tire pressure warning system may not operate properly.
 - If non-genuine Toyota wheels are used.
 - A tire has been replaced with a tire that is not an OE (Original Equipment) tire.
 - A tire has been replaced with a tire that is not of the specified size.
 - Tire chains, etc. are equipped.
 - If a window tint that affects the radio wave signals is installed.
 - If there is a lot of snow or ice on the vehicle, particularly around the wheels or wheel housings.
 - If the tire inflation pressure is extremely higher than the specified level.
 - If tires not equipped with tire pressure warning valves and transmitters are used.
 - If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
 - | Performance may be affected in the following situations.
 - Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
 - When carrying a portable radio, cellular phone, cordless phone or other wireless communication device

If tire position information is not correctly displayed due to the radio wave conditions, the display may be corrected by driving and changing the radio wave conditions.

- | When the vehicle is parked, the time taken for the warning to start or go off could be extended.
- | When tire inflation pressure declines rapidly for example when a tire has burst, the warning may not function.

Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. (→P.538)

n When replacing the tires and wheels

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. In this case, after driving for about 10 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.

**NOTICE****n Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps**

I When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact your Toyota dealer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.

I Make sure to install the tire valve caps. If the tire valve caps are not installed, water could enter the tire pressure warning valves and the tire pressure warning valves could be bound.

I When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.

n To avoid damage to the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire.

Registering the position of each wheel**n When to register the position of each wheel**

It is necessary to register the position of each wheel after performing a tire rotation.

Wheel position registration can be performed by oneself. Wheel position registration is performed by driving forward with moderate left and right turns. However, depending on the driving conditions and driving environment, registration may take some time to complete.

n Registering the position of each wheel

1 Park the vehicle in a safe place, turn the power switch off and wait 15 minutes or more.

2 Start the EV system.

The wheel position registration procedure cannot be performed while the vehicle is moving.

3 Select  on the multimedia display.

4 Select "Vehicle customize".

5 Select "Tire pressure".

6 Select "Tire rotation".

7 Select "Continue".

A message indicating that wheel position registration is being performed will be displayed on the multi-information display. "---" will be displayed for the tire inflation pressure of each tire and wheel position registration will begin.

8 Drive straight (with occasional left and right turns) at approximately 25 mph (40 km/h) or more for approximately 10 to 30 minutes.

When wheel position registration is complete, a message indicating

that registration has been completed and the inflation pressure of each tire will be displayed on the multi-information display.

Even if it is not possible to drive continuously at approximately 25 mph (40 km/h) or more, registration can be completed by driving for a long time. However, if registration does not complete after driving for 1 hour or more, park the vehicle in a safe place and leave it with the power switch in ON for approximately 15 minutes or more, and then perform the driving procedure again.

n **When performing wheel position registration**

- | Normally, wheel position registration can be completed within approximately 30 minutes.
- | Wheel position registration is performed while driving at a vehicle speed of approximately 25 mph (40 km/h) or more.

n **Wheel position registration procedure**

- | If the power switch is turned off while registering the wheel position, the next time the power switch is turned to ON, the wheel position registration will resume and it will not be necessary to restart the procedure.
- | While the position of each wheel is being determined and the inflation pressures are not being displayed, if the inflation pressure of a tire drops, the tire pressure warning light will come on.

n **If the wheel position cannot be registered easily**

- | In the following situations, wheel position registration may take longer than usual to be completed or may not be possible.
 - Vehicle is not driven at approximately 25 mph (40 km/h) or more
 - Vehicle is driven on unpaved

roads

- | If wheel position registration does not complete after driving for 1 hour or more, park the vehicle in a safe place for approximately 15 minutes and then drive the vehicle again.
- | If the vehicle is reversed during wheel position registration, all data collected until then will be cleared. Perform driving again.

Setting the tire pressure

n **When you need to setting the tire pressure**

In the following situations, it will be necessary to perform the tire inflation pressure setting procedure of the tire pressure warning system.

- When the specified tire inflation pressure has changed, such as due to carried load, etc.
- When the tire inflation pressure is changed such as when the tire size is changed.

If the tire inflation pressure has been adjusted to the specified level, perform the tire inflation setting procedure by selecting specified inflation pressure on the multimedia display.

(→P.537)

When the tire inflation pressure is to be other than specified, such as when tires other than the specified size are used, etc., set the tire inflation pressure using the current pressure.

Make sure to adjust the tire inflation pressure of each tire to the appropriate level before performing tire pressure setting. The tire pressure warning system operates based on this tire inflation pressure. (→P.537)

n **Setting by selecting a specified tire inflation pressure**

1 Start the EV system.

The tire inflation pressure cannot be set while the vehicle is moving.

2 Select on the multimedia display.

3 Select "Vehicle customize".


4 Select "Tire pressure".

5 Select "Set indicated air pressure" and then select the desired front and rear tire pressures.

6 Select "OK".

The tire pressure warning light will slowly blink 3 times.

After setting the tire inflation pressure, a message indicating that setting has been completed will be displayed on the multi-information display.



n **Setting using the current tire inflation pressure**

1 Adjust the tire inflation pressure of each tire to the appropriate level.

Make sure to adjust the tire inflation pressure with the tires cold.

2 Start the EV system.

The tire inflation pressure cannot be set while the vehicle is moving.

3 Select on the multimedia display.

4 Select "Vehicle customize".


5 Select "Tire pressure".

6 Select "Set current air pressure".

7 Select "Continue".

The tire pressure warning light will slowly blink 3 times and a message indicating that tire inflation pressure is being set will be displayed on the multi-information display.

After setting the tire inflation pressure, a message indicating that setting has been completed will be displayed on the multi-information display.



n **Warning performance of the tire pressure warning system (Setting using the current tire inflation pressure)**

l When performing the tire pressure

setting using the current tire inflation pressure, the warning timing of the tire pressure warning system will vary according to the conditions under which tire pressure setting was performed. Therefore, a warning may be output even if the tire inflation pressure drops slightly or if the tire inflation pressure increases above that when the tire inflation pressure was set.

- I Make sure to perform the tire pressure setting procedure after adjusting the tire inflation pressure. Also, make sure the tires are cold before performing the tire pressure setting procedure or adjusting the tire inflation pressure.

n Tire inflation pressure setting procedure (Setting using the current tire inflation pressure)

- I If the power switch is turned off while setting the tire inflation pressure, the next time the power switch is turned to ON, the setting procedure will resume and it will not be necessary to restart the procedure.

- I If the tire inflation pressure setting procedure is started unnecessarily, adjust the tire inflation pressure to the specified level with the tires cold and then perform setting by selecting a specified tire inflation pressure, or perform the tire inflation pressure setting procedure with the current tire inflation pressure.

n If the tire inflation pressure cannot be set easily

- I Normally, it takes approximately 3 minutes to complete the setting procedure to the current tire inflation pressure.
- I If the tire pressure warning light does not blink 3 times when starting the tire inflation pressure setting procedure, the procedure may not have started. Perform the procedure again from the begin-

ning.

- I If tire inflation pressure setting procedure cannot be completed after performing the above procedure, contact your Toyota dealer.



WARNING

n When setting using the current tire inflation pressure

Make sure to adjust the tire inflation pressure of each tire to the appropriate level before performing tire pressure setting. Otherwise, the tire pressure warning light may not illuminate even if the tire inflation pressure drops or may illuminate even though the tire inflation pressure is normal.

Registering ID codes

n When to register ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer.

n How to registration ID code

Before performing ID code registration, make sure that no wheels with tire pressure warning valve and transmitters installed are near the vehicle.

- 1 Park the vehicle in a safe place, turn the power switch off and wait 15 minutes or more.

- 2 Start the EV system.


The ID code registration procedure

cannot be performed while the vehicle is moving.

- 3 Select  on the multimedia display.
- 4 Select "Vehicle customize".
- 5 Select "Tire pressure".
- 6 Check if the desired wheel set ("Set 1" or "Set 2") is displayed.

ID codes will be registered to the displayed wheel set. To change the wheel set to be registered, select the displayed set, and then select the wheel set you wish to register.

If ID codes have already been registered for that wheel set, the tire pressure warning light will slowly blink 3 times, and a message indicating that change is occurring will be displayed on the multi-information display.



- 7 Select "New tire registration".
- 8 Select "Continue".

The tire pressure warning light will slowly blink 3 times and a message indicating that ID code registration is being performed will be displayed on the multi-information display. Wheel set changing will be canceled and registration will begin.

When registration is being performed, the tire pressure warning light will blink for approximately 1 minute then illuminate and "---" will

be displayed for the inflation pressure of each tire on the multi-information display.

- 9 Drive straight (with occasional left and right turns) at approximately 25 mph (40 km/h) or more for approximately 10 to 30 minutes.

When registration is complete, the tire pressure warning light will turn off and a message indicating that registration has been completed will be displayed on the multi-information display.

Registration may take longer than normal to complete if the vehicle speed cannot be maintained at approximately 25 mph (40 km/h) or more. If registration cannot be completed after driving for 1 hour or more, perform the registration procedure again from the beginning.

- 10 If the tire inflation pressure of the wheel set installed differs from that of the previous set, it will be necessary to perform the tire inflation pressure setting procedure of the tire pressure warning system. (→P.536)

If the specified tire inflation pressure is the same, it will not be necessary to perform the tire inflation pressure setting procedure.

n When registering ID codes

- | Normally, wheel position registration can be completed within approximately 30 minutes.
- | ID code registration is performed while driving at a vehicle speed of approximately 25 mph (40 km/h) or more.
- | ID codes can be registered by yourself, but depending on the driving conditions and driving

environment, registration may take some time to complete.

- | When using a wheel set which all of the ID codes have already been registered, the wheel set can be changed in a short amount of time. (→P.540)

n If ID codes are not registered easily

- | In the following situations, ID code registration may take longer than usual to be completed or may not be possible.
 - When the vehicle has not been parked for approximately 15 minutes or more before being driven
 - Vehicle is not driven at approximately 25 mph (40 km/h) or more
 - Vehicle is driven on unpaved roads
 - Vehicle is driven near other vehicles and system cannot recognize tire pressure warning valve and transmitters of your vehicle over those of other vehicles
 - Wheel with tire pressure warning valve and transmitter installed is inside or near the vehicle
- | If the vehicle is reversed during registration, all data collected until then will be cleared. Perform driving again.
- | If registration does not complete after driving for 1 hour or more, perform the ID code registration procedure again from the beginning.
- | If the tire pressure warning light does not blink 3 times when starting ID code registration procedure, the procedure may not have started. Perform the procedure again from the beginning.
- | If the ID codes cannot be registered even when performing the above procedure, contact your Toyota dealer.

Canceling ID code registration

To cancel ID code registration after it has been started, select “New tire registration” again on the multimedia display.

If ID code registration has been canceled, the tire pressure warning light will turn off.

If the warning light does not turn off, ID code registration may not have been cancelled correctly. To cancel registration, select “New tire registration” again on the multimedia display.

Selecting wheel set

Your vehicle is equipped with a tire pressure warning system with a function to register two sets of ID codes. This allows for registration of a second wheel set, for example a winter set.

- The wheel set can be changed only if a second wheel set has been registered to the system. If a second wheel set has not been registered, “Set 2 (Unregistered)” will be displayed and it will not be possible to change to the selected wheel set.

ID codes can be registered by yourself. (→P.538)

- Only a change between both registered wheel set is possible, mixing between these wheel sets is not supported.

- While registering ID codes, it may not be possible to change between wheel sets normally. Cancel registration before changing between wheel sets.

n Changing ID codes between different wheel sets

- 1 Install the desired wheel set.
- 2 Select  on the multimedia display.
- 3 Select "Vehicle customize".
- 4 Select "Tire pressure".
- 5 Select the wheel set ("Set 1" or "Set 2") displayed for the set selection setting.
- 6 Select the wheel set you wish to register, and then select "OK".


The tire pressure warning light will slowly blink 3 times, a message indicating that change is occurring will be displayed, and the wheel set change will begin.

Wheel set change will begin and the tire pressure warning light will blink for 1 minute and then illuminate. Also, while the change is being performed, "---" will be displayed for the tire inflation pressure of each tire on the multi-information display.

After approximately 2 minutes, the wheel set change will complete, the tire pressure warning light will turn off, and a completion message will be displayed on the multi-information display.

If changing does not complete after approximately 4 minutes, a message indicating that the change could not be completed will be displayed.

Check which wheel set is installed and perform the change procedure again from the beginning.



- 7 If the specified tire inflation pressure of the wheel set installed differs from that of the previous set, it will be necessary to perform the tire inflation pressure setting procedure of the tire pressure warning system. (→P.536)

If the specified tire inflation pressure is the same, it will not be necessary to perform the tire inflation pressure setting procedure.

- 8 Register the position of each wheel. (→P.535)

Replacing the tire

When replacing the tires yourself, prepare the necessary tools and a jack.

If necessary tire replacement seems difficult to perform, contact your Toyota dealer.

Before jacking up the vehicle


- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift position to P.
- Stop the EV system.
- Turn on the emergency flashers.
- Turn off the power back door system. (→P.174)

n Tools

As your vehicle is equipped with an emergency tire puncture repair kit, the following tools for replacing a tire are not included with your vehicle. They can be purchased at your Toyota dealer.

- | Jack
- | Jack handle
- | Wheel nut wrench

Location of the tools



- A** Jack handle*
- B** Wheel nut wrench*
- C** Towing eyelet
- D** Jack*

*: Contact your Toyota dealer for the tools.



WARNING

n Using the tire jack

Observe the following precautions.

Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.

- ! Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- ! Do not use other tire jacks for replacing tires on this vehicle.


- ! Put the jack properly in its jack point.
- ! Do not put any part of your body under the vehicle while it is supported by the jack.
- ! Do not start the EV system or drive the vehicle while the vehicle is supported by the jack.
- ! Do not raise the vehicle while someone is inside.
- ! When raising the vehicle, do not put an object on or under the jack.

⚠ WARNING

- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- When lowering the vehicle, make sure that there is no-one near the vehicle. If there are people nearby, warn them vocally before lowering.

Replacing a flat tire

1 Chock the tires.




Tire	Wheel chock positions
Front left-hand side	Behind the rear right-hand side tire
Front right-hand side	Behind the rear left-hand side tire
Rear left-hand side	In front of the front right-hand side tire
Rear right-hand side	In front of the front left-hand side tire


2 Vehicles with 20-inch tires:
Do not remove the wheel

ornament.
Vehicles with 18-inch tires:
Remove the wheel ornament
using the wrench.

To protect the wheel ornament,
place a rag between the wrench
and the wheel ornament.




3 Slightly loosen the wheel
nuts (one turn).




4 Turn the **A** part of the jack by
hand and place the top of the
jack in the position shown in
the illustration.


► Front




► Rear



- 5** Install the wheel nut wrench in jack handle.




- 6** Raise the vehicle until the tire is slightly raised off the ground.



- 7** Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.



⚠ WARNING**n Replacing a flat tire**

I Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven.

After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.


I Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.

- Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. Remove any oil or grease that has adhered when installing the wheel nuts.
- After replacing a tire, check the tightening torque as soon as possible. If you cannot confirm the tightening torque yourself, have the vehicle inspected by your Toyota dealer.
- Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.
- When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
- If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Toyota dealer.

Installing the tire


- 1** Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, causing the tire to come off.



- 2** Install the tire and loosely tighten each wheel nut by hand by approximately the same amount.


Turn the wheel nuts until the washers come into contact with the disc wheel.



A Washer


B Disc wheel

3 Lower the vehicle.



4 Securely tighten the wheel nuts two or three times in the order shown in the illustration using a wheel nut wrench.


Tightening torque:
76 ft•lbf (103 N•m, 10.5 kgf•m)



5 Stow all the tools.

n Vehicles with 18-inch tires: When reinstalling the wheel ornament

Align the cutout of the wheel ornament with the valve stem as shown in the illustration.




Tire inflation pressure


Make sure to maintain proper tire inflation pressure. Tire inflation pressure should be checked at least once per month. However, Toyota recommends that tire inflation pressure be checked once every two weeks.

Checking the specified tire inflation pressure

The recommended cold tire inflation pressure and tire size are displayed on the tire and loading information label.
(→P.615)



Inspection and adjustment procedure



A Tire valve

B Tire pressure gauge

- 1** Remove the tire valve cap.
- 2** Press the tip of the tire pressure gauge onto the tire valve.
- 3** Read the pressure using the gauge gradations.
- 4** If the tire inflation pressure is not at the recommended level, adjust the pressure. If you add too much air, press the center of the valve to deflate.
- 5** After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.
- 6** Put the tire valve cap back on.

n Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- | Reduced electricity consumption
- | Reduced driving comfort and poor handling
- | Reduced tire life due to wear
- | Reduced safety
- | Damage to the drive train

If a tire needs frequent inflating, have it checked by your Toyota dealer.

n Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- | Check only when the tires are cold.
If your vehicle has been parked for at least 3 hours or has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.
- | Always use a tire pressure gauge. It is difficult to judge if a tire is properly inflated based only on its appearance.
- | It is normal for the tire inflation pressure to be higher after driving as heat is generated in the tire. Do not reduce tire inflation pressure after driving.
- | Never exceed the vehicle capacity weight.
Passengers and luggage weight should be placed so that the vehicle is balanced.

n Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month.

**WARNING****n Proper inflation is critical to save tire performance**

Keep your tires properly inflated. If the tires are not properly inflated, the following conditions may occur which could lead to an accident resulting in death or serious injury:

- | Excessive wear
- | Uneven wear
- | Poor handling
- | Possibility of blowouts resulting from overheated tires
- | Air leaking from between tire and wheel
- | Wheel deformation and/or tire damage
- | Greater possibility of tire damage while driving (due to road hazards, expansion joints, sharp edges in the road, etc.)

**NOTICE****n When inspecting and adjusting tire inflation pressure**

Be sure to put the tire valve caps back on.

If a valve cap is not installed, dirt or moisture may get into the valve and cause an air leak, resulting in decreased tire inflation pressure.

Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause a loss of handling control.

Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width and inset*.

Replacement wheels are available at your Toyota dealer.

*: Conventionally referred to as offset.

Toyota does not recommend using the following:

- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

n When replacing wheels

The wheels of your vehicle are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. (→P.534)

**WARNING****n When replacing wheels**

I Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in a loss of handling control.

I Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

n When installing the wheel nuts

Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage.

In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts.

n Use of defective wheels prohibited

Do not use cracked or deformed wheels.

Doing so could cause the tire to leak air during driving, possibly causing an accident.

**NOTICE****n Replacing tire pressure warning valves and transmitters**

I Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Toyota dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Toyota dealer.

I Ensure that only genuine Toyota wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.

Aluminum wheel precautions

- Use only Toyota wheel nuts and wheel nut wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel bolts are still tight after driving 1000 miles (1600 km).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Toyota genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

Air conditioning filter


The air conditioning filter must be changed regularly to maintain air conditioning efficiency.

Removal method


- 1 Turn the power switch off.

Confirm that the charging connector is not connected.


- 2 Open the front passenger's door.
- 3 While pressing the claw, hold handle **A** and remove the panel.




- 4 Vehicles with footwell lights: Unplug the connector.




- 5 Unlock the filter cover (**A**), pull the filter cover out of the claws (**B**), and remove the filter cover.



- 6 Hold the filter case **A** and remove the lower filter case.




- 7** Hold the filter case **A** and pulldown the upper filter case.




- 8** Hold the filter case **A** and remove the upper filter case.

Dust and dirt (fallen leaves, etc.) may have accumulated within the bottom of the air conditioning unit, so remove it with a vacuum cleaner.



- 9** Remove the air conditioning filter from the upper and lower filter case and replace it with a new one.




Install so that the arrow points to the

rear of the vehicle.

- 10** When installing, reverse the steps listed.

n When installing the filter cover

Slide the recessed part **A** of the filter cover on the upper surface of the upper filter case **B** as shown in the figure, and attach it so that it is lifted toward the insertion part of the cover attachment.



n Checking interval

Inspect and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, early replacement may be required. (For scheduled maintenance information, please refer to the "Owner's Manual Supplement" or "Scheduled Maintenance".)

n If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

n Air conditioning filter with deodorizing function

When fragrances are placed in your vehicle, the deodorizing effect may become significantly weakened in a short period.

When an air conditioning odor comes out continuously, replace the air conditioning filter.

**WARNING****n When replacing the air conditioning filter**

Observe the following precautions. Failure to do so may result in the air conditioning system operating during the procedure, possibly resulting in injury.

Check that the charging connector is not connected.

**NOTICE****n When using the air conditioning system**


Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

The filter is replaceable. When cleaning the filter, do not clean with water or an air gun.

n To prevent damage to the filter cover

When moving the filter cover in the direction of arrow to release the fitting, pay attention not to apply excessive force to the claws. Otherwise, the claws may be damaged.

**Electronic key battery**

Replace the battery with a new one if it is depleted.

As the key may be damaged if the following procedure is not performed properly, it is recommended that key battery replacement be performed by your Toyota dealer.

n If the electronic key battery is depleted

The following symptoms may occur:

- l The smart key system and wireless remote control will not function properly.
- l The operational range will be reduced.

Items to prepare

Prepare the following before replacing the battery:


- Flathead screwdriver
- Small flathead screwdriver
- Lithium battery CR2450

n Use a CR2450 lithium battery

- l Batteries can be purchased at your Toyota dealer, local electrical appliance shops or camera stores.
- l Replace only with the same or equivalent type recommended by the manufacturer.
- l Dispose of used batteries according to the local laws.

Replacing the battery


- 1 Remove the lock and take out the mechanical key.



- 2 Remove the cover.

Use a screwdriver of an appropriate size. Forcedly prying may cause the cover damaged.

To prevent damage to the key, cover the tip of the flathead screwdriver with a tape.




- 3 Remove the depleted battery using a small flathead screwdriver.

When removing the cover, the electronic key module may stick to the cover and the battery may not be visible.

In this case, remove the electronic key module in order to remove the battery.

When removing the battery, use a screwdriver of an appropriate size. Insert a new battery with the “+” terminal facing up.

terminal facing up.



- 4 When installing the key cover and mechanical key, install by conducting step 2 and step 1 with the directions reversed.

! WARNING

n Battery precautions

Observe the following precautions.

Failure to do so may result in death or serious injury.

- ! Do not swallow the battery. Doing so may cause chemical burns.
- ! A coin battery or button battery is used in the electronic key. If a battery is swallowed, it may cause severe chemical burns in as little as 2 hours and may result in death or serious injury.
- ! Keep away new and removed batteries from children.
- ! If the cover cannot be firmly closed, stop using the electronic key and stow the key in the place where children cannot reach, and then contact your Toyota dealer.
- ! If you accidentally swallow a battery or put a battery into a part of your body, get emergency medical attention immediately.

**WARNING**

n To prevent battery explosion or leakage of flammable liquid or gas

- l Replace the battery with a new battery of the same type. If a wrong type of battery is used, it may explode.
- l Do not expose batteries to extremely low pressure due to high altitude or extremely high temperatures.
- l Do not burn, break or cut a battery.

**NOTICE**

n When replacing the battery

Use a flathead screwdriver of appropriate size. Applying excessive force may deform or damage the cover.

n For normal operation after replacing the battery

Observe the following precautions to prevent accidents:

- l Always work with dry hands. Moisture may cause the battery to rust.
- l Do not touch or move any other component inside the remote control.
- l Do not bend either of the battery terminals.

Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

Checking and replacing fuses


1 Turn the power switch off.

Confirm that the charging connector is not connected.

2 Open the fuse box cover.


► **Motor compartment**

Push the tab in and lift the lid off.




► **Left side instrument panel**

Remove the lid.




- 3** Remove the fuse.
Only type A fuse can be removed using the pullout tool.



- 4** Check if the fuse is blown.

Replace the blown fuse with a new fuse of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.


- Type A



- A** Normal fuse

- B** Blown fuse


- Type B



- A** Normal fuse

- B** Blown fuse

- Type C



- A** Normal fuse

- B** Blown fuse

n After a fuse is replaced

- l When installing the lid, make sure that the tab is installed securely.
- l If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement.
- l If the replaced fuse blows again, have the vehicle inspected by your Toyota dealer.

n If there is an overload in a circuit

The fuses are designed to blow, protecting the wiring harness from damage.

n When replacing an electronic component, such as a lights, etc.

Toyota recommends that you use genuine Toyota products designed for this vehicle. Because certain bulbs are connected to circuits designed to prevent overload, non-genuine parts or parts not designed for this vehicle may be unusable.

**WARNING****n To prevent system breakdowns and vehicle fire**


Observe the following precautions.

Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- I** Never use a fuse of a higher amperage rating than that indicated, or use any other object in place of a fuse.
- I** Always use a genuine Toyota fuse or equivalent. Never replace a fuse with a wire, even as a temporary fix.
- I** Do not modify the fuses or fuse boxes.

**NOTICE****n Before replacing fuses**

Have the cause of electrical overload determined and repaired by your Toyota dealer as soon as possible.

Headlight aim**Vertical movement adjusting bolts**

A Adjustment bolt A

B Adjustment bolt B


Before checking the headlight aim

- Park the vehicle on level ground.
- Make sure the tire inflation pressure is at the specified level.
- Have someone sit in the driver's seat.
- Bounce the vehicle several times.

Adjusting the headlight aim


- 1** Using a Phillips-head screwdriver, turn bolt A in either direction.

Remember the turning direction and the number of turns.



- 2** Turn bolt B the same number of turns and in the same direction as step 1.

If the headlight cannot be adjusted using this procedure, take the vehicle to your Toyota dealer to adjust the headlight aim.



Light bulbs

If any exterior light does not turn on, have it replaced by your Toyota dealer.

n LED lights

The lights consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Toyota dealer to have the light replaced.

n Condensation build-up on the inside of the lens

Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction. Contact your Toyota dealer for more information in the following situations:

- l Large drops of water have built up on the inside of the lens.
- l Water has built up inside the headlight.
- n **When replacing an electronic component, such as a lights, etc.**

→P.556

When trouble arises

8

8-1. Essential information

Emergency flashers **560**

If your vehicle has to be
stopped in an emergency
..... **560**

If the vehicle is submerged
or water on the road is ris-
ing **561**

8-2. Steps to take in an emer- gency

If your vehicle needs to be
towed..... **563**

If you think something is
wrong **566**

If a warning light turns on or
a warning buzzer sounds
..... **568**

If a warning message is dis-
played..... **578**

If you have a flat tire.... **585**

If the EV system will not
start..... **596**

If you lose your keys ... **597**

If the electronic key does
not operate properly .. **598**

If the 12-volt battery is dis-
charged **600**

If your vehicle overheats
..... **604**

If the vehicle becomes stuck
..... **606**


Emergency flashers

The emergency flashers are used to warn other drivers when the vehicle has to be stopped on the road due to a breakdown, etc.

Operating instructions

Press the switch.

All the turn signal lights will flash. To turn them off, press the switch once again.



n Emergency flashers

- I If the emergency flashers are used for a long time while the EV system is not operating (while the "READY" indicator is not illuminated), the 12-volt battery may discharge.
- I If any of the SRS airbags deploy (inflate) or in the event of a strong rear impact, the emergency flashers will turn on automatically. The emergency flashers will turn off automatically after operating for approximately 20 minutes. To manually turn the emergency flashers off, press the switch twice. (The emergency flashers may not turn on automatically depending on the force of the impact and conditions of the collision.)


If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

Stopping the vehicle

- 1 Steadily step on the brake pedal with both feet and firmly depress it.
Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.
- 2 Shift the shift position to N.
► If the shift position is shifted to N
- 3 After slowing down, stop the vehicle in a safe place by the road.
- 4 Stop the EV system.
► If the shift position cannot be shifted to N
- 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- 4 To stop the EV system, press and hold the power switch for 2 consecutive seconds or

more, or press it briefly 3 times or more in succession.



- 5 Stop the vehicle in a safe place by the road.

n If emergency stopped

The functions of the air conditioning, etc. may be partially limited in order to reduce the power consumption of the 12-volt battery.



WARNING

n If the EV system has to be turned off while driving

Turning the EV system off while driving will not cause a loss of steering or braking control. However, power assist for the steering wheel may be lost making it difficult to steer smoothly before stopping the vehicle depending on the remaining charge in the 12-volt battery or usage conditions. Decelerate as much as possible before turning off the EV system.

If the vehicle is submerged or water on the road is rising

This vehicle is not designed to be able to drive on roads that are deeply flooded with water. Do not drive on roads where the roads may be submerged or the water may be rising. It is dangerous to remain in the vehicle, if it is anticipated that the vehicle will be flooded or set adrift. Remain calm and follow the following.

- If the door can be opened, open the door and exit the vehicle.
- If the door cannot be opened, open the window using the power window switch and ensure an escape route.
- If the window can be opened, exit the vehicle through the window.
- If the door and window cannot be opened due to the rising water, remain calm, wait until the water level inside the vehicle rises to the point that the water pressure inside of the vehicle equals the water pressure outside of the vehicle and then open the door after waiting for the rising water to enter the vehicle, and exit the vehicle.

When the outside water level exceeds half the height of the door, the door cannot be opened from the inside due to water pressure.

n **Water level exceeds the floor**

When the water level exceeds the floor and time has passed, the electrical equipment will get damaged, the power windows will not operate, the motor stops, and the vehicle may not be able to get moving.

n **Using an emergency escape hammer^{*1}**

Laminated glass^{*2} is used in the windshield and the windows on this vehicle.


Laminated glass cannot be shattered with an emergency hammer^{*1}.

^{*1}: Contact your Toyota dealer or aftermarket accessory manufacturer for further information about an emergency hammer.

^{*2}: If equipped

n **How to distinguish laminated glass**

When looking from the cross-sectional view point, laminated glass is two sheets of glass pasted together.



A Laminated glass

B Tempered glass

! WARNING

n **Caution while driving**

Do not drive on roads where the roads may be submerged or the water may be rising. Otherwise the vehicle may be damaged and cannot move, as well as become flooded and set adrift, which may lead to death.

If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Toyota dealer or commercial towing service, using a wheel-lift type truck or flat-bed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

Situations when it is not possible to be towed by another vehicle

In the following situations, it is not possible to be towed by another vehicle using cables or chains, as the front wheels may be locked due to the parking lock. Contact your Toyota dealer or commercial towing service.

- There is a malfunction in the shift control system. (→P.236, 583)
- There is a malfunction in the immobilizer system. (→P.66)
- There is a malfunction in the smart key system. (→P.598)
- The 12-volt battery is discharged. (→P.600)


Situations when it is necessary to contact dealers before towing

The following may indicate a problem with your transmission. Contact your Toyota dealer or commercial towing service before towing.

- The EV system warning message is shown on the multi-information display and the vehicle does not move.
- The vehicle makes an abnormal sound.


Towing with a wheel-lift type truck

- From the front



Use a towing dolly under the rear wheels.

► From the rear




Use a towing dolly under the front wheels.

! WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

n When towing the vehicle

Be sure to transport the vehicle with all four wheels raised off the ground. If the vehicle is towed with the tires contacting the ground, the drivetrain or related parts may be damaged, the vehicle may fly off the truck, or electricity generated by the operation of the motor may cause a fire to occur depending on the nature of the damage or malfunction.




! NOTICE

n To prevent damage to the vehicle when towing using a wheel-lift type truck

When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.

n Towing with a sling-type truck

Do not tow with a sling-type truck to prevent body damage.



Using a flatbed truck

When using a flatbed truck to transport the vehicle, use tire strapping belts. Refer to the owner's manual of the flatbed truck for the tire strapping method.

In order to suppress vehicle movement during transportation, set the parking brake and turn the power switch off.

Emergency towing

If a tow truck is not available in an emergency, your vehicle may be temporarily towed using cables or chains secured to the emergency towing eyelet. This

should only be attempted on hard surfaced roads for short distances at under 18 mph (30 km/h).


A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.

Emergency towing procedure


To have your vehicle towed by another vehicle, the towing eyelet must be installed to your vehicle. Install the towing eyelet using the following procedure.

- 1 Take out the towing eyelet. (→P.586)
- 2 Remove the eyelet cover using a flathead screwdriver.


To protect the bodywork, place a rag between the screwdriver and the vehicle body as shown in the illustration.



- 3 Insert the towing eyelet into the hole and tighten partially by hand.



- 4 Tighten down the towing eyelet securely using a wheel bolt wrench or hard metal bar.



- 5 Securely attach cables or chains to the towing eyelet.

Take care not to damage the vehicle body.

- 6 Enter the vehicle being towed and start the EV system.

If the EV system does not start, turn the power switch to ON.

- 7 Shift the shift position to N and release the parking brake.

Turn automatic mode off. (→P.246)

n While towing

If the EV system is off, the power assist for the brakes and steering

will not function, making steering and braking more difficult.

n Wheel nut wrench

Wheel nut wrench can be purchased at your Toyota dealer.



WARNING

Observe the following precautions. Failure to do so may result in death or serious injury.

n While towing

I When towing using cables or chains, avoid sudden starts, etc., which place excessive stress on the towing eyelet, cables or chains. The towing eyelet, cables or chains may become damaged, broken debris may hit people, and cause serious damage.

I Do not perform any of the following as doing so may cause the parking lock mechanism to engage, locking the front wheels and possibly leading to an accident resulting in death or serious injury:

- Unfasten the driver's seat belt and open the driver's door.
- Turn the power switch off.

n Installing towing eyelets to the vehicle

Make sure that towing eyelets are installed securely. If not securely installed, towing eyelets may come loose during towing.



NOTICE

n To prevent damage to the vehicle during emergency towing

Do not secure cables or chains to the suspension components.

If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Toyota dealer as soon as possible.

Visible symptoms

- Fluid leaks under the vehicle (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear

Audible symptoms

- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Other noises related to the EV system

Operational symptoms

- Stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness,

spongy feeling, pedal almost
touches the floor

If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Toyota dealer.

Actions to the warning lights or warning buzzers

n Brake system warning light (warning buzzer)

Warning light	Details/Actions
<div>The image shows two square warning light icons. The top one is black with the word "BRAKE" in white capital letters, with "(U.S.A.)" below it. The bottom one is red with a white exclamation mark inside a circle, with "(Red)" and "(Canada)" below it.</div>	<p>Indicates that:</p> <ul style="list-style-type: none">● The brake fluid level is low; or● The brake system is malfunctioning <p>→ Immediately stop the vehicle in a safe place and contact your Toyota dealer. Continuing to drive the vehicle may be dangerous.</p>

n Brake system warning light (warning buzzer)

Warning light	Details/Actions
<div>The image shows a yellow square warning light icon with a black exclamation mark inside a circle.</div>	<p>Indicates a malfunction in:</p> <ul style="list-style-type: none">● The regenerative braking system;● The electronically controlled brake system; or● The parking brake system <p>→ Have the vehicle inspected by your Toyota dealer immediately.</p>

n Charging system warning light*

Warning light	Details/Actions
<div>The image shows a black square warning light icon with a white battery symbol (a rectangle with a minus sign on the left and a plus sign on the right).</div>	<p>Indicates a malfunction in the vehicle's charging system</p> <p>→ Immediately stop the vehicle in a safe place and contact your Toyota dealer.</p>

*: This light illuminates on the multi-information display.

n EV system malfunction indicator lamp (warning buzzer)

Warning light	Details/Actions
	<p>Indicates a malfunction in the EV system</p> <p>→ Immediately stop the vehicle in a safe place and contact your Toyota dealer.</p>

n SRS warning light (warning buzzer)

Warning light	Details/Actions
	<p>Indicates a malfunction in:</p> <ul style="list-style-type: none"> ● The SRS airbag system; or ● The front passenger occupant classification system; or ● The seat belt pretensioner system <p>→ Have the vehicle inspected by your Toyota dealer immediately.</p>

n ABS warning light (warning buzzer)

Warning light	Details/Actions
<p>ABS (U.S.A.) or</p> <p> (Canada)</p>	<p>Indicates a malfunction in:</p> <ul style="list-style-type: none"> ● The ABS; or ● The brake assist system <p>→ Have the vehicle inspected by your Toyota dealer immediately.</p>

n Inappropriate pedal operation warning light* (warning buzzer)

Warning light	Details/Actions
	<p>When a buzzer sounds:</p> <p>Indicates a malfunction in:</p> <ul style="list-style-type: none"> ● Brake Override System is malfunctioning ● Drive-Start Control is malfunctioning ● Drive-Start Control is operating <p>→ Follow the instructions displayed on the multi-information display.</p> <p>When a buzzer does not sound:</p> <p>Brake Override System is operating</p> <p>→ Release the accelerator pedal and depress the brake pedal.</p>

*: This light illuminates on the multi-information display.

n **Electric power steering system warning light (warning buzzer)**

Warning light	Details/Actions
 (Red) or  (Yellow)	Indicates a malfunction in the EPS (Electric Power Steering) system → Have the vehicle inspected by your Toyota dealer immediately.

n **Traction battery charge warning light**

Warning light	Details/Actions
 (Yellow)	Indicates that the remaining charge of the traction battery is low and charging is required When the outside temperature is low, this light may turn on earlier than usual to urge the driver to charge the traction battery early. → Charge the traction battery. (→P.87)

n **Seat belt reminder light (Driver's and front passenger's (warning buzzer)*)**

Warning light	Details/Actions
 (Type A)	Warns the driver and/or front passenger to fasten their seat belts → Fasten the seat belt. If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.

*: Driver's seat belt warning buzzer:

The driver's seat belt warning buzzer sounds to alert the driver that his or her seat belt is not fastened. Once the power switch is turned to ON, the buzzer sounds. If the seat belt is still unfastened, the buzzer sounds intermittently for a certain period of time after the vehicle reaches a certain speed.

Front passenger's seat belt warning buzzer:

The front passenger's seat belt warning buzzer sounds to alert the front

passenger that his or her seat belt is not fastened. If the seat belt is unfastened, the buzzer sounds intermittently for a certain period of time after the vehicle reaches a certain speed.

n **Seat belt reminder light (Rear passengers') (warning buzzer)***

Warning light	Details/Actions
 (Type A)	Warns the rear passengers to fasten their seat belts → Fasten the seat belt.

*: Rear passengers' seat belt warning buzzer:

The rear passengers' seat belt warning buzzer sounds to alert the rear passenger that his or her seat belt is not fastened. If the seat belt is unfastened, the buzzer sounds intermittently for a certain period of time, after the seat belt is fastened and unfastened and the vehicle reaches a certain speed.

n **Seat belt reminder light (Driver's and front passenger's) (warning buzzer)***

Warning light	Details/Actions
 (Type B)	Warns the driver and/or passenger to fasten their seat belts → Fasten the seat belt. If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.

*: Driver's seat belt warning buzzer:

The driver's seat belt warning buzzer sounds to alert the driver that his or her seat belt is not fastened. Once the power switch is turned to ON, the buzzer sounds. If the seat belt is still unfastened, the buzzer sounds intermittently for a certain period of time after the vehicle reaches a certain speed.

Front passenger's seat belt warning buzzer:

The front passenger's seat belt warning buzzer sounds to alert the front passenger that his or her seat belt is not fastened. If the seat belt is unfastened, the buzzer sounds intermittently for a certain period of time after the vehicle reaches a certain speed.

n **Seat belt reminder light (Rear passengers’)***

Warning light	Details/Actions
	Warns the driver and/or passenger to fasten their seat belts → Fasten the seat belt.

*: Rear passengers’ seat belt warning buzzer:

The rear passengers’ seat belt warning buzzer sounds to alert the rear passenger that his or her seat belt is not fastened. While the shift position is in a position other than P, if a rear passenger seat belt that was fastened is then unfastened, the buzzer sounds for a certain period of time.

n **Tire pressure warning light**

Warning light	Details/Actions
	When the light comes on after blinking for approximately 1 minute (a buzzer does not sound): Malfunction in the tire pressure warning system → Have the system checked by your Toyota dealer. When the light comes on (a buzzer sounds): Low tire inflation pressure from natural causes → After the temperature of the tires has lowered sufficiently, check the inflation pressure of each tire and adjust them to the specified level. (→P.615) Low tire inflation pressure from flat tire → Immediately stop the vehicle in a safe place and perform the necessary actions (→P.575)

n **PCS warning light (warning buzzer)**

Warning light	Details/Actions
	Indicates a malfunction in the PCS (Pre-Collision System). → Follow the instructions displayed on the multi-information display. If the PCS (Pre-Collision System) or VSC (Vehicle Stability Control) system is disabled, the PCS warning light will illuminate.

n **LTA indicator (warning buzzer)**

Warning light	Details/Actions
 (Yellow)	Indicates a malfunction in the LTA (Lane Tracing Assist). → Follow the instructions displayed on the multi-information display.

n **LDA indicator (warning buzzer)**

Warning light	Details/Actions
 (Yellow)	Indicates a malfunction in the LDA (Lane Departure Alert). → Follow the instructions displayed on the multi-information display.

n **PDA indicator (warning buzzer)**

Warning light	Details/Actions
 (Yellow)	Indicates a malfunction in the PDA (Proactive Driving Assist). → Follow the instructions displayed on the multi-information display.

n **Dynamic radar cruise control indicator (warning buzzer)**

Warning light	Details/Actions
 (Yellow)	Indicates a malfunction in the dynamic radar cruise control. → Follow the instructions displayed on the multi-information display.

n **Cruise control indicator (warning buzzer)**

Warning light	Details/Actions
 (Yellow)	Indicates a malfunction in the cruise control. → Follow the instructions displayed on the multi-information display.

n Driving assist information indicator

Warning light	Details/Actions
	<p>The following systems may be malfunctioning.</p> <ul style="list-style-type: none">● PCS (Pre-Collision System)● LDA (Lane Departure Alert) <p>→ Follow the instructions displayed on the multi-information display.</p> <p>Indicates any of the following systems are malfunctioning, disabled, or turned off.</p> <ul style="list-style-type: none">● PKSB (Parking Support Brake)● RCD (Rear Camera Detection)● BSM (Blind Spot Monitor)● RCTA (Rear cross traffic alert)● Safe Exit Assist <p>→ Follow the instructions displayed on the multi-information display.</p>

n Intuitive parking assist OFF indicator (warning buzzer)

Warning light	Details/Actions
	<p>When a buzzer sounds:</p> <p>Indicates a malfunction in the intuitive parking assist function</p> <p>→ Have the vehicle inspected by your Toyota dealer.</p> <p>When a buzzer does not sound:</p> <p>Indicates that the system is temporarily unavailable, possibly due to a sensor being dirty or covered with ice, etc.</p> <p>→ Follow the instructions displayed on the multi-information display. (→P.581)</p>

n Slip indicator

Warning light	Details/Actions
	<p>Indicates a malfunction in:</p> <ul style="list-style-type: none">● The VSC system;● The TRAC system;● The Trailer Sway Control;● The hill-start assist control system <p>→ Have the vehicle inspected by your Toyota dealer immediately.</p>

n Brake hold operated indicator

Warning light	Details/Actions
 (Flashes)	Indicates a malfunction in the brake hold system → Have the vehicle inspected by your Toyota dealer immediately.

n Parking brake indicator

Warning light	Details/Actions
 (Flashes) (U.S.A.) or  (Flashes) (Canada)	It is possible that the parking brake is not fully engaged or released → Operate the parking brake switch once again. This light comes on the parking brake is not released. If the light turns off after the parking brakes is fully released, the system is operating normally.

n Warning buzzer

In some cases, the buzzer may not be heard due to being in a noisy location or audio sound.

n Front passenger detection sensor, seat belt reminder and warning buzzer

- l If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.
- l If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

n SRS warning light

This warning light indicates problems with the following:

- l Airbag sensor assembly
- l Front impact sensors
- l Side impact sensors (front door)

- l Side impact sensors (front)
- l Front passenger occupant classification sensors
- l Driver's seat position sensor
- l Front passenger's seat belt buckle switch
- l SRS warning light
- l "AIR BAG ON" indicator light
- l "AIR BAG OFF" indicator light
- l SRS airbags
- l SRS system related wiring harnesses and power sources

n Electric power steering system warning light (warning buzzer)

When the 12-volt battery charge becomes insufficient or the voltage temporarily drops, the electric power steering system warning light may come on and the warning buzzer may sound.

n When the tire pressure warning light comes on

Inspect the tires to check if a tire is punctured.

If a tire is punctured: →P.585

If none of the tires are punctured:
Turn the power switch off then turn it to ON. Check if the tire pressure warning light comes on or blinks.

- ▶ If the tire pressure warning light blinks for approximately 1 minute then stays on

There may be a malfunction in the tire pressure warning system. Have the vehicle inspected by your Toyota dealer immediately.

- ▶ If the tire pressure warning light comes on

- 1 After the temperature of the tires has lowered sufficiently, check the inflation pressure of each tire and adjust them to the specified level.
- 2 If the warning light does not turn off even after several minutes have elapsed, check that the inflation pressure of each tire is at the specified level and perform the tire inflation pressure setting procedure. (→P.536)

If the warning light does not turn off even after several minutes have elapsed since performing the tire inflation pressure setting procedure, have the vehicle inspected by your Toyota dealer as soon as possible.

n The tire pressure warning light may come on due to natural causes

The tire pressure warning light may come on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

n Conditions that the tire pressure warning system may not function properly

→P.533



WARNING

n If both the ABS and the brake system warning lights remain on

Stop your vehicle in a safe place immediately and contact your Toyota dealer.

The vehicle will become extremely unstable during braking, and the ABS system may fail, which could cause an accident resulting in death or serious injury.

n When the electric power steering system warning light comes on

When the light comes on yellow, the assist to the power steering is restricted. When the light comes on red, the assist to the power steering is lost and handling operations of the steering wheel become extremely heavy.

When steering wheel operations are heavier than usual, grip the steering wheel firmly and operate it using more force than usual.

n If the tire pressure warning light comes on

Be sure to observe the following precautions.

Failure to do so could cause a loss of vehicle control and result in death or serious injury.

- I Stop your vehicle in a safe place as soon as possible. Adjust the tire inflation pressure immediately.

- I If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If a tire is flat, repair the flat tire by using emergency tire puncture repair kit.

 WARNING

I Avoid abrupt maneuvering and braking.
If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes.

n If a blowout or sudden air leakage should occur

The tire pressure warning system may not activate immediately.

n Maintenance of the tires

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency (for electric vehicles, traction battery efficiency) and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.



NOTICE

n To ensure the tire pressure warning system operates properly

Do not install tires with different specifications or makers, as the tire pressure warning system may not operate properly.

If a warning message is displayed

The multi-information display shows warnings of system malfunctions, incorrectly performed operations, and messages that indicate a need for maintenance. When a message is shown, perform the correction procedure appropriate to the message.

If a warning message is displayed again after the appropriate actions have been performed, contact your Toyota dealer.

Additionally, if a warning light comes on or flashes at the same time that a warning message is displayed, take the appropriate corrective action for the warning light. (→P.568)

n Warning messages

The warning messages explained below may differ from the actual messages according to operation conditions and vehicle specifications.

n Warning buzzer

In some cases, the buzzer may not be heard due to being in a noisy location or audio sound.

n If “Traction Battery Temperature Very High Stop in a Safe Place Now and Exit the Vehicle” is displayed

This message may be displayed if

the traction battery temperature becomes extremely high. Immediately stop the vehicle in a safe place, exit the vehicle, and contact your Toyota dealer.

n If “EV System Stopped Steering Power Low” is displayed

This message is displayed if the EV system is stopped while driving.

When steering wheel operations are heavier than usual, grip the steering wheel firmly and operate it using more force than usual.

n If “EV System overheated Output power reduced” is displayed

This message may be displayed when driving under severe operating conditions. (For example, when driving up a long steep hill.)

Handling method: →P.604

n If “Shift System Malfunction Shifting Unavailable Drive to a Safe Place and Stop” or “Shift System Malfunction Driving Unavailable” is displayed

There is a malfunction in the shift control system. Have the vehicle inspected by your Toyota dealer immediately.

n If “Shift is in N Release Accelerator Before Shifting” is displayed

The accelerator pedal has been depressed when the shift position is in N.

Release the accelerator pedal and shift the shift position to D or R.

n If “Press brake when vehicle is stopped EV system may overheat” is displayed

The message may be displayed when the accelerator pedal is depressed to hold the vehicle while the vehicle is stopped on an incline, etc. The EV system may overheat. Release the accelerator pedal and depress the brake pedal.

n If “Auto Power OFF to Conserve Battery” is displayed

Power was turned off due to the automatic power off function. Next time when starting the EV system, operate the EV system for approximately 5 minutes to recharge the 12-volt battery.

n If “Regenerative braking limited. Press brake to decelerate.” is displayed

Regenerative braking may be restricted in the following situations. Firmly depress the brake pedal to decelerate the vehicle.

- l When electrical energy cannot be regenerated any more as the traction battery is fully charged
- l When the temperature of the traction battery is extremely high or extremely low
- l When the temperature of the electric motor or power control unit, etc., is extremely high

n If “High Power Consumption Power to Climate Temporarily Limited” is displayed

Turn off unnecessary electronic equipment to reduce power consumption.

Please wait until the power supply returns to normal.

n If “Headlight System Malfunction Visit Your Dealer” is displayed

The following systems may be malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

- l The LED headlight system
- l AHB (Automatic High Beam)

n If “Maintenance Required Soon” is displayed

Indicates that all maintenance according to the driven distance on the maintenance schedule* should be performed soon.

Comes on approximately 4500 miles (7200 km) after the message has been reset.

If necessary, perform maintenance.

Please reset the message after the maintenance is performed.

(→P.515)

*: Refer to the separate “Scheduled Maintenance Guide” or “Owner’s Manual Supplement” for the maintenance interval applicable to your vehicle.

n If “Maintenance Required Visit Your Dealer” is displayed

Indicates that all maintenance is required to correspond to the driven distance on the maintenance schedule*.

Comes on approximately 5000 miles (8000 km) after the message has been reset. (The indicator will not work properly unless the message has been reset.)

Perform the necessary maintenance.

Please reset the message after the maintenance is performed.

(→P.515)

*: Refer to the separate “Scheduled Maintenance Guide” or “Owner’s Manual Supplement” for the maintenance interval applicable to your vehicle.

n If “Parking Assist Unavailable Sensor Blocked” is displayed

A sensor may be covered with water drops, ice, snow, dirt, etc. Remove the water drops, ice, snow, dirt, etc., from the sensor to return the system to normal.

Also, due to ice forming on a sensor at low temperatures, a warning message may be displayed or the sensor may not be able to detect an object. Once the ice melts, the system will return to normal.

If a sensor is dirty, the position of the dirty sensor will be shown on the display.

If an abnormality is displayed even though there are no water drops, ice, snow or dirt, the sensor may be operating abnormally. Have the vehicle inspected by your Toyota dealer.

n If “Parking Assist Unavailable Low Visibility See Owner’s Manual” is displayed

Indicates one of the following systems is disabled.

l  RCD (Rear Camera Detection)

l  PKSB (Parking Support Brake)

Remove any dirt or foreign matter from the rear camera.

n If “System Stopped Check Side Mirror Status Reopen Side Mirrors” is displayed

PKSB is temporarily unavailable because the outside rear view mirrors are folded. Extend the outside rear view mirrors. If the 12-volt battery was discharged or has been removed and installed, fold and extend the outside rear view mirrors.

n If “System Malfunction Visit Your Dealer” is displayed

Indicates one of the following systems is disabled.

l  PCS (Pre-Collision System)

l  LDA (Lane Departure Alert)

l  LTA (Lane Tracing Assist)

l  LCA (Lane Change Assist) (if equipped)

l  AHB (Automatic High Beam)

l  Dynamic radar cruise control

l  RSA (Road Sign Assist) (if

equipped)

|  PDA (Proactive Driving Assist)

|  BSM (Blind Spot Monitor)

|  RCTA (Rear Cross Traffic Alert)

|  Safe Exit Assist

|  Intuitive parking assist

|  PKSB (Parking Support Brake)

|  RCD (Rear Camera Detection)

Have the vehicle inspected by Toyota dealer immediately.

n If “System Stopped See Owner’s Manual” is displayed

Indicates one of the following systems is disabled.

Check the displayed icon, and follow the following correction methods.

|  PCS (Pre-Collision System)

|  LDA (Lane Departure Alert)

|  LTA (Lane Tracing Assist)

|  LCA (Lane Change Assist) (if equipped)

|  AHB (Automatic High Beam)

|  Dynamic radar cruise control

|  RSA (Road Sign Assist) (if equipped)

|  PDA (Proactive Driving Assist)

|  BSM (Blind Spot Monitor)

|  RCTA (Rear Cross Traffic Alert)

|  Safe Exit Assist

|  Intuitive parking assist

|  PKSB (Parking Support Brake)

|  RCD (Rear Camera Detection)

Follow the following correction methods.

- Check the voltage of the 12-volt battery
- Check the sensors that the Toyota Safety Sense 3.0 uses for foreign matter covering them. Remove them if any. (→P.264)
- Check if the back door is open.
- Check the situations in which the sensors may not operate properly, and improve the situation if applicable. (→P.339, 343, 347, 354, 358)
- Check the sensors including camera sensors for foreign matter covering them. Remove them if any. (→P.344)
- Check if there is any foreign matter attached to the rear bumper near the radar sensor and remove it if there is. (→P.336)
- When problems are solved and the sensors are operational, this indication may disappear by itself.

n If “System Stopped Front Camera Low Visibility See Owner’s Manual” is displayed

Indicates one of the following systems is disabled.

|  PCS (Pre-Collision System)

|  LDA (Lane Departure Alert)

|  LTA (Lane Tracing Assist)

|  LCA (Lane Change Assist) (if equipped)

|  AHB (Automatic High Beam)

|  Dynamic radar cruise control

|  RSA (Road Sign Assist) (if

equipped)

- l  PDA (Proactive Driving Assist)

Follow the following correction methods.

- Using the windshield wipers, remove the dirt or foreign matter from the windshield.
- Using the air conditioning system, defog the windshield.
- Close the hood, remove any stickers, etc. to clear the obstruction in front of the front camera.

- n **If “System Stopped Front Camera Out of Temperature Range Wait until Normal Temperature” is displayed**

Indicates one of the following systems is disabled.

- l  PCS (Pre-Collision System)
- l  LDA (Lane Departure Alert)
- l  LTA (Lane Tracing Assist)
- l  LCA (Lane Change Assist) (if equipped)
- l  AHB (Automatic High Beam)
- l  Dynamic radar cruise control
- l  RSA (Road Sign Assist) (if equipped)
- l  PDA (Proactive Driving Assist)

Follow the following correction methods.

- If the front camera is hot, such as after the vehicle is parked in the sun, use the air conditioning system to decrease the temperature around the front camera
- If a sunshade was used when the vehicle was parked, depending on its type, the sunlight reflected from the surface of the sunshade may cause the temperature of the front camera to become excessively

high

- If the front camera is cold, such as after the vehicle is parked in an extremely cold environment, use the air conditioning system to increase the temperature around the front camera

- n **If “System Stopped Front Radar Sensor Blocked Clean Radar Sensor” is displayed**

Indicates one of the following systems is disabled.

- l  PCS (Pre-Collision System)
- l  LTA (Lane Tracing Assist)
- l  LCA (Lane Change Assist) (if equipped)
- l  Dynamic radar cruise control
- l  PDA (Proactive Driving Assist)

Follow the following correction methods.

- Check if there is any foreign matter attached to the radar sensor or radar sensor cover and clean them if necessary (→P.265)
- This message may be displayed when driving in an open area with few nearby vehicles or structures, such as a desert, grasslands, suburbs, etc.
The message may be cleared by driving the vehicle in an area with structures, vehicles, etc., nearby.

- n **If “System Stopped Front Radar Sensor Out of Temperature Range Wait until Normal Temperature” is displayed**

Indicates one of the following systems is disabled.

- l  PCS (Pre-Collision System)
- l  LTA (Lane Tracing Assist)
- l  LCA (Lane Change Assist) (if equipped)

- l  Dynamic radar cruise control
- l  PDA (Proactive Driving Assist)

The temperature of the radar sensor is outside of the operating range. Wait for the temperature to become appropriate.

- n **If “System Stopped Front Radar In Self Calibration See Owner’s Manual” is displayed**

Indicates one of the following systems is disabled.

- l  PCS (Pre-Collision System)
- l  LTA (Lane Tracing Assist)
- l  LCA (Lane Change Assist) (if equipped)
- l  Dynamic radar cruise control
- l  PDA (Proactive Driving Assist)

Follow the following correction methods.

- Check if there is any foreign matter attached to the radar sensor or radar sensor cover and clean them if necessary (→P.265)
- The radar sensor may be misaligned and will be adjusted automatically while driving. Continue driving for a while.

- n **If “Unavailable Activation Condition not Satisfied See Owner’s Manual” is displayed (if equipped)**

 The LCA function cannot be used as the operating conditions have not been met. (→P.290)

Operate the turn signal lever again after all of the operating conditions are met.

- n **If “Cruise Control Unavailable See Owner’s Manual” is displayed**

Indicates one of the following systems is disabled.

- l Dynamic radar cruise control
- l Cruise control

A message is displayed when the driving assist switch is pushed repeatedly.

Press the driving assist switch quickly and firmly.

- n **If “Driver Monitor Out of Temperature Range Wait until Normal Temperature” is displayed**

Indicates one of the following systems is disabled.

- l Driver monitor
- l Traffic Jam Assist (if equipped)

The temperature of the driver monitor camera is outside of the operating range. Wait for the temperature to become appropriate.

- n **If “Driver Monitor Unavailable See Owner’s Manual” is displayed**

The lens of the driver monitor camera may be dirty.

When there is dirt on the camera lens, clean it with a dry, soft cloth so as to not damage it.

- n **If a message that indicates the need for visiting your Toyota dealer is displayed**

The system or part shown on the multi-information display is malfunctioning. Have the vehicle inspected by your Toyota dealer immediately.

- n **If a message that indicates the need for the rotary shifter operation is displayed**

To prevent the rotary shifter from being operated incorrectly or the vehicle from moving unexpectedly, a message that requires shifting the shift position may be displayed on the multi-information display. In that case, follow the instruction of the message and shift the shift position.

n If a message that indicates the need for referring to Owner's Manual is displayed

- | If any of the following messages are shown on the multi-information display, follow the instructions.
 - "Check Charging System Close Charging Port Lid" (→P.124)
 - "Charging system malfunction" (→P.124)
 - "Charging stopped High energy use" (→P.124)
- | If any of the following messages are shown on the multi-information display, it may indicate a malfunction. Have the vehicle inspected by your Toyota dealer immediately.
 - "Smart Key System malfunction See owner's manual"
 - "Traction battery system malfunction"
 - "Accelerator system malfunction"
 - "Plug-in Charging System Malfunction"
 - "EV system malfunction"
 - "Shift System Malfunction Apply Parking Brake Securely When Parking See Owner's Manual"
 - "Shift System Malfunction See Owner's Manual"
 - "Shift System Malfunction Stop in a Safe Place See Owner's Manual"
 - "P Switch Malfunction Apply Parking Brake Securely When Parking See Owner's Manual"
 - "Shift System Unavailable Apply Parking Brake Securely When Parking See Owner's Manual"
 - "Battery Low Shifting Unavailable See Owner's Manual"
- | If any of the following messages are shown on the multi-information display, it may indicate a malfunction. Immediately stop the vehicle and contact your Toyota dealer.
 - "Braking Power Low"



NOTICE

n If "High Power Consumption Power to Climate Temporarily Limited" is displayed frequently

There is a possible malfunction relating to the charging system or the 12-volt battery may be deteriorating. Have the vehicle inspected by your Toyota dealer.

n If "Battery Low" is displayed frequently

The 12-volt battery may have deteriorated. As the battery may discharge in this state when left unattended, have the vehicle inspected by your Toyota dealer.

n If "Maintenance Required For Traction Battery At Your Dealer" is shown

The traction battery is scheduled to be inspected or replaced. Have the vehicle inspected by your Toyota dealer immediately.

| Continuing to drive the vehicle without having the traction battery inspected will cause the EV system not to start.

| If the EV system does not start, contact your Toyota dealer immediately.

If you have a flat tire

Your vehicle is not equipped with a spare tire, but instead is equipped with an emergency tire puncture repair kit.

A puncture caused by a nail or screw passing through the tire tread can be repaired temporarily with the emergency tire puncture repair kit.

(The kit contains a bottle of sealant. The sealant can be used only once to temporarily repair one tire without removing the nail or screw from the tire.) Depending on the damage condition of the flat tire, it may not be able to be repaired with the emergency tire puncture repair kit.

After temporarily repairing the tire with the kit, have the tire repaired or replaced by your Toyota dealer.



WARNING

n If you have a flat tire

Do not continue driving with a flat tire.


Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

Before repairing the vehicle

- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift position to P.
- Stop the EV system.
- Turn on the emergency flashers.
- Check the degree of the tire damage.

A tire should only be repaired with the emergency tire puncture repair kit if the damage is caused by a nail or screw passing through the tire tread.

- Do not remove the nail or screw from the tire. Removing the object may widen the opening and make emergency repair with the repair kit impossible.
- To avoid sealant leakage, move the vehicle until the area of the puncture, if known, is positioned at the top of the tire.




n A flat tire that cannot be repaired with the emergency tire puncture repair kit

In the following cases, the tire cannot be repaired with the emergency tire puncture repair kit. Contact your Toyota dealer.

- | When the tire is damaged due to driving without sufficient air pressure
- | When there are any cracks or damage at any location on the tire, such as on the side wall,
- | When the tire is visibly separated from the wheel
- | When the cut or damage to the tread is 0.16 in. (4 mm) long or more
- | When the wheel is damaged
- | When two or more tires have been punctured
- | When more than one sharp objects such as nails or screws have passed through the tread on a single tire

except the tread

Location of the emergency tire puncture repair kit and tools




A Towing eyelet

B Emergency tire puncture repair kit


Emergency tire puncture repair kit components

► Bottle



A Sticker

► Compressor



A Air pressure gauge

B Compressor switch

C Power plug

D Hose

E Air release cap

n Emergency tire puncture repair kit

The sealant stored in the emergency tire puncture repair kit can be used only once to temporarily repair a single tire. If the sealant in the bottle and other parts of the kit have been used and need to be replaced, contact your Toyota dealer.

The compressor can be used repeatedly.

The sealant can be used when the outside temperature is from -40°F (-40°C) to 140°F (60°C).

The kit is exclusively designed for size and type of tires originally installed on your vehicle. Do not use it for tires that a different size than the original ones, or for any other purposes.

If the sealant gets on your clothes, it may stain.

If the sealant adheres to a wheel or the surface of the vehicle body, the stain may not be removable if it is not cleaned at once. Immediately wipe away the sealant with a wet cloth.

During operation of the kit, a loud operation noise is produced. This does not indicate a malfunction.

Do not use to check or to adjust the tire pressure.

n Note for checking the emergency tire puncture repair kit

Check the sealant expiry date occasionally. The expiry date is shown on the bottle.

Do not use sealant whose expiry date has already passed. Otherwise, repairs conducted using the emergency tire puncture repair kit may not be performed properly.

The sealant has a limited life span. The expiry date is marked on the bottle. The sealant should be replaced before the expiry

date. Contact your Toyota dealer for replacement.

WARNING

n If you have a flat tire

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair.

Driving with a flat tire may cause a circumferential groove on the side wall. In such a case, the tire may explode when using a repair kit.

n Caution while driving

I Store the repair kit in the luggage compartment. Injuries may result in the event of an accident or sudden braking.

I The repair kit is exclusively only for your vehicle. Do not use repair kit on other vehicles, which could lead to an accident causing death or serious injury.

I Do not use repair kit for tires that are different size than the original ones, or for any other purpose. If the tires have not been completely repaired, it could lead to an accident causing death or serious injury.


n Precautions for use of the sealant

I Ingesting the sealant is hazardous to your health. If you ingest sealant, consume as much water as possible, then immediately consult a doctor.


I If sealant gets in eyes or adheres to skin, immediately wash it off with water. If discomfort persists, consult a doctor.

Taking out the emergency tire puncture repair kit


1 Open the deck board.



2 Lift the deck mat up and remove it.



3 Take out the emergency tire puncture repair kit.



1 Compressor


2 Bottle

Emergency repair procedure

- 1 Take out the repair kit from the plastic bag.

Attach the sticker enclosed with the bottle on the specified locations. (See step10.)


- 2 Remove the hose and take out the power plug from the compressor.



- 3 Connect the bottle to the compressor.


Insert and connect the bottle straight into the compressor as shown in the illustration, and check that the claws of the bottle are con-

sealed in the holes.




- 4 Connect the hose to the bottle.

As shown in the illustration, make sure the hose is connected securely to the bottle.




- 5** Remove the valve cap from the valve of the punctured tire.




- 6** Extend the hose. Remove the air release cap from the hose.

You will use the air release cap again. Therefore keep it in a safe place.




- 7** Connect the hose to the valve.

Screw the end of the hose clockwise as far as possible.




- 8** Make sure that the compressor switch is off.




- 9** Connect the power plug to the power outlet socket. (→P.479)

- 10** Attach the sticker provided with the tire puncture repair kit to a position easily seen from the driver's seat.



- 11** Check the specified tire inflation pressure.


Tire inflation pressure is specified on the label as shown. (→P.615)




12 Start the EV system.

(→P.234)

13 To inject the sealant and inflate the tire, turn the compressor switch on.



14 Inflate the tire until the recommended pressure is reached.



A The sealant will be injected and the pressure will spike to between 44 psi (300 kPa, 3.0 kgf/cm² or bar) and 58 psi (400 kPa, 4.0 kgf/cm² or bar), then gradually decrease.

B The air pressure gauge will display the actual tire inflation pressure about 1 to 5 minutes after the switch is turned on.

- Turn the compressor switch off and then check the tire inflation pressure. Being careful not to over inflate, check and repeat the inflation procedure until the specified tire inflation pressure is reached.

- The tire can be inflated for about 5 to 20 minutes (depending on the outside temperature). If the tire inflation pressure is still lower than the specified point after inflation for 25 minutes, the tire is too damaged to be repaired. Turn the compressor switch off and contact your Toyota dealer.

- If the tire inflation pressure exceeds the specified air pressure, let out some air to adjust the tire inflation pressure. (→P.593)


15 With the compressor switch off, pull out the power plug from the power outlet socket and then disconnect the hose from the valve on the tire.

Some sealant may leak when the hose is removed.

16 Install the valve cap onto the valve of the emergency repaired tire.


- 17** Attach the air release cap to the end of the hose.

If the air release cap is not attached, the sealant may leak and the vehicle may get dirty.




- 18** Temporarily store the bottle in the luggage compartment while it is connected to the compressor.
- 19** To spread the liquid sealant evenly within the tire, immediately drive safely for about 3 miles (5 km) below 50 mph (80 km/h).
- 20** After driving, stop your vehicle in a safe place on a hard, flat surface and reconnect the repair kit.

Remove the air release cap from the hose before reconnecting the hose.



- 21** Turn the compressor switch on and wait for several sec-

onds, then turn it off. Check the tire inflation pressure.




- A** If the tire inflation pressure is under 19 psi (130 kPa, 1.3 kgf/cm² or bar): The puncture cannot be repaired. Contact your Toyota dealer.
- B** If the tire inflation pressure is 19 psi (130 kPa, 1.3 kgf/cm² or bar) or higher, but less than the specified air pressure: Proceed to step **22**.
- C** If the tire inflation pressure is the specified air pressure (→P.615): Proceed to step **23**.

- 22** Turn the compressor switch on to inflate the tire until the specified air pressure is reached. Drive for about 3 miles (5 km) and then perform step **20**.

- 23** Attach the air release cap to the end of the hose.

If the air release cap is not attached, the sealant may leak and

the vehicle may get dirty.



24 Store the bottle in the luggage compartment while it is connected to the compressor.

25 Taking precautions to avoid sudden braking, sudden acceleration and sharp turns, drive carefully at under 50mph (80 km/h) to the nearest Toyota dealer that is less than 62 miles (100 km) away for tire repair or replacement.


For repair and replacement of a tire or disposal of the tire puncture repair kit, contact your Toyota dealer.

When having the tire repaired or replaced, make sure to tell the Toyota dealer that the sealant is injected.

n If the tire is inflated to more than the specified air pressure

- 1** Disconnect the hose from the valve.
- 2** Install the air release cap to the end of the hose and push the

protrusion on the air release cap into the valve to let some air out.



- 3** Disconnect the hose from the valve, remove the air release cap from the hose and then reconnect the hose.
 - 4** Turn the compressor switch on and wait for several seconds, then turn it off. Check that the air pressure indicator shows the specified air pressure is reached. (→P.615)
If the air pressure is under the designated pressure, turn the compressor switch on again and repeat the inflation procedure until the specified air pressure is reached.
- n After a tire is repaired with the emergency tire puncture repair kit**
- l** The tire pressure warning valve and transmitter should be replaced.
 - l** Even if the tire inflation pressure is at the recommended level, the tire pressure warning light may come on/flash.

! WARNING

n When fixing the flat tire

- l** Stop your vehicle in a safe and flat area.

**WARNING**

- I Do not touch the wheels or the area around the brakes immediately after the vehicle has been driven.

After the vehicle has been driven, the wheels and the area around the brakes may be extremely hot. Touching these areas with hands, feet or other body parts may result in burns.

- I Connect the valve and hose securely with the tire installed on the vehicle.

If the hose is not properly connected to the valve, air leakage may occur as sealant may be sprayed out.

- I If the hose comes off the valve while inflating the tire, there is a risk that the hose will move abruptly due to air pressure.

- I After inflation of the tire has completed, the sealant may splatter when the hose is disconnected or some air is let out of the tire.

- I Follow the operation procedure to repair the tire. If the procedure is not followed, the sealant may spray out.

- I Keep back from the tire while it is being repaired, as there is a chance of it bursting while the repair operation is being performed. If you notice any cracks or deformation of the tire, turn off the compressor switch and stop the repair operation immediately.

- I The repair kit may overheat if operated for a long period of time. Do not operate the compressor continuously for more than 40 minutes.

- I Parts of the repair kit become hot during operation. Be careful handling the repair kit during and after operation. Do not touch the metal part connecting the bottle and the compressor. It will be extremely hot.

- I Do not attach the vehicle speed warning sticker to an area other than the one indicated. If the sticker is attached to an area where an SRS airbag is located, such as the pad of the steering wheel, it may prevent the SRS airbag from operating properly.

n Driving to spread the liquid sealant evenly

Observe the following precautions to reduce the risk of accidents.

Failing to do so may result in a loss of vehicle control and cause death or serious injury.

- I Drive the vehicle carefully at a low speed. Be especially careful when turning and cornering.

- I If the vehicle does not drive straight or you feel a pull through the steering wheel, stop the vehicle and check the following:

- Tire condition. The tire may have separated from the wheel.
- Tire inflation pressure. If tire inflation pressure is 19 psi (130 kPa, 1.3 kgf/cm² or bar) or below, this may indicate severe tire damage.



NOTICE

n When performing an emergency repair

- I** Perform the emergency repair without removing the nail or screw that has punctured the tread of the tire. If the object that has punctured the tire is removed, repair by the emergency tire puncture repair kit may not be possible.
- I** The kit is not waterproof. Make sure that the repair kit is not exposed to water, such as when it is being used in the rain.
- I** Do not put the repair kit directly onto dusty ground such as sand at the side of the road. If the kit vacuums up dust etc., a malfunction may occur.
- I** Make sure the sealant bottle of the repair kit is in a vertical position. The repair kit does not operate properly when it is laid.

n Precautions for the emergency tire puncture repair kit

- I** The repair kit power source should be 12 V DC suitable for vehicle use. Do not connect the repair kit to any other source.
- I** Place the repair kit in a storage to prevent it from being exposed to dirt or water.
- I** Store the repair kit in the luggage compartment out of reach of children.
- I** Do not disassemble or modify the repair kit. Do not subject parts such as the air pressure indicator to impacts. This may cause a malfunction.

n To avoid damage to the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Toyota dealer as soon as possible. After use of liquid sealant, make sure to replace the tire pressure warning valve and transmitter when repairing or replacing the tire. (→P.534)

If the EV system will not start

Reasons for the EV system not starting vary depending on the situation. Check the following and perform the appropriate procedure:

Contact your Toyota dealer if the problem cannot be repaired, or if repair procedures are unknown.

The EV system will not start even though the correct starting procedure is being followed. (→P.234)

One of the following may be the cause of the problem:

- The charging cable may be connected to the vehicle. (→P.91)
- The electronic key may not be functioning properly.* (→P.598)
- The traction battery may be completely discharged. Charge the traction battery. (→P.87)
- There may be a malfunction in the immobilizer system.* (→P.66)
- There may be a malfunction in the shift control system.* (→P.236, 583)

- The EV system may be malfunctioning due to an electrical problem such as electronic key battery depletion or a blown fuse. However, depending on the type of malfunction, an interim measure is available to start the EV system. (→P.597)
- There is a possibility that the temperature of the traction battery is extremely low (approximately below -22°F [-30°C]). (→P.75, 235)

*: It may not be possible to shift the shift position from P.

The interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

- The 12-volt battery may be discharged. (→P.600)
- The 12-volt battery terminal connections may be loose or corroded. (→P.527)

The interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- One or both of the 12-volt battery terminals may be discon-

nected. (→P.527)

- The 12-volt battery may be discharged. (→P.600)

Contact your Toyota dealer if the problem cannot be repaired, or if repair procedures are unknown.

Emergency start function

When the EV system does not start, the following steps can be used as an interim measure to start the EV system if the power switch is functioning normally. Do not use this starting procedure except in cases of emergency.

- 1 Set the parking brake.
- 2 Turn the power switch to ACC.^{*1, 2}
- 3 Press and hold the power switch for about 15 seconds while depressing the brake pedal firmly.

Even if the EV system can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by your Toyota dealer.

^{*1}: ACC mode can be enabled/disabled on the customize menu. (→P.632)

^{*2}: When ACC is disabled, turn the power switch to ON then OFF, and perform the following step within 5 seconds.

If you lose your keys

New genuine mechanical keys can be made by your Toyota dealer using another mechanical key and the key number stamped on your key number plate.

Keep the plate in a safe place such as your wallet, not in the vehicle.



NOTICE

n When an electronic key is lost

If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit your Toyota dealer immediately with all remaining electronic keys that were provided with your vehicle.

If the electronic key does not operate properly

If communication between the electronic key and vehicle is interrupted (→P.177) or the electronic key cannot be used because the battery is depleted, the smart key system and wireless remote control cannot be used. In such cases, the doors can be opened and the EV system can be started by following the procedure below.

n When the electronic key does not work properly

- l Make sure that the smart key system has not been deactivated in the customization setting. If it is off, turn the function on.
- l Check if battery-saving mode is set. If it is set, cancel the function. (→P.177)
- l The electronic key function may be stopped. (→P.177)



NOTICE


n In case of a smart key system malfunction or other key-related problems

Take your vehicle with all the electronic keys provided with your vehicle, to your Toyota dealer.

Locking and unlocking the doors

Use the mechanical key (→P.154) in order to perform the

following operations.




1 Locks all the doors

2 Unlocks the door

Turning the key rearward unlocks the driver's door. Turning the key once again within 5 seconds unlocks the other doors.

n Key linked functions



1 Closes the windows (turn and hold)

2 Opens the windows (turn and hold)

These settings must be customized by your Toyota dealer.

WARNING

n When using the mechanical key and operating the power windows

Operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window.


Also, do not allow children to operate the mechanical key. It is possible for children and other passengers to get caught in the power window.

Starting the EV system

- 1** Depress the brake pedal.
- 2** Touch the electronic key to the power switch.

When the electronic key is detected, a buzzer sounds and the power switch will turn to ON.

When the smart key system is deactivated in customization setting and ACC customization is in on, the power switch will turn to ACC.



- 3** Firmly depress the brake pedal and check that  is shown on the multi-information display.
- 4** Press the power switch shortly and firmly.

In the event that the EV system still

cannot be started, contact your Toyota dealer.

n Stopping the EV system

Set the parking brake, shift the shift position to P and press the power switch as you normally do when stopping the EV system.

n Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. (→P.553)

n Alarm

Using the mechanical key to lock the doors will not set the alarm system.

If a door is unlocked using the mechanical key when the alarm system is set, the alarm may be triggered. (→P.67)

n Changing power switch modes

Release the brake pedal and press the power switch in step **3** above.

The EV system does not start and modes will be changed each time the switch is pressed. (→P.237)

If the 12-volt battery is discharged

The following procedures may be used to start the EV system if the vehicle's 12-volt battery is discharged.


You can also call your Toyota dealer or a qualified repair shop.

Restarting the EV system

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your vehicle by following the steps below.


- 1 Confirm that the electronic key is being carried.

When connecting the jumper (or booster) cables, depending on the situation, the alarm may activate and doors locked. (→P.68)



- 2 Open the hood. (→P.521)
- 3 Open the positive (+) battery terminal cover.


While pressing on the claw, open the cover as shown in the illustration.



- 4 Connect a positive jumper cable clamp to **A** on your vehicle and connect the clamp on the other end of the positive cable to **B** on the second vehicle. Then, connect a negative cable clamp to **C** on the second vehicle and connect the clamp at the other end of

the negative cable to **D**.

Use jumper cables that can reach the specified terminals and connecting point.



A Positive (+) battery terminal (your vehicle)

B Positive (+) battery terminal (second vehicle)

C Negative (-) battery terminal (second vehicle)

D Metallic point shown in the illustration

- 5** Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- 6** Open and close any of the doors of your vehicle with the power switch off.
- 7** Maintain the engine speed of the second vehicle and start the EV system of your vehicle by turning the power switch to ON.
- 8** Make sure the "READY" indicator comes on. If the indica-

tor light does not come on, contact your Toyota dealer.

- 9** Once the EV system has started, remove the jumper cables in the exact reverse order from which they were connected.

- 10** Close the positive (+) battery terminal cover.

Once the EV system starts, have the vehicle inspected at your Toyota dealer as soon as possible.

n Starting the EV system when the 12-volt battery is discharged

The EV system cannot be started by push-starting.

n **To prevent 12-volt battery discharge**

- | When ACC customization is in off, power is still provided to the multimedia system even though the power switch is off.
- | Turn off the headlights, the air conditioning system, the audio system, etc. while the EV system is off.
- | Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

n **Charging the 12-volt battery**

The electricity stored in the 12-volt battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the 12-volt battery may discharge, and the EV system may be unable to start. (The 12-volt battery recharges automatically while the EV system is operating.)

n **When the 12-volt battery is removed or discharged**

- | Information stored in the ECU is cleared. When the 12-volt battery is depleted, have the vehicle inspected at your Toyota dealer.
- | In some cases, it may not be possible to unlock the doors using the smart key system when the 12-volt battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.
- | The EV system may not start on the first attempt after the 12-volt battery has recharged but will start normally after the second attempt. This is not a malfunction.
- | The power switch mode is memorized by the vehicle. When the 12-volt battery is reconnected, the system will return to the mode it was in before the 12-volt battery

was discharged. Before disconnecting the 12-volt battery, turn the power switch off. If you are unsure what mode the power switch was in before the 12-volt battery discharged, be especially careful when reconnecting the 12-volt battery.

- | If the 12-volt battery discharges, it may not be possible to shift the shift position to other positions. In this case, the vehicle cannot be towed without lifting both front wheels because the front wheels will be locked.
- | The power back door must be initialized. (→P.170)

n **When replacing the 12-volt battery**

- | Use a 12-volt battery that conforms to European regulations.
- | Use a 12-volt battery that the case size is same as the previous one (LN1), 20 hour rate capacity (20HR) is equivalent (50Ah) or greater, and performance rating (CCA) is equivalent (315A) or greater.
- If the sizes differ, the 12-volt battery cannot be properly secured.
- If an improper 12-volt battery is used, battery performance may decrease and the EV system may not be able to restart.
- If the 20 hour rate capacity is low, even if the time period where the vehicle is not used is a short time, the 12-volt battery may discharge and the EV system may not be able to start.

For details, consult your Toyota dealer.

**WARNING****n When removing the 12-volt battery terminals**

Always remove the negative (-) terminal first. If the positive (+) terminal contacts any metal in the surrounding area when the positive (+) terminal is removed, a spark may occur, leading to a fire in addition to electrical shocks and death or serious injury.

n Avoiding 12-volt battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the 12-volt battery:

- I Make sure each jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- I Do not allow the other end of the jumper cable connected to the "+" terminal to come into contact with any other parts or metal surfaces in the area, such as brackets or unpainted metal.
- I Do not allow the + and - clamps of the jumper cables to come into contact with each other.
- I Do not smoke, use matches, cigarette lighters or allow open flame near the 12-volt battery.

n 12-volt battery precautions

The 12-volt battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the 12-volt battery:

- I When working with the 12-volt battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- I Do not lean over the 12-volt battery.
- I In the event that battery fluid (acid) comes in to contact with the skin or eyes, immediately wash the affected area with water and seek medical attention.
Place a wet sponge or cloth over the affected area until medical attention can be received.
- I Always wash your hands after handling the 12-volt battery support, terminals, and other battery-related parts.
- I Do not allow children near the 12-volt battery.
- n When replacing the 12-volt battery**
 - I When the vent plug and indicator are close to the hold down clamp, the battery fluid (sulfuric acid) may leak.
 - I For information regarding 12-volt battery replacement, contact your Toyota dealer.



NOTICE

n When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fan.

n When connecting jumper cables

Make sure to connect jumper cables to the specified terminals and connecting point. Failure to do so may adversely affect the electronic devices or damage to them.

If your vehicle overheats


When “EV system overheated Output power reduced” is shown on the multi-information display, your vehicle may be overheating.



NOTICE

n Cooling system coolant

The radiator coolant is exclusive for radiator usage. Damage may occur when water or any other type of coolant is used, so never use any other fluid. When there is no “Toyota Genuine Traction Battery Coolant”, immediately contact your Toyota dealer.




Correction procedures

- 1** Stop the vehicle in a safe place and turn off the air conditioning system.
- 2** Leave the EV system operating and carefully lift the hood.
- 3** Check if the cooling fan is operating.
If the fan is operating:
Wait until the “EV system overheated Output power reduced” message disap-

pears and then stop the EV system. If the message does not disappear, call your Toyota dealer.

If the fan is not operating: Stop the EV system immediately and call your Toyota dealer.

- 4** After the EV system has cooled down, inspect the hoses and radiator core (radiator) for any leaks.




A Radiator

B Cooling fan

If a large amount of coolant leaks, immediately contact your Toyota dealer.

- 5** The coolant level is satisfactory if it is between the “MAX” and “MIN” lines on the reservoir.




A Reservoir

B “MAX” line

C “MIN” line

- 6** If the coolant is insufficient, replenish with “Toyota Genuine Traction Battery Coolant”.

If you don’t have “Toyota Genuine Traction Battery Coolant”, contact your Toyota dealer.



1 Remove the bolt and cover.

2 Open the reservoir cap.

Have the vehicle inspected at the nearest your Toyota dealer.

⚠ WARNING

n To prevent an accident or injury when inspecting under the hood of your vehicle

Observe the following precautions.

Failure to do so may result in serious injury such as burns.

I If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The motor compartment may be very hot.

I Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fan. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.

**WARNING**

- I** Do not loosen the coolant reservoir cap while the EV system and radiator are hot. High temperature steam or coolant could spray out.

**NOTICE****n When adding coolant**

Add coolant slowly after the EV system has cooled down sufficiently. Adding cool coolant to a hot EV system too quickly can cause damage to the EV system.

n To prevent damage to the cooling system

Observe the following precautions:

- I** Avoid contaminating the coolant with foreign matter (such as sand or dust, etc.).
- I** Do not use water or any other coolant when refilling coolant. Also, do not use any additive agents for the coolant.

If the vehicle becomes stuck


Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt or snow:

Recovering procedure

- 1** Stop the EV system. Set the parking brake and shift the shift position to P.
- 2** Remove the mud, snow or sand from around the front wheels.
- 3** Place wood, stones or some other material under the front wheels to help provide traction.
- 4** Restart the EV system.
- 5** Shift the shift position to D or R and release the parking brake. Then, while exercising caution, depress the accelerator pedal.

n When it is difficult to free the vehicle

Press  to turn off TRAC.



**WARNING****n When attempting to free a stuck vehicle**

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

n When shifting the shift position

Be careful not to shift the shift position with the accelerator pedal depressed.

This may lead to unexpected rapid acceleration of the vehicle that may cause an accident resulting in death or serious injury.

**NOTICE****n To avoid damage to the transmission and other components**

I Avoid spinning the front wheels and depressing the accelerator pedal more than necessary.

I If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

9-1. Specifications

Maintenance data 610

Tire information 617

9-2. Customization

Customizable features
..... 627

9-3. Initialization

Items to initialize 640

9-4. Free/open source software

Free/open source software
information 641

Maintenance data

Dimensions and weight

Overall length		190.2 in. (4830 mm)
Overall width		73.2 in. (1860 mm)
Overall height ^{*1}		65.9 in. (1675 mm)
Wheelbase		112.2 in. (2850 mm)
Tread	Front	63.0 in. (1600 mm)
	Rear	63.4 in. (1610 mm) ^{*2} 63.4 in. (1611 mm) ^{*3}
Vehicle capacity weight (Occupants + luggage)		1045 lb. (475 kg)
Trailer Weight Rating (Trailer weight + cargo weight)		3500 lb. (1500 kg)

^{*1}: Unladen vehicle

^{*2}: Tires and wheels type A (→P.615)

^{*3}: Tires and wheels type B (→P.615)

Seating capacity

Seating capacity	5 (Front 2, Rear 3)
------------------	---------------------

Vehicle identification


n Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle.

This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.


This number is stamped on the

top left of the instrument panel.




This number is also stamped

under the right-hand front seat.



This number is also on the Certification Regulation Label.




n Motor model type and motor number


The motor model type and the

motor number are stamped on the motor as shown.

► Front electric motor (traction motor)



► Rear electric motor (traction motor)



Front electric motor (traction motor)

Model	2XM
Type	Permanent magnet synchronous motor
Maximum output	167 kW
Maximum torque	198.1 ft•lbf (268.6 N•m, 27.4 kgf•m)

Rear electric motor (traction motor)

Model	2XM
Type	Permanent magnet synchronous motor

Maximum output	167 kW
Maximum torque	198.1 ft•lbf (268.6 N•m, 27.4 kgf•m)

Traction battery

Type	Lithium-ion battery
Cell voltage	3.76 V/cell
Cell rated capacity	191 Ah
Quantity	104 cells
Voltage	391.0 V

Cooling system

Capacity*	8.8 qt. (8.3 L, 7.3 Imp. qt.)
Coolant type	<div>Use either of the following:<ul style="list-style-type: none">• “Toyota Genuine Traction Battery Coolant”• Similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technologyDo not use plain water alone.</div>

*: The coolant capacity is a reference quantity.
If replacement is necessary, contact your Toyota dealer.


**NOTICE****n Cooling system coolant**

In order to ensure maximum performance of the traction battery cooling system and limit risks of battery short circuit and other damage to your vehicle, Toyota recommends using “Toyota Genuine Traction Battery Coolant” or similar high-quality ethylene glycol-based, low electric conductivity coolant, non-amine and non-borate coolant with azole additives.

Toyota cannot guarantee that the use of a product other than “Toyota Genuine Traction Battery Coolant” will prevent risks of battery short circuit or other damage.

Never use water as it will cause damage.

Do not reuse coolant that has been removed from the radiator.

**Heater system**

Capacity*	4.3 qt. (4.1 L, 3.6 Imp. qt.)
Coolant type	<p>Use either of the following:</p> <ul style="list-style-type: none"> • “Toyota Super Long Life Coolant” • Similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology <p>Do not use plain water alone.</p>

*: The coolant capacity is a reference quantity.

If replacement is necessary, contact your Toyota dealer.

Electrical system (12-volt battery)

Open voltage at 68°F (20°C):	12.0 V or More In the case the voltage is less than standard, charge battery. (Turn the power switch off and turn on the headlights for 30 seconds.)
Charging rates: Slow charge	5 A max.

Front eAxle

Fluid capacity *	3.2 qt. (3.0 L, 2.6 Imp.qt.)
Fluid type	e-Transaxle Fluid TE

*: The fluid capacity is a reference quantity.
If replacement is necessary, contact your Toyota dealer.



NOTICE

n Front eAxle fluid type

Using transaxle fluid other than the above type may cause abnormal noise or vibration, or ultimately damage the front eAxle of your vehicle.

Rear eAxle

Fluid capacity *	3.2 qt. (3.0 L, 2.6 Imp.qt.)
Fluid type	e-Transaxle Fluid TE

*: The fluid capacity is a reference quantity.
If replacement is necessary, contact your Toyota dealer.



NOTICE

n Rear eAxle fluid type

Using transaxle fluid other than the above type may cause abnormal noise or vibration, or ultimately damage the rear eAxle of your vehicle.

Brakes

Pedal clearance ^{*1}	2.26 in. (57.5 mm) Min.
Pedal free play	0.04 — 0.24 in. (1 — 6 mm)
Parking brake indicator ^{*2}	When pushing the parking brake switch for 1 to 4 seconds: turns off When pulling the parking brake switch for 1 to 4 seconds: comes on
Fluid type	FMVSS No. 116 DOT 3 or SAE J1703 FMVSS No. 116 DOT 4 or SAE J1704

^{*1}: Minimum pedal clearance when depressed with a force of 67.5 lbf (300 N, 30.6 kgf) while the EV system is operating.

^{*2}: Make sure to confirm that the brake warning light (yellow) does not illuminate. (If the brake warning light illuminates, refer to P.568.)

Steering

Free play	Less than 1.2 in. (30 mm)
-----------	---------------------------

Tires and wheels

► 18-inch tires (Type A)


Tire size	235/60R18 103V
Tire inflation pressure (Recommended cold tire inflation pressure)	► Front 39 psi (270 kPa, 2.7 kgf/cm ² or bar) ► Rear 39 psi (270 kPa, 2.7 kgf/cm ² or bar)
Wheel size	18 × 7 1/2J
Wheel bolt torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

► 18-inch tires (Type B)

Tire size	235/65R18 106V
Tire inflation pressure (Recommended cold tire inflation pressure)	► Front 38 psi (260 kPa, 2.6 kgf/cm ² or bar) ► Rear 38 psi (260 kPa, 2.6 kgf/cm ² or bar)
Wheel size	18 × 7 1/2J
Wheel bolt torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

Tire information

Typical tire symbols



A Location of treadwear indicators (→P.530)

B Load limit at maximum cold tire inflation pressure (→P.620)

C Maximum cold tire inflation pressure (→P.615)

This means the pressure to which a tire may be inflated.

D Tire size (→P.618)

E TUBELESS or TUBE TYPE

A tubeless tire does not have a tube and air is directly put into the tire. A tube type tire has a tube inside the tire and the tube maintains the air pressure.

F Radial tires or bias-ply tires

A radial tire has "RADIAL" on the sidewall. A tire not marked "RADIAL" is a bias-ply tire.

G Summer tires or all season tires (→P.531)

An all season tire has "M+S" on the sidewall. A tire not marked "M+S" is a summer tire.

H Tire ply composition and materials


Plies are layers of rubber-coated parallel cords. Cords are the strands which form the plies in a tire.

I DOT and Tire Identification Number (TIN) (→P.618)

J Uniform tire quality grading

For details, see "Uniform Tire Quality Grading" that follows.

Typical DOT and Tire Identification Number (TIN)




- A** DOT symbol*
- B** Tire Identification Number (TIN)
- C** Tire manufacturer's identification mark
- D** Manufacturer's code
- E** Manufacturing week
- F** Manufacturing year

*: The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.

Tire size


n Typical tire size information

The illustration indicates typical tire size.




- A** Section width (millimeters)
- B** Aspect ratio (tire height to section width)
- C** Tire construction code (R = Radial, D = Diagonal)
- D** Wheel diameter (inches)
- E** Load index (2 digits or 3 digits)
- F** Speed symbol (alphabet with one letter)

n Tire dimensions



- A** Section width
- B** Tire height
- C** Wheel diameter

Tire section names



- A** Bead
- B** Sidewall
- C** Shoulder
- D** Tread
- E** Belt
- F** Inner liner
- G** Reinforcing rubber
- H** Carcass
- I** Rim lines
- J** Bead wires
- K** Chafer

Uniform Tire Quality Grading

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Toyota vehicles with information on uniform tire quality grading.

Your Toyota dealer will help answer any questions you may have as you read this information.

n DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

n Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1 - 1/2) times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use. Performance may differ significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

n Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified govern-

ment test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

n **Temperature A, B, C**

The temperature grades are A (the highest), B, and C, representing the tire’s resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to

degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

Grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grades of a tire assume that it is properly inflated and not overloaded.

Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Glossary of tire terminology

Tire related term	Meaning
Cold tire inflation pressure	Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition
Maximum inflation pressure	The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire
Recommended inflation pressure	Cold tire inflation pressure recommended by a manufacturer

Tire related term	Meaning
Accessory weight	The combined weight (in excess of those standard items which may be replaced) of transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not)
Curb weight	The weight of a motor vehicle with standard equipment, including the maximum capacity of traction battery and coolant, and if so equipped, air conditioning and additional weight optional traction motor
Maximum loaded vehicle weight	The sum of: (a) Curb weight (b) Accessory weight (c) Vehicle capacity weight (d) Production options weight
Normal occupant weight	150 lb. (68 kg) times the number of occupants specified in the second column of Table 1* that follows
Occupant distribution	Distribution of occupants in a vehicle as specified in the third column of Table 1* below
Production options weight	The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim
Rim	A metal support for a tire or a tire and tube assembly upon which the tire beads are seated
Rim diameter (Wheel diameter)	Nominal diameter of the bead seat
Rim size designation	Rim diameter and width

Tire related term	Meaning
Rim type designation	The industry manufacturer's designation for a rim by style or code
Rim width	Nominal distance between rim flanges
Vehicle capacity weight (Total load capacity)	The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity
Vehicle maximum load on the tire	The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight, and dividing by two
Vehicle normal load on the tire	The load on an individual tire that is determined by distributing to each axle its share of curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table 1* below), and dividing by two
Weather side	The surface area of the rim not covered by the inflated tire
Bead	The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim
Bead separation	A breakdown of the bond between components in the bead
Bias ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread
Carcass	The tire structure, except tread and sidewall rubber which, when inflated, bears the load
Chunking	The breaking away of pieces of the tread or sidewall
Cord	The strands forming the plies in the tire
Cord separation	The parting of cords from adjacent rubber compounds

Tire related term	Meaning
Cracking	Any parting within the tread, sidewall, or innerliner of the tire extending to cord material
CT	A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire
Extra load tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Groove	The space between two adjacent tread ribs
Innerliner	The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire
Innerliner separation	The parting of the innerliner from cord material in the carcass
Intended outboard sidewall	(a) The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or (b) The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle
Light truck (LT) tire	A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles
Load rating	The maximum load that a tire is rated to carry for a given inflation pressure
Maximum load rating	The load rating for a tire at the maximum permissible inflation pressure for that tire
Maximum permissible inflation pressure	The maximum cold inflation pressure to which a tire may be inflated

Tire related term	Meaning
Measuring rim	The rim on which a tire is fitted for physical dimension requirements
Open splice	Any parting at any junction of tread, sidewall, or innerliner that extends to cord material
Outer diameter	The overall diameter of an inflated new tire
Overall width	The linear distance between the exteriors of the sidewalls of an inflated tire, including elevations due to labeling, decorations, or protective bands or ribs
Passenger car tire	A tire intended for use on passenger cars, multipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less.
Ply	A layer of rubber-coated parallel cords
Ply separation	A parting of rubber compound between adjacent plies
Pneumatic tire	A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load
Radial ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread
Reinforced tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Section width	The linear distance between the exteriors of the sidewalls of an inflated tire, excluding elevations due to labeling, decoration, or protective bands
Sidewall	That portion of a tire between the tread and bead
Sidewall separation	The parting of the rubber compound from the cord material in the sidewall

Tire related term	Meaning
Snow tire	A tire that attains a traction index equal to or greater than 112, compared to the ASTM F2493 standard reference test tire when using the snow traction test on the medium pack snow surface as described in ASTM F1805-20, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and which is marked with an Alpine Symbol () on at least one sidewall
Test rim	The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire
Tread	That portion of a tire that comes into contact with the road
Tread rib	A tread section running circumferentially around a tire
Tread separation	Pulling away of the tread from the tire carcass
Treadwear indicators (TWI)	The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread
Wheel-holding fixture	The fixture used to hold the wheel and tire assembly securely during testing

*: Table 1 -Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capacity, Number of occupants	Vehicle normal load, Number of occupants	Occupant distribution in a normally loaded vehicle
2 through 4	2	2 in front
5 through 10	3	2 in front, 1 in second seat

Designated seating capacity, Number of occupants	Vehicle normal load, Number of occupants	Occupant distribution in a normally loaded vehicle
11 through 15	5	2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat
16 through 22	7	2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat

Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. The settings of these features can be changed by using multimedia system or at your Toyota dealer.

Some of the customizable features are changed in conjunction with the settings of My Settings. (→P.209)

Customizing vehicle features

n To change setting with

- 1 Select  on the multimedia display.
- 2 Select “Vehicle customize” or “Driving assist”.
- 3 Select the item to change the settings of from the list.

For functions that can be turned on/off, select  (ON) /  (OFF).

For functions whose level can be adjusted, such as volume, sensor sensitivity, etc., slide the icon on the bar.

n To change setting with

- 1 Select  on the multimedia display.
- 2 Select “Driving assist”.
- 3 Select the item to change the settings of from the list.

Each time the switch is selected, the setting will be enabled/disabled.

When enabling is selected, the item display will be emphasized.

n During customization

Stop the vehicle in a safe place, apply the parking brake, and shift the shift position to P. Also, to prevent 12-volt battery discharge, leave the EV system operating while customizing the features.

n Using the icon

Some vehicle customize settings can also be changed through the  icon.



NOTICE

n During customization

To prevent 12-volt battery discharge, ensure that the EV system is operating while customizing features.

Customizable Features

Some function settings are changed simultaneously with other functions being customized. Contact your Toyota dealer for further details.

A Settings that can be changed using the multimedia system

B Settings that can be changed by your Toyota dealer

Definition of symbols: O = Available, — = Not available

n Charging system (→P.94, 100)

Function	Customized setting	A	B
Charging Current	<ul style="list-style-type: none">• 8A• 16A• 24A• 32A• MAX	O	—
Charging limit	<ul style="list-style-type: none">• 50%• 60%• 70%• 80%• 90%• Full	O	—
DC charging power	<ul style="list-style-type: none">• 50 kW• 75 kW• 100 kW• 125 kW• MAX	O	—
Traction battery cooler	<ul style="list-style-type: none">• On• Off	O	—

n Gauges, meters and multi-information display (→P.139, 142)

The language, units of measure, etc. of some items displayed on the meter or multi-information display will be changed according to settings on the multimedia display. Refer to “MULTIMEDIA OWNER’S MANUAL”.

Function	Customized setting	A	B
Suggestion function	<ul style="list-style-type: none">• On• On (when the vehicle is stopped)• Off	O	O
Stop light indicator	<ul style="list-style-type: none">• On• Off	O	—

n **Rear seat reminder (→P.159)**

Function	Customized setting	A	B
Rear seat reminder function*	<ul style="list-style-type: none"> On Off 	O	O

*: This setting changes in accordance with My Settings

n **Door lock (→P.157, 598)**

Function	Customized setting	A	B
Unlocking using a mechanical key	<ul style="list-style-type: none"> All doors unlocked in one step Driver's door unlocked in one step, all doors unlocked in two step 	—	O
Automatic door locking function	<ul style="list-style-type: none"> Shift position linked door locking operation Speed linked door locking operation Off 	O	O
Automatic door unlocking function	<ul style="list-style-type: none"> Shift position linked door unlocking operation Driver's door linked door unlocking operation Off 	O	O

n **Power back door (→P.162)**

Function	Customized setting	A	B
Power back door opening position	<ul style="list-style-type: none"> 1 to 5 User optional setting 	O	—
Power back door operation	<ul style="list-style-type: none"> On Off 	O	—
Buzzer volume	<ul style="list-style-type: none"> Small Nomal Large 	O	—
Operation buzzer	<ul style="list-style-type: none"> On Off 	—	O
Hands Free Power Back Door (kick sensor)	<ul style="list-style-type: none"> On Off 	O	O

Function	Customized setting	A	B
Kick in buzzer (kick sensor)	<ul style="list-style-type: none"> On Off 	—	☐
Close & lock (walk away) function	<ul style="list-style-type: none"> On Off 	—	☐

n Smart key system and wireless remote control (→P.154, 175)

Function	Customized setting	A	B
Operation buzzer volume	<ul style="list-style-type: none"> Off 1 to 7 	☐	☐
Operation signal (Emergency flashers)	<ul style="list-style-type: none"> On Off 	☐	☐
Time elapsed before automatic door lock function is activated if door is not opened after being unlocked	<ul style="list-style-type: none"> Off 30 seconds 60 seconds 120 seconds 	☐	☐
Open door warning buzzer	<ul style="list-style-type: none"> On Off 	—	☐

n Smart key system (→P.175)

Function	Customized setting	A	B
Smart key system	<ul style="list-style-type: none"> On Off 	—	☐
Smart door unlocking	<ul style="list-style-type: none"> Driver's door All the doors 	☐	☐
Time elapsed before unlocking all the door when gripping and holding the driver's door handle	<ul style="list-style-type: none"> Off 1.5 seconds 2 seconds 2.5 seconds 	—	☐
Number of consecutive door lock operations	<ul style="list-style-type: none"> 2 times As many as desired 	—	☐

n **Wireless remote control (→P.154)**

Function	Customized setting	A	B
Wireless remote control	<ul style="list-style-type: none"> On Off 	—	O
Unlocking operation	<ul style="list-style-type: none"> All doors unlocked in one step Driver's door unlocked in one step, all doors unlocked in two step 	O	O
Theft deterrent panic mode	<ul style="list-style-type: none"> On Off 	—	O
Locking operation when door opened	<ul style="list-style-type: none"> On Off 	O	O
The function that activates the  switch of the wireless remote control when locking the door(→P.163)	<ul style="list-style-type: none"> On (Unlocking all the door) On (Unlocking back door only) Off 	—	O

n **Driving position memory* (→P.206)**

Function	Customized setting	A	B
Selection the door linking driving position memory with door unlock operation	<ul style="list-style-type: none"> Driver's door All doors 	—	O

*: If equipped

n **Enabling easier driver entry and exit (power easy access system)* (→P.206)**

Function	Customized setting	A	B
Driver's seat slide movement when exiting the vehicle	<ul style="list-style-type: none"> Off Full Partial 	O	O

*: If equipped

n Outside rear view mirrors (→P.199)

Function	Customized setting	A	B
Automatic mirror folding and extending operation	<ul style="list-style-type: none">• Off• Linked to the locking/unlocking of the doors• Linked to operation of the power switch	—	O

n Power windows (→P.203)

Function	Customized setting	A	B
Mechanical key linked operation	<ul style="list-style-type: none">• On• Off	—	O
Wireless remote control linked operation	<ul style="list-style-type: none">• On (open only)• Off	—	O
Wireless remote control linked operation signal (buzzer)	<ul style="list-style-type: none">• On• Off	—	O

n Power switch (→P.237)

Function	Customized setting	A	B
ACC customization Enabling/Disabling ACC mode	<ul style="list-style-type: none">• On• Off	O	O

n Reverse warning buzzer (→P.238)

Function	Customized setting	A	B
Signal (buzzer) when the shift position is in R	<ul style="list-style-type: none">• Continual• Mute	—	O

n Automatic light control system (→P.251)

Function	Customized setting	A	B
Light sensor sensitivity	<ul style="list-style-type: none"> • Darker • Dark • Normal • Bright • Brighter 	☐	☐
Time elapsed before headlights automatically turn off after doors are closed	<ul style="list-style-type: none"> • Off • 30 seconds • 60 seconds • 90 seconds 	☐	☐
Windshield wiper linked headlight illumination	<ul style="list-style-type: none"> • On • Off 	—	☐

n Pre-Collision System (→P.273)

Function	Customized setting	A	B
Pre-Collision System	<ul style="list-style-type: none"> • ON • OFF 	☐	—
Warning timing*	<ul style="list-style-type: none"> • Later • Default • Earlier 	☐	—

*: This setting changes in accordance with My Settings

n Front Cross Traffic Alert^{*1}(→P.306)

Function	Customized setting	A	B
Front Cross Traffic Alert	<ul style="list-style-type: none"> • ON • OFF 	☐	—
Alert timing ^{*2}	<ul style="list-style-type: none"> • Later • Default • Earlier 	☐	—

^{*1}: If equipped

^{*2}: This setting changes in accordance with My Settings

n Lane Departure Alert system (LDA) (→P.293)

Function	Customized setting	A	B
Lane Departure Alert system (LDA)*	<ul style="list-style-type: none">• ON• OFF	☐	—
Alert timing*	<ul style="list-style-type: none">• Default• Earlier	☐	—
Alert options*	<ul style="list-style-type: none">• Vibration• Audible	☐	—

*: This setting changes in accordance with My Settings

n Lane Change Assist*¹ (→P.290)

Function	Customized setting	A	B
Lane Change Assist* ²	<ul style="list-style-type: none">• ON• OFF	☐	—

*¹: If equipped

*²: This setting changes in accordance with My Settings

n Dynamic Radar Cruise Control (DRCC) (→P.311)

Function	Customized setting	A	B
Extended Resume Time*	<ul style="list-style-type: none">• ON• OFF	☐	—
Acceleration setting*	<ul style="list-style-type: none">• Low• Mid• High	☐	—
Guide message*	<ul style="list-style-type: none">• ON• OFF	☐	—
Curve speed reduction*	<ul style="list-style-type: none">• OFF• Low• Mid• High	☐	—

*: This setting changes in accordance with My Settings

n Proactive Driving Assist (→P.300)

Function	Customized setting	A	B
Proactive Driving Assist (PDA)*	<ul style="list-style-type: none"> ON OFF 	☐	—
Support sensitivity*	<ul style="list-style-type: none"> Low Mid High 	☐	—
Deceleration Assist (DA)*	<ul style="list-style-type: none"> ON OFF 	☐	—
Obstacle Anticipation Assist (OAA)*	<ul style="list-style-type: none"> ON OFF 	☐	—

*: This setting changes in accordance with My Settings

n Road Sign Assist*¹ (→P.308)

Function	Customized setting	A	B
Road Sign Assist* ²	<ul style="list-style-type: none"> ON OFF 	☐	—
Excess speed notification method* ²	<ul style="list-style-type: none"> None Visual Visual and Audible 	☐	—
Other notifications method* ²	<ul style="list-style-type: none"> None Visual Visual and Audible 	☐	—
Excess speed notification level* ²	<ul style="list-style-type: none"> 5 mph (10 km/h) 3 mph (5 km/h) 1 mph (2 km/h) 	☐	—

*¹: If equipped

*²: This setting changes in accordance with My Settings

n Driver break suggestion (→P.293)

Function	Customized setting	A	B
Driver break suggestion	<ul style="list-style-type: none"> ON OFF 	☐	—

n **Traffic Jam Assist^{*1}** (→P.329)

Function	Customized setting	A	B
Traffic Jam Assist ^{*2}	<ul style="list-style-type: none">• ON• OFF	☐	—
Driver Monitor Camera Recording ^{*2}	<ul style="list-style-type: none">• ON• OFF	☐	—

^{*1}: If equipped

^{*2}: This setting changes in accordance with My Settings

n **Driver monitor** (→P.271)

Function	Customized setting	A	B
Warning function [*]	<ul style="list-style-type: none">• ON• OFF	☐	—

^{*}: This setting changes in accordance with My Settings

n **BSM (Blind Spot Monitor)** (→P.335)

Function	Customized setting	A	B
BSM (Blind Spot Monitor)	<ul style="list-style-type: none">• On• Off	☐	—
Outside rear view mirror indicator brightness [*]	<ul style="list-style-type: none">• Dim• Bright	☐	—
Alert timing for presence of approaching vehicle (sensitivity) [*]	<ul style="list-style-type: none">• Later• Default• Earlier	☐	—
Buzzer warning [*]	<ul style="list-style-type: none">• On• Off	☐	—

^{*}: This setting changes in accordance with My Settings

n RCTA (Rear cross traffic alert) function (→P.351)

Function	Customized setting	A	B
RCTA (Rear cross traffic alert)	<ul style="list-style-type: none"> • On • Off 	O	—
Buzzer volume of RCTA when operating ^{*1, 2}	<ul style="list-style-type: none"> • Soft • Normal • Loud 	O	—

^{*1}: The sound volume is linked among the intuitive parking assist, RCTA, and RCD.

^{*2}: This setting changes in accordance with My Settings

n Safe Exit Assist (→P.340)

Function	Customized setting	A	B
Safe Exit Assist	<ul style="list-style-type: none"> • On • Off 	O	—
Outside rear view mirrors display [*]	<ul style="list-style-type: none"> • On • Off 	O	—
Detection sensitivity [*]	<ul style="list-style-type: none"> • Low • Mid • High 	O	—

^{*}: This setting changes in accordance with My Settings

n Intuitive parking assist (→P.344)

Function	Customized setting	A	B
Intuitive parking assist ^{*1}	<ul style="list-style-type: none"> • On • Off 	O	—
Buzzer volume of Intuitive parking assist when operating ^{*1, 2}	<ul style="list-style-type: none"> • Level 1~3 	O	—
Distance from which the front center sensor starts detection	<ul style="list-style-type: none"> • Near • Standard 	O ^{*3}	—
Distance from which the rear center sensor starts detection	<ul style="list-style-type: none"> • Near • Standard 	O ^{*3}	—

^{*1}: This setting changes in accordance with My Settings

- ^{*2}: The sound volume is linked among the intuitive parking assist, RCTA, and RCD.
- ^{*3}: For vehicles with panoramic view monitor, the setting can be changed on the panoramic view monitor settings screen. For details, refer to “MULTI-MEDIA OWNER’S MANUAL”.

n **PKSB (Parking Support Brake) (→P.360)**

Function	Customized setting	A	B
PKSB (Parking Support Brake) function*	<ul style="list-style-type: none">• ON• OFF	O	—

*: This setting changes in accordance with My Settings

n **RCD (Rear Camera Detection) function (→P.356)**

Function	Customized setting	A	B
RCD (Rear Camera Detection) function	<ul style="list-style-type: none">• ON• OFF	O	—

n **Automatic air conditioning system (→P.454)**

Function	Customized setting	A	B
A/C auto switch operation	<ul style="list-style-type: none">• On• Off	O	O

n **Illumination (→P.466)**

Function	Customized setting	A	B
Time elapsed before the interior lights turn off	<ul style="list-style-type: none">• Off• 7.5 seconds• 15 seconds• 30 seconds	O	—
Operation after the power switch is turned off	<ul style="list-style-type: none">• On• Off	—	O
Operation when the doors are unlocked	<ul style="list-style-type: none">• On• Off	—	O
Operation when you approach the vehicle with the electronic key on your person	<ul style="list-style-type: none">• On• Off	—	O

Function	Customized setting	A	B
Footwell lights, shift lights, inside door handle lights, door trim ornament lights, center console light, instrument panel ornament lights and console box light	<ul style="list-style-type: none">• On• Off	—	O
Time elapsed before the outer foot lights turn off	<ul style="list-style-type: none">• Off• 15 seconds	O	—
Operation of the outer foot lights when you approach the vehicle with the electronic key on your person	<ul style="list-style-type: none">• On• Off	—	O
Operation of the outer foot lights when the doors are unlocked	<ul style="list-style-type: none">• On• Off	—	O
Door illumination when Safe Exit Assist (SEA) is operating	<ul style="list-style-type: none">• On• Off	—	O

(emergency flashers) settings.

n **Vehicle customization**

- | When the speed linked door locking function and shift position linked door locking function are both on, the door lock operates as follows.
 - When shifting the shift position to any position other than P, all the doors will be locked.
 - If the vehicle is started with all the doors locked, the speed linked door locking function will not operate.
 - If the vehicle is started with any door unlocked, the speed linked door locking function will operate.
- | When the doors remain closed after unlocking the doors and the timer activated automatic door lock function is activated, the signals will be generated in accordance with the Operation signal (buzzer) and the Operation signal

Items to initialize

The following items must be initialized for normal system operation after such cases as the 12-volt battery being reconnected, or maintenance being performed on the vehicle:

List of items to initialize

Item	When to initialize	Reference
Power back door	<ul style="list-style-type: none">• After reconnecting or changing the 12-volt battery• After changing a fuse	P.170
Power window	<ul style="list-style-type: none">• When functioning abnormally	P.203
Intuitive parking assist	<ul style="list-style-type: none">• If the 12-volt battery was discharged or has been removed and installed	P.344
Tire pressure warning system	<ul style="list-style-type: none">• When the specified tire inflation pressure has changed, such as due to carried load, etc.• When the tire inflation pressure is changed such as when the tire size is changed.	P.536

Free/open source software information

Water pump

This product (inverter water pump for AWD vehicles) includes software that is licensed under open-source software.

You can find license information for this free and open-source software at the following URL.

<https://www.aisin.com/info/ewp/license001.html>

Digital Key

This product contains Free/open source software (FOSS).

License information and/or the source code of this FOSS can be obtained at the following URL:

<https://www.denso.com/global/en/opensource/dkey/toyota/>

Multi-terrain Monitor

About Free / Open-Source Software Information

This product includes the free / open-source software.

You can obtain the licensing information of the free / open-source software from the following URL.

<https://www.denso.com/global/en/opensource/svss/toyota/>

10-1.For owners

Reporting safety defects for
U.S. owners..... 644

Reporting safety defects for
Canadian owners 644

Seat belt instructions for
Canadian owners (in
French)..... 645

SRS airbag instructions for
Canadian owners (in
French)..... 646

Headlight aim instructions
for Canadian owners (in
French)..... 651

Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-800-331-4331).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov> ; or write to: Administrator, NHTSA, 1200 New Jersey Ave. SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

Reporting safety defects for Canadian owners


Canadian customers who wish to report a safety-related defect to Transport Canada, Defects Investigations and Recalls, may telephone the toll-free hotline 1-800-333-0510, mail Transport Canada - ASFAD, 330 Sparks Street, Ottawa, ON, K1A 0N5, or complete the online form at <https://www.tc.gc.ca/recalls>.

Seat belt instructions for Canadian owners (in French)

The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.

Utilisation correcte des ceintures de sécurité



- Déroulez la sangle diagonale de telle sorte qu'elle passe bien sur l'épaule, sans pour autant être en contact avec le cou ou glisser de l'épaule.
- Placez la sangle abdominale le plus bas possible sur les hanches.
- Réglez la position du dossier de siège. Asseyez-vous le dos droit et calez-vous bien dans le siège.
- Ne vrillez pas la ceinture de

sécurité.

Entretien et soin

n Traitement des ceintures de sécurité

Nettoyez avec un chiffon ou une éponge humidifiés avec de l'eau savonneuse tiède. Vérifiez régulièrement que les ceintures ne sont pas usées, effilochées ou entaillées excessivement.



AVERTISSEMENT

n Détérioration et usure des ceintures de sécurité


Inspectez le système de ceintures de sécurité régulièrement. Contrôlez l'absence de coupures, d'effilochages et de pièces desserrées. N'utilisez pas une ceinture de sécurité endommagée avant qu'elle ne soit remplacée. Une ceinture de sécurité endommagée ne permet pas de protéger un occupant de blessures graves ou mortelles.

SRS airbag instructions for Canadian owners (in French)

The following is a French explanation of SRS airbag instructions extracted from the SRS airbag section in this manual.

See the SRS airbag section for more detailed SRS airbag instructions in English.

Système de coussins gonflables SRS



- A** Coussin gonflable conducteur/coussin gonflable du passager avant SRS

Contribuent à réduire l'impact au niveau de la tête et du thorax du conducteur et du passager avant

- B** Coussin gonflable de genoux SRS

Permettent de réduire le choc pour le conducteur et le passager avant

- C** Coussin gonflable latéral SRS

Contribuent à réduire l'impact au niveau du thorax des occupants des sièges avant

- D** Coussins gonflables rideaux SRS

- Contribuent à réduire l'impact au niveau de la tête des occupants des sièges avant et des sièges arrière latéraux

- Peut contribuer à empêcher les occupants d'être éjectés du véhicule en cas de tonneau

Votre véhicule est équipé de COUSSINS GONFLABLES INTELLIGENTS conçus selon les normes de sécurité américaines applicables aux véhicules à moteur (FMVSS208). L'ensemble des capteurs de coussins gonflables (ECU) régule le déploiement des coussins gonflables sur la base des informations qu'il reçoit des capteurs, etc., indiqués ci-dessus dans le schéma illustrant les composants du système. Parmi ces informations figurent la gravité du choc et l'occupation du véhicule par les passagers. Le déploiement rapide des coussins gonflables est obtenu au moyen d'une réaction chimique dans les dispositifs pyrotechniques, qui produit un gaz inoffensif permettant d'amortir le mouvement des occupants.



AVERTISSEMENT

n Précautions relatives aux coussins gonflables SRS

Respectez les précautions suivantes.

Le non-respect de ces précautions peut occasionner des blessures graves, voire mortelles.

- I** Le conducteur et tous les passagers doivent porter correctement leur ceinture de sécurité. Les coussins gonflables SRS sont des dispositifs supplémentaires à utiliser avec les ceintures de sécurité.

- I** Le coussin gonflable conducteur SRS se déploie avec une force considérable et peut occasionner des blessures graves, voire mortelles, tout particulièrement si le conducteur se trouve très près du coussin gonflable. L'autorité fédérale chargée de la sécurité routière aux États-Unis (NHTSA) conseille:

La zone à risque du coussin gonflable conducteur se situant dans les premiers 2 à 3 in. (50 à 75 mm) de déploiement, vous placer à 10 in. (250 mm) de votre coussin gonflable conducteur vous garantit une marge de sécurité suffisante. Cette distance est à mesurer entre le centre du volant et le sternum. Si votre position de conduite actuelle vous place à moins de 10 in. (250 mm) du coussin gonflable conducteur, vous pouvez changer votre position de conduite de plusieurs façons:

- Reculez votre siège le plus possible, de manière à pouvoir encore atteindre confortablement les pédales.


! AVERTISSEMENT

- Inclinez légèrement le dossier de siège. Bien que les véhicules aient une conception différente, un grand nombre de conducteurs peuvent s'asseoir à une distance de 10 in. (251 mm), même avec le siège conducteur complètement avancé, simplement en inclinant un peu le dossier de siège. Si vous avez des difficultés à voir la route après avoir incliné le dossier de votre siège, utilisez un coussin ferme et antidérapant pour vous rehausser ou remontez le siège si votre véhicule est équipé de cette fonction.
- Si votre volant est réglable, inclinez-le vers le bas. Cela a pour effet d'orienter le coussin gonflable en direction de votre poitrine plutôt que de votre tête et de votre cou. Réglez votre siège selon les recommandations de la NHTSA, tout en conservant le contrôle du véhicule avec les pédales et le volant, et en préservant la vue des commandes du tableau de bord.
- ! Si vous attachez une rallonge de ceinture de sécurité à une boucle de ceinture de sécurité du passager avant sans l'attacher au pêne de la ceinture de sécurité, le système de coussins gonflables SRS détermine que le passager avant a attaché sa ceinture de sécurité, bien que la ceinture de sécurité ne soit pas bouclée. Dans ce cas, les coussins gonflables frontaux SRS du passager avant peuvent ne pas se déployer correctement lors d'une collision, pouvant occasionner des blessures graves, voire mortelles. Veillez à porter la ceinture de sécurité correctement en cas d'utilisation d'une rallonge de ceinture de sécurité.

! Le coussin gonflable frontal SRS se déploie avec une force considérable et peut occasionner des blessures graves, voire mortelles, tout particulièrement si le passager avant se trouve très près du coussin gonflable. Le siège du passager avant doit être éloigné le plus possible du coussin gonflable, avec le dossier réglé de façon à ce que le passager avant soit assis bien droit dans le siège.


! Les nourrissons et les enfants qui ne sont pas correctement assis et/ou attachés peuvent être grièvement blessés ou tués par le déploiement d'un coussin gonflable. Un nourrisson ou un enfant trop petit pour utiliser une ceinture de sécurité doit être correctement attaché au moyen d'un siège de sécurité enfant. Toyota recommande vivement d'installer tous les nourrissons et enfants sur les sièges arrière du véhicule et de prévoir pour eux des systèmes de retenue adaptés. Les sièges arrière sont plus sûrs pour les nourrissons et les enfants que le siège du passager avant. (→P.48)

! Ne vous asseyez pas sur le bord du siège et ne vous appuyez pas contre la planche de bord.



! AVERTISSEMENT


- Ne laissez pas un enfant rester debout devant le coussin gonflable passager avant SRS ou s'asseoir sur les genoux du passager avant.




- Les occupants des sièges avant ne doivent en aucun cas tenir d'objets sur leurs genoux.
- Ne vous appuyez pas contre la porte, le rail latéral de toit ou les montants avant, latéraux ou arrière.




- Ne laissez personne s'agenouiller sur un siège en appui contre la porte ou sortir la tête ou les mains à l'extérieur du véhicule.



- Ne fixez rien et ne posez rien sur des emplacements tels que la planche de bord, la garniture du volant et la partie inférieure du tableau de bord.



- Ne fixez rien à des emplacements tels que les portes, la vitre du pare-brise, les vitres latérales, les montants avant ou arrière, des rails latéraux de toit et des poignées de maintien. (À l'exception de l'étiquette de limitation de vitesse → P.589)



- Ne suspendez aucun cintre ou objet dur aux crochets à vêtements. Ces éléments peuvent se transformer en projectiles si les coussins gonflables rideaux SRS se déploient, le choc pouvant entraîner des blessures graves, voire mortelles.
- Si un cache en vinyle est fixé sur la zone où le coussin gonflable de genoux SRS se déploie, veuillez à le retirer.



AVERTISSEMENT

N'utilisez aucun accessoire de siège recouvrant les zones de déploiement des coussins gonflables SRS, car il risque de gêner le déploiement des coussins gonflables SRS. De tels accessoires peuvent empêcher les coussins gonflables SRS de se déployer correctement, peuvent désactiver le système ou entraîner le déploiement involontaire des coussins gonflables SRS, ce qui peut éventuellement occasionner des blessures graves, voire mortelles.

Évitez de faire subir des chocs ou des pressions excessives aux composants des systèmes de coussins gonflables SRS, aux portes avant ou à leur zone adjacente.
En effet, cela pourrait entraîner un dysfonctionnement des coussins gonflables SRS.

Ne touchez aucun composant des coussins gonflables SRS immédiatement après leur déploiement (gonflage), car ils peuvent être chauds.

Si vous avez des difficultés à respirer après le déploiement des coussins gonflables SRS, ouvrez une porte ou une vitre pour faire entrer de l'air frais, ou bien descendez du véhicule si cela ne présente pas de danger. Essuyez tout résidu dès que possible afin d'éviter d'éventuelles irritations de la peau.

Si un composant renfermant un coussin gonflable SRS est endommagé ou fissuré, faites-le remplacer par votre concessionnaire Toyota.

Ne placez rien sur le siège du passager avant, comme un coussin par exemple. Cela a pour conséquence de répartir le poids du passager sur toute la surface du siège, ce qui empêche le capteur de détecter correctement le poids du passager. En conséquence, les coussins gonflables frontaux SRS du siège du passager avant risquent de ne pas se déployer en cas de collision.

Modification et mise au rebut des composants du système de coussins gonflables SRS

Ne mettez pas votre véhicule au rebut et ne procédez à aucune des modifications suivantes sans consulter votre concessionnaire Toyota. Les coussins gonflables SRS peuvent ne pas fonctionner correctement ou se déployer involontairement, ce qui peut provoquer des blessures graves, voire mortelles.

Dépose, repose, démontage ou réparation des coussins gonflables SRS

Réparation, dépose ou modification des pièces suivantes ou de leurs alentours

- Volant
- Tableau de bord
- Planche de bord
- Sièges
- Garnissage des sièges
- Montants avant
- Montants latéraux
- Montants arrière
- Rails latéraux de toit
- Panneaux de portes avant


AVERTISSEMENT

- Garniture de porte avant
- Haut-parleurs de porte avant
- | Modifications des panneaux de portes avant (par exemple, perçage de trous dans les panneaux)
- | Réparation ou modification des pièces suivantes ou de leurs alentours
- Aile avant
- Pare-chocs avant
- Côtés de l'intérieur du véhicule
- | Installation des pièces suivantes ou accessoires
- Pare-buiffe ou pare-kangourou
- Chasse-neige
- Treuils
- Porte-bagages de toit
- | Modifications de la suspension du véhicule
- | Installation d'appareils électroniques, tels que des émetteurs/récepteurs radios mobiles (émetteurs RF) et des lecteurs CD
- | Modifications apportées à votre véhicule pour les personnes atteintes d'un handicap physique

Headlight aim instructions for Canadian owners (in French)

The following is a French explanation of headlight aim instructions from the headlight aim section in this manual.

Boulons de réglage du mouvement vertical



A Boulon de réglage A


B Boulon de réglage B

Avant de vérifier le réglage des phares

- Stationnez le véhicule sur une surface plane.
- Assurez-vous que la pression de gonflage des pneus est au niveau recommandé.
- Faites asseoir quelqu'un dans le siège conducteur.
- Balancez le véhicule plusieurs fois.


Réglage du faisceau des phares

- 1 À l'aide d'un tournevis cruciforme, tournez le boulon A dans n'importe quel sens. Mémorisez le sens dans lequel vous avez tourné et le nombre de tours.



- 2 Tournez le boulon B du même nombre de tours dans le même sens qu'à l'étape 1.

Si vous n'arrivez pas à régler le phare en procédant de la sorte, confiez le véhicule à votre concessionnaire Toyota pour qu'il règle le faisceau des phares.



Index

What to do if... (Trouble-
shooting) 654

Alphabetical Index..... 657

What to do if... (Troubleshooting)

If you have a problem, check the following before contacting your Toyota dealer.

The doors cannot be locked, unlocked, opened or closed



You lose your keys

- If you lose your mechanical keys, new genuine keys or mechanical keys can be made by your Toyota dealer. (→P.597)
- If you lose your electronic keys, the risk of vehicle theft increases significantly. Contact your Toyota dealer immediately. (→P.597)



The doors cannot be locked or unlocked

- Is the electronic key battery weak or depleted? (→P.553)
- Is the power switch in ON? When locking the doors, turn the power switch off. (→P.237)
- Is the electronic key left inside the vehicle?

When locking the doors, make sure that you have the electronic key on your person.

- The function may not operate properly due to the condition of the radio wave. (→P.177)



The rear door cannot be opened

- Is the child-protector lock set?

The rear door cannot be opened from inside the vehicle when the lock is set. Open the rear door from outside and then unlock the child-protector lock. (→P.160)

If you think something is wrong



The EV system does not start

- Is the charging cable attached to the vehicle? (→P.91)
- Did you press the power switch while firmly depressing the brake pedal? (→P.234)
- Is the shift position in P? (→P.239)
- Is the electronic key anywhere detectable inside the vehicle? (→P.176)
- Is the electronic key battery weak or depleted?

In this case, the EV system can be started in a temporary way.
(→P.599)

- Is the 12-volt battery discharged? (→P.600)



The windows do not open or close by operating the power window switches

- Is the window lock switch pressed?

The power window except for the one at the driver's seat cannot be operated if the window lock switch is pressed. (→P.205)



The power switch is turned off automatically

- The auto power off function will be operated if the vehicle is left in ACC or ON (the EV system is not operating) for a period of time. (→P.238)



A warning buzzer sounds during driving

- The seat belt reminder light is flashing

Are the driver and the passengers wearing the seat belts? (→P.570, 571)

Are the driver and the passengers wearing the seat belts? (→P.571, 572)

- The parking brake indicator is on

Is the parking brake released?
(→P.248)

Depending on the situation, other types of warning buzzer may also sound. (→P.568, 578)



An alarm is activated and the horn sounds

- Did anyone inside the vehicle open a door during setting the alarm?

The sensor detects it and the alarm sounds. (→P.67)

Do one of the following to deactivate or stop the alarms:

- Unlock the doors.
- Turn the power switch to ACC or ON, or start the EV system. (The alarm will be deactivated or stopped after a few seconds.)



A warning buzzer sounds when leaving the vehicle

- Is the message displayed on the multi-information display?

Check the message on the multi-information display. (→P.578)



A warning light turns on or a warning message is displayed

- When a warning light turns on or a warning message is displayed, refer to P.568, 578.

When a problem has occurred



If you have a flat tire

- Stop the vehicle in a safe place and repair the flat tire temporarily with the emergency tire puncture repair kit. (→P.585)



The vehicle becomes stuck

- Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P.606)

Alphabetical Index

A

A/C

- Air conditioning filter 551
- Automatic air conditioning system 454
- My Room Mode 115

ABS (Anti-lock Brake System)

- 438
- Warning light 569

AC charging 94

AC charging cable

- If the charging connector cannot be unlocked 86

ACA (Active Cornering Assist)

- 439

Acoustic Vehicle Alerting System

- 72

Active Cornering Assist (ACA)

- 439

Air conditioning filter 551

Air conditioning system

- Air conditioning filter 551
- Automatic air conditioning system 454

Airbags

- Airbag operating conditions.. 34, 35
- Airbag precautions for your child 36
- Correct driving posture 27
- Curtain shield airbag precautions 36
- Front passenger occupant classification system 41
- General airbag precautions.... 36
- Modification and disposal of airbags 39
- Side airbag precautions 36
- Side and curtain shield airbags precautions..... 36
- SRS airbags 33

SRS warning light.....569

Alarm 67

- Warning buzzer 568

ALL AUTO (ECO) control 452

Anchor brackets 50, 59

Antennas (smart key system) 175

Anti-lock Brake System (ABS)

- 438
- Warning light.....569

Approach warning 318

Armrest.....489

Assist grips 489

Audio system-linked display .146

Automatic air conditioning system 454

Automatic headlight leveling

- system 252

Automatic light control system

- 251

Average electricity consumption

- 144

AWD operation status 146

B

Back door 162

Back-up lights

- Replacing light bulbs 558

Battery (12-volt battery)

- Battery checking.....527
- If the 12-volt battery is discharged 600
- Preparing and checking before winter 444
- Replacing 602
- Warning light.....568

Battery (traction battery)

- Charging 94, 100
- Location 70
- Traction battery cooler.....88
- Traction battery heater 88
- Warning messages.....124

Battery Electric Vehicle driving tips	79
Blind Spot Monitor (BSM)	335
Bottle holders	470
Brake	
Brake hold	249
Fluid	615
Parking brake	245
Regenerative braking	71
Warning light	568
Brake assist	438
Brake hold	
Warning lights	575
Brake Override System	214
Break-in tips	214
Brightness control	
Instrument panel light control	141
BSM (Blind Spot Monitor)	335
Buzzer	
Driver monitor	271

C

Camera	
Digital Rear-view Mirror	194
Driver monitor	271
Card holders	471
Card key	152
Care	
Exterior	508
Interior	512
Seat belts	512
Wheels and wheel ornaments	508
Cargo capacity	219, 222
Cargo hooks	472
Chains	446
Charging	
AC charging	94
Charging components	83
Charging methods	87
Charging procedure	94, 100
Charging schedule function	105
Charging time may increase	93
Charging tips	90
DC charging	100
Display	90, 107, 115, 116, 124
How to use Plug & Charge system	129
Information related to charging display ..	90, 107, 115, 116, 124
Locking and unlocking the AC charging connector	85
My Room Mode	115
Opening and closing the charging port lids	83
Plug & Charge system	129
Safety functions	91
Things to know before charging	91
Warning messages	124
When AC charging cannot be performed	118
When charging schedule function cannot be performed ...	122
When DC charging cannot be performed	119
When DC charging cannot be performed normally	131
When Plug & Charge cannot be set normally	131
Charging equipment	83
Charging methods	87
AC charging	94
DC charging	100
Charging ports	
Charging port lid	83
Locking and unlocking the AC charging connector	85
Opening and closing	83
Charging schedule function ..	105
Setting	107
Charging tips	90
Charging-linked functions	
My Room Mode	88

Traction battery cooler.....	88
Traction battery heater	88
Traction battery warming control	88
Child restraint system	
Fixed with a LATCH system ...	57
Fixed with a seat belt	52
Front passenger occupant classification system.....	41
Points to remember	48
Riding with children	47
Types of child restraint system installation method	50
Using an anchor bracket	59
Child safety	
12-volt battery precautions...	603
Airbag precautions	36
Child restraint system.....	50
Electronic sunshade.....	478
Heated steering wheel and seat heater precautions	463
How your child should wear the seat belt.....	30
Power back door precautions	162
Power window lock switch....	205
Power window precautions ..	204
Rear door child-protectors....	160
Seat belt extender precautions	30
Seat belt precautions	47
Child-protectors	160
Cleaning	
Digital Rear-view Mirror.....	194
Exterior	508
Interior	512
Seat belts	512
Wheels and wheel ornaments	508
Clock	139
Coat hooks.....	489
Console box.....	469

Coolant	
Capacity	612, 613
Checking	524, 526
Preparing and checking before winter.....	444
Cooling system	
EV system overheating	604
Cruise control	
Dynamic radar cruise control	311
Warning lights.....	573
Cup holders.....	470
Current electricity consumption	144
Curtain shield airbags.....	33
Customizable features	627

D

Daytime running light system	251
Daytime running lights	
Light switch.....	251
Replacing light bulbs	558
DC charging	100
Deck board	472
Deck under tray	474
Defogger	
Outside rear view mirrors	457
Rear window.....	457
Windshield.....	457, 458
Digital Rear-view Mirror	
Function.....	190
Dimension	610
Dinghy towing.....	233
Display	
Charging. 90, 107, 115, 116, 124	
Dynamic radar cruise control	314
Intuitive parking assist.....	344
Multi-information display.....	142
Plug & Charge system.....	131
RCTA.....	351
Warning message.....	578
Do-it-yourself maintenance ...	516
Door courtesy lights.....	466

Door lock

- Power back door 162
- Side doors 157
- Smart key system..... 175
- Wireless remote control 154

Doors

- Automatic door locking and unlocking system..... 161
- Door glasses 203
- Door lock warning buzzer..... 158
- Outside rear view mirrors 199
- Rear door child-protectors..... 160
- Side doors 157

Driver's seat position memory

- Driving position memory..... 206
- Memory recall function 208
- Power easy access system .. 206

Drive-start control 219**Driving**

- Battery Electric Vehicle driving tips..... 79
- Break-in tips 214
- Correct driving posture 27
- Procedures..... 213
- Winter drive tips 444

Driving information display... 144**Driving position memory 206**

- Memory recall function 208
- Power easy access system .. 206

Driving range 139**Driving support system information display 145****Dynamic radar cruise control 311**

- Warning lights..... 573
- Warning message 317

Electric motor (traction motor)

- Location 70

Electric Power Steering (EPS)

- 439
- Warning light..... 570

Electric Vehicle system features

- 70

Electric Vehicle system precautions 74**Electricity consumption. 144, 148**

- Average electricity consumption 144
- Current electricity consumption 144

Electronic key 152, 155

- Battery-saving function 176
- If the electronic key does not operate properly 598
- Replacing the battery 553

Electronic sunshade 477

- Operation..... 477

Electronically Controlled Brake System (ECB)..... 438**Emergency Driving Stop System**

- 326

Emergency flashers 560**Emergency tire puncture repair kit 585****Emergency, in case of**

- If a warning buzzer sounds .. 568
- If a warning light turns on 568
- If a warning message is displayed 578
- If the 12-volt battery is discharged 600
- If the electronic key does not operate properly 598
- If the EV system will not start 596
- If the vehicle is submerged or water on the road is rising .. 561
- If you have a flat tire 585
- If you lose your keys..... 597

E**ECB (Electronically Controlled Brake System) 438****Eco heat/cool 456****Eco mode 243****EDR (Event data recorder)..... 10**

If you think something is wrong	566
If your vehicle becomes stuck	606
If your vehicle has to be stopped in an emergency.....	560
If your vehicle needs to be towed	563
If your vehicle overheats	604
Engine	
Hood.....	521
Identification number.....	611
EPS (Electric Power Steering)	
.....	439
Warning light	570
EV system	
Acoustic Vehicle Alerting System	72
Battery Electric Vehicle driving tips.....	79
Brake Override System	214
Drive-start control.....	219
Driving range	81
Electric Vehicle system precautions.....	74
Emergency shut off system....	78
Features	70
How to use AC charging.....	94
How to use DC charging	100
If the EV system will not start.....	596
If your vehicle has to be stopped in an emergency.....	560
Overheating.....	604
Power meter.....	139
Power switch	234
Regenerative braking	71
Starting the EV system.....	234
Event data recorder (EDR).....	10

F

FCTA (Front Cross Traffic Alert)	
.....	306

Flat tire

Tire pressure warning system	533
Vehicles without a spare tire.....	585
Floor mats	26
Fluid	
Brake	615
Transmission	614
Washer	530
Footwell lights	466
Front Cross Traffic Alert (FCTA)	
.....	306

Front passenger occupant classification system	41
---	-----------

Front seats

Adjustment	181
Cleaning	512
Correct driving posture	27
Driving position memory	206
Head restraints	184
Memory recall function	208
Power easy access system	206
Seat heaters	463
Seat position memory.....	206
Seat ventilators.....	463

Front side marker light

Light switch.....	251
Replacing light bulbs	558

Front turn signal lights

Replacing light bulbs	558
Turn signal lever	244

Fuses	555
--------------------	------------

G

Garage door opener	499
Gauges	139
Grip Control	436
Grocery bag hooks.....	472

H

Hands Free Power Back Door.....	166
--	------------

Head restraints	184
Headlight aim.....	557
Headlights	251
Light switch	251
Replacing light bulbs	558
Heated steering wheel	
ALL AUTO (ECO) control	452
Heater coolant	
Capacity	613
Checking	524
Heaters	
Front automatic air conditioning system.....	454
Heated steering wheel	463
Outside rear view mirrors	457
Seat heaters.....	463
Traction battery heater	88
Hill-start assist control	439
Hood	
Open	521
Hooks	
Cargo hooks.....	472
Coat hooks	489
Grocery bag hooks.....	472
Retaining hooks (floor mat)	26
Horn	188
How to use Plug & Charge system	129

I

Identification	
Engine	611
Vehicle.....	610
If your vehicle overheats	604
Ignition switch (Power switch)	
.....	234
Auto power off function	238
Changing power switch modes	237
If your vehicle has to be stopped in an emergency.....	560
Starting the EV system.....	234

Illuminated entry system	466
Immobilizer system	66
Indicators	
Charging indicator	84
Initialization	
Electronic sunshade	477
Items to initialize	640
Maintenance	515
Power windows	203
Inside rear view mirror ...	189, 190
Intercooler coolant	
Capacity	612
Interior lights.....	466
Intuitive parking assist	
Function.....	344
Warning lights.....	574

J

Jack	
Positioning a floor jack	523
Jam protection function	
Power back door	167
Power windows	203

K

Keyless entry	
Smart key system.....	175
Wireless remote control.....	154
Keys	
Battery-saving function.....	176
Electronic key	152
If the electronic key does not operate properly	598
If you lose your keys.....	597
Key number plate	152
Keyless entry	154, 175
Mechanical key.....	152
Power switch	234
Replacing the battery	553
Warning buzzer	176
Wireless remote control.....	154

Knee airbags.....33

L

Lane change Assist (LCA).....290

Lane Departure Alert (LDA) ...293

Warning lights.....573

Lane Tracing Assist (LTA)

Operation285

Warning lights.....573

LATCH anchors57

LCA (Lane change Assist).....290

LDA (Lane Departure Alert) ...293

Warning lights.....573

Lever

Auxiliary catch lever521

Hood lock release lever.....521

Turn signal lever.....244

Wiper lever256

License plate lights

Light switch251

Replacing light bulbs558

Light bulbs

Replacing558

Lights

Automatic High Beam system
.....253

Front personal lights.....467

Headlight switch251

Interior lights.....466, 467

Interior lights list466

Rear personal lights467

Replacing light bulbs558

Turn signal lever.....244

Vanity lights478

**Locking and unlocking the AC
charging connector.....85**

LTA (Lane Tracing Assist)

Operation285

Warning lights.....573

Luggage cover.....474

M

Maintenance

Do-it-yourself maintenance ..519

General maintenance516

Maintenance data.....610

Maintenance requirements...515

Max cool457

Max heat456

Menu icons.....143

Meter

Clock139

Indicators.....136

Instrument panel light control141

Meter control switches.....144

Meters139

Multi-information display.....142

Warning lights.....568

Warning message.....578

Mirrors

Digital Rear-view Mirror.....190

Inside rear view mirror.....189

Outside rear view mirror defog-
gers457

Outside rear view mirrors199

Vanity mirrors.....478

Motor

Compartment.....524

Multi-information display

Audio system-linked display .146

Charging. 90, 107, 115, 116, 124

Driving information display ...144

Driving support system informa-
tion display145

Dynamic radar cruise control314

Electricity consumption.....144

Menu icons143

Meter control switches.....144

Navigation system-linked display
.....145

Plug & Charge system.....131

Suggestion function.....147

Tire pressure	533
Warning message	578
Multi-terrain Monitor	371
How to switch the display	375
If you notice any symptoms	431
Screen display	372
My Room Mode	115
Starting My Room Mode	115
Warning messages	116
My Settings	209

N

Navigation system-linked display	145
---	------------

O

Odometer	141
Odometer and trip meter display	141
Display items	141
Open tray	471
Opener	521
Hood	521
Outer foot lights	466
Location	466
Outside door handle lights	466
Outside rear view mirrors	199
Adjustment	199
BSM (Blind Spot Monitor)	335
Folding	200, 201
Linked mirror function when reversing	201
Mirror position memory	206
Outside rear view mirror defoggers	457
RCTA function	351
Safe Exit Assist	340
Outside temperature	139

P

Paddle shift switch	243
----------------------------------	------------

Panic mode	154
Parking assist sensors (intuitive parking assist)	344
Parking brake	245
Operation	245
Parking brake engaged warning buzzer	248
Warning light	575
Warning message	247, 248
Parking lights	251
Light switch	251
Replacing light bulbs	558
Parking Support Brake function (moving vehicles rear of the vehicle)	367
Parking Support Brake function (pedestrians rear of the vehicle)	369
Parking Support Brake function (static objects front and rear of the vehicle)	365
PCS (Pre-Collision System)	273
Function	273
Warning light	572
PDA	573
Warning lights	573
PDA (Proactive driving assist)	300
Personal lights	466
PKSB (Parking Support Brake)	360
Plug & Charge system	129
Information related to charging display	131
Warning messages	131
Power back door	162
Hands Free Power Back Door	166
Smart key system	163
Power control unit coolant	526
Checking	526

Preparing and checking before winter.....	444
Power easy access system ...	206
Power meter.....	139
Power outlets.....	479
Power outlets (1500 W).....	490
Power steering (Electric power steering system).....	439
Warning light	570
Power switch	234
Auto power off function	238
Changing power switch modes	237
If your vehicle has to be stopped in an emergency.....	560
Starting the EV system.....	234
Power windows	
Door lock linked window operation	204
Jam protection function	203
Operation	203
Window lock switch	205
Pre-Collision System (PCS)	
Function	273
Warning light	572

R

Radar cruise control (dynamic radar cruise control)	311
Radiator.....	525
RCD (Rear Camera Detection)	356
RCTA	
Function	351
RCTA function.....	352
Rear Cross Traffic Alert (RCTA)	351
Rear seats	182
Adjustment	182
Folding down the rear seatbacks	182
Head restraints.....	184

Seat heaters	463
Rear side marker lights	
Light switch.....	251
Replacing light bulbs	558
Rear turn signal lights	
Replacing light bulbs	558
Turn signal lever	244
Rear view mirror	
Digital Rear-view Mirror	190
Inside rear view mirror	189
Outside rear view mirrors	199
Rear window defogger	457
Rear window wiper	259
Regenerative braking	71
Replacing	
Electronic key battery	553
Fuses.....	555
Light bulbs	558
Tires.....	542
Resetting the message indicating maintenance is required	515
Road Sign Assist (RSA)	308
RSA (Road Sign Assist)	308

S

Safe Exit Assist.....	340
Safety Connect	62
Seat belt reminder light..	570, 571
Seat belts	
Automatic Locking Retractor ..	31
Child restraint system installation	50
Cleaning and maintaining the seat belt.....	512
Emergency Locking Retractor	31
How to wear your seat belt	28, 30
How your child should wear the seat belt.....	30
Pregnant women, proper seat belt use	29
Reminder light and buzzer .	570, 571

- Seat belt extender 30
- Seat belt pretensioners 32
- SRS warning light..... 569
- Seat heaters**
 - ALL AUTO (ECO) control 452
- Seat position memory**..... 206
- Seat ventilators** 463
- Seating capacity**..... 222
- Seats**
 - Adjustment 181, 182
 - Adjustment precautions 181, 183
 - Child seats/child restraint system installation 48
 - Cleaning 512
 - Driving position memory..... 206
 - Folding down the rear seatbacks 182
 - Head restraints..... 184
 - Power easy access system .. 206
 - Properly sitting in the seat..... 27
 - Seat heaters..... 463
 - Seat position memory 206
 - Seat ventilators 463
- Secondary Collision Brake (Secondary collision reduction at the time of a frontal collision)** 439
- Sensor**
 - Automatic headlight system . 251
 - Automatic High Beam system 253
 - Digital Rearview Mirror 194
 - Inside rear view mirror..... 189
 - Intuitive parking assist..... 344
 - LDA (Lane Departure Alert with steering control) 293
 - LTA (Lane Tracing Assist)..... 285
 - Radar sensor..... 336, 341
 - Rain-sensing windshield wipers 257
 - RCTA..... 352
- Service plug**..... 74
- Service reminder message**.... 515
- Shift lever light**..... 466
- Shift position**..... 238
 - Paddle shift switch..... 243
- Side airbags** 33
- Side doors** 157
- Side marker lights**
 - Light switch..... 251
 - Replacing light bulbs 558
- Side mirrors**
 - Adjustment 199
 - BSM (Blind Sport Monitor).... 335
 - Folding..... 200, 201
 - Linked mirror function when reversing..... 201
 - Mirror position memory..... 206
 - RCTA function..... 351
- Side turn signal lights**
 - Replacing light bulbs 558
 - Turn signal lever 244
- Side windows**..... 203
- Smart key system**
 - Antenna location..... 175
 - Entry functions..... 157, 163
 - Starting the EV system..... 234
- Snow tires** 444
- SOC (State of Charge) gauge** 139
- Software update**..... 261
- Specifications** 610
- Speedometer**..... 139
- Steering wheel**
 - Adjustment 188
 - Heated steering wheel..... 463
 - Meter control switches..... 144
 - Power easy access system .. 206
 - Steering wheel position memory 206
- Stop lights**
 - Replacing light bulbs 558
- Storage features** 469
- Stuck**
 - If the vehicle becomes stuck 606

Suggestion function.....	147
Sun visors.....	478
Sunshade.....	477
Switches	
Automatic High Beam system	253
Brake Hold switch	249
Camera switch	375
Digital Rear-view Mirror control switches	190
Door lock switches	160
Driving position memory switches	206
Dynamic radar cruise control switch	314
Eco mode	243
Electronic sunshade switch ..	477
Emergency flashers switch ..	560
Garage door opener switches	499
Grip Control.....	436
Heated steering wheel switch	463
Ignition switch (Power switch)	234
Inside lock buttons	160
Light switches.....	251
Meter control switches	144
Outside rear view mirror switches	199
Paddle shift switch	243
Parking brake switch.....	245
Power switch	234
Power window switches	203
RCTA switch.....	352
Seat heater switches.....	463
Seat ventilator switches	463
“SOS” button	62
Tilt and telescopic steering control switch	188
Vehicle-to-vehicle distance switch	314

VIEW switch	375
VSC OFF switch	439
Window lock switch	205
Windshield wiper and washer switch	256
X-MODE switch	434
Switching the meter display ..	141

T

Tail lights

Light switch.....	251
Replacing light bulbs	558

Theft deterrent system

Alarm	67
Immobilizer system.....	66

Things you should know

If you notice any symptoms ..	431
-------------------------------	-----

Tire inflation pressure

Maintenance data.....	615
Tire inflation pressure display function	533
Warning light.....	572

Tire information617

Glossary	620
Size	618
Tire identification number	618
Uniform Tire Quality Grading	619

Tire pressure display533

Tire pressure warning system

Function.....	533
Installing tire pressure warning valves and transmitters	534
Registering ID codes	538
Registering the position of each wheel	535
Selecting wheel set	540
Setting the tire pressure	536
Warning light.....	572

Tires

Chains	446
Checking	530

- Emergency tire puncture repair kit.....585
 - If you have a flat tire.....585
 - Inflation pressure.....547
 - Information617
 - Replacing542
 - Rotating tires532
 - Size615
 - Snow tires444
 - Tire inflation pressure display function.....533
 - Tire pressure warning system533
 - Warning light572
 - Top tether strap59**
 - Total load capacity610**
 - Towing**
 - Dinghy towing.....233
 - Emergency towing.....563
 - Towing eyelet565
 - Trailer towing.....223
 - Toyota Safety Sense 3.0**
 - AHB (Automatic High Beam) 253
 - Driver monitor.....271
 - Dynamic radar cruise control 311
 - Emergency Driving Stop System326
 - FCTA (Front Cross Traffic Alert)306
 - LCA (Lane change Assist)290
 - LDA (Lane Departure Alert) ..293
 - LTA (Lane Tracing Assist)285
 - PCS (Pre-Collision System) .273
 - PDA (Proactive driving assist)300
 - RSA (Road Sign Assist)308
 - Software update261
 - Traffic Jam Assist329
 - TRAC (Traction Control)439**
 - Traction battery**
 - Charging.....94, 100
 - Location.....70
 - Specification612
 - Traction battery cooler.....88
 - Traction battery heater88
 - Warning messages.....124
 - Traction Control (TRAC)439**
 - Traffic Jam Assist.....329**
 - Trailer Sway Control.....439**
 - Trailer towing223**
 - Trip meters141**
 - Turn signal lights**
 - Replacing light bulbs558
 - Turn signal lever244
- U**
- USB charging ports.....479**
- V**
- Vanity lights478**
 - Vanity mirrors478**
 - Vehicle data recording7**
 - Vehicle identification number 610**
 - Vehicle Stability Control (VSC)439**
 - Ventilators (seat ventilators) .463**
 - VSC (Vehicle Stability Control)439**
- W**
- Warning buzzers**
 - ABS569
 - Airbags569
 - Approach warning318
 - Brake system.....568
 - Cruise control573
 - Door lock158
 - Dynamic radar cruise control 573
 - Electric power steering570
 - EV system malfunction569
 - Inappropriate pedal operation569

Intuitive parking assist..	349, 574
LDA (Lane Departure Alert) ..	573
LTA (Lane Tracing Assist)...	285, 573
Open window	204
PCS (Pre-Collision System) ..	572
PDA.....	573
Pre-collision warning	274
Seat belt	570, 571
Tire pressure	572
Warning lights	568
ABS	569
Brake hold operated indicator	575
Brake system	568
Charging system	568
Cruise control indicator	573
Driving assist information indicator	574
Dynamic radar cruise control indicator.....	573
Electric power steering	570
EV system malfunction indicator lamp	569
Inappropriate pedal operation warning light.....	569
Intuitive parking assist OFF indicator	574
LDA indicator	573
LTA indicator.....	573
Parking brake indicator	575
PDA indicator	573
Pre-collision system	572
Seat belt reminder light	570, 571
Slip indicator.....	574
SRS.....	569
Tire pressure	572
Traction battery charge warning light.....	570
Warning messages.....	578

Washer

Low washer fluid warning message.....	530
Preparing and checking before winter	444
Switch	256

Washing and waxing508

Weight

Cargo capacity	219, 222
Load limits	222
Weight	610

Wheels

Replacing wheels	542
Size	615

Window lock switch205

Windows

Power windows	203
Rear window defogger	457
Washer	256

Windshield wipers

Rain-sensing windshield wipers	256
--------------------------------------	-----

Winter driving tips444

Wireless charger.....481

Wireless remote control

Battery-Saving Function	176
Locking/Unlocking	154
Replacing the battery	553

X

X-MODE434

Grip control	434
--------------------	-----

For information regarding the equipment listed below, refer to the “MULTIMEDIA OWNER’S MANUAL”.

· Voice control system

- Navigation system
- Audio system
- Toyota parking assist monitor
- Panoramic view monitor

Certifications

► Smart key system and immobilizer system

FCC ID: NI4TMLF19D-6

US

NOTE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

96

NOTE

CA

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

811

NOTE

CA

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

811

► Smart key system

FCC ID:HYQ23ABN

FCC ID:HYQ14FBX

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

<For 14FBX>

The FCC ID is affixed inside the equipment. You can find the ID when replacing the battery.

NOTE:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

<For 14FBX>

The IC Certification number is affixed inside the equipment. You can find the number when replacing the battery.

NOTE:

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

<Pour 14FBX>

Le numéro d'accréditation IC est apposé à l'intérieur de l'appareil. Ce numéro est visible au remplacement de la pile.

► Digital key

FCC ID:HYQ17EAD

NOTE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTION : Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.

Co-location: This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The antenna cannot be removed (and changed) by user.

Co-location: This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

CAUTION: Radio Frequency Radiation Exposure

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

L'utilisateur n'est pas autorisé à retirer (ou modifier) l'antenne.

Emplacement : Cet émetteur ne doit pas être installé ou utilisé conjointement avec d'autres antennes ou émetteurs.

ATTENTION : exposition aux radiofréquences

Cet équipement est conforme aux limites d'exposition aux rayonnements d'ISDE établies pour un environnement non contrôlé ainsi que la norme CNR-102 de la réglementation d'ISDE relative à l'exposition aux radiofréquences (RF). Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et le corps.

► Toyota Safety Sense 3.0

FCC ID: HYQDNMWR011

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiofrequency radiation exposure Information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator (antenna) and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

NOTE:

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'ISDE. Cet équipement doit être installé et utilisé en gardant une distance de 20 cm ou plus entre le dispositif rayonnant et le corps.

► **BSM (Blind Spot Monitor)**

Radiofrequency radiation exposure Information:

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Notice:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Radiofrequency radiation exposure information:

This equipment complies with radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

CS-102-F-1

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Informations sur l'exposition aux rayonnements radiofréquences:

Cet équipement est conforme aux limites d'exposition aux rayonnements définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

CS-102-F-1

► Wireless charger

FCC ID : ACJ932AT2501

NOTE:

This device complies with part 15 and part 18 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a wireless power charger, pursuant to part 18 of the FCC Rules. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research.

AT2501 has been tested and found to comply with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines.

The contact information for maintenance is described in the car manual by the manufacturer of the car in which this wireless charger is installed.

NOTE:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAUTION:

This equipment complies with ISSED radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the ISSED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'ISDE.

Cet équipement doit être installé et utilisé en gardant une distance de 20 cm ou plus entre le radiateur et le corps humain.

The Qi logo is a trademark of the Wireless Power Consortium. Qi ID: 14561

► Garage door opener

This device complies with FCC rules part 15 and Innovation, Science, and Economic Development Canada RSS-210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received including interference that may cause undesired operation. WARNING: The transmitter has been tested and complies with FCC and ISSED rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

This equipment complies with FCC and ISSED radiation exposure limits set forth for an uncontrolled environment. End Users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be at least 20 cm from the user and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with FCC rules part 15 and Innovation, Science, and Economic Development Canada RSS-210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received including interference that may cause undesired operation. WARNING: The transmitter has been tested and complies with FCC and ISDE rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

This equipment complies with FCC and ISDE radiation exposure limits set forth for an uncontrolled environment. End Users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be at least 20 cm from the user and must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet appareil est conforme aux règlements de la FCC, section 15, et au CNR-210 d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est assujéti aux deux conditions suivantes (1) cet appareil ne doit pas causer d'interférences nuisibles et (2) cet appareil doit accepter toute interférence reçue, y compris celle qui pourrait entraîner un dysfonctionnement. MISE EN GARDE L'émetteur a subi des tests et est conforme aux règlements de la FCC et d'ISDE. Les changements ou modifications non approuvés explicitement par la partie responsable de la conformité pourraient rendre caduque l'autorisation de l'utilisateur de se servir du dispositif.

Cet appareil est conforme aux limites d'exposition aux radiations de la FCC et d'ISDE établies pour un environnement non contrôlé. Les utilisateurs finaux doivent respecter les instructions d'utilisation spécifiques pour satisfaire aux exigences de conformité aux expositions de RF. L'émetteur doit se trouver à 20 cm au minimum de l'utilisateur et ne doit pas être situé au même endroit que tout autre émetteur ou antenne ni fonctionner avec un autre émetteur ou antenne.

► Tire pressure warning system

FCC ID: PAXPMVH000

NOTE

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: PAXPMVH100

NOTE

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

NOTE

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

“Perchlorate Material – special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate.”

► Intuitive parking assist/Clearance Sonar System

Product name : Intuitive parking assist

Compliance statement : This device complies with part 18 of the FCC Rules.

Responsible Party : DENSO International America, Inc.


24777 Denso Drive, Southfield Michigan 48033 U.S.A.

<https://www.denso.com/us-ca/en/about-us/company-information/us/diam/>

This ISM device complies with Canadian ICES-001.

Get appareil ISM est conforme à la norme NMB-001 du Canada.

CHARGING STATION INFORMATION



- A** Auxiliary catch lever (→P.521)
- B** Charging port lid (→P.83)
- C** Power back door switch (→P.164)
- D** Hood lock release lever (→P.521)
- E** Tire inflation pressure (→P.615)

External power source	P.87
Time needed for charging	P.90
Traction battery type	P.612
Cold tire inflation pressure	P.615



WARNING: Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

Your Toyota dealer

Your Toyota dealer will provide quality maintenance and any other assistance you may require.

If there is not a Toyota dealer near you, please call the following number:

■ U.S. OWNERS

- In the U.S. mainland or Canada:
Toyota Customer Experience Center
1-800-331-4331 (Toll-Free)
- In Hawaii:
Servco Automotive Customer Services
1-888-272-5515 (Toll-Free)

■ CANADIAN OWNERS

- In Canada or the U.S. mainland:
Toyota Canada Customer Interaction Centre
1-888-TOYOTA-8 or **1-888-869-6828** (Toll-Free)

Please access our **websites** for further information.

- The U.S. mainland: **www.toyota.com**
- Hawaii: **www.toyotahawaii.com**
- Canada : **www.toyota.ca**

©2026 TOYOTA MOTOR CORPORATION

All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of Toyota Motor Corporation.

